

Level 5 — Motor drive: EPOS2 CiA 402 as commanded

Owner: EPOS2 70/10 drive; commands from epos2_joint_bridge.py (SDO 0x6040/0x6060 + RPDO2), feedback via TPDO1 / SDO statusword
Simplified: only states and transitions the bridge uses · CiA 402 names · source-derived, not runtime-verified

drive state

composite (Operation Enabled)

context / interface

fault states

controlword written by bridge

drive-internal (CiA 402)

command chain inferred*

context link

Not commanded

quick stop 0x0002, disable voltage 0x0000, disable operation 0x0007; node exit only closes the CAN socket

NMT and SDO (unresolved)

sdo_read/write from /node_<id>/... (ros2_canopen); bus.yml is not in Agrobot; heartbeat 0x05 only observed

PDO map (assumed DCF)

RPDO1 0x20C1 PVT record
RPDO2 0x6040 + 0x6060
TPDO1 0x20C4:01, 0x6041, 0x6061
TPDO2 0x6064 + 0x606C

Fault visibility

TPDO1 / SDO statusword bit 3
→ /epos2/jN/fault; bridge reacts only in its next command