# 比亚迪ム多轿车电路图册





# 目 录


1、启动、发电	
2、组合仪表	2
3、BMC	3
4、转向轴锁	5
5、网关	7
6、驻车辅助系统	8
7、空调控制部分	9
8、空调部分	
9、电子风扇	12
10、雨刮、洗涤	13
11、窗控	
12、ECM(4G15)	16
13、483 CVT	19
14、TCU	22
15、ABS(BOSCH)	24
16、ABS 德尔福 7.8	25
17、SRS	26
18、音响系统	28
19、室内灯	29
20、大灯	31
21、小灯	32

L3	轿车	电路	图册
----	----	----	----

22、	雾灯	. 33
23、	转向灯	. 34
24、	制动灯	. 35
25、	前大灯调节	. 36
26、	点烟器、电动外后视镜、内后视镜方向显示	. 37
27、	CAN-BUS(低速 CAN)	. 39
28、	CAN-BUS(高速 CAN)	. 40
29、	短接器	. 41
30、	保险、继电器	. 42




# 1、启动、发电



1




# 2、组合仪表






#### 3、BCM











#### 4、转向轴锁











#### 5、网关






#### 6、驻车辅助系统






# 7、空调控制部分






# 8、空调部分











# 9、电子风扇







# 10、雨刮、洗涤






# 11、窗控









# 12、ECM(4G15)
















#### 13、483 CVT















#### 14、TCU











#### 15、ABS(BOSCH)







#### 16、ABS 德尔福 7.8






#### 17、SRS








#### 18、音响系统






# 19、室内灯











#### 20、大灯






# 21、小灯






# 22、雾灯






#### 23、转向灯






# 24、制动灯






# 25、前大灯调节






# 26、点烟器、电动外后视镜、内后视镜方向显示











# 27、CAN-BUS(低速 CAN)






# 28、CAN-BUS(高速 CAN)





# 29、短接器





# 30、保险、继电器

#### 配置表

配置	4G15发动机	483+CVT	标准型配置	旗舰型配置
代号	1*	2*	3*	4*

#### 线色标准

代码	В	L	Br	G	Gr	Lg	0	P	R	V	₩	Y
颜色	黑	蓝	棕	绿	灰	嫩绿	橙黄	粉红	紅	紫	白	黄

#### 保险

F1/1	F1/2	F1/3	F1/4	F1/5	F1/6	F1/7	F1/8	F1/9	F1/10	F1/11	F1/12
1 0 A	10A	1 0 A	10A	15A	**A	40A	25A	30A	15A	30A	5 A
左前远光	右前远光	右前近光	左前近光	转向轴锁	预留	大灯	всм	电喷主继电器	室内灯	点火开关2#	Keyless
F1/13	F1/14	F1/15	F1/16	F1/17	F1/18	F1/19	F1/20	F1/21			
1 0 A	1 0 A	20A	5 A	100A	**A	30A	25A	40A			
电喇叭	告警灯	CVT-TCU	发电机	主保险	预留	电子风扇	ABS-ECU	ABS-ECU			

F2/1	F2/2	F2/3	F2/4	F2/5	F2/6	F2/7	F2/8	F2/9	F2/10	F2/11	F2/12
1 0A	15A	1 0 A	**A	15A	**A	7. 5A	2 0 A	15A	15A	25A	30A
ABS	SRS	组合仪表	预留	油泵	预留	DLC	雨刮	小灯	制动灯	车门	2#门窗
F2/13	F2/14	F2/15	F2/16	F2/17	F2/18	F2/19	F2/20	F2/21	F2/22	F2/23	F2/24
2 0 A	15A	1 0 A	7. 5A	10A	15A	**A	5 A	15A	30A	30A	40A
点火开关1#	前雾灯	后雾灯	启动电源	空调	TCU	预留	大灯调节	点烟器	1#门窗	后除霜	鼓风机

#### 继电器

K1/1	K1/2	K1/3	K1/4	K1/5	K1/6	K1/7	K1/8	K1/9	K1/10
A/C离合继电器	大灯继电器	风扇3#继电器	IG2继电器	电喇叭继电器	风扇2#继电器	ACC继电器	风扇1#继电器	制动灯继电器	电喷主继电器

KG/1	KG/2	KG/3	KG/4	KG/5	KG/6
小灯继电器	启动继电器	前雾灯继电器	鼓风机继电器	倒车灯继电器	START LOCK 继电器

K2/1	K2/2	K2/3	K2/4	K2/5
油泵继电器	门窗继电器	预留	后除霜继电器	IG1继电器