DISPLAYS & IND LIGHTS DRIVER CONNECTORS						BUTTONS / SWITCHES / KNOBS CONNECTORS								
EWMU / CMDS DSUB1			EWPI DSUB2				EWMU / CMDS	EWPI						
							CN1 (IDC 2X13 PIN HEADER)	CN2 (IDC 2X5 PIN HEADER)						
DC-37 FEMALE			DB-25 FEMALE				DB-25 MALE (STRAIGHT THRU)	TO DB-9 MALE (STRAIGHT THRU)						
USE 24 AWG CABLE			USE 24 AWG CABLE				(,			
SOURCE	DC37	FUNCTION	SOURCE	DB25	FUNCTION	SOURCE	IDC	DB	FUNCTION	SOURCE	IDC	DB	FUNCTION	
	PIN			PIN			26	25			10	9		
							PIN	PIN			PIN	PIN		
5V PS +	1	+5V	5V PS +	1	+5V	TEENSY DGND	1	1	ROTARY SWITCH COMMON	TEENSY DGND	1	1	BUTTON COMMON	
5V PS GND	2	GND	5V PS GND	2	GND	TEENSY PIN 28	2	14	EWMU/CMDS MODE SWITCH - OFF	TEENSY PIN 19	2	2	PRI BUTTON	
5V PS GND	3	GND	5V PS GND	3	GND	TEENSY PIN 29	3	2	EWMU/CMDS MODE SWITCH - STBY	TEENSY PIN 21	3	3	SEP BUTTON	
5V PS GND	4	GND	N/C	4	N/C	TEENSY PIN 30	4	15	EWMU/CMDS MODE SWITCH - MAN	TEENSY PIN 20	4	4	UNK BUTTON	
5V PS GND	5	GND	N/C	5	N/C	TEENSY PIN 31	5	3	EWMU/CMDS MODE SWITCH - SEMI	TEENSY PIN 18	5	5	MD BUTTON	
TEENSY PIN 12	6	DATA IN	TEENSY PIN 15	6	DATA IN	TEENSY PIN 32	6	16	EWMU/CMDS MODE SWITCH - AUTO	N/C	6	6	N/C	
TEENSY PIN 10	7	CLK	TEENSY PIN 10	7	CLK	TEENSY PIN 27	7	4	EWMU DISP SWITCH - MENU CMDS FL SWITCH - ON/OFF	TEENSY 3V3	7	7	BRIGHTNESS POT (+)	
TEENSY PIN 8	8	BLANKING	TEENSY PIN 17	8	BLANKING	TEENSY PIN 11	8	17	EWMU DISP SWITCH - ON/OFF	TEENSY PIN 16	8	8	BRIGHTNESS POT - WIPER	
5V PS GND	9	CASE GND	5V PS GND	9	CASE GND	TEENSY PIN 26	9	5	EWMU RWR SWITCH - MENU CMDS CH SWITCH - ON/OFF	TEENSY AGND	9	9	BRIGHTNESS POT (-)	
5V PS +	10	CMDS IND LGHT +5V	5V PS +	10	EWPI IND LEDS +5V	TEENSY PIN 8	10	18	EWMU/CMDS RWR SWITCH - ON/OFF	N/C	10	N/C	N/C	
5V PS GND	11	CMDS DISP RDY LAMPS (-)	5V PS GND	11	PRI LED (-)	TEENSY PIN 25	11	6	EWMU JMR SWITCH - MENU CMDS O2 SWITCH - ON/OFF					
5V PS GND	12	CMDS NO GO LAMPS (-)	5V PS GND	12	UNK LED (-)	TEENSY PIN 7	12	19	EWMU/CMDS JMR SWITCH - ON/OFF					
5V PS GND	13	CMDS GO LAMPS (-)	5V PS GND	13	ML LED (-)	TEENSY PIN 24	13	7	EWMU MWS - MENU CMDS O1 SWITCH - ON/OFF					
BL GND	14	BACKLIGHTING GND	BL GND	14	BACKLIGHTING GND	TEENSY PIN 6	14	20	EWMU/CMDS MWS SWITCH - ON/OFF					
BL GND	15	BACKLIGHTING GND	BL+	15	BACKLIGHTING +	TEENSY PIN 0	15	8	EWMU/CMDS JETTISON SWITCH - ON/OFF					
BL+	16	BACKLIGHTING +	TEENSY PIN 1	16	COL1	TEENSY DGND	16	21	TOGGLE SWITCH COMMON					
BL+	17	BACKLIGHTING +	TEENSY PIN 1	17	COL1	TEENSY PIN 36	17	9	EWMU BUTTON MATRIX COL1 CMDS PRGM - 1					
TEENSY PIN 1	18	COL1	TEENSY PIN 2	18	COL2	TEENSY PIN 37	18	22	EWMU BUTTON MATRIX COL2 CMDS PRGM - 2					
TEENSY PIN 1	19	COL1	TEENSY PIN 2	19	COL2	TEENSY PIN 38	19	10	EWMU BUTTON MATRIX COL3 CMDS PRGM - 3					
TEENSY PIN 1	20	COL1	TEENSY PIN 3	20	COL3	TEENSY PIN 39	20	23	EWMU BUTTON MATRIX COL4 CMDS PRGM - 4					
TEENSY PIN 1	21	COL1	TEENSY PIN 3	21	COL3	TEENSY PIN 33	21	11	EWMU BUTTON MATRIX ROW1 CMDS MODE - BYP					
TEENSY PIN 2	22	COL2	TEENSY PIN 4	22	COL4	TEENSY PIN 34	22	24	EWMU BUTTON MATRIX ROW2 CMDS PRGM - BIT					
TEENSY PIN 2	23	COL2	TEENSY PIN 4	23	COL4	TEENSY 3V3	23	12	BRIGHTNESS POT (+)					
TEENSY PIN 2	24	COL2	TEENSY PIN 5	24	COL5				BRIGHTNESS POT - WIPER					
TEENSY PIN 2	25	COL2	TEENSY PIN 5	25	COL5				BRIGHTNESS POT (-)					
TEENSY PIN 3	26	COL3				N/C	26	N/C	N/C					
TEENSY PIN 3	27	COL3												
TEENSY PIN 3	28	COL3												
TEENSY PIN 3	29	COL3												
TEENSY PIN 4	30	COL4												
TEENSY PIN 4	31	COL4												
TEENSY PIN 4	32	COL4												
TEENSY PIN 4	33	COL4												
TEENSY PIN 5	34	COL5												
TEENSY PIN 5	35	COL5						REV: 1.01						
TEENSY PIN 5		COL5							Date: 2021-05-24	Sheet:	liah	+n;	1/1	
TEENSY PIN 5	37	COL5							Date. 2021-05-24	Drawn By:	ııgı	ILIIII	ıg	