VECTOR



Vector AUTOSAR Solution

Installation Guide

Version 6.12.01

Content

1 Introduction ... **3**
2 Installation ... **4**
2.1 System Requirements and Constraints ... 4
2.2 STEP 1: Install the MICROSAR Classic SIP delivery ... 4
2.3 STEP 2: Install Tools ... 4
2.3.1 DaVinci External Components ... 5
2.3.2 DaVinci Configurator Classic ... 5
2.3.3 DaVinci Developer Classic ... 5
2.3.4 vVIRTUALtarget ... 5
2.3.5 TA Tool Suite ... 5
2.3.6 Evaluation Bundles only: CANdelaStudio ... 5
2.4 STEP 3: Activate Tool Licenses ... 6
2.5 Next Steps ... 6
3 Update ... **7**
3.1 DaVinci External Components ... 7
3.2 DaVinci Configurator Classic ... 7
3.3 DaVinci Developer Classic ... 7
3.4 Evaluation Bundles only: CANdelaStudio ... 8
4 Deinstallation ... **9**
4.1 MICROSAR Classic SIP ... 9
4.2 DaVinci Developer Classic ... 9
4.3 DaVinci Configurator Classic ... 9
4.4 Remove DaVinci Configurator Classic from MICROSAR Classic SIP ... 9
5 Additional Information ... **11**
5.1 Reference Documents ... 11
5.2 System Requirements ... 11
5.3 MCAL Integrate and Update ... 11
5.4 MCALs Using EB Tresos Studio ... 12
5.5 RTE Version ... 12
6 Contact ... **13**

1 Introduction

This document gives you a short overview of the first steps after you have received your MICROSAR Classic SIP delivery.

For the installation of the MICROSAR Classic SIP and tools, proceed with chapter Installation on page 4. The update of already installed software is described in chapter Update on page 7. For the deinstallation of the MICROSAR Classic SIP or tools refer to chapter Deinstallation on page 9. More information can be found in the section Additional Information on page 11.



Note

Information that applies only to specific deliveries is marked accordingly:

- **Evaluation Bundles only:** This information applies to Evaluation Bundles only.
- **MICROSAR Classic Standard SIPs only:** This information applies to all MICROSAR Classic SIP deliveries with the exception of Evaluation Bundles.

The term **MICROSAR Classic SIP** covers both, Evaluation Bundles and MICROSAR Classic Standard SIPs.

2 Installation

This chapter describes the system requirements and constraints as well as the required installation steps.

2.1 System Requirements and Constraints

The following system requirements and constraints apply:

- **Tool System Requirements**
  Before starting tool installation, refer to the section System Requirements on page 11.
- **Administrator Rights**
  Make sure that you have administrator rights; some setups need them for tool installation.
- **Local SIP Installation Path**
  Please use a local installation path for your MICROSAR Classic SIP. Installation on a network drive may lead to tool performance issues and errors.
- **MICROSAR Classic Standard SIPs only: MCAL Handling**
  MCALs are usually not part of the MICROSAR Classic SIP delivery (except Vector is MCAL reseller). For detailed information about the MCAL handling, refer to chapter MCAL Integrate and Update on page 11.
- **Evaluation Bundles only: CANoe**
  If you have to create or edit legacy files like DBC, LDF or FIBEX and you do not have CANoe, please contact Vector.

2.2 STEP 1: Install the MICROSAR Classic SIP delivery

You have received two e-mails from Vector:

1. one e-mail with the download link and installation instructions,
2. one e-mail with the password for decrypting the delivery.

If not already done, install your MICROSAR Classic SIP delivery as described in the first e-mail that you have received from Vector.



Cross Reference

Refer to the Delivery Description [1] to find detailed information about your MICROSAR Classic SIP delivery.

2.3 STEP 2: Install Tools

This section describes the installation of related tools. Please note that the tools depend on the scope of your order.

Evaluation Bundles only: Your Evaluation Bundle may include more than one license for the respective tools. In this case your delivery will contain multiple folders with the tool installations, named like the serial number of the tool licenses.

2.3.1 DaVinci External Components

To install the DaVinci External Components, proceed as follows:

1. Download the DaVinci External Components from here: http://download.vector.com/davinci/ExternalComponentsSetup.zip.
2. Extract the downloaded **DaVinci_ExternalComponentsSetup.zip** file.
3. Run the extracted **DaVinci_ExternalComponentsSetup.exe** and follow the installation instructions.

The DaVinci External Components are now installed.

2.3.2 DaVinci Configurator Classic

The DaVinci Configurator Classic is delivered as part of your MICROSAR Classic SIP and runs without installation (no separate installation required).

2.3.3 DaVinci Developer Classic

This section is only relevant if you use the DaVinci Developer Classic for creating SWCs.

The DaVinci Developer Classic is delivered separately (not part of the MICROSAR Classic SIP delivery). To install the DaVinci Developer Classic , run the **setup.exe** of the DaVinci Developer Classic delivery and follow the installation instructions.

2.3.4 vVIRTUALtarget

This section is only relevant for MICROSAR Classic SIPs that include vVIRTUALtarget modules.

To build and execute the virtual ECU, you need a vVIRTUALtarget tool license. Contact sales@vector.com to learn more and for pricing details.

2.3.5 TA Tool Suite

This section is only relevant if you use the TA Tool Suite for managing the timing behavior in your MICROSAR Classic multi-core project.

The TA Tool Suite is delivered separately as a ZIP archive (not part of the MICROSAR Classic SIP delivery). To install the TA Tool Suite, download the ZIP archive and extract it to a chosen installation folder. For more information, refer to the TA Tool Suite Manual located in the Documentation folder of your TA Tool Suite installation.

2.3.6 Evaluation Bundles only: CANdelaStudio

To install CANdelaStudio, proceed as follows:

1. Open **...\Vector_AUTOSAR_Solution\CANdela_Studio_x.x_SPx**
2. Start the **CANdelaStudioInstall.exe** and follow the installation instructions.

CANdela Studio is installed to the path you have specified.

2.4 STEP 3: Activate Tool Licenses

Depending on your order, you have received an e-mail with information on how to activate your tool licenses. Please follow these instructions.

2.5 Next Steps

After you have completed the above-mentioned installation steps, proceed with the Startup Document [3].

3 Update

This section describes how to update your Vector tools. We recommend to always use the latest service pack of the tools.

3.1 DaVinci External Components

The DaVinci tools will inform you if a newer version of the External Components, than the one you have installed, exists.

To update your DaVinci External Components, proceed as follows:

1. Download the DaVinci External Components from here: http://download.vector.com/davinci/ExternalComponentsSetup.zip
2. Extract the downloaded **DaVinci_ExternalComponentsSetup.zip** file.
3. Run **DaVinci_ExternalComponentsSetup.exe** and follow the installation instructions.

The DaVinci External Components are now updated.

3.2 DaVinci Configurator Classic

To update DaVinci Configurator Classic, proceed as follows:

1. Go to the SIP folder .\DaVinciConfigurator.
2. Run the **InstallationManager.exe**.
3. Click **[Search for Updates]**. A web page **DaVinci Download Area** opens displaying a download link if a newer service pack is available.
4. Click on the ZIP file to download the latest service pack.
5. Extract the downloaded ZIP file.
6. Run the extracted EXE file to start the DaVinci Configurator Classic Service Pack Installer.
7. On the **SIP Selection page**, select the SIP(s) to be updated and click **[Next >]**.
8. On the **Compatibility Check** page, click **[Next >]** to start the update.
9. After completion, click **[Finish]** to exit the Installation wizard.

The DaVinci Configurator Classic is now updated.

3.3 DaVinci Developer Classic

To update DaVinci Developer Classic, proceed as follows:

1. Open the Vector Download-Center www.vector.com/servicepacks_davinci_DEV.
2. Download the latest service pack of the compatible version of the DaVinci DeveloperC Classic.
   To find out the compatible DaVinci Developer Classic version, refer to the Vector KnowledgeBase.

3. Extract the downloaded ZIP file.
4. Run the extracted EXE file and follow the installation instructions.

The DaVinci Developer Classic is now updated.

3.4 Evaluation Bundles only: CANdelaStudio

To update CANdelaStudio, proceed as follows:

1. Open the link: https://vector.com/vi_downloadcenter_en.html.
2. Download the latest service pack of CANdelaStudio.
3. Extract the downloaded ZIP file.
4. Run the extracted EXE file and follow the installation instructions.
5. Open the existing CANdelaStudio folder and copy your license file **Activation_libFNP.dll** to the new installation folder.

The CANdelaStudio is now updated.

4 Deinstallation

4.1 MICROSAR Classic SIP

To uninstall your MICROSAR Classic SIP, proceed as follows:

1. Open **Programs and Features** in the Windows Control Panel.
2. Select the Vector MICROSAR Classic SIP that you want to remove.
3. Click **[uninstall]**.

The MICROSAR Classic SIP has been uninstalled.

4.2 DaVinci Developer Classic

To uninstall your DaVinci Developer Classic , proceed as follows:

1. Open **Programs and Features** in the Windows Control Panel.
2. Select Vector DaVinci Developer Classic.
3. Click **[uninstall]**.

The DaVinci Developer Classic has been uninstalled.

4.3 DaVinci Configurator Classic

The DaVinci Configurator Classic is installed and uninstalled together with the MICROSAR Classic SIP. A separate deinstallation is not required.

4.4 Remove DaVinci Configurator Classic from MICROSAR Classic SIP



Note

The removal of the DaVinci Configurator Classic is supported with R18 or later.

If you plan to archive the MICROSAR Classic SIP and you want to remove the DaVinci Configurator Classic to shrink the size of the MICROSAR Classic SIP, proceed as follows:

1. Navigate to the MICROSAR Classic SIP folder .\DaVinciConfigurator.
2. Run **InstallationManager.exe**.
3. Click **[Remove DaVinci Configurator from SIP]**.

Before using the MICROSAR Classic SIP, you have to re-install the DaVinci Configurator Classic:

1. Navigate to the MICROSAR Classic SIP folder .\DaVinciConfigurator
2. Run **InstallationManager.exe**.
3. Click **[Download DaVinci Configurator]**. A web page **DaVinci Download Area** will open in your browser displaying a download link with the matching version/service packs.

4. Download the latest DaVinci Configurator Service Pack Installer via the download link.
5. Start the DaVinci Configurator Classic Service Pack Installer and select your MICROSAR Classic SIP.

5 Additional Information

5.1 Reference Documents

This section lists the documents that are referenced within this Installation Guide.

No.	Title and Description
[1]	**DeliveryDescription_<CBDyynnnnnnn>.html** The Delivery Description contains detailed information about your delivery. The Delivery Description is located in the .\Doc\DeliveryInformation folder of your MICROSAR Classic SIP delivery.
[2]	**DocumentationGuide_*.pdf** Get an overview of all delivered documents, their content and where they are located. This document is stored in the root folder of your MICROSAR Classic SIP.
[3]	**Startup_<OEM>_<SLP>.pdf** **Startup_<OEM>_<SLP>.chm** This User Manual describes how to get the delivery basically running step by step and how to start with Vector AUTOSAR Solution. Get familiar with MICROSAR Classic BSW modules and tools like DaVinci Developer Classic and DaVinci Configurator Classic. The Startup document is available as PDF or as CHM. You find these documents in the folder .\Doc\UserManuals of your MICROSAR Classic SIP.

5.2 System Requirements

The system requirements can be found as follows:

- DaVinci Configurator Classic
  https://www.vector.com/int/en/products/products-a-z/software/davinci-configurator-pro/
- DaVinci Developer Classic
  https://www.vector.com/int/en/products/products-a-z/software/davinci-developer/
- CANdelaStudio
  https://www.vector.com/de/de/produkte/produkte-a-z/software/candelastudio/
- CANoe
  https://www.vector.com/int/en/products/products-a-z/software/canoe/

5.3 MCAL Integrate and Update

This section is only relevant if the **TechnicalReference_3rdParty-MCAL-Integration_<Controller>.pdf** is contained in the SIP folder .\Components\Mcal_<Controller>\Documentation or .\Doc\TechnicalReferences. If the documentTechnicalReference_3rdParty-MCAL-Integration_<Controller>.pdf exists, read the MCAL-specific information in it.

The MCAL is usually not part of the MICROSAR Classic SIP delivery (except Vector is MCAL reseller). Therefore, you must order the required MCAL directely from the semiconductor manufacturer.

The MICROSAR Classic SIP includes the third party MCAL Integration Helper Tool that allows you to integrate or update a third party MCAL with your MICROSAR Classic SIP. To integrate or update a third party MCAL, execute the **3rdPartyMcalIntegrationHelper.exe** that is located in the SIP folder .\ThirdPary\MCALIntegrationHelper\ and follow the instructions.



Cross Reference

For detailed information refer to **UserManual_3rdParty-MCAL-Integration.pdf**.

5.4 MCALs Using EB Tresos Studio

The following video explains how a third party MCAL based on the configuration/generation tool Tresos Studio can be integrated with the Vector AUTOSAR Solution.



Multimedia Link

https://youtu.be/kSyiWBYlYyw

5.5 RTE Version

You can find the RTE version in the Delivery Description [1]:

Open the Delivery Description and search for **Rte_Asr4** in the Component Version Information section.

6 Contact

Visit our website for more information on

- News
- Products
- Demo software
- Support
- Training data
- Addresses

www.vector.com