

QUICK GUIDE



Working status

LED	Descriptions	Status
GSM	Dark, no light or no flashing	No SIM card or no GSM signal
	Bright, no flashing	Receive GSM signal normally
Y. 1		Good GSM & GPRS signal, but not connected to sever
	Flash 200ms every 2 sec periodically (slow flashing)	Connected to sever
GPS	Flash 200ms every 2 sec periodically (slow flashing)	Good GPS signal GPS located
	Flash 100ms every 0.5 sec periodically (fast flashing)	Searching for GPS signal
	Dark	No GPS Signal

Configurations

Configurations	Content of SMS
GPRS time sending interval	timer,min,max Ex: timer,15,600#
Server config	server, <ip domain="" or="">,<port># Ex: server,vnetgps.com,2016#</port></ip>
Time zone	timezone, <gmt time="" zone=""># Ex: timezone,7#</gmt>
Vibrantion alarm	motion, <enable (0)="" (1)="" disable=""> < coefficient > Ex: motion, 1, 0.125# (the smaller coefficient, the more sensitive)</enable>
Location	url#
Factory reset	default#
Reset	reset# or hard reset

VIETNAM ELECTRONICS & TELECOMMUNICATION JOINT STOCK COMPANY

🤶 No 233-234, Block C6, Dai Kim ward, Hoang Mai dist, Ha Noi

(84) 243 640 0767



info@vn-et.com 💮 www.vnetgps.vn

Installation

