
Inside the Sobel module there is a DIVIDER GENERATOR instantiation named division_ip.

For creating the instance follow the steps:

Go to IP Catalog in project manager >>> search for divider generator IP >>> make its settings as shown below



NB – change the component name as division ip

We also want to instantiate an output buffer, for these follow the steps:

Go to IP Catalog in project manager >>> search for fifo generator IP >>> make its settings as shown below

