## **NAME**

sdptool — control and interrogate SDP servers

#### **SYNOPSIS**

**sdptool** [options] {command} [command parameters ...]

#### DESCRIPTION

**sdptool** provides the interface for performing SDP queries on Bluetooth devices, and administering a local SDP database.

## **COMMANDS**

The following commands are available. In all cases **bdaddr** specifies the device to search or browse. If *lo-cal* is used for **bdaddr**, then the local SDP database is searched.

Services are identified and manipulated with a 4-byte **record\_handle** (NOT the service name). To find a service's **record\_handle**, look for the "Service RecHandle" line in the **search** or **browse** results

## search [--bdaddr bdaddr] [--tree] [--raw] [--xml] service\_name

Search for services..

Known service names are DID, SP, DUN, LAN, FAX, OPUSH, FTP, HS, HF, HFAG, SAP, NAP, GN, PANU, HCRP, HID, CIP, A2SRC, A2SNK, AVRCT, AVRTG, UDIUE, UDITE and SYNCML.

## browse [--tree] [--raw] [--xml] [bdaddr]

Browse all available services on the device specified by a Bluetooth address as a parameter.

## records [--tree] [--raw] [--xml] bdaddr

Retrieve all possible service records.

## add [ --handle=N --channel=N ]

Add a service to the local SDP database.

You can specify a handle for this record using the --handle option.

You can specify a channel to add the service on using the --channel option.

NOTE: Local adapters configuration will not be updated and this command should be used only for SDP testing.

## del record handle

Remove a service from the local SDP database.

NOTE: Local adapters configuration will not be updated and this command should be used only for SDP testing.

## get [--tree] [--raw] [--xml] [--bdaddr bdaddr] record\_handle

Retrieve a service from the local SDP database.

## setattr record handle attrib id attrib value

Set or add an attribute to an SDP record.

## setseq record\_handle attrib\_id attrib\_values

Set or add an attribute sequence to an SDP record.

## **OPTIONS**

**--help** Displays help on using sdptool.

## **EXAMPLES**

sdptool browse 00:80:98:24:15:6D

sdptool browse local

sdptool add DUN

sdptool del 0x10000

## **BUGS**

Documentation needs improving.

# **AUTHOR**

Maxim Krasnyansky <maxk@qualcomm.com>. Man page written by Edd Dumbill <ejad@debian.org>.