# **Epson L3250 Printer Setup on Your Laptop**

# 1. Download the Epson Printer Software

## 1. Open the Download Page:

Click on this link to access the Epson L3250 support page.

## 2. Select Your Operating System:

 The website should automatically detect your operating system. If it doesn't, you can manually select it from the dropdown menu.

#### 3. Download the Software:

- Scroll down to the "Drivers and Downloads" section.
- Download the "Printer Driver" or the "Epson Software Updater" depending on your preference. If you're unsure, downloading the printer driver is recommended.

# 2. Install the Epson Printer Software

#### 1. Locate the Downloaded File:

 Once the download is complete, navigate to your "Downloads" folder or the location where the file was saved.

#### 2. Run the Installer:

Double-click on the downloaded file to begin the installation process.

#### 3. Follow the Installation Wizard:

- The Epson installation wizard will guide you through the setup process. Follow the on-screen instructions.
- Accept the End User License Agreement when prompted.
- Choose the "Standard" installation option if available, which will install all necessary drivers and utilities.

#### 4. Connect the Printer:

 When prompted, connect your Epson L3250 printer to your laptop using a USB cable. The installation wizard may ask you to connect the printer at this stage.

# 3. Connect the Printer to Your Wi-Fi Network

### 1. Using the Epson Software:

- During the installation process, the wizard may ask if you want to connect the printer to a Wi-Fi network.
- Select "Wireless Network Setup" and follow the on-screen instructions to connect the printer to your Wi-Fi network.
- You will need to select your Wi-Fi network from a list and enter the password.

### 2. Manual Wi-Fi Setup (If Needed):

- If the software doesn't prompt for Wi-Fi setup, you can do this manually from the printer:
  - 1. Press the **Wi-Fi** button on the printer until the indicator light flashes.
  - 2. On your laptop, connect to the temporary Wi-Fi network that the printer broadcasts.
  - 3. Open a web browser and type 192.168.192.168 in the address bar to access the printer's setup page.
  - 4. Follow the on-screen instructions to connect the printer to your Wi-Fi network.

# 4. Test the Printer

### 1. Print a Test Page:

- After the installation is complete, it is recommended to print a test page to ensure that everything is working correctly.
- Go to "Devices and Printers" on your laptop, right-click on the Epson L3250, and select "Print Test Page."

### 2. Scan a Document (Optional):

o If your setup includes scanner drivers, test the scanner by scanning a document.

# 5. Troubleshooting (If Necessary)

- **Connection Issues:** Ensure that both your laptop and the printer are connected to the same Wi-Fi network.
- **Driver Issues:** If the printer is not recognized, ensure you downloaded the correct driver for your operating system.
- **Wi-Fi Setup:** If the Wi-Fi setup fails, you can try connecting the printer to your router using a WPS button or perform the setup via the printer's control panel.

# 6. Enjoy Your Printer!

 Your Epson L3250 should now be successfully set up on your laptop. You can start printing, scanning, and copying as needed.