XPlanar Application 2.0 Release Notes

- Key Updates
  - Updates made for TF5890 5.0 Compatibility
    - Backwards compatible to version 4.5
  - SPT_BaseTypes is no longer a required dependency
    - Less confusion when using other coding styles/frameworks
    - **InitComplete property changed to Initialized *Possible Breaking Change**
  - I_XPlanarSystem interface added for use with OOP style frameworks
    - **Mover/Track/Station counts are automatically determined based on declarations. *Possible Breaking Change**
    - SystemParameters no longer required.
    - New object counts are available via the XPlanar GVL.
      - XPlanar.MoverCount
      - XPlanar.TrackCount
      - XPlanar.StationCount
    - Existing syntax > New syntax example

```
FOR i := 1 TO SystemParameters.STATION_COUNT DO
    ip.Stations[i].Execute();
END_FOR
```

```
FOR i := 1 TO XPlanar.StationCount DO
    ip.Stations[i].Execute();
END_FOR
```

  - Backend interfaces and index values are automatically set during Initialization
    - ~~Ip.Movers[1] := Movers[1];~~ < This type of manual setting is no longer needed
    - ~~Ip.Tracks[1] := Tracks[1];~~
    - ~~Ip.Stations[1] := Station1~~
  - Read BTN Only option added for IdentifyMovers method.
  - MoverQueue removed from XPlanar Stations
    - No more confusion with movers getting queued in a station during recovery requiring additional dequeue commands
    - A new mover collection property is available showing all movers in and destined for that station.
  - New FB_XPlanarPositionTrigger added as an option for on-the-fly mover handling.
  - AtRotationPosition optimized for TF Version and System tile type to allow rotate anywhere
  - I_MoverData interface added as option for custom data tracking.