




PINOUT



- █ Power
- █ GND
- █ Serial Pin
- █ Analog Pin
- █ Control
- █ Physical Pin
- █ Port Pin
- █ Touch Pin
- ~ PWM Pin

Low Level Bootloader

P2 + **GND**

Boot modes and safe boot

P12 + **3.3V**

- 1-3sec Safe boot, latest firmware is selected
- 4-6sec Safe boot, previous user update selected
- 7-9sec Safe boot, the factory firmware is selected

Internal Functions

25 **GPIO16** **EMAC^{CLKOUT}** **U2RXD** **HS1DATA4** External Antenna Switch

