# 4. FreeRTOS application

- 4. FreeRTOS application
  - 4.1. Purpose of the experiment
  - 4.2. Configure FreeRTOS information
  - 4.3. Analysis of the experimental flow chart
  - 4.4. core code explanation
  - 4.5. Hardware connection
  - 4.6. Experimental effect


## 4.1. Purpose of the experiment

Based on the program of "Key Control Buzzer Whistle", the function is imported into the FreeRTOS system to run, to detect the state of KEY1 on the expansion board, and to control the buzzer to whistle. Press the button once, the buzzer will beep (every 200 milliseconds), press the button again, the buzzer will be turned off.


## 4.2. Configure FreeRTOS information

Since each new project needs configuration information, it is more troublesome. Fortunately, STM32CubeIDE provides the function of importing .ioc files, which can help us save time.

- 1. Import the ioc file from the BEEP project and name it FreeRTOS.
- Click Middleware->FreertOS, select CMSIS\_V1, click Tasks and Queues, there will be one task
  by default, and then create two new tasks, one of which manages the buzzer and the other
  manages the buttons.



3. The buzzer task information is shown in the following figure:



Task Name: The task name.

Priority: Set the priority.

Stack Size: heap space, the size can be modified according to the actual situation.

Entry Function: The task function entity.

Code Generation Option: Code generation configuration, the default is weak to generate task

entities, you can choose external not to generate task entities.

Parameter: The task parameter.


Allocation: You can choose Dynamic dynamic allocation or Static static allocation.

Buffer Name: The statically allocated buff name.

Control Block Name: Statically allocated block name.

The key task is the same, just with a different name.

## 4.3. Analysis of the experimental flow chart



## 4.4. core code explanation

1. Create new buzzer driver library bsp\_task.h and bsp\_task.c files in BSP. Add the following to bsp\_task.h:

```
void Task_Entity_LED(void);
void Task_Entity_Beep(void);
void Task_Entity_Key(void);
```

Among them, the Task\_Entity\_LED() function manages the LED lights, the Task\_Entity\_Beep() manages the buzzer, and the Task\_Entity\_Key() manages the buttons.

```
// LED light task entity function LED灯任务实体函数

void Task_Entity_LED(void)
{
    while (1)
    {
        // The indicator lights up every 100 milliseconds 指示灯每隔100毫秒亮一次
        LED_TOGGLE();
        osDelay(100);
    }
}
```

```
// Buzzer task entity function 蜂鸣器任务实体函数
void Task Entity Beep (void)
{
   while (1)
       if (enable beep)
          // The buzzer goes off every 200 milliseconds 蜂鸣器每200毫秒响一次
          BEEP ON();
          osDelay(100);
          BEEP OFF();
          osDelay(100);
       }
       else
          BEEP OFF();
          osDelay(100);
       }
   }
}
   // Key task entity function 按键任务实体函数
  void Task Entity Key (void)
   {
       while (1)
       {
           if (Keyl State(1) == KEY PRESS)
               // Button controls the buzzer switch 按键控制蜂鸣器开关
               enable beep = !enable beep;
           }
           osDelay(10);
       }
   }
```

2. Introduce bsp.h into the freertos.c file, find the corresponding entity functions of the three tasks, and call the task functions we manually created.

```
, ---- ,
void StartDefaultTask(void const * argument)
   /* USER CODE BEGIN StartDefaultTask */
   /* Infinite loop */
   // for(;;)
   // {
   // osDelay(1);
   // }
  Task Entity LED();
   /* USER CODE END StartDefaultTask */
/* USER CODE END Header StartTask BEEP */
void StartTask BEEP(void const * argument)
  /* USER CODE BEGIN StartTask BEEP */
  /* Infinite loop */
  // for(;;)
  // {
  // osDelay(1);
  // }
  Task Entity Beep();
  /* USER CODE END StartTask BEEP */
}
```

```
/* USER CODE END Header_StartTask_KEY */
void StartTask_KEY(void const * argument)
{
    /* USER CODE BEGIN StartTask_KEY */
    /* Infinite loop */
    // for(;;)
    // {
        // osDelay(1);
        // }
    Task_Entity_Key();
    /* USER CODE END StartTask_KEY */
}
```

#### 4.5. Hardware connection

The LED light, key KEY1 and buzzer in FreeRTOS application are all onboard components and do not need to be connected manually.

## 4.6. Experimental effect

After the program is programmed, the LED light flashes every 200 milliseconds, press the button, the buzzer beeps (every 200 milliseconds), press the button again, the buzzer turns off.