

www.4dsystems.com.au

Initialisation Codes for the 4D Systems 4DOLED-282815 Display

Command Defines:

```
#def SET COLUMN ADDRESS
                                               0x15
#def SET_ROW_ADDRESS
                                               0x75
#def WRITE_GRAM
                                               0x5C
#def READ_GRAM
                                               0x5D
#def STOP_MOVING
                                               0x9E
#def START_MOVING
                                               0x9F
#def REMAP_COLOUR_SETTINGS
                                               0xA0
#def DISPLAY_START_LINE
                                               0xA1
#def DISPLAY_OFFSET
                                               0xA2
#def DISPLAY OFF
                                               0xA4 // Entire Display Off, All Pixels Turn Off
#def DISPLAY_ALL_ON
                                               0xA5 // Entire Display On, All Pixels Turn On at GS Level 63
#def DISPLAY_NORMAL
                                               0xA6 // Normal Display
                                               0xA7 // Inverse Display
#def DISPLAY_INVERSE
#def FUNCTION SELECTION
                                               0xAB
#def DISPLAY NOP
                                               0xAD
#def DISPLAY SLEEP OFF
                                               0xAE
#def DISPLAY SLEEP ON
                                               0xAF
#def DISPLAY NOP2
                                               0xB0
#def PHASE_PRECHARGE
                                               0xB1
#def DISPLAY_ENHANCE
                                               0xB2
#def CLOCK_FREQUENCY
                                               0xB3
#def SEGMENT_LOW_VOLTAGE
                                               0xB4
#def SET_GPIO
                                               0xB5
#def SECOND_PRECHARGE
                                               0xB6
#def SET_GRAYSCALE_LUT
                                               0xB8
#def RESET_GRAYSCALE_LUT
                                               0xB9
#def PRECHARGE VOLTAGE RGB
                                               0xBB
#def SET_VCOMH
                                               0xBE
#def CONTRAST_RGB
                                               0xC1
#def CONTRAST_MASTER
                                               0xC7
#def DUTY CYCLE
                                               0xCA // same (set mux ration)
#def OLED_NOP2
                                               0xD1
#def OLED_NOP3
                                               0xE3
#def COMMAND LOCK
                                               0xFD
```

Init Code (Command, Data1, ... DataN)

```
COMMAND LOCK, 0x12,
                                                  // Unlock Driver IC (0x12/0x16/0xB0/0xB1)
COMMAND LOCK, 0xB1,
                                                  // Unlock All Commands (0x12/0x16/0xB0/0xB1)
DISPLAY OFF,
                                                  // Display Off (0x00/0x01)
CLOCK_FREQUENCY, 0xF1,
                                                  // Set Clock as 120 Frames/Sec
DUTY_CYCLE, 0x7F,
                                                  // 1/96 Duty (0x0F~0x7F)
DISPLAY_OFFSET, 0,
                                                  // Shift Mapping RAM Counter (0x00~0x7F)
DISPLAY_START_LINE, 0x00,
                                                  // Set Mapping RAM Display Start Line (0x00~0x7F)
REMAP_COLOUR_SETTINGS, 0x74,
                                                  // Set Horizontal Address Increment
   // Column Address 0 Mapped to SEG0
   // Color Sequence D[15:0]=[RRRRR:GGGGGG:BBBBB]
   // Scan from COM127 to COM0
   // Enable COM Split Odd Even
   // 65,536 Colors Mode (0x74)
   // * 262,144 Colors Mode (0xB4)
SET_GPIO, 0x00,
                                                  // Set Low Voltage Level of SEG Pin
FUNCTION_SELECTION, 0x01,
                                                  // Enable Internal VDD Regulator, Select 8-bit Parallel Interface
SEGMENT_LOW_VOLTAGE, 0xA0,0xB5,0x55,
                                                  // Enable External VSL, Set Segment Low Voltage
CONTRAST RGB, 0xC8,0x80,0x8A,
                                                  // Set Contrast of Color A (Red)
   // Set Contrast of Color B (Green)
```

Porting of this Initialisation code to your chosen hosts language will be required. Please refer to the datasheet for the Driver IC used on the display, for more information. (SSD1351)



www.4dsystems.com.au

// Set Contrast of Color C (Blue) CONTRAST MASTER, 0x0F, // Set Scale Factor of Segment Output Current Control (0-15) RESET_GRAYSCALE_LUT, // just use internal table for Gray Scale Table PHASE_PRECHARGE, 0x32, // Set Phase 1 as 5 Clocks & Phase 2 as 3 Clocks PRECHARGE VOLTAGE RGB, 0x17, // Set Pre-Charge Voltage Level as 0.50*VCC DISPLAY ENHANCE, 0xA4, 0x00, 0x00, // UNDOCUMENTED COMMAND Enhance Display Performance SECOND_PRECHARGE, 0x01, // Set Second Pre-Charge Period as 1 Clock SET_VCOMH, 0x05, // Set Common Pins Deselect Voltage Level as 0.82*VCC DISPLAY_NORMAL, // Normal Display Mode (0x02) DISPLAY_SLEEP_ON, // not sleeping