# Equipment care

This guide covers the grinders and kettles we sell. Following it keeps them within the two-year warranty.

### Grinder cleaning

Clean the burrs of the hand grinder once a month. Grind a spoonful of uncooked rice, then brush the burrs with the brush that comes in the box. Never wash the burrs with water: they rust.

# Kettle descaling

Descale the gooseneck kettle every four weeks in hard-water cities such as Istanbul and Ankara. Fill it halfway with one part white vinegar and two parts water, boil, leave for an hour and rinse twice. The temperature display may show E2 while the kettle is too hot to measure; let it cool for ten minutes.

# Warranty

The warranty covers faults in materials and workmanship for two years from delivery.
It does not cover broken glass, burrs damaged by stones in the beans, or kettles used without water.
To claim, the customer emails a photo and the order number to destek@demlik.example.