Error code Dx Description

Error code Dx Description	
0 RFID reader failure	0x0000001
1 Display communication failure	0x00000002
2 Electromagnetic lock failure	0x00000004
3 Meter communication failure	0x00000008
4 Emergency stop switch failure	0x0000010
5 AC contactor failure	0x00000020
6 BMS power failure	0x00000040
7 Backend(CMS) communication failure	0x00000080
8 Module communication failure	0x00000100
9 Insulation failure	0x00000200
10 Temperature failure	0x00000400
11 Memory failure	0x00000800
12 PFC module bus overvoltage	0x00001000
13 PFC module bus undervoltage	0x00002000
14 DC/DC failure	0x00004000
15 Module temperature failure	0x00008000
16 DC contactor failure	0x00010000
17 Input overvoltage	0x00020000
18 Input overcurrent	0x00040000
19 Input undervoltage	0x00080000
20 Input phase loss	0x00100000
21 Grid frequency abnormal	0x00200000
22 Output overvoltage	0x00400000
23 Output undervoltage	0x00800000
24 Output overcurrent	0x01000000
25 Output short circuit	0x02000000
26 Output open circuit	0x04000000
27 Single cell voltage high	0x08000000
28 Single cell temperature high	0x10000000
29 BMS fault	0x20000000
30 Battery not connected	0x40000000
31 Battery overvoltage	0x80000000
32 Battery undervoltage	0x000000100000000
33 SOC too high	0x0000000200000000
34 Battery pack insulation failure	0x0000000400000000
35 Battery pack output connector failure	0x0000000800000000
36 Connection confirmation failure	0x0000001000000000
37 Module failure	0x0000002000000000
38 Battery connection reverse	0x000000400000000
39 BMS communication timeout	0x0000008000000000
40	0x0000010000000000
41	0x0000020000000000
42	0x0000040000000000
43 Fan failure	0x000004000000000000000000000000000000
44 AC module failure	0x000010000000000000
45 Fault due to Connector temperature too high	0x0000100000000000000
To radic due to connector temperature too mgn	0,0000200000000000000000000000000000000

46 Communication failure with small board	0x0000400000000000
56	
57	
58	
59 32 Charger communication failure	0x0800000000000000
60 Parallel contactor failure	0x10000000000000000
61 Access control failure	0x20000000000000000
62 Relay control board communication failure	0x40000000000000000
63 Relay switching failure	0x8000000000000000