

Public Properties

Name	Description
AnnotationView	Gets the annotation view for this annotation.
BentLeaderLength	Gets or sets the length of the bent leader for this annotation.
Color	Gets or sets the color of this annotation. Annotation color is supported only in SOLIDWORKS drawings.
FrameLineStyle	Gets or sets the frame's line style for this annotation.
FrameThickness	Gets or sets the frame's line thickness for this annotation.
FrameThicknessCustom	Gets or sets the frame's line thickness for this annotation.
Layer	Gets or sets the layer used by this annotation. Layers are supported only in SOLIDWORKS drawings.
LayerOverride	Gets or sets whether the annotation has properties that override the default properties of the layer.
LeaderLineStyle	Gets or sets the leader's lines style for this annotation.
LeaderThickness	Gets or sets the leader's line thickness for this annotation.
LeaderThicknessCustom	Gets or sets the leader's custom line thickness for this annotation.
Owner	Gets the owner of this annotation.
	NOTE: This property is a get-only property. Set is not implemented.
OwnerType	Gets the type of owner of this annotation.
	NOTE: This property is a get-only property. Set is not implemented.
Style	Gets or sets the line style for this annotation.
UseDocDispFrame	Gets or sets whether to use the document's frame's line style and thickness or a specified line style and thickness for this annotation.
UseDocDispLeader	Gets or sets whether to use the document's leader's line style and thickness or a specified line style and thickness for this annotation.
Visible	Gets or sets the visibility state of this annotation.
Width	Gets or sets the line width enumeration value for this annotation.

[Top](#)

Public Methods

Name	Description
AddOrUpdateStyle	Adds or updates the annotation linked to the specified style.
ApplyDefaultStyleAttributes	Applies the default style attribute to this annotation.
CanShowInAnnotationView	Gets whether this annotation can be shown in the specified annotation view.
CanShowInMultipleAnnotationViews	Gets whether this annotation can be shown in multiple annotation views.
CheckSpelling	Spell checks the text in this annotation.
ConvertToMultiJog	Converts a note with a leader to a note with a multi-jog leader.
DeleteStyle	Deletes the specified style.
DeSelect	Deselects this annotation.
GetArrowHeadCount	Gets the number of arrowheads on this symbol.
GetArrowHeadSizeAtIndex	Gets the arrow head size of the specified leader on this annotation.
GetArrowHeadStyleAtIndex	Gets the arrow head style of a specific leader on this annotation.
GetAttachedEntities	Obsolete. Superseded by IAnnotation::GetAttachedEntities2.
GetAttachedEntities2	Obsolete. Superseded by IAnnotation::GetAttachedEntities3.
GetAttachedEntities3	Gets the entities to which this annotation is attached.
GetAttachedEntityCount2	Obsolete. Superseded by IAnnotation::GetAttachedEntityCount3.
GetAttachedEntityCount3	Gets the number of entities to which this annotation is attached.
GetAttachedEntityTypes	Gets the types of entities attached to this annotation.
GetBentLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle.
GetDashedLeader	Gets whether this leader is a dashed line or a solid line.
GetDimXpertFeature	Gets the DimXpert feature associated with this annotation.
GetDimXpertName	Gets the DimXpert name for this annotation.
GetDisplayData	Gets the display data for this annotation.
GetFlipPlaneTransform	Gets the transformation matrix of the annotation plane in the opposite direction.
GetLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle.
GetLeaderAllAround	Gets the setting for all-around symbol display of this annotation.
GetLeaderCount	Gets the number of leaders on this annotation.
GetLeaderPerpendicular	Gets the perpendicular bent leader display setting for this annotation.
GetLeaderPointsAtIndex	Gets coordinate information about a specified leader on this annotation.
GetLeaderSide	Gets the leader attachment side setting for this annotation.
GetLeaderStyle	Gets the style of this leader.
GetMultiJogLeaderCount	Gets the number of multi-jog leaders on this annotation.
GetMultiJogLeaders	Gets the multi-jog leaders on this annotation.

[GetName](#)
[GetNext](#)
[GetNext2](#)
[GetNext3](#)
[GetParagraphs](#)

[GetPlane](#)

[GetPMIData](#)

[GetPMIType](#)

[GetPosition](#)
[GetSmartArrowHeadStyle](#)
[GetSpecificAnnotation](#)
[GetStyleName](#)
[GetTextFormat](#)
[GetTextFormatCount](#)
[GetType](#)

[GetUseDocTextFormat](#)

[GetVisualProperties](#)
[IGetAttachedEntities](#)
[IGetAttachedEntityCount](#)
[IGetAttachedEntityTypes](#)
[IGetDisplayData](#)
[IGetLeaderPointsAtIndex](#)
[IGetMultiJogLeaders](#)
[IGetNext](#)
[IGetNext2](#)
[IGetPosition](#)
[IGetSpecificAnnotation](#)
[IGetTextFormat](#)
[IGetVisualProperties](#)
[IsDangling](#)
[IsDimXpert](#)
[ISetAttachedEntities](#)

[ISetTextFormat](#)

[LoadStyle](#)
[SaveStyle](#)
[Select](#)
[Select2](#)
[Select3](#)
[SelectByMark](#)
[SetArrowHeadSizeAtIndex](#)
[SetArrowHeadStyleAtIndex](#)
[SetAttachedEntities](#)
[SetLeader](#)
[SetLeader2](#)
[SetLeader3](#)

[SetLeaderAttachmentPointAtIndex](#)

[SetName](#)
[SetPosition](#)
[SetPosition2](#)
[SetStyleName](#)
[SetTextFormat](#)

Gets the name of this annotation.
[Obsolete. Superseded by IAnnotation::GetNext3.](#)
[Obsolete. Superseded by IAnnotation::GetNext3.](#)

Gets the next annotation.
Gets the paragraphs in this note annotation.

Gets the rotation matrix of the annotation relative to the X-Y plane of the model.

Gets the Product and Manufacturing Information (PMI) feature data object for this STEP 242 annotation.
Gets the type of Product and Manufacturing Information (PMI) associated with this STEP 242 annotation.

Gets the position of this annotation.
Gets the setting for smart arrowhead style for this annotation.
Gets the specific underlying object associated with this annotation.
Gets the name of the style applied to this annotation.
Gets the text format for the specified text in this annotation.
Gets the number of text formats for this annotation.

Gets the type of the annotation.
Gets whether SOLIDWORKS is currently using the document default text format setting for this annotation.
Gets the visual properties of this annotation.

[Obsolete. Superseded by IAnnotation::GetAttachedEntities2.](#)
[Obsolete. Superseded by IAnnotation::GetAttachedEntityCount2.](#)
Gets the types of all entities attached to this annotation.

Gets the display data for the annotation.
Gets coordinate information about a specified leader on this annotation.
Gets the multi-jog leaders on this annotation.
[Obsolete. Superseded by IAnnotation::GetNext3.](#)
[Obsolete. Superseded by IAnnotation::GetNext3.](#)

Gets the position of this annotation.
Gets the specific underlying object associated with this annotation.
Gets the text format for the specified text in this annotation.
Gets the visual properties of this annotation.
Gets whether this annotation is dangling.
Gets whether the annotation is a DimXpert annotation.
Attaches this annotation to the specified entities.

Sets the text format information for the specified text within this annotation.

Loads the specified style.
Saves the specified style.
[Obsolete. Superseded by IAnnotation::Select3.](#)
[Obsolete. Superseded by IAnnotation::Select3.](#)
Selects this annotation and marks it.
[Obsolete. Superseded by IAnnotation::Select3.](#)
Sets the size of the arrow head of the specified leader on this annotation.
Sets the arrow head style of a specific leader on this annotation.
Attaches this annotation to the specified entities.
[Obsolete. Superseded by IAnnotation::SetLeader3.](#)
[Obsolete. Superseded by IAnnotation::SetLeader3.](#)
Sets the leader characteristics for this annotation.
Sets the specified attachment point of a leader for an annotation with the specified index.

Sets the name of this annotation.
[Obsolete. Superseded by IAnnotation::SetPosition2.](#)
Sets the position of this annotation.
Sets the style for this annotation.
Sets the text format for the specified text in this annotation.