



- ICurveDrivenPatternFeatureData
- ICurveParamData
- ICustomBendAllowance
- ICustomPropertyManager
- ICutListItem
- ICutListSortOptions
- IDatumOrigin
- IDatumTag
- IDatumTargetSym
- IDecal
- IDeleteBodyFeatureData
- IDeleteFaceFeatureData
- IDerivedPartFeatureData
- IDerivedPatternFeatureData
- IDesignTable
- IDetailCircle
- IDiagnoseResult
- IDimension
- IDimensionSensorData
- IDimensionTolerance
- IDimPatternFeatureData
- IDimXpertManager
- IDisplayData
- IDisplayDimension**
 - Members
- IDisplayStateSetting
- IDistanceMateFeatureData
- IDocumentSpecification
- IDomeFeatureData2
- IDowelSymbol
- IDraftFeatureData2
- IDragArrowManipulator
- IDragOperator
- IDrawingComponent
- IDrawingDoc
- IDrSection
- IDSPBRMaterial
- IEdge
- IEdgeFlangeFeatureData
- IEdgePoint
- IEndCapFeatureData
- IEntity
- IEnumBodies2
- IEnumCoEdges
- IEnumComponents2
- IEnumDisplayDimensions
- IEnumDocuments2
- IEnumDrSections
- IEnumEdges
- IEnumFaces2
- IEnumLoops2
- IEnumModelViews
- IEnumSketchHatches
- IEnumSketchPoints
- IEnumSketchSegments
- IEnvironment
- IEquationMgr
- IExplodeStep
- IExportPdfData
- IExtrudeFeatureData2
- IFace2
- IFaceDecalProperties
- IFaceHatch
- IFacet
- IFamilyTableAnnotation
- IFamilyTableFeature
- IFaultEntity
- IFeatMgrView
- IFeature
- IFeatureFolder
- IFeatureManager
- IFeatureStatistics
- IFillPatternFeatureData
- IFillSurfaceFeatureData
- IFlatPatternFeatureData
- IFlatPatternFolder
- IFlyoutGroup

... \ Interfaces \ IDisplayDimension

IDisplayDimension Interface

Represents instances of dimensions displayed in parts, assemblies, drawings and sensors.

.NET Syntax

Visual Basic (Declaration)

Public Interface IDisplayDimension

Visual Basic (Usage)

Dim instance As IDisplayDimension

C#

public interface IDisplayDimension

C++/CLI

public interface class IDisplayDimension

Example

Get Chamfer Display Dimension (C#)
Get Chamfer Display Dimension (VB.NET)
Get Chamfer Display Dimension (VBA)
Get and Set Sensor (C#)
Get and Set Sensor (VB.NET)
Get and Set Sensor (VBA)
Get DimXpert Display Dimensions and Feature (C#)
Get DimXpert Display Dimensions and Feature (VB.NET)
Get DimXpert Display Dimensions and Feature (VBA)
Set Properties of Angular Running Dimension (VBA)
Set Properties of Angular Running Dimension (VB.NET)
Set Properties of Angular Running Dimension (C#)

Remarks

You can display a SOLIDWORKS dimension more than once. For example, you can bring the base-extrude dimension into three different views on a drawing. These three dimensions are referred to as display dimensions and are represented by the DisplayDimension object in the SOLIDWORKS API. The original base-extrude dimension is represented by the Dimension object in the SOLIDWORKS API.

SOLIDWORKS stores many of the properties associated with a dimension with the underlying Dimension object. For example, you must get the Dimension object using IDisplayDimension::GetDimension to access or modify the underlying dimension value.

Accessors

IAnnotation::GetSpecificAnnotation and IAnnotation::IGetSpecificAnnotation

IDisplayDimension::GetNext5

IDrawingDoc::AddChamferDim and IDrawingDoc::IAddChamferDim

IDrawingDoc::AddHoleCallout2 and IDrawingDoc::IAddHoleCallout2

IDrawingDoc::CreateAngDim4 and IDrawingDoc::ICreateAngDim4

IDrawingDoc::CreateDiamDim4 and IDrawingDoc::ICreateDiamDim4

IDrawingDoc::CreateLinearDim4

IDrawingDoc::CreateOrdinateDim4 and IDrawingDoc::ICreateOrdinateDim4

IEnumDisplayDimensions::Next

IFeature::EnumDisplayDimensions

IFeature::GetDisplayDimension

IFeature::GetFirstDisplayDimension

IFeature::GetNextDisplayDimension

ILinearPatternFeatureData::D1Axis

ILinearPatternFeatureData::D2Axis

ILocalLinearPatternFeatureData::D1Axis

ILocalLinearPatternFeatureData::D2Axis

IMacroFeatureData::GetDisplayDimensions and IMacroFeatureData::IGetDisplayDimensions

IMate2::DisplayDimension2

IModelDoc2::AddDiameterDimension2 and IModelDoc2::IAddDiameterDimension2

IModelDoc2::AddHorizontalDimension2 and IModelDoc2::IAddHorizontalDimension2

IModelDoc2::AddRadialDimension2 and IModelDoc2::IAddRadialDimension2

IModelDoc2::AddVerticalDimension2 and IModelDoc2::IAddVerticalDimension2

IModelDocExtension::AddDimension

IModelDocExtension::AddPathLengthDim

IModelDocExtension::AddSpecificDimension

IModelDocExtension::AddSymmetricDimension

IModelDocExtension::InsertChainDimensions

ISketchBlockDefinition::GetDisplayDimensions and ISketchBlockDefinition::IGetDisplayDimensions

ISketchManager::AddAlongXDimension, ISketchManager::AddAlongYDimension, and ISketchManager::AddAlongZDimension

ISketchRelation::GetDisplayDimension

IView::GetFirstDisplayDimension5

IView::GetDisplayDimensions and IView::IGetDisplayDimensions

Access Diagram

DisplayDimension