

The following tables list the members exposed by ISketch.

Public Properties

Name	Description
IModelToSketchXform	Obsolete. Superseded by ISketch::ModelToSketchTransform. NOTE: This property is a get-only property. Set is not implemented. Gets the model-to-sketch transform for this sketch.
ModelToSketchTransform	NOTE: This property is a get-only property. Set is not implemented. Obsolete. Superseded by ISketch::ModelToSketchTransform.
ModelToSketchXform	NOTE: This property is a get-only property. Set is not implemented. Gets the sketch relation manager.
RelationManager	NOTE: This property is a get-only property. Set is not implemented.

[Top](#)

Public Methods

Name	Description
AutoDimension	Obsolete. Superseded by ISketch::AutoDimension2.
AutoDimension2	Obsolete. Superseded by ISketchManager::FullyDefineSketch.
CheckFeatureUse	Checks to see if this sketch is valid for use in creating a specified feature.
ConstrainAll	Attempts to solve all of the apparent relations in the sketch and returns the number of constraints that were added to the sketch.
GetArcCount	Gets the number of arcs in the sketch.
GetArcs	Obsolete. Superseded by ISketch::GetArcs2 and ISketch::IGetArcs2.
GetArcs2	Gets all of the arcs in the sketch.
GetAutomaticSolve	Checks whether the computation to solve the sketch geometry of the part as modifications are automatically performed.
GetConstrainedStatus	Gets the current constrained status of the sketch.
GetContourEdgeCount	Gets the number of edges for this sketch contour.
GetContourEdges	Gets the edges for a sketch that has one contour.
GetDetachSegmentOnDrag	Gets the Detach Segment on Drag setting.
GetEllipseCount	Gets the number of ellipses in the sketch.
GetEllipses	Obsolete. Superseded by ISketch::GetEllipses3 and ISketch::IGetEllipses3.
GetEllipses2	Obsolete. Superseded by ISketch::GetEllipses3 and ISketch::IGetEllipses3.
GetEllipses3	Gets all of the ellipses in the sketch.
GetLineCount	Obsolete. Superseded by ISketch::GetLineCount2.
GetLineCount2	Gets the number of lines in the sketch with an option to exclude or include crosshatch lines.
GetLines	Obsolete. Superseded by ISketch::GetLines2 and ISketch::IGetLines2.
GetLines2	Gets all of the lines in the sketch with an option to include or exclude crosshatch lines.

GetParabolaCount	Gets the number of parabolas in the sketch.
GetParabolas	Obsolete. Superseded by ISketch::GetParabolas2 and ISketch::IGetParabolas2.
GetParabolas2	Gets all of the parabolas in the sketch.
GetPolyLineCount	Not implemented.
GetPolylines	Not implemented.
GetReferenceEntity	Gets the entity on which this sketch was created.
GetSketchBlockInstanceCount	Gets the number of block instances in this sketch (i.e., the sketch under which the block instances are displayed in the FeatureManager design tree).
GetSketchBlockInstances	Gets the block instances in this sketch (i.e., the sketch under which the block instances are displayed in the FeatureManager design tree).
GetSketchContourCount	Gets the number of sketch contours in this sketch.
GetSketchContours	Gets the sketch contours in this sketch.
GetSketchHatches	Gets an array of sketch hatches that exist in this sketch.
GetSketchPathCount	Gets the number of sketch paths in this sketch.
GetSketchPaths	Gets the sketch paths in this sketch.
GetSketchPictureCount	Gets the number of pictures on this sketch.
GetSketchPictures	Gets the pictures on this sketch.
GetSketchPoints	Obsolete. Superseded by ISketch::GetSketchPoints2, ISketch::IGetSketchPoints2, and ISketch::IEnumSketchPoints.
GetSketchPoints2	Gets the sketch points in this sketch.
GetSketchPointsCount	Obsolete. Superseded by ISketch::GetSketchPointsCount2.
GetSketchPointsCount2	Gets the number of sketch points in this sketch.
GetSketchRegionCount	Gets the number of sketch regions in this sketch.
GetSketchRegions	Gets the sketch regions in this sketch.
GetSketchSegments	Gets the sketch segments in this sketch, which include line, arc, spline, parabola, and ellipse entities.
GetSketchSlotCount	Gets the number of sketch slots in this sketch.
GetSketchSlots	Gets the sketch slots in this sketch.
GetSketchTextSegments	Gets the sketch segments that represent the selected text in the sketch.
GetSplineCount	Gets the number of splines in this sketch.
GetSplineInterpolateCount	Gets the number of points in the spline and number of splines in the sketch.
GetSplineParams	Obsolete. Superseded by ISketch::GetSplineParams2 and ISketch::IGetSplineParams2.
GetSplineParams2	Obsolete. Superseded by ISketch::GetSplineParams3.
GetSplineParams3	Obsolete. Superseded by ISketch::GetSplineParams4.
GetSplineParams4	Obsolete. Superseded by ISketch::GetSplineParams5.
GetSplineParams5	Gets the parameterization data of the specified spline in this sketch.
GetSplineParamsCount	Obsolete. Superseded by ISketch::GetSplineParamsCount2.
GetSplineParamsCount2	Obsolete. Superseded by ISketch::GetSplineParamsCount3.
GetSplineParamsCount3	Gets the number of splines in the sketch and the size of array required to hold the data for them.
GetSplines	Gets information for each spline by tessellation instead of by interpolation as is done by ISketch::GetSplinesInterpolate and ISketch::IGetSplinesInterpolate .
GetSplinesInterpolate	Gets the spline points by interpolation instead of by tessellation as is done by ISketch::GetSplines and ISketch::IGetSplines .
GetUserPoints	Obsolete. Superseded by ISketch::GetUserPoints2 and ISketch::IGetUserPoints2.
GetUserPoints2	Gets all of the user points in this sketch.
GetUserPointsCount	Gets the number of user points in the sketch.
IEnumSketchHatches	Gets the sketch hatches enumeration in this sketch.
IEnumSketchPoints	Gets the sketch points enumeration in this sketch.
IEnumSketchSegments	Gets the sketch segments enumeration in this sketch.
IEnumSketchTextSegments	Gets the sketch segments enumeration for the selected text in this sketch.

IGetArcs	Obsolete. Superseded by ISketch::GetArcs2 and ISketch::IGetArcs2 .
IGetArcs2	Gets all of the arcs in the sketch.
IGetContourEdges	Gets the edges for a sketch that has one contour.
IGetEllipses	Obsolete. Superseded by ISketch::GetEllipses3 and ISketch::IGetEllipses3 .
IGetEllipses2	Obsolete. Superseded by ISketch::GetEllipses3 and ISketch::IGetEllipses3 .
IGetEllipses3	Gets all of the ellipses in the sketch.
IGetLines	Obsolete. Superseded by ISketch::GetLines2 and ISketch::IGetLines2 .
IGetLines2	Gets all of the lines in the sketch with an option to include or exclude crosshatch lines.
IGetParabolas	Obsolete. Superseded by ISketch::GetParabolas2 and ISketch::IGetParabolas2 .
IGetParabolas2	Gets all of the parabolas in the sketch.
IGetPolylines	Not implemented.
IGetSketchBlockInstances	Gets the block instances in this sketch (i.e., the sketch under which the block instances are displayed in the FeatureManager design tree).
IGetSketchContours	Gets the sketch contours in this sketch.
IGetSketchPaths	Gets the sketch paths in this sketch.
IGetSketchPictures	Gets the pictures on this sketch.
IGetSketchPoints2	Gets the sketch points in this sketch.
IGetSketchRegions	Gets the sketch regions in this sketch.
IGetSketchSlots	Gets the sketch slots in this sketch.
IGetSplineParams	Obsolete. Superseded by ISketch::GetSplineParams2 and ISketch::IGetSplineParams2 .
IGetSplineParams2	Obsolete. Superseded by ISketch::IGetSplineParameters3.
IGetSplineParams3	Obsolete. Superseded by ISketch::GetSplineParams4.
IGetSplines	Gets information for each spline by tessellation instead of by interpolation as is done by ISketch::GetSplinesInterpolate and ISketch::IGetSplinesInterpolate .
IGetSplinesInterpolate	Gets the spline points by interpolation instead of by tessellation as is done by ISketch::GetSplines and ISketch::IGetSplines .
IGetUserPoints	Obsolete. Superseded by ISketch::GetUserPoints2 and ISketch::IGetUserPoints2 .
IGetUserPoints2	Gets all of the user points in this sketch.
InsertRouteLine	Inserts a route line in an explode line sketch or a 3D sketch to indicate component relationships.
Is3D	Gets whether this sketch is 2D or 3D.
IsBoundaryBoxSketch	Determines whether the sketch is a boundary box.
IsDerived	Gets whether a sketch is derived.
IsShared	Gets whether this sketch is used by more than one feature.
IsSketchEditable	Gets whether this sketch is editable.
MergePoints	Merges sketch points within a specified distance.
SetAutomaticSolve	Controls whether the computation to solve the sketch geometry of the part as modifications are automatically performed.
SetDetachSegmentOnDrag	Sets the Detach Segment on Drag setting.
SetSketchEditable	Sets whether this sketch is editable.
SetWorkingPlaneOrientation	Sets the orientation for sketching geometry in a 3D sketch. It sets the planar location for new 2D and 3D geometry in a 3D sketch.