

Public Properties

	Name	Description
	Angle	Gets or sets the rotation angle of the view.
	Bodies	Gets or sets the bodies of a multibody part to show in the drawing view.
	BreakLineGap	Gets or sets the width of the gap for a break line.
	CropViewJaggedOutline	Gets or sets whether to use a jagged outline in this cropped drawing view.
	CropViewJaggedShapeIntensity	Gets or sets the shape intensity of the jagged outline in this cropped drawing view.
	CropViewNoOutline	Gets or sets whether to show an outline in this cropped drawing view.
	DisableAutoUpdate	Gets or sets whether to disable the automatic update of this view.
	DisplayState	Gets or sets the name of the display state for this drawing view.
	EmphasizeOutline	Gets or sets whether the outlines of section views are emphasized in this drawing view.
	FlipView	Gets or sets whether to flip a flat-pattern view of a sheet metal part.
	FocusLocked	Gets or sets whether or not focus is locked on this view.
	HiddenEdges	Gets the hidden edges in the drawing view or sets the hidden edges in the drawing view to be visible.
	IPosition	Gets or sets the X and Y location of the model view's geometric center, relative to the drawing sheet origin.
	IScaleRatio	Gets or sets the scale of the drawing view, returning the results in ratio format (n:n).
	LinkParentConfiguration	Gets or sets whether to link a projected or auxiliary view with the parent configuration.
	ModelToViewTransform	Gets the math transform to go from model to drawing view space.
	NOTE: This property is a get-only property. Set is not implemented.	
	Name	Obsolete. Superseded by <code>::GetName2</code> and <code>::SetName2</code>.
	Position	Gets or sets the X and Y location of the model view's geometric center, relative to the drawing sheet origin.
	PositionLocked	Gets or sets whether this drawing view's position is locked.
	ProjectedDimensions	Gets or sets whether dimensions in this view are true or projected.
	ReferencedConfiguration	Gets or sets the configuration referenced by this drawing view.
	ReferencedConfigurationID	Gets the persistent reference ID of the configuration referenced in this drawing view.
	ReferencedDocument	Gets the document referenced by this drawing view.
	RootDrawingComponent	Obsolete. Superseded by <code>IView::RootDrawingComponent2</code>.
	RootDrawingComponent2	Gets the root component of this drawing view.
	ScaleDecimal	Gets or sets the scale of the drawing view, returning the results in decimal format.
	ScaleHatchPattern	Gets or sets whether to scale the hatch pattern to the drawing view.
	ScaleRatio	Gets or sets the scale of the drawing view, returning the results in ratio format (n:n).
	Sheet	Gets the sheet on which this drawing view exists.
	ShowSheetMetalBendNotes	Gets or sets whether to show sheet metal bend notes.
	SuppressState	Gets or sets the view suppress state.
	Type	Gets the drawing view type.
	UseParentScale	Gets or sets the drawing view's scale to match the parent drawing view's scale.
	UseSheetScale	Gets or sets whether the scale of the drawing view is the same as the scale of the drawing sheet on which this view is located.
Top		

Public Methods

	Name	Description
	AlignDrawingView	Specifies the alignment of this auxiliary drawing view.
	AlignWithView	Sets view alignment.
	AutoInsertCenterMarks	Obsolete. Superseded by <code>IView::AutoInsertCenterMarks2</code>.
	AutoInsertCenterMarks2	Automatically inserts the specified center marks in this view.
	Crop	Obsolete. Superseded by <code>IView::Crop2</code>.
	Crop2	Crops this view using the selected closed sketch profile.
	EnumHiddenComponents	Obsolete. Superseded by <code>IView::EnumHiddenComponents2</code>.
	EnumHiddenComponents2	Gets the hidden components enumeration in this drawing view.
	EnumSectionLines	Obsolete. Superseded by <code>IView::EnumSectionLines2</code>.
	EnumSectionLines2	Gets the section lines enumeration in the view.
	GetAlignment	Gets the alignment information of this view.
	GetAnnotationCount	Gets the number of annotations in this view.
	GetAnnotations	Gets the annotations in this view.
	GetAnnotationsByType	Gets the annotations of the specified type in this view.
	GetArcCount	Gets the number of arcs in this view.
	GetArcs	Obsolete. Superseded by <code>::GetArcs4</code> and <code>::IGetArcs4</code>.
	GetArcs2	Obsolete. Superseded by <code>::GetArcs4</code> and <code>::IGetArcs4</code>.
	GetArcs3	Obsolete. Superseded by <code>::GetArcs4</code> and <code>::IGetArcs4</code>.
	GetArcs4	Gets all of the information for all of the arcs added by a user in this drawing view.
	GetBaseView	Gets the base (parent) view used to create this view.
	GetBendLineCount	Gets the number of bendlines in a flat-pattern drawing view.
	GetBendLines	Gets the bendlines in a flat-pattern drawing view.
	GetBendNoteAttributeString	Gets the internal string that is used to format the text of the specified bend note attribute in this drawing view of a sheet metal part.
	GetBendNoteTextFormat	Gets the text format of all bend notes in this drawing view of a sheet metal part.
	GetBodiesCount	Gets the number of bodies of a multibody part in the drawing view.
	GetBomTable	Gets the BOM table found in this drawing view.
	GetBreakLineCount	Obsolete. Superseded by <code>IView::GetBreakLineCount2</code>.
	GetBreakLineCount2	Gets the number of breaks lines and breaks in this view.
	GetBreakLineInfo	Obsolete. Superseded by <code>IView::GetBreakLineInfo2</code>.
	GetBreakLineInfo2	Gets information for all of the break lines in this view.
	GetBreakLines	Gets the all of the breaks in this view.
	GetBreakOutSectionCount	Gets the number of broken-out sections in this view.
	GetBreakOutSections	Gets all of the broken-out sections in this view.
	GetCenterLineCount	Gets the number of centerlines on this drawing view.
	GetCenterLines	Gets all of the centerline annotations on this drawing view.

[GetCenterLineSketch](#)
[GetCenterMarkCount](#)
[GetCenterMarkCount2](#)
[GetCenterMarkInfo](#)
[GetCenterMarks](#)
[GetCorresponding](#)
[GetCorrespondingEntity](#)
[GetCThreadCount](#)
[GetCThreadQuality](#)
[GetCThreads](#)
[GetDatumOriginCount](#)
[GetDatumOrigins](#)
[GetDatumPoints](#)
[GetDatumPoints2](#)
[GetDatumPointsCount](#)
[GetDatumTagCount](#)
[GetDatumTags](#)
[GetDatumTargetSymCount](#)
[GetDatumTargetSyms](#)

[GetDependentViewCount](#)

[GetDependentViews](#)
[GetDesignTableExtent](#)
[GetDetail](#)
[GetDetailCircleCount](#)
[GetDetailCircleCount2](#)
[GetDetailCircleInfo](#)
[GetDetailCircleInfo2](#)
[GetDetailCircles](#)
[GetDetailCircleStrings](#)
[GetDimensionCount](#)
[GetDimensionCount2](#)
[GetDimensionCount3](#)
[GetDimensionCount4](#)
[GetDimensionDisplayInfo](#)
[GetDimensionDisplayInfo2](#)
[GetDimensionDisplayInfo3](#)
[GetDimensionDisplayInfo4](#)
[GetDimensionDisplayInfo5](#)
[GetDimensionDisplayInfoSize](#)
[GetDimensionDisplayInfoSize2](#)

[GetDimensionDisplayString](#)

[GetDimensionDisplayString2](#)

[GetDimensionDisplayString3](#)

[GetDimensionDisplayString4](#)
[GetDimensionDisplayString5](#)
[GetDimensionIds](#)
[GetDimensionIds2](#)
[GetDimensionIds3](#)
[GetDimensionIds4](#)
[GetDimensionInfo](#)
[GetDimensionInfo2](#)
[GetDimensionInfo3](#)
[GetDimensionInfo4](#)
[GetDimensionInfo5](#)
[GetDimensionInfo6](#)
[GetDimensionInfo7](#)
[GetDimensionString](#)
[GetDimensionString2](#)
[GetDimensionString3](#)

[GetDimensionString4](#)

[GetDisplayData](#)
[GetDisplayData2](#)
[GetDisplayData3](#)

[GetDisplayData4](#)

[GetDisplayDimensionCount](#)
[GetDisplayDimensions](#)
[GetDisplayEdgesInShadedMode](#)
[GetDisplayMode](#)
[GetDisplayMode2](#)
[GetDisplayTangentEdges](#)
[GetDisplayTangentEdges2](#)
[GetDowelSymbolCount](#)
[GetDowelSymbols](#)
[GetEllipseCount](#)
[GetEllipses](#)
[GetEllipses2](#)
[GetEllipses3](#)
[GetEllipses4](#)
[GetEllipses5](#)
[GetFaceHatchCount](#)
[GetFaceHatches](#)

Gets the sketch that contains all of the centerline information for this view.

[Obsolete. Superseded by IView::GetCenterMarkCount2.](#)

Gets the number of center marks that are features in the view.

Gets information about each center mark that is a feature in the view.

Gets all of the center marks that are features in the view.

Gets the object in this drawing view that corresponds to the specified part or assembly object.

Gets the entity in this drawing view that corresponds to the specified part or assembly entity.

Gets the number of cosmetic threads in this drawing view.

Gets the cosmetic thread display quality in this view.

Gets all of the cosmetic threads on this drawing view.

Gets the number of datum origins on this drawing view.

Gets all of the datum origins on this drawing view.

Obsolete. Superseded by `IView::GetDatumPoints2` and `IView::IGetDatumPoints2`.

Gets all of the information about all the datum points in this view.

Gets the number of datum points in this view.

Gets the number of datum tags on this drawing view.

Gets all of the datum tags on this drawing view.

Gets the number of datum target symbols on this drawing view.

Gets all of the datum target symbols on this drawing view.

Gets the number of all, or only the specified, dependent views (i.e., alternate position, detail, section, etc.) in this view.

Gets either all, or only the specified, dependent views in this view.

Gets the size and location of the design table associated with this drawing view.

Gets the detail circle for this detail view.

[Obsolete. Superseded by IView::GetDetailCircleCount2.](#)

Gets the number of detail circles in the drawing view.

Obsolete. Superseded by `IView::GetDetailCircleInfo2` and `IView::IGetDetailCircleInfo2`.

Gets all of the information about each detail circle in the view.

Gets the detail circles in this view.

Gets an array of strings; each string represents the text label for a detail circle in this view.

[Obsolete. Superseded by IView::GetDimensionCount4.](#)

[Obsolete. Superseded by IView::GetDimensionCount4.](#)

[Obsolete. Superseded by IView::GetDimensionCount4.](#)

Gets the number of display dimensions in the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDimensionDisplayInfo5` and `IView::IGetDimensionDisplayInfo5`.

Obsolete. Superseded by `IView::GetDimensionDisplayInfo5` and `IView::IGetDimensionDisplayInfo5`.

Obsolete. Superseded by `IView::GetDimensionDisplayInfo5` and `IView::IGetDimensionDisplayInfo5`.

Obsolete. Superseded by `IView::GetDimensionDisplayInfo5` and `IView::IGetDimensionDisplayInfo5`.

Gets the display dimension information for the current drawing sheet or the current drawing view.

[Obsolete. Superseded by IView::GetDimensionDisplayInfoSize2.](#)

Gets the number of the dimension lines in the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDimensionDisplayString4` and `IView::IGetDimensionDisplayString4`.

Obsolete. Superseded by `IView::GetDimensionDisplayString4` and `IView::IGetDimensionDisplayString4`.

Obsolete. Superseded by `IView::GetDimensionDisplayString4` and `IView::IGetDimensionDisplayString4`.

[Obsolete. Superseded by IView::GetDimensionDisplayString5.](#)

Gets all of the dimension text in the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDimensionIds4` and `IView::IGetDimensionIds4`.

Obsolete. Superseded by `IView::GetDimensionIds4` and `IView::IGetDimensionIds4`.

Obsolete. Superseded by `IView::GetDimensionIds4` and `IView::IGetDimensionIds4`.

Gets the dimension names from the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDimensionInfo6` and `IView::IGetDimensionInfo6`.

Obsolete. Superseded by `IView::GetDimensionInfo6` and `IView::IGetDimensionInfo6`.

Obsolete. Superseded by `IView::GetDimensionInfo6` and `IView::IGetDimensionInfo6`.

Obsolete. Superseded by `IView::GetDimensionInfo6` and `IView::IGetDimensionInfo6`.

Obsolete. Superseded by `IView::GetDimensionInfo6` and `IView::IGetDimensionInfo6`.

[Obsolete. Superseded by IView::GetDimensionInfo7.](#)

Gets all of the dimension information in the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDimensionString4` and `IView::IGetDimensionString4`.

Obsolete. Superseded by `IView::GetDimensionString4` and `IView::IGetDimensionString4`.

Obsolete. Superseded by `IView::GetDimensionString4` and `IView::IGetDimensionString4`.

Gets the strings containing the text associated with each dimension in the current drawing sheet or the current drawing view.

Obsolete. Superseded by `IView::GetDisplayData3` and `IView::IGetDisplayData3`.

Obsolete. Superseded by `IView::GetDisplayData3` and `IView::IGetDisplayData3`.

[Obsolete. Superseded by IView::GetDisplayData4.](#)

[Gets the the IDisplayData object for this drawing view containing only those model items that are visible in the view.](#)

Gets the number of display dimensions in this drawing view.

Gets all of the display dimension on this drawing view.

Gets whether to display the edges in this when the drawing view is in shaded mode.

[Obsolete. Superseded by IView::GetDisplayMode2.](#)

Gets the current display mode of the view.

[Obsolete. Superseded by IView::GetDisplayTangentEdges2.](#)

Gets the current tangent edge display mode of the drawing view.

Gets the number of dowel symbols in this drawing view.

Gets all of the dowel symbols on this drawing view.

Gets the number of ellipses in the view.

Obsolete. Superseded by `IView::GetEllipses5` and `IView::IGetEllipses5`.

Obsolete. Superseded by `IView::GetEllipses5` and `IView::IGetEllipses5`.

Obsolete. Superseded by `IView::GetEllipses5` and `IView::IGetEllipses5`.

Obsolete. Superseded by `IView::GetEllipses5` and `IView::IGetEllipses5`.

Gets all of the ellipses added by a user in this drawing view.

Gets the number of face hatches in the view.

Gets the face hatches in the view.

[GetFacettedHlrDisplay](#)

[GetFirstAnnotation](#)

[GetFirstAnnotation2](#)

[GetFirstAnnotation3](#)

[GetFirstBlockInstance](#)

[GetFirstCenterLine](#)

[GetFirstCenterMark](#)

[GetFirstCenterMark2](#)

[GetFirstCenterOfMass](#)

[GetFirstCThread](#)

[GetFirstCustomSymbol](#)

[GetFirstDatumOrigin](#)

[GetFirstDatumTag](#)

[GetFirstDatumTargetSym](#)

[GetFirstDisplayDimension](#)

[GetFirstDisplayDimension2](#)

[GetFirstDisplayDimension3](#)

[GetFirstDisplayDimension4](#)

[GetFirstDisplayDimension5](#)

[GetFirstDisplayDimension6](#)

[GetFirstDowelSymbol](#)

[GetFirstGTOL](#)

[GetFirstMultiJogLeader](#)

[GetFirstMultiJogLeader2](#)

[GetFirstNote](#)

[GetFirstNote2](#)

[GetFirstRevisionCloud](#)

[GetFirstRevisionCloud2](#)

[GetFirstSFSymbol](#)

[GetFirstTableAnnotation](#)

[GetFirstTableAnnotation2](#)

[GetFirstWeldBead](#)

[GetFirstWeldSymbol](#)

[GetGTolCount](#)

[GetGTols](#)

[GetHiddenComponents](#)

[GetKeepLinkedToBOM](#)

[GetKeepLinkedToBOMName](#)

[GetLineCount](#)

[GetLineCount2](#)

[GetLines](#)

[GetLines2](#)

[GetLines3](#)

[GetLines4](#)

[GetMirrorViewOrientation](#)

[GetMultiJogLeaderCount](#)

[GetMultiJogLeaders](#)

[GetName2](#)

[GetNextView](#)

[GetNoteCount](#)

[GetNotes](#)

[GetOrientationName](#)

[GetOutline](#)

[GetParabolaCount](#)

[GetParabolas](#)

[GetParabolas2](#)

[GetPolyLineCount](#)

[GetPolyLineCount2](#)

[GetPolyLineCount3](#)

[GetPolyLineCount4](#)

[GetPolyLineCount5](#)

[GetPolylines](#)

[GetPolylines2](#)

[GetPolylines3](#)

[GetPolylines4](#)

[GetPolylines5](#)

[GetPolylines6](#)

[GetPolylines7](#)

[GetPolyLinesAndCurves](#)

[GetPolyLinesAndCurvesCount](#)

[GetProjectionArrow](#)

[GetProjectionLineCount](#)

[GetProjectionLines](#)

[GetReferencedModelName](#)

[GetRelatedTangentEdgeCount](#)

[GetRelatedTangentEdges](#)

[GetRevisionCloudCount](#)

[GetRevisionClouds](#)

[GetSection](#)

[GetSectionLineCount](#)

[GetSectionLineCount2](#)

[GetSectionLineInfo](#)

[GetSectionLineInfo2](#)

[GetSectionLines](#)

Gets whether HLR/HLV (Hidden Lines Removed/Hidden Lines Visible) edges should be displayed faceted in the view.

[Obsolete. Superseded by IView::GetFirstAnnotation3.](#)

[Obsolete. Superseded by IView::GetFirstAnnotation3.](#)

Gets the first annotation in this drawing view.

Obsolete. Not superseded.

Gets the first centerline in this view.

[Obsolete. Superseded by IView::GetFirstCenterMark2.](#)

Gets the first center mark in the view.

Gets the first center of mass in this view.

Gets the first cosmetic thread in the view.

Obsolete. Not superseded.

Gets the first datum origin in this drawing view.

Gets the first datum tag in the view.

Gets the first datum target symbol in the view.

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension6.](#)

Gets the first display dimension in this drawing view.

Gets the first dowel symbol in the view.

Gets the first geometric tolerance in this view.

[Obsolete. Superseded by IView::GetFirstMultiJogLeader2.](#)

Gets the first multi-jog leader in the view.

[Obsolete. Superseded by IView::GetFirstNote2.](#)

Gets the first note in the view.

[Obsolete. Superseded by IView::GetFirstRevisionCloud2.](#)

Gets the first revision cloud annotation in this view.

Gets the first surface-finish symbols in the view.

[Obsolete. Superseded by IView::GetFirstTableAnnotation2.](#)

Gets the first table annotation in this view.

Gets the first weld bead annotation in this view.

Gets the first weld symbol in the view.

Gets the number of geometric tolerances in this drawing view.

Gets all of the geometric tolerances on this drawing view.

Gets the hidden components in this drawing view.

Gets whether this drawing view is linked to a BOM or weldment cut-list table.

Gets the name of the BOM or weldment cut-list table feature to which this drawing view is linked.

[Obsolete. Superseded by IView::GetLineCount2.](#)

Gets the number of lines in this view with an option to include or exclude crosshatch lines.

Obsolete. Superseded by **::GetLines4** **and** **::IGetLines4.**

Obsolete. Superseded by **::GetLines4** **and** **::IGetLines4.**

Obsolete. Superseded by **::GetLines4** **and** **::IGetLines4.**

Gets all of the lines in the view with an option to include or exclude crosshatch lines.

Gets whether this view is mirrored.

Gets the number of multi-jog leaders on this drawing view.

Gets all of the multi-jog leaders in this drawing view.

Gets the name of this drawing view displayed in the FeatureManager design tree.

Gets the next drawing view in the drawing.

Gets the number notes in this drawing view.

Gets the notes in this drawing view.

Gets the predefined name of this view.

Gets the bounding box for a view (sheet or drawing) in meters on the drawing page.

Gets the number of parabolas in the view.

Obsolete. Superseded by **::GetParabolas2** **and** **::IGetParabolas2.**

Gets all of the information about all of the parabolas in this view.

[Obsolete. Superseded by IView::GetPolyLineCount5.](#)

[Obsolete. Superseded by IView::GetPolyLineCount5.](#)

[Obsolete. Superseded by IView::GetPolyLineCount5.](#)

[Obsolete. Superseded by IView::GetPolyLineCount5.](#)

Gets the number of polylines in this view with an option to include or exclude crosshatch lines.

Obsolete. Superseded by **::GetPolyLines6** **and** **::IGetPolyLines6.**

Obsolete. Superseded by **::GetPolyLines6** **and** **::IGetPolyLines6.**

Obsolete. Superseded by **::GetPolyLines6** **and** **::IGetPolyLines6.**

Obsolete. Superseded by **::GetPolyLines6** **and** **::IGetPolyLines6.**

Obsolete. Superseded by **::GetPolyLines6** **and** **::IGetPolyLines6.**

[Obsolete. Superseded by IView::GetPolyLines7.](#)

Gets all of the polylines in the view with an option to include or exclude crosshatch lines.

Gets the arcs, ellipses, splines, and polylines in the view with an option to include or exclude crosshatch lines.

Gets the number of lines, including arcs, ellipses, splines, and polylines, in the view with the option to include or exclude cross hatch lines.

Gets the projection arrow for this projected view.

Gets the number of projection lines (arrows) in this drawing view.

Gets the projection lines (arrows) in this drawing view.

Gets the name of the model that is referenced in the drawing view.

[Gets the number of visible tangent edges for the specified bendline in a flat-pattern drawing view.](#)

[Gets the visible tangent edges for the specified bendline in a flat-pattern drawing view.](#)

Gets the number of revision cloud annotations in this view.

Gets all of the revision cloud annotations in this view.

Gets the section for this section view.

[Obsolete. Superseded by IView::GetSectionLineCount2.](#)

Gets the number of section lines in the view.

Obsolete. Superseded by **::GetSectionLineInfo2** **and** **::GetSectionLineInfo2.**

Gets all of the information about the section lines in the view.

Gets the section lines in the view.

[GetSectionLineStrings](#)
[GetSFSymbolCount](#)
[GetSFSymbols](#)
[GetSketch](#)
[GetSketchPictureCount](#)
[GetSketchPictures](#)
[GetSMBoundingBoxDisplayData](#)
[GetSMBoundingBoxDisplayData2](#)

[GetSolidHatchCount](#)

[GetSolidHatchInfo](#)
[GetSplineCount](#)
[GetSplines](#)
[GetSplines2](#)
[GetSplines3](#)
[GetTableAnnotationCount](#)
[GetTableAnnotations](#)
[GetTemporaryAxes](#)
[GetTemporaryAxesCount](#)
[GetUniqueName](#)
[GetUseParentDisplayMode](#)
[GetUserPoints](#)
[GetUserPoints2](#)
[GetUserPointsCount](#)
[GetViewXform](#)
[GetVisible](#)
[GetVisibleComponentCount](#)
[GetVisibleComponents](#)
[GetVisibleDrawingComponents](#)
[GetVisibleEntities](#)
[GetVisibleEntities2](#)
[GetVisibleEntityCount](#)

[GetVisibleEntityCount2](#)

[GetWeldBeadCount](#)
[GetWeldBeads](#)
[GetWeldSymbolCount](#)
[GetWeldSymbols](#)
[GetWitnessEntitiesCount](#)
[GetWitnessGeomInfo](#)
[GetXform](#)
[HasDesignTable](#)
[IGetAnnotations](#)
[IGetArcs](#)
[IGetArcs2](#)
[IGetArcs3](#)
[IGetArcs4](#)
[IGetBaseView](#)
[IGetBendLines](#)
[IGetBodies](#)
[IGetBomTable](#)
[IGetBreakLineInfo](#)
[IGetBreakLineInfo2](#)
[IGetBreakLines](#)
[IGetBreakOutSections](#)
[IGetCenterLines](#)
[IGetCenterMarkInfo](#)
[IGetCenterMarks](#)
[IGetCThreads](#)
[IGetDatumOrigins](#)
[IGetDatumPoints](#)
[IGetDatumPoints2](#)
[IGetDatumTags](#)
[IGetDatumTargetSyms](#)
[IGetDependentViews](#)
[IGetDesignTableExtent](#)
[IGetDetail](#)
[IGetDetailCircleInfo](#)
[IGetDetailCircleInfo2](#)
[IGetDetailCircles](#)
[IGetDetailCircleStrings](#)
[IGetDimensionDisplayInfo](#)
[IGetDimensionDisplayInfo2](#)
[IGetDimensionDisplayInfo3](#)
[IGetDimensionDisplayInfo4](#)
[IGetDimensionDisplayInfo5](#)

[IGetDimensionDisplayString](#)

[IGetDimensionDisplayString2](#)

[IGetDimensionDisplayString3](#)

[IGetDimensionDisplayString4](#)
[IGetDimensionIds](#)
[IGetDimensionIds2](#)
[IGetDimensionIds3](#)
[IGetDimensionIds4](#)

Gets an array of strings; each string represents the text label for a section line in this view.
Gets the number of surface finish symbols on this drawing view.
Gets all of the surface finish symbols in this drawing view.
Gets the sketch used by this view.
Gets the number of sketch pictures imported to this view when a drawing is created from a part.
Gets all of the sketch pictures imported to this view when a drawing is created from a part.
[Obsolete. Superseded by IView::GetSMBoundingBoxDisplayData2.](#)
Gets the boundary-box sketch display data of a flat-pattern drawing view.
Gets the number of visible solid-fill hatches in a detail, break, or crop view and the size of the array for their boundary data.
Gets the boundary data for all visible solid-fill hatches in a detail, break, or crop view.
Gets the number of splines in the view.
Obsolete. Superseded by [::GetSplines3](#) **and** [::IGetSplines3](#).
Obsolete. Superseded by [::GetSplines3](#) **and** [::IGetSplines3](#).
Gets all of the splines added by a user in the drawing view.
Gets the number of table annotations in this drawing view.
Gets all of the table annotations on this drawing view.
Gets the information of the temporary axes displayed in this view.
Gets the number of temporary axes in this view.
Gets the unique name of this section view.
Gets whether the view is using its parent settings or if it is using its own local settings.
Obsolete. Superseded by [::GetUserPoints2](#) **and** [::IGetUserPoints2](#).
Gets all of the information about all of the user points in this view.
Gets the number of user points in the view.
Gets the transform from model space origin to drawing space origin.
Gets the visibility of this drawing view.
Gets the number of visible components in this drawing view.
Gets the visible components in this drawing view.
Gets all of the unobscured drawing components in this drawing view of an assembly drawing.
[Obsolete. Superseded by IView::GetVisibleEntities2.](#)
Gets the visible entities of the specified type for the specified component in this drawing view.
[Obsolete. Superseded by IView::GetVisibleEntityCount2.](#)

Gets the number of visible entities of the specified type for the specified component in this drawing view.

Gets the number of weld beads on this drawing view.
Gets all of the weld beads on this drawing view.
Gets the number of weld symbols on this drawing view.
Gets all of the weld symbols on this drawing view.
Gets the number of virtual sharp witness lines in this drawing view.
Gets the geometry data for all of the virtual sharp witness lines in this drawing view.
Gets the matrix used for displaying this drawing view.
Gets whether this drawing view has a design table associated with it.
Gets the annotations in this view.
Obsolete. Superseded by [::GetArcs4](#) **and** [::IGetArcs4](#).
Obsolete. Superseded by [::GetArcs4](#) **and** [::IGetArcs4](#).
Obsolete. Superseded by [::GetArcs4](#) **and** [::IGetArcs4](#).
Gets all of the information for all of the arcs added by a user in this drawing view.
Gets the base (parent) view used to create this view.
[Gets the bendlines in a flat-pattern drawing view.](#)
Gets the bodies of a multibody part in the drawing view.
Gets the BOM table found in this drawing view.
[Obsolete. Superseded by IView::IGetBreakLineInfo2.](#)
Gets information for all of the break lines in this view.
Gets the all of the breaks in this view.
Gets all of the broken-out sections in this view.
Gets all of the centerlines on this drawing view.
Gets information about each center mark that is a feature in the view.
Gets all of the center marks that are features in the view.
Gets all of the cosmetic threads on this drawing view.
Gets all of the datum origins on this drawing view.
Obsolete. Superseded by [::GetDatumPoints2](#) **and** [::IGetDatumPoints2](#).
Gets all of the information about all the datum points in this view.
Gets all the datum tags on this drawing view.
Gets all of the datum target symbols on this drawing view.
Gets either all, or only the specified, dependent views in this view.
Gets the size and location of the design table associated with this drawing view.
Gets the detail circle for this detail view.
Obsolete. Superseded by [::GetDetailCircleInfo2](#) **and** [::IGetDetailCircleInfo2](#).
Gets all of the information about each detail circle in the view.
Gets the detail circles in this view.
Gets an array of strings; each string represents the text label for a detail circle in this view.
Obsolete. Superseded by [::GetDimensionDisplayInfo5](#) **and** [::IGetDimensionDisplayInfo5](#).
Obsolete. Superseded by [::GetDimensionDisplayInfo5](#) **and** [::IGetDimensionDisplayInfo5](#).
Obsolete. Superseded by [::GetDimensionDisplayInfo5](#) **and** [::IGetDimensionDisplayInfo5](#).
Obsolete. Superseded by [::GetDimensionDisplayInfo5](#) **and** [::IGetDimensionDisplayInfo5](#).
Gets the display dimension information for the current drawing sheet or the current drawing view.

Obsolete. Superseded by [::GetDimensionDisplayString4](#) **and** [::IGetDimensionDisplayString4](#).

Obsolete. Superseded by [::GetDimensionDisplayString4](#) **and** [::IGetDimensionDisplayString4](#).

Obsolete. Superseded by [::GetDimensionDisplayString4](#) **and** [::IGetDimensionDisplayString4](#).

Gets all of the dimension text in the current drawing sheet or the current drawing view.
Obsolete. Superseded by [::GetDimensionIds4](#) **and** [::IGetDimensionIds4](#).
Obsolete. Superseded by [::GetDimensionIds4](#) **and** [::IGetDimensionIds4](#).
Obsolete. Superseded by [::GetDimensionIds4](#) **and** [::IGetDimensionIds4](#).
Gets the dimension names from the current drawing sheet or the current drawing view.

[IGetDimensionInfo](#)
[IGetDimensionInfo2](#)
[IGetDimensionInfo3](#)
[IGetDimensionInfo4](#)
[IGetDimensionInfo5](#)
[IGetDimensionInfo6](#)
[IGetDimensionString](#)
[IGetDimensionString2](#)
[IGetDimensionString3](#)

[IGetDimensionString4](#)

[IGetDisplayData](#)
[IGetDisplayData2](#)

[IGetDisplayData3](#)

[IGetDisplayDimensions](#)
[IGetDowelSymbols](#)
[IGetEllipses](#)
[IGetEllipses2](#)
[IGetEllipses3](#)
[IGetEllipses4](#)
[IGetEllipses5](#)
[IGetFaceHatches](#)
[IGetFirstAnnotation](#)
[IGetFirstAnnotation2](#)
[IGetFirstCenterOfMass](#)
[IGetFirstCThread](#)
[IGetFirstCustomSymbol](#)
[IGetFirstDatumTag](#)
[IGetFirstDatumTargetSym](#)
[IGetFirstDisplayDimension](#)
[IGetFirstDisplayDimension2](#)
[IGetFirstDisplayDimension3](#)
[IGetFirstDowelSymbol](#)
[IGetFirstGTOL](#)
[IGetFirstMultiJogLeader](#)
[IGetFirstNote](#)
[IGetFirstRevisionCloud](#)
[IGetFirstSFSymbol](#)
[IGetFirstWeldSymbol](#)
[IGetGTols](#)
[IGetLines](#)
[IGetLines2](#)
[IGetLines3](#)
[IGetLines4](#)
[IGetMultiJogLeaders](#)
[IGetNextView](#)
[IGetNotes](#)
[IGetOutline](#)
[IGetParabolas](#)
[IGetParabolas2](#)
[IGetPolyLines](#)
[IGetPolyLines2](#)
[IGetPolyLines3](#)
[IGetPolyLines4](#)
[IGetPolyLines5](#)
[IGetPolyLines6](#)
[IGetPolyLines7](#)

[IGetPolyLinesAndCurves](#)

[IGetProjectionArrow](#)
[IGetProjectionLines](#)
[IGetRelatedTangentEdges](#)
[IGetRevisionClouds](#)
[IGetSection](#)
[IGetSectionLineInfo](#)
[IGetSectionLineInfo2](#)
[IGetSectionLines](#)
[IGetSectionLineStrings](#)
[IGetSFSymbols](#)
[IGetSketch](#)
[IGetSketchPictures](#)
[IGetSMBoundingBoxDisplayData](#)
[IGetSolidHatchInfo](#)
[IGetSplines](#)
[IGetSplines2](#)
[IGetSplines3](#)
[IGetTableAnnotations](#)
[IGetTemporaryAxes](#)
[IGetUserPoints](#)
[IGetUserPoints2](#)
[IGetViewXform](#)
[IGetVisibleComponents](#)
[IGetVisibleEntities](#)
[IGetVisibleEntities2](#)
[IGetWeldBeads](#)
[IGetWeldSymbols](#)

Obsolete. Superseded by [::GetDimensionInfo6](#) **and** [::IGetDimensionInfo6](#).
Obsolete. Superseded by [::GetDimensionInfo6](#) **and** [::IGetDimensionInfo6](#).
Obsolete. Superseded by [::GetDimensionInfo6](#) **and** [::IGetDimensionInfo6](#).
Obsolete. Superseded by [::GetDimensionInfo6](#) **and** [::IGetDimensionInfo6](#).
Obsolete. Superseded by [::GetDimensionInfo6](#) **and** [::IGetDimensionInfo6](#).

[Obsolete. Superseded by IView::GetDimensionInfo7.](#)

Obsolete. Superseded by [::GetDimensionString4](#) **and** [::IGetDimensionString4](#).
Obsolete. Superseded by [::GetDimensionString4](#) **and** [::IGetDimensionString4](#).
Obsolete. Superseded by [::GetDimensionString4](#) **and** [::IGetDimensionString4](#).

Gets the strings containing the text associated with each dimension in the current drawing sheet or the current drawing view.

Obsolete. Superseded by [::GetDisplayData3](#) **and** [::IGetDisplayData3](#).
Obsolete. Superseded by [::GetDisplayData3](#) **and** [::IGetDisplayData3](#).

[Gets the the IDisplayData object for this drawing view containing only those model items that are visible in the view.](#)

Gets all of the display dimensions on this drawing view.

Gets all of the dowel symbols on this drawing view.

Obsolete. Superseded by [::GetEllipses5](#) **and** [::IGetEllipses5](#).
Obsolete. Superseded by [::GetEllipses5](#) **and** [::IGetEllipses5](#).
Obsolete. Superseded by [::GetEllipses5](#) **and** [::IGetEllipses5](#).
Obsolete. Superseded by [::GetEllipses5](#) **and** [::IGetEllipses5](#).

Gets all of the ellipses added by a user in this drawing view.

Gets the face hatches in the view.

[Obsolete. Superseded by IView::GetFirstAnnotation3.](#)

[Obsolete. Superseded by IView::GetFirstAnnotation3.](#)

Gets the first center of mass in this view.

Gets the first cosmetic thread in the view.

Obsolete. Not superseded.

Gets the first datum tag in the view.

Gets the first datum target symbol in the view.

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

[Obsolete. Superseded by IView::GetFirstDisplayDimension5.](#)

Gets the first dowel symbol in the view.

Gets the first geometric tolerance in this view.

Gets the first multi-jog leader in the view.

Gets the first note in the view.

Gets the first revision cloud annotation in this view.

Gets the first surface-finish symbols in the view.

Gets the first weld symbol in the view.

Gets all of the geometric tolerances on this drawing view.

Obsolete. Superseded by [::GetLines4](#) **and** [::IGetLines4](#).
Obsolete. Superseded by [::GetLines4](#) **and** [::IGetLines4](#).
Obsolete. Superseded by [::GetLines4](#) **and** [::IGetLines4](#).

Gets all of the lines in the view with an option to include or exclude crosshatch lines.

Gets all of the multi-jog leaders in this drawing view.

Gets the next drawing view in the drawing.

Gets the notes in this drawing view.

Gets the bounding box for a view (sheet or drawing) in meters on the drawing page.

Obsolete. Superseded by [::GetParabolas2](#) **and** [::IGetParabolas2](#).

Gets all of the information about all of the parabolas in this view.

Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).
Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).
Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).
Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).
Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).
Obsolete. Superseded by [::GetPolyLines6](#) **and** [::IGetPolyLines6](#).

[Obsolete. Superseded by IView::IGetPolylines7.](#)

Gets all of the polylines in the view with an option to include or exclude crosshatch lines

Gets the arcs, ellipses, splines, and polylines in the view with an option to include or exclude crosshatch lines.

Gets the projection arrow for this projected view.

Gets the projection lines (arrows) in this drawing view.

[Gets the visible tangent edges for the specified bendline in a flat-pattern drawing view.](#)

Gets all of the revision cloud annotations in this view.

Gets the section for this section view.

Obsolete. Superseded by [::GetSectionLineInfo2](#) **and** [::GetSectionLineInfo2](#).

Gets all of the information about the section lines in the view.

Gets the section lines in the view.

Gets an array of strings; each string represents the text label for a section line in this view.

Gets all of the surface finish symbols in this drawing view.

Gets the sketch used by this view.

Gets all of the sketch pictures imported to this view when a drawing is created from a part.

Gets the boundary-box sketch display data of a flat-pattern drawing view.

Gets the boundary data for all visible solid-fill hatches in a detail, break, or crop view.

Obsolete. Superseded by [::GetSplines3](#) **and** [::IGetSplines3](#).
Obsolete. Superseded by [::GetSplines3](#) **and** [::IGetSplines3](#).

Gets all of the splines added by a user in the drawing view.

Gets all of the table annotations in this drawing view.

Gets the information of the temporary axes displayed in this view.

Obsolete. Superseded by [::GetUserPoints2](#) **and** [IView::IGetUserPoints2](#).

Gets all of the information about all of the user points in this view.

Gets the transform from model space origin to drawing space origin.

Gets the visible components in this drawing view.

[Obsolete. Superseded by IView::IGetVisibleEntities2.](#)

Gets the visible entities of the specified type for the specified component in this drawing view.

Gets all of the weld beads on this drawing view.

Gets all of the weld symbols on this drawing view.

[IGetWitnessGeomInfo](#)
[IGetXform](#)
[IInsertBomTable](#)
[IImportAnnotations](#)
[IInsertAlternateView](#)
[IInsertBendTable](#)
[IInsertBomTable](#)
[IInsertBomTable2](#)
[IInsertBomTable3](#)
[IInsertBomTable4](#)
[IInsertBomTable5](#)
[IInsertBomTable6](#)
[IInsertBreak](#)
[IInsertBreak2](#)
[IInsertBreak3](#)
[IInsertCutListPropertyNote](#)
[IInsertHoleTable](#)
[IInsertHoleTable2](#)
[IInsertHoleTable3](#)
[IInsertPunchTable](#)

[IInsertViewAsBlock](#)

[IInsertWeldmentTable](#)
[IInsertWeldTable](#)
[IsBroken](#)
[IsCropped](#)
[ISelectEntity](#)
[ISetBodies](#)
[ISetXform](#)
[IsExploded](#)
[IsFlatPatternView](#)
[IsLightweight](#)
[IsModelBreakState](#)
[IsModelLoaded](#)
[IsModelOutOfDate](#)
[IsPerspectiveView](#)
[LoadModel](#)
[MergeBendTags](#)
[RemoveAlignment](#)
[ReplaceViewWithBlock](#)
[ReplaceViewWithSketch](#)
[ResetSketchVisibility](#)
[SelectEntity](#)
[SetBendNoteTextFormat](#)
[SetDisplayMode](#)
[SetDisplayMode2](#)
[SetDisplayMode3](#)
[SetDisplayMode4](#)
[SetDisplayTangentEdges](#)
[SetDisplayTangentEdges2](#)
[SetKeepLinkedToBOM](#)
[SetLightweightToResolved](#)
[SetMirrorViewOrientation](#)
[SetName2](#)
[SetResolvedToLightweight](#)
[SetViewPosition](#)
[SetVisible](#)
[SetXform](#)
[ShowExploded](#)
[ShowModelBreakState](#)
[UpdateViewDisplayGeometry](#)
[UseDefaultAlignment](#)

Gets the geometry data for all of the virtual sharp witness lines in this drawing view.
Gets the matrix used for displaying this drawing view.
Inserts a Bill of Materials (BOM) table for this drawing view using Microsoft Excel.
Imports the specified annotations into this drawing view.
Inserts an **Alternate Position View** of the currently selected drawing view.
Inserts a bend table for this drawing view.
Inserts a Bill of Materials (BOM) table for this drawing view using Microsoft Excel.
[Obsolete. Superseded by IView::InsertBomTable3.](#)
[Obsolete. Superseded by IView::InsertBomTable4.](#)
[Obsolete. Superseded by IView::InsertBomTable5.](#)
[Obsolete. Superseded by IView::InsertBomTable6.](#)
Inserts a bill of materials (BOM) table for this drawing view using SOLIDWORKS table functionality.
[Obsolete. Superseded by IView::InsertBreak2.](#)
[Obsolete. Superseded by IView::InsertBreak3.](#)
Inserts the specified type of break at the specified location in this drawing view.
Inserts a note that contains all of the cut list item properties of a sheet metal part.
[Obsolete. Superseded by IView::InsertHoleTable2.](#)
[Obsolete. Superseded by IView::InsertHoleTable3.](#)
Inserts a hole table in this drawing view.
Inserts a punch table in the flat pattern drawing view of a sheet metal part.
Creates a sketch block from this view and aligns the specified manipulator point with the specified sketch block position on the drawing sheet.
Inserts a weldment cut-list table into this drawing view.
Inserts a weld table into this drawing view.
Gets whether the drawing view is displayed with a break.
Get whether this drawing view is cropped.
Selects an entity in this drawing view.
Sets the bodies of a multibody part to include in the view.
Sets the matrix used for display of this drawing view.
Gets whether the drawing view is currently showing the assembly as exploded or collapsed.
Gets whether a drawing view is a flat-pattern drawing view.
Gets whether the drawing view is lightweight.
Gets whether this drawing view is a Model Break View.
Gets whether the model is loaded in this drawing view.
Gets whether the model in this drawing view is up-to-date with the current model.
Gets whether this drawing view is showing a perspective view of the model.
Loads the model if the model has not already been loaded for this drawing view.
Merges or unmerges bend tags in drawings of sheet metal parts.
Removes the alignment from this drawing view.
Converts this view into a sketch block with the specified manipulator location.
Converts this view into a sketch.
Resets the visibility of the sketches in the drawing view so that the drawing view reflects the model.
Selects an entity in this drawing view.
Sets the text format of all bend notes in this drawing view of a sheet metal part.
[Obsolete. Superseded by IView::SetDisplayMode3.](#)
[Obsolete. Superseded by IView::SetDisplayMode3.](#)
[Obsolete. Superseded by IView::SetDisplayMode4.](#)
Sets the display mode of this drawing view.
[Obsolete. Superseded by IView::SetDisplayTangentEdges2.](#)
Sets the tangent edge display mode of the drawing view.
Sets whether this drawing view is linked to the specified BOM or weldment cut-list table.
Changes the drawing view from lightweight to resolved.
Sets whether to mirror this view.
Sets the name of this drawing view, as displayed in the FeatureManager design tree.
Changes the drawing view from resolved to lightweight.
Moves this drawing view.
Sets the visibility of this drawing view.
Sets the matrix used for display of this drawing view.
Shows an exploded assembly in this drawing view.
Sets whether to display the specified Model Break View.
Updates the displayed geometry for a drawing view.
Restores the default alignment for this drawing view.