

SOLIDWORKS API (.NET VBA C#) — Reference

(7/337): IAdvancedHoleElementData- IAdvancedSaveAsOptions

SOLIDWORKS API Documentation (converted from CHM)

IAdvancedHoleElementData (Type)

IAdvancedHoleElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleElementData Interface

Allows access to Advanced Hole element data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAdvancedHoleElementData
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData
```

C#

```
public interface IAdvancedHoleElementData
```

C++/CLI

```
public interface class IAdvancedHoleElementData
```

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

IAdvancedHoleElementData is extended by the following:

- [ICounterboreElementData](#)
- [ICountersinkElementData](#)
- [IStraightElementData](#)
- [IStraightTapElementData](#)
- [ITaperedTapElementData](#)

After accessing the IAdvancedHoleElementData object, cast it to a hole type-specific object using one of the interfaces above and set the hole type-specific properties.

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IModelDocExtension::CreateAdvancedHoleElementData](#)

Access Diagram

[AdvancedHoleElementData](#)

See Also

[IAdvancedHoleElementData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleFeatureData Interface](#)

[See Also](#) [Properties](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleElementData Interface

The following tables list the members exposed by [IAdvancedHoleElementData](#).

 Public Properties

Name	Description
 BlindDepth	Gets or sets the depth for the blind end condition of this Advanced Hole element.
 CalloutString	Gets or sets the hole callout string for this Advanced Hole element.
 Diameter	Gets or sets the diameter of this Advanced Hole element.
 DiameterOverride	Gets or sets whether to override the diameter of this Advanced Hole element.
 ElementType	Gets the type of this Advanced Hole element.
 EndCondition	Gets or sets the end condition for this Advanced Hole element.
 FastenerType	Gets or sets the fastener type for this Advanced Hole element.
 OffsetDistance	Gets or sets the offset distance for this Advanced Hole element.
 OffsetReverseDirection	Gets or sets whether to reverse the offset direction for this Advanced Hole element.
 Orientation	Gets or sets the orientation of this Advanced Hole element.
 SelectionEntity	Gets or sets the entity used to specify the Up to Selection or Offset from Surface end condition for this Advanced Hole element.
 Size	Gets or sets the size of this Advanced Hole element.
 Standard	Gets or sets the hole standard used for this Advanced Hole element.

[Top](#)

 See Also

[IAdvancedHoleElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAdvancedHoleElementData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleElementData Interface

For a list of all members of this type, see [IAdvancedHoleElementData members](#).

 Public Properties

Name	Description
 BlindDepth	Gets or sets the depth for the blind end condition of this Advanced Hole element.
 CalloutString	Gets or sets the hole callout string for this Advanced Hole element.
 Diameter	Gets or sets the diameter of this Advanced Hole element.
 DiameterOverride	Gets or sets whether to override the diameter of this Advanced Hole element.
 ElementType	Gets the type of this Advanced Hole element.
 EndCondition	Gets or sets the end condition for this Advanced Hole element.
 FastenerType	Gets or sets the fastener type for this Advanced Hole element.
 OffsetDistance	Gets or sets the offset distance for this Advanced Hole element.
 OffsetReverseDirection	Gets or sets whether to reverse the offset direction for this Advanced Hole element.
 Orientation	Gets or sets the orientation of this Advanced Hole element.
 SelectionEntity	Gets or sets the entity used to specify the Up to Selection or Offset from Surface end condition for this Advanced Hole element.
 Size	Gets or sets the size of this Advanced Hole element.
 Standard	Gets or sets the hole standard used for this Advanced Hole element.

[Top](#)

See Also

[IAdvancedHoleElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BlindDepth Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : BlindDepth Property (IAdvancedHoleElementData)

Gets or sets the depth for the blind end condition of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property BlindDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Double  
  
instance.BlindDepth = value  
  
value = instance.BlindDepth
```

C#

```
System.double BlindDepth {get; set;}
```

C++/CLI

```
property System.double BlindDepth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Blind depth

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::BlindDepth](#).

Example

See the [IAdvancedHoleElementData](#) examples.

Remarks

This property is valid only if [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false, [IAdvancedHoleElementData::EndCondition](#) is set to [swEndConditions_e.swEndCondBlind](#), and the hole element's corresponding override property is set to true:

- [ICounterboreElementData::EndConditionOverride](#)
- [ICountersinkElementData::EndConditionOverride](#)
- [ITaperedTapElementData::EndConditionOverride](#)

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)
[IStraightTapElementData::Equation Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CalloutString Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : CalloutString Property (IAdvancedHoleElementData)

Gets or sets the hole callout string for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property CalloutString As System.String
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.String  
  
instance.CalloutString = value  
  
value = instance.CalloutString
```

C#

```
System.string CalloutString {get; set;}
```

C++/CLI

```
property System.String^ CalloutString {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole callout string (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::CalloutString](#).

Example

See the [IAdvancedHoleElementData](#) examples.

Remarks

This property is valid only if [IAdvancedHoleFeatureData::CustomizeCallout](#) is set to true.

The hole callout string is formatted as follows:

<LibraryName-SymbolName> <callout_var1> <callout_var2>... <callout_varn>

where:

- LibraryName* and *SymbolName* are defined in `c:\ProgramData\SolidWorks\SolidWorks 20nn\Language\English\lgto1.sym`.
- callout_var1-n* are callout variables. Use [IModelDocExtension::GetCalloutVariableString](#) to get the strings for hole callout variables defined in [swCalloutVariable](#) e. You can also find the hole callout variable strings by clicking **Hole Callout > Callout Variables** in the Advanced Hole PropertyManager.

Note: You must include the right- and left-angle brackets and the hyphens when setting the elements of this property string:

"<HOLE-SPOT><MOD-DIAM> <ah-cboredia> <HOLE-DEPTH> <ah-cboredepth><ah-cboreside>"

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diameter Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : Diameter Property (IAdvancedHoleElementData)

Gets or sets the diameter of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

Property Diameter As System.Double

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Double
```

```
instance.Diameter = value  
value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Diameter of the Advanced Hole

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::Diameter](#).

Example

See the [IAdvancedHoleElementData](#) examples.

Remarks

This property is valid only if [IAdvancedHoleElementData::DiameterOverride](#) is set to true.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DiameterOverride Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : DiameterOverride Property (IAdvancedHoleElementData)

Gets or sets whether to override the diameter of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

Property DiameterOverride As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Boolean
```

```
instance.DiameterOverride = value
```

```
value = instance.DiameterOverride
```

C#

```
System.bool DiameterOverride {get; set;}
```

C++/CLI

```
property System.bool DiameterOverride {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the diameter, false to not

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::DiameterOverride](#).

Example

See the [IAdvancedHoleElementData](#) examples.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)
[IAdvancedHoleElementData::Diameter Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ElementType Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : ElementType Property (IAdvancedHoleElementData)

Gets the type of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ElementType As System.Integer

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Integer
```

```
value = instance.ElementType
```

C#

```
System.int ElementType {get;}
```

C++/CLI

```
property System.int ElementType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Advanced Hole element type as defined in [swAdvWzdGeneralHoleTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::ElementType](#).

Example

See the [IAdvancedHoleElementData](#) examples.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)
[IAdvancedHoleElementData::Orientation Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EndCondition Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : EndCondition Property (IAdvancedHoleElementData)

Gets or sets the end condition for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property EndCondition As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Integer
```

```
instance.EndCondition = value
```

```
value = instance.EndCondition
```

C#

```
System.int EndCondition {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::EndCondition](#).

Example

See the [AdvancedHoleElementData](#) examples.

Remarks

Valid end conditions for the Advanced Hole as defined in [swEndConditions_e](#):

- swEndCondBlind
- swEndCondThroughAll
- swEndCondUpToNext
- swEndCondOffsetFromSurface
- swEndCondUpToSelection

This property can be set for a given hole element only when its corresponding override property is set to true:

- [ICounterboreElementData::EndConditionOverride](#)
- [ICountersinkElementData::EndConditionOverride](#)
- [ITaperedTapElementData::EndConditionOverride](#)

- and -

- [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)
[IStraightTapElementData::Equation Property \(\)](#)
[IAdvancedHoleElementData::OffsetDistance Property \(\)](#)
[IAdvancedHoleElementData::OffsetReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FastenerType Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : FastenerType Property (IAdvancedHoleElementData)

Gets or sets the fastener type for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property FastenerType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Integer  
  
instance.FastenerType = value
```

```
value = instance.FastenerType
```

C#

```
System.int FastenerType {get; set;}
```

C++/CLI

```
property System.int FastenerType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole fastener type as defined in [swWzdHoleStandardFastenerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::FastenerType](#).

Example

See the [AdvancedHoleElementData](#) examples.

Remarks

The hole fastener must match the [AdvancedHoleElementData::Standard](#) and be appropriate for the [AdvancedHoleElementData::ElementType](#), or an error occurs.

If [AdvancedHoleElementData::ElementType](#) is set to [swAdvWzdGeneralHoleTypes_e.swAdvWzdTaperTap](#), then this property gets and sets only [swWzdHoleStandardFastenerTypes_e.*TaperedPipeTap](#).

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDistance Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : OffsetDistance Property (IAdvancedHoleElementData)

Gets or sets the offset distance for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Double
```

```
instance.OffsetDistance = value
```

```
value = instance.OffsetDistance
```

C#

```
System.double OffsetDistance {get; set;}
```

C++/CLI

```
property System.double OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::OffsetDistance](#).

Remarks

This property is valid only when [IAAdvancedHoleElementData::EndCondition](#) is set to [swEndConditions_e.swEndCondOffsetFromSurface](#).

You can set this property only if this hole element's corresponding property is set to false:

- [ICounterboreElementData::UseStandardDepth](#)
- [ICountersinkElementData::UseStandardDepth](#)
- [ITaperedTapElementData::UseStandardDepth](#)

See Also

[IAAdvancedHoleElementData Interface](#)
[IAAdvancedHoleElementData Members](#)
[IAAdvancedHoleElementData::OffsetReverseDirection Property \(\)](#)
[IStraightTapElementData::Equation Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetReverseDirection Property (IAAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAAdvancedHoleElementData Interface](#) : OffsetReverseDirection Property (IAAdvancedHoleElementData)

Gets or sets whether to reverse the offset direction for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAAdvancedHoleElementData  
Dim value As System.Boolean
```

```
instance.OffsetReverseDirection = value
```

```
value = instance.OffsetReverseDirection
```

C#

```
System.bool OffsetReverseDirection {get; set;}
```

C++/CLI

```
property System.bool OffsetReverseDirection {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the offset direction, false to not

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::OffsetReverseDirection](#).

Remarks

This property is valid only when [AdvancedHoleElementData::EndCondition](#) is set to [swEndConditions_e.swEndCondOffsetFromSurface](#).

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)
[AdvancedHoleElementData::OffsetDistance Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Orientation Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : Orientation Property (IAdvancedHoleElementData)

Gets or sets the orientation of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

Property Orientation As System.Integer

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Integer
```

```
instance.Orientation = value
```

```
value = instance.Orientation
```

C#

```
System.int Orientation {get; set;}
```

C++/CLI

```
property System.int Orientation {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Orientation as defined in [swHoleElementOrientation_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::Orientation](#).

Example

See the [IAdvancedHoleElementData](#) examples.

Remarks

This property is not valid if [IAdvancedHoleElementData::ElementType](#) is set to [swAdvWzdGeneralHoleTypes_e](#):

- swAdvWzdStraight
- swAdvWzdStraightTap

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectionEntity Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : SelectionEntity Property (IAdvancedHoleElementData)

Gets or sets the entity used to specify the Up to Selection or Offset from Surface end condition for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property SelectionEntity As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Object
```

```
instance.SelectionEntity = value
```

```
value = instance.SelectionEntity
```

C#

```
System.object SelectionEntity {get; set;}
```

C++/CLI

```
property System.Object^ SelectionEntity {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition entity

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::SelectionEntity](#).

Remarks

This property is valid only when [IAdvancedHoleElementData::EndCondition](#) is set to [swEndConditions_e](#):

- swEndCondOffsetFromSurface (end condition entity is a [face](#), [surface](#), [plane](#), [edge](#), or [vertex](#))

- OR -

• swEndCondUpToSelection (end condition entity is a face, surface, or plane)
See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : Size Property (IAdvancedHoleElementData)

Gets or sets the size of this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

Property Size As System.String

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.String
```

```
instance.Size = value
```

```
value = instance.Size
```

C#

```
System.string Size {get; set;}
```

C++/CLI

```
property System.String^ Size {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Size specific to the type of hole element

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::Size](#).

Example

See the [IAdvancedHoleElementData](#) examples.

Remarks

The size must be appropriate for the [IAdvancedHoleElementData::FastenerType](#).

Valid sizes are listed in the Element Specification section of the Advanced Hole PropertyManager. Select a type from the Type dropdown and inspect the Size dropdown for valid sizes.

See Also

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard Property (IAdvancedHoleElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleElementData Interface](#) : Standard Property (IAdvancedHoleElementData)

Gets or sets the hole standard used for this Advanced Hole element.

.NET Syntax

Visual Basic (Declaration)

Property Standard As System.Integer

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleElementData  
Dim value As System.Integer
```

```
instance.Standard = value
```

```
value = instance.Standard
```

C#

```
System.int Standard {get; set;}
```

C++/CLI

```
property System.int Standard {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Hole standard as defined in [swWzdHoleStandards_e](#)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleElementData::Standard](#).

Example

See the [IAdvancedHoleElementData](#) examples.

See Also

[IAdvancedHoleElementData Interface](#)
[IAdvancedHoleElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

IAdvancedHoleFeatureData (Type)

IAdvancedHoleFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleFeatureData Interface

Allows access to the Advanced Hole feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAdvancedHoleFeatureData
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData
```

C#

```
public interface IAdvancedHoleFeatureData
```

C++/CLI

```
public interface class IAdvancedHoleFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[AdvancedHoleFeatureData](#)

See Also

[IAdvancedHoleFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleElementData Interface](#)

IAdvancedHoleFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleFeatureData Interface

The following tables list the members exposed by [IAdvancedHoleFeatureData](#).

Public Properties

Name	Description
 CustomizeCallout	Gets or sets whether to customize the hole callouts of the elements of this Advanced Hole.
 FarSideElementsCount	Gets the number of far side hole elements in this Advanced Hole.
 NearSideElementsCount	Gets the number of near side hole elements in this Advanced Hole.
 UseBaselineDimensions	Gets or sets whether to use baseline dimensions in this Advanced Hole.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the Advanced Hole feature.
 GetFarSideElements	Gets the far side hole elements in this Advanced Hole.
 GetNearSideElements	Gets the near side hole elements in this Advanced Hole.
 ReleaseSelectionAccess	Releases access to the selections used to define the Hole Wizard feature.
 SetFarSideElements	Sets the far side hole elements in this Advanced Hole.
 SetNearSideElements	Sets the near side hole elements in this Advanced Hole.

[Top](#)

See Also

[IAdvancedHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleElementData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAdvancedHoleFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleFeatureData Interface

For a list of all members of this type, see [IAdvancedHoleFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define the Advanced Hole feature.
 GetFarSideElements	Gets the far side hole elements in this Advanced Hole.
 GetNearSideElements	Gets the near side hole elements in this Advanced Hole.
 ReleaseSelectionAccess	Releases access to the selections used to define the Hole Wizard feature.
 SetFarSideElements	Sets the far side hole elements in this Advanced Hole.
 SetNearSideElements	Sets the near side hole elements in this Advanced Hole.

[Top](#)

See Also

[IAdvancedHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleElementData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAdvancedHoleFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedHoleFeatureData Interface

For a list of all members of this type, see [IAdvancedHoleFeatureData members](#).

Public Properties

Name	Description
------	-------------

 CustomizeCallout	Gets or sets whether to customize the hole callouts of the elements of this Advanced Hole.
 FarSideElementsCount	Gets the number of far side hole elements in this Advanced Hole.
 NearSideElementsCount	Gets the number of near side hole elements in this Advanced Hole.
 UseBaselineDimensions	Gets or sets whether to use baseline dimensions in this Advanced Hole.

[Top](#)

See Also

[IAdvancedHoleFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IAdvancedHoleElementData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : AccessSelections Method (IAdvancedHoleFeatureData)

Gains access to the selections used to define the Advanced Hole feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
[IModelDoc2](#) for the part
Component
Null or Nothing

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::AccessSelections](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

This method puts the model into a rollback state to allow access to the selections that define this feature.

You must use either of the following methods to restore the original state of the model:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#), if you modified the feature
- [IAdvancedHoleFeatureData::ReleaseSelectionAccess](#), if you did not modify the feature

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomizeCallout Property (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : CustomizeCallout Property (IAdvancedHoleFeatureData)

Gets or sets whether to customize the hole callouts of the elements of this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

Property CustomizeCallout As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Boolean
```

```
instance.CustomizeCallout = value
```

```
value = instance.CustomizeCallout
```

C#

```
System.bool CustomizeCallout {get; set;}
```

C++/CLI

```
property System.bool CustomizeCallout {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to customize hole callouts, false to use default hole callouts

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::CustomizeCallout](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

If you set this property to true, use [IAdvancedHoleElementData::CalloutString](#) to customize the hole callouts.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FarSideElementsCount Property (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : FarSideElementsCount Property (IAdvancedHoleFeatureData)

Gets the number of far side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FarSideElementsCount As System.Integer

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Integer
```

```
value = instance.FarSideElementsCount
```

C#

```
System.int FarSideElementsCount {get;}
```

C++/CLI

```
property System.int FarSideElementsCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of far side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::FarSideElementsCount](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFarSideElements Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : GetFarSideElements Method (IAdvancedHoleFeatureData)

Gets the far side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFarSideElements() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Object  
  
value = instance.GetFarSideElements()
```

C#

```
System.object GetFarSideElements()
```

C++/CLI

```
System.Object^ GetFarSideElements();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of far side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::GetFarSideElements](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)
[IAdvancedHoleFeatureData::SetFarSideElements Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNearSideElements Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : GetNearSideElements Method (IAdvancedHoleFeatureData)

Gets the near side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNearSideElements() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Object
```

```
value = instance.GetNearSideElements()
```

C#

```
System.object GetNearSideElements()
```

C++/CLI

```
System.Object^ GetNearSideElements();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of near side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::GetNearSideElements](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)
[IAdvancedHoleFeatureData::SetNearSideElements Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NearSideElementsCount Property (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : NearSideElementsCount Property (IAdvancedHoleFeatureData)

Gets the number of near side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property NearSideElementsCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Integer
```

```
value = instance.NearSideElementsCount
```

C#

```
System.int NearSideElementsCount {get;}
```

C++/CLI

```
property System.int NearSideElementsCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of near side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::NearSideElementsCount](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : ReleaseSelectionAccess Method (IAdvancedHoleFeatureData)

Releases access to the selections used to define the Hole Wizard feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::ReleaseSelectionAccess](#).

Remarks

[IAdvancedHoleFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

You must use either of the following methods to restore the original state of the model:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#), if you modified the feature
- this method, if you did not modify the feature

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetFarSideElements Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : SetFarSideElements Method (IAdvancedHoleFeatureData)

Sets the far side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFarSideElements( _  
    ByVal ElmArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim ElmArray As System.Object  
  
instance.SetFarSideElements(ElmArray)
```

C#

```
void SetFarSideElements(  
    System.object ElmArray  
)
```

C++/CLI

```
void SetFarSideElements(  
& System.Object^ ElmArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ElmArray
Array of far side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData.SetFarSideElements](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)
[IAdvancedHoleFeatureData::GetFarSideElements Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetNearSideElements Method (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : SetNearSideElements Method (IAdvancedHoleFeatureData)

Sets the near side hole elements in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetNearSideElements( _  
    ByVal ElmArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim ElmArray As System.Object  
  
instance.SetNearSideElements(ElmArray)
```

C#

```
void SetNearSideElements(  
    System.object ElmArray  
)
```

C++/CLI

```
void SetNearSideElements(  
& System.Object^ ElmArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ElmArray
Array of near side hole elements

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::SetNearSideElements](#).

Example

See the [IAdvancedHoleFeatureData](#) examples.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)
[IAdvancedHoleFeatureData::GetNearSideElements Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseBaselineDimensions Property (IAdvancedHoleFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedHoleFeatureData Interface](#) : UseBaselineDimensions Property (IAdvancedHoleFeatureData)

Gets or sets whether to use baseline dimensions in this Advanced Hole.

.NET Syntax

Visual Basic (Declaration)

Property UseBaselineDimensions As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAdvancedHoleFeatureData  
Dim value As System.Boolean
```

```
instance.UseBaselineDimensions = value  
value = instance.UseBaselineDimensions
```

C#

```
System.bool UseBaselineDimensions {get; set;}
```

C++/CLI

```
property System.bool UseBaselineDimensions {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use baseline dimensions, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AdvancedHoleFeatureData::UseBaselineDimensions](#).

Remarks

If you set this property to true, then you can get and set:

- [ICounterboreElementData::UseStandardDepth](#)
- [ICountersinkElementData::UseStandardDepth](#)
- [ITaperedTapElementData::UseStandardDepth](#)
- [IStraightTapElementData::Equation](#) (for the Offset From Surface end condition only)

but you cannot set any end conditions or end condition overrides.

If you set this property to false, then the UseStandardDepth properties above are not valid, but you can get and set:

- [ICounterboreElementData::EndConditionOverride](#)
- [ICountersinkElementData::EndConditionOverride](#)
- [ITaperedTapElementData::EndConditionOverride](#)
- [IAdvancedHoleElementData::EndCondition](#) (only if the corresponding EndConditionOverride for the element is set to true)
- [IAdvancedHoleElementData::BlindDepth](#) (for the Blind end condition only)
- [IStraightTapElementData::Equation](#) (for the Blind end condition only)

See Also

[IAdvancedHoleFeatureData Interface](#)
[IAdvancedHoleFeatureData Members](#)

Availability

IAdvancedSaveAsOptions (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAdvancedSaveAsOptions Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedSaveAsOptions Interface

Allows access to all **File > Save As** options when saving a SOLIDWORKS Part, Assembly, or Drawing.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAdvancedSaveAsOptions
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions
```

C#

```
public interface IAdvancedSaveAsOptions
```

C++/CLI

```
public interface class IAdvancedSaveAsOptions
```

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions](#).

Example

'VBA

'This example shows how to save a drawing with advanced options.

'-----

' Preconditions:

' 1. Open:

' *public_documents\samples\tutorial\advdrawings\foodprocessor.slddrw*

' 2. Open the Immediate window.

'

' Postconditions:

' 1. Inspect the Immediate window for the list of reference components,

' before and after name modifications to the drawing and its template.

' 2. Inspect the DrwSavedFolder and Ref sub-folders. In those

' directories, the names of top-level documents are changed to "SamplePart.*".

' The reference component names are changed to include a "Prff_" prefix and

' a "_Suff" suffix.

'

' NOTE: Because the drawing and template are used elsewhere,

' do not save changes.

'-----

```
Dim swApp As SldWorks.SldWorks
```

```
Dim swModel As ModelDoc2
```

```
Dim ModelExt As ModelDocExtension
```

```
Dim AdvOptData As AdvancedSaveAsOptions
```

```
Dim aFileName As String
```

```
Dim OrFileName As String
```

```
Dim Opt As Long
```

```
Dim Error As Long
```

```
Dim Warning As Long
```

```
Dim Status As Boolean
```

```
Dim i As Long
```

```
Dim k As Long
```

```
Const Suff As String = "_Suff"
```

```
Const Prff As String = "Prff_"
```

```
Option Explicit
```

```

Sub main()

    Dim DrwExtArr As Variant
    DrwExtArr = Array(".slddrw", ".drwdot")

    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set ModelExt = swModel.Extension

    OrFileName = Left(swModel.GetPathName(), InStrRev(swModel.GetPathName(), "\"))
    Debug.Print OrFileName

    Dim IDList As Variant
    Dim fileNameList As Variant
    Dim pathNameList As Variant

    If Dir(OrFileName & "DrwSavedFolder", vbDirectory) = "" Then
        MkDir (OrFileName & "DrwSavedFolder")
        MkDir (OrFileName & "Ref")
    End If

    For i = 0 To UBound(DrwExtArr)

        aFileName = OrFileName & "DrwSavedFolder\SamplePart" & DrwExtArr(i)
        Debug.Print aFileName

        Set AdvOptData = ModelExt.GetAdvancedSaveAsOptions((1 + 2 + 4))

        AdvOptData.SaveAllAsCopy = True

        'Uncomment below to save model and references as SOLIDWORKS 2020
        'AdvOptData.SaveAsPreviousVersion = 13000

        AdvOptData.GetItemsNameAndPath IDList, fileNameList, pathNameList

        PrintList fileNameList, pathNameList

        AdvOptData.SetPrefixSuffixToAll Prff, Suff

        AdvOptData.GetItemsNameAndPath IDList, fileNameList, pathNameList

        For k = 0 To UBound(IDList)

            If k = 0 Then ' For setting root folder and root file name
                pathNameList(k) = OrFileName & "DrwSavedFolder"
                fileNameList(k) = "SamplePart" & DrwExtArr(i)
            Else
                pathNameList(k) = OrFileName & "Ref"
            End If

        Next

        Error = AdvOptData.ModifyItemsNameAndPath(IDList, fileNameList, pathNameList)

        Debug.Print "Modify Paths Status : " & Error
        Debug.Print " "
        AdvOptData.GetItemsNameAndPath IDList, fileNameList, pathNameList

        PrintList fileNameList, pathNameList

        SaveFunctionCall (DrwExtArr(i))

        Debug.Print " "

    Next

    Debug.Print "Total Count " & i

End Sub

Sub SaveFunctionCall(Typ As String)

    Opt = (1 + 2)
    Debug.Print aFileName
    Status = ModelExt.SaveAs3(aFileName, 0, Opt, Nothing, AdvOptData, Error, Warning)

    Debug.Print "Save Status for Type " & Typ & " is : " & Status & " " & Error & " " & Warning

End Sub

```

```
Sub PrintList(sList As Variant, sList2 As Variant)
    Dim j As Long
    For j = 0 To UBound(sList)
        Debug.Print sList(j) & " **>>** " & sList2(j)
    Next
    Debug.Print "Total Count in the List is : " & j
End Sub
```

 Accessors

[IModelDocExtension::GetAdvancedSaveAsOptions](#)

 Access Diagram

[AdvancedSaveAsOptions](#)

 See Also

[IAdvancedSaveAsOptions Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAdvancedSaveAsOptions Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAdvancedSaveAsOptions Interface

The following tables list the members exposed by [IAdvancedSaveAsOptions](#).

 Public Properties

Name	Description
 ConfigurationsToSave	Sets the subset of configurations to save.
 Description	Adds a description of the save.
 GeometryToSave	Sets the geometry to save only when saving an assembly as a part.
 OverrideDefaults	Sets whether to override defaults only when saving an assembly as a part.
 PreserveGeometryReferences	Sets whether to preserve geometry references only when saving an assembly as a part.
 SaveAllAsCopy	Sets whether to save all component references as copies.
 SaveAsPreviousVersion	Sets the SOLIDWORKS version to save to.

[Top](#)

 Public Methods

Name	Description
 GetItemsNameAndPath	Gets all reference components' names and paths.
 ModifyItemsNameAndPath	Modifies the specified reference components with the specified names and paths.
 SetPrefixSuffixToAll	Sets a prefix and/or a suffix on all component reference names.

[Top](#)

 See Also

[IAdvancedSaveAsOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAdvancedSaveAsOptions Interface Methods

[See Also](#)



For a list of all members of this type, see [IAdvancedSaveAsOptions members](#).

 Public Methods

Name	Description
 GetItemsNameAndPath	Gets all reference components' names and paths.
 ModifyItemsNameAndPath	Modifies the specified reference components with the specified names and paths.
 SetPrefixSuffixToAll	Sets a prefix and/or a suffix on all component reference names.

[Top](#)

 See Also

[IAdvancedSaveAsOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAdvancedSaveAsOptions Interface Properties

[See Also](#)



For a list of all members of this type, see [IAdvancedSaveAsOptions members](#).

 Public Properties

Name	Description
 ConfigurationsToSave	Sets the subset of configurations to save.
 Description	Adds a description of the save.
 GeometryToSave	Sets the geometry to save only when saving an assembly as a part.
 OverrideDefaults	Sets whether to override defaults only when saving an assembly as a part.
 PreserveGeometryReferences	Sets whether to preserve geometry references only when saving an assembly as a part.
 SaveAllAsCopy	Sets whether to save all component references as copies.
 SaveAsPreviousVersion	Sets the SOLIDWORKS version to save to.

[Top](#)

 See Also

[IAdvancedSaveAsOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ConfigurationsToSave Property (IAdvancedSaveAsOptions)

[See Also](#)



Sets the subset of configurations to save.

 Visual Basic Syntax

Visual Basic (Declaration)

WriteOnly Property ConfigurationsToSave As System.Object

Visual Basic (Usage)

```
Dim instance As IAdvancedSaveAsOptions  
instance.ConfigurationsToSave = value
```

C#



```
System.Object ConfigurationsToSave {set;}
```

C++/CLI

```
property System.Object^ ConfigurationsToSave {  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of configuration names to save

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::ConfigurationsToSave](#).

Remarks

The active configuration is always saved with the subset of configurations.

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

Description Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : Description Property (IAdvancedSaveAsOptions)

Adds a description of the save.

.NET Syntax

Visual Basic (Declaration)

```
WriteOnly Property Description As System.String
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
instance.Description = value
```

C#

```
System.string Description {set;}
```

C++/CLI

```
property System.String^ Description {  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Description

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::Description](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GeometryToSave Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : GeometryToSave Property (IAdvancedSaveAsOptions)

Sets the geometry to save only when saving an assembly as a part.

.NET Syntax

Visual Basic (Declaration)

WriteOnly Property GeometryToSave As System.Integer

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
instance.GeometryToSave = value
```

C#

```
System.int GeometryToSave {set;}
```

C++/CLI

```
property System.int GeometryToSave {  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Geometry to save as defined in [swGeometryToSave_e](#)

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::GeometryToSave](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetItemsNameAndPath Method (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : GetItemsNameAndPath Method (IAdvancedSaveAsOptions)

Gets all reference components' names and paths.

.NET Syntax

```
Sub GetItemsNameAndPath( _
    ByRef IdsList As System.Object, _
    ByRef NamesList As System.Object, _
    ByRef PathsList As System.Object _
)
```



```
Dim instance As IAdvancedSaveAsOptions
Dim IdsList As System.Object
Dim NamesList As System.Object
Dim PathsList As System.Object

instance.GetItemsNameAndPath(IdsList, NamesList, PathsList)
```

```
void GetItemsNameAndPath(
    out System.object IdsList,
    out System.object NamesList,
    out System.object PathsList
)
```

```
void GetItemsNameAndPath(
    & [Out] System.Object^ IdsList,
    & [Out] System.Object^ NamesList,
    & [Out] System.Object^ PathsList
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdsList
Array of component reference IDs
NamesList
Array of component reference names
PathsList
Array of component reference paths

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::GetItemsNameAndPath](#).

Example

See the [IAdvancedSaveAsOptions](#) example.

Remarks

IdsList, NamesList, and PathsList are the same array size and map one to one. Call this method to obtain the current list of component references before calling [IAdvancedSaveAsOptions::ModifyItemsNameAndPath](#) to modify them.

This method lists component references according to the Options parameter that was specified in the call to [IModelDocExtension::GetAdvancedSaveAsOptions](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

ModifyItemsNameAndPath Method (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : ModifyItemsNameAndPath Method (IAdvancedSaveAsOptions)

Modifies the specified reference components with the specified names and paths.

.NET Syntax

Visual Basic (Declaration)

```
Function ModifyItemsNameAndPath( _  
    ByVal IdsList As System.Object, _  
    ByVal NamesList As System.Object, _  
    ByVal PathsList As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
Dim IdsList As System.Object  
Dim NamesList As System.Object  
Dim PathsList As System.Object  
Dim value As System.Integer  
  
value = instance.ModifyItemsNameAndPath(IdsList, NamesList, PathsList)
```

C#

```
System.int ModifyItemsNameAndPath(  
    System.object IdsList,  
    System.object NamesList,  
    System.object PathsList  
)
```

C++/CLI

```
System.int ModifyItemsNameAndPath(  
& System.Object^ IdsList,  
& System.Object^ NamesList,  
& System.Object^ PathsList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IdsList

Array of reference component IDs (see **Remarks**)

NamesList

Array of new reference component names

PathsList

Array of new reference component paths

Return Value

Return code as defined in [swSaveItemsPathError_e](#)

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::ModifyItemsNameAndPath](#).

Example

See the [IAdvancedSaveAsOptions](#) example.

Remarks

Before calling this method call:

1. [IAdvancedSaveAsOptions::SetPrefixSuffixToAll](#)
2. [IAdvancedSaveAsOptions::GetItemsNameAndPath](#) to populate IdsList.

IdsList, NamesList, and PathsList are the same array size and map one to one. Use Nothing or null to specify no change to an individual reference in each array.

If you use this method to change the name or path of the top-level document, then it overrides the name or path passed in the Name parameter of [IModelDocExtension::SaveAs3](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)
[IAdvancedSaveAsOptions::SaveAsPreviousVersion Property \(\)](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaults Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : OverrideDefaults Property (IAdvancedSaveAsOptions)

Sets whether to override defaults only when saving an assembly as a part.

.NET Syntax

Visual Basic (Declaration)

WriteOnly Property OverrideDefaults As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
instance.OverrideDefaults = value
```

C#

```
System.bool OverrideDefaults {set;}
```

C++/CLI

```
property System.bool OverrideDefaults {  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override defaults, false to not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::OverrideDefaults](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

PreserveGeometryReferences Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : PreserveGeometryReferences Property (IAdvancedSaveAsOptions)

Sets whether to preserve geometry references only when saving an assembly as a part.

.NET Syntax

Visual Basic (Declaration)

```
WriteOnly Property PreserveGeometryReferences As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
instance.PreserveGeometryReferences = value
```

C#

```
System.bool PreserveGeometryReferences {set;}
```

C++/CLI

```
property System.bool PreserveGeometryReferences {  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to preserve geometry references, false to not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::PreserveGeometryReferences](#).

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveAllAsCopy Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : SaveAllAsCopy Property (IAdvancedSaveAsOptions)

Sets whether to save all component references as copies.

.NET Syntax

Visual Basic (Declaration)

```
WriteOnly Property SaveAllAsCopy As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
instance.SaveAllAsCopy = value
```

C#

```
System.bool SaveAllAsCopy {set;}
```

C++/CLI

```
property System.bool SaveAllAsCopy {
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to save all as a copy, false (default) to not

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::SaveAllAsCopy](#).

Example

See the [IAdvancedSaveAsOptions](#) example.

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveAsPreviousVersion Property (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : SaveAsPreviousVersion Property (IAdvancedSaveAsOptions)

Sets the SOLIDWORKS version to save to.

.NET Syntax

Visual Basic (Declaration)

```
WriteOnly Property SaveAsPreviousVersion As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions
instance.SaveAsPreviousVersion = value
```

C#

```
System.int SaveAsPreviousVersion {set;}
```

C++/CLI

```
property System.int SaveAsPreviousVersion {
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

SOLIDWORKS version to save to (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::SaveAsPreviousVersion](#).

Example

See the [IAdvancedSaveAsOptions](#) example.

Remarks

Examine the Remarks of [ISldWorks::VersionHistory](#) to find the SOLIDWORKS version to save to.

For this property to save a model as a previous version, you must also use [IAdvancedSaveAsOptions::ModifyItemsNameAndPath](#) to change the name/path of all of the model's references. You must provide a different name/path than the current name/path, otherwise the SaveAs operation may fail because overwriting the same file is not supported.

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetPrefixSuffixToAll Method (IAdvancedSaveAsOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAdvancedSaveAsOptions Interface](#) : SetPrefixSuffixToAll Method (IAdvancedSaveAsOptions)

Sets a prefix and/or a suffix on all component reference names.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetPrefixSuffixToAll( _  
    ByVal PrefixString As System.String, _  
    ByVal SuffixString As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IAdvancedSaveAsOptions  
Dim PrefixString As System.String  
Dim SuffixString As System.String
```

```
instance.SetPrefixSuffixToAll(PrefixString, SuffixString)
```

C#

```
void SetPrefixSuffixToAll(  
    System.string PrefixString,  
    System.string SuffixString  
)
```

C++/CLI

```
void SetPrefixSuffixToAll(  
& System.String^ PrefixString,  
& System.String^ SuffixString  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PrefixString
Prefix
SuffixString
Suffix

Visual Basic for Applications (VBA) Syntax

See [AdvancedSaveAsOptions::SetPrefixSuffixToAll](#).

Example

See the [IAdvancedSaveAsOptions](#) example.

Remarks

This method applies a prefix/suffix to the names of all references except the top-level document. After calling this method, call [IAdvancedSaveAsOptions::ModifyItemsNameAndPath](#) to modify the name and path of individual references and/or the top-level assembly.

See Also

[IAdvancedSaveAsOptions Interface](#)
[IAdvancedSaveAsOptions Members](#)

Availability

SOLIDWORKS 2020 SP02, Revision Number 28.2