

SOLIDWORKS API (.NET VBA C#) — Reference

(9/337): IAnnotation (part 1 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IAnnotation (part 1 of 3) (Type)

IAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotation Interface

Allows access to notes, weld symbols, datum tags, display dimensions, blocks, cosmetic threads, center marks, centerlines, and other annotation types.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

■ .NET Syntax

Visual Basic (Declaration)

```
Public Interface IAnnotation
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
```

C#

```
public interface IAnnotation
```

C++/CLI

```
public interface class IAnnotation
```

■ Visual Basic for Applications (VBA) Syntax

See [Annotation](#).

■ Example

[Get Whether Note Contains Rich-embedded Text \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)
[Select Table Cells \(C#\)](#)
[Select Table Cells \(VB.NET\)](#)
[Select Table Cells \(VBA\)](#)

■ Remarks

Because IAnnotation is a high-level representation of all annotation types, it provides functions that are generic to all types of annotations. For example, every annotation has a name and position, so IAnnotation provides functions that access this data.

Although IAnnotation has specific lower-level objects (such as [INote](#)), it does not have any derived classes in the SOLIDWORKS API. This means that you cannot use an IAnnotation pointer to call functions in the lower-level objects. You also cannot use QueryInterface to obtain the underlying classes. Instead, SOLIDWORKS provides [IAnnotation::GetSpecificAnnotation](#), which accesses underlying objects.

Similarly if you are holding onto a lower-level class, then you can obtain the corresponding IAnnotation object using the GetAnnotation method of that class (see the **Accessors** list in this topic).

■ Accessors

[IAnnotation::GetNext3 Method](#)
[IAnnotationView::Annotations](#)
[IAnnotationView::IGetAnnotations](#)
[ICenterLine::GetAnnotation Method](#)
[ICenterMark::GetAnnotation Method](#)
[ICenterOfMass::GetAnnotation](#) and [ICenterOfMass::IGetAnnotation](#)
[ICThread::GetAnnotation](#) and [ICThread::IGetAnnotation Method](#)
[IDatumOrigin::GetAnnotation Method](#)
[IDatumTag::GetAnnotation](#) and [IDatumTag::IGetAnnotation Method](#)

[IDatumTargetSym::GetAnnotation](#) and [IDatumTargetSym::IGetAnnotation Method](#)
[IDisplayDimension::GetAnnotation](#) and [IDisplayDimension::IGetAnnotation Method](#)
[IDowelSymbol::GetAnnotation](#) and [IDowelSymbol::IGetAnnotation Method](#)
[IGtol::GetAnnotation](#)
[ILayer::GetItems](#)
[IModelDoc2::GetFirstAnnotation2 Method](#)
[IModelDocExtension::GetAnnotations Method](#)
[IModelDocExtension::InsertAnnotationFavorite Method](#)
[IMultiJogLeader::GetAnnotation](#) and [IMultiJogLeader::IGetAnnotation Method](#)
[INote::GetAnnotation](#) and [INote::IGetAnnotation Method](#)
[IRevisionCloud::GetAnnotation](#) and [IRevisionCloud::IGetAnnotation](#)
[ISFSymbol::GetAnnotation Method](#)
[ITableAnnotation::GetAnnotation Method](#)
[IView::GetAnnotations Method](#)
[IView::GetFirstAnnotation3 Method](#)
[IWeldBead::GetAnnotation Method](#)
[IWeldSymbol::GetAnnotation Method](#) and [IWeldSymbol::IGetAnnotation Method](#)

 Access Diagram

[Annotation](#)

 See Also

[IAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetObjectIds Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotation Interface

For a list of all members of this type, see [IAnnotation members](#).

 Public Methods

Name	Description
 AddOrUpdateStyle	Adds or updates the annotation linked to the specified style.
 ApplyDefaultStyleAttributes	Applies the default style attribute to this annotation.
 CanShowInAnnotationView	Gets whether this annotation can be shown in the specified annotation view .
 CanShowInMultipleAnnotationViews	Gets whether this annotation can be shown in multiple annotation views .
 CheckSpelling	Spell checks the text in this annotation.
 ConvertToMultiJog	Converts a note with a leader to a note with a multi-jog leader.
 DeleteStyle	Deletes the specified style.
 Deselect	Deselects this annotation.
 GetArrowHeadCount	Gets the number of arrowheads on this symbol.
 GetArrowHeadSizeAtIndex	Gets the arrow head size of the specified leader on this annotation.
 GetArrowHeadStyleAtIndex	Gets the arrow head style of a specific leader on this annotation.
 GetAttachedEntities	Obsolete. Superseded by IAnnotation::GetAttachedEntities2 .
 GetAttachedEntities2	Obsolete. Superseded by IAnnotation::GetAttachedEntities3 .
 GetAttachedEntities3	Gets the entities to which this annotation is attached.
 GetAttachedEntityCount2	Obsolete. Superseded by IAnnotation::GetAttachedEntityCount3 .

	GetAttachedEntityCount3	Gets the number of entities to which this annotation is attached.
	GetAttachedEntityTypes	Gets the types of entities attached to this annotation.
	GetBentLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle .
	GetDashedLeader	Gets whether this leader is a dashed line or a solid line.
	GetDimXpertFeature	Gets the DimXpert feature associated with this annotation.
	GetDimXpertName	Gets the DimXpert name for this annotation.
	GetDisplayData	Gets the display data for this annotation.
	GetFlipPlaneTransform	Gets the transformation matrix of the annotation plane in the opposite direction.
	GetLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle .
	GetLeaderAllAround	Gets the setting for all-around symbol display of this annotation.
	GetLeaderCount	Gets the number of leaders on this annotation.
	GetLeaderPerpendicular	Gets the perpendicular bent leader display setting for this annotation.
	GetLeaderPointsAtIndex	Gets coordinate information about a specified leader on this annotation.
	GetLeaderSide	Gets the leader attachment side setting for this annotation.
	GetLeaderStyle	Gets the style of this leader.
	GetMultiJogLeaderCount	Gets the number of multi-jog leaders on this annotation.
	GetMultiJogLeaders	Gets the multi-jog leaders on this annotation.
	GetName	Gets the name of this annotation.
	GetNext	Obsolete. Superseded by IAnnotation::GetNext3 .
	GetNext2	Obsolete. Superseded by IAnnotation::GetNext3 .
	GetNext3	Gets the next annotation.
	GetParagraphs	Gets the paragraphs in this note annotation.
	GetPlane	Gets the rotation matrix of the annotation relative to the X-Y plane of the model.
	GetPMIData	Gets the Product and Manufacturing Information (PMI) feature data object for this STEP 242 annotation.
	GetPMIType	Gets the type of Product and Manufacturing Information (PMI) associated with this STEP 242 annotation.
	GetPosition	Gets the position of this annotation.
	GetSmartArrowHeadStyle	Gets the setting for smart arrowhead style for this annotation.
	GetSpecificAnnotation	Gets the specific underlying object associated with this annotation.
	GetStyleName	Gets the name of the style applied to this annotation.
	GetTextFormat	Gets the text format for the specified text in this annotation.
	GetTextFormatCount	Gets the number of text formats for this annotation.
	GetType	Gets the type of the annotation.
	GetUseDocTextFormat	Gets whether SOLIDWORKS is currently using the document default text format setting for this annotation.
	GetVisualProperties	Gets the visual properties of this annotation.
	IGetAttachedEntities	Obsolete. Superseded by IAnnotation::GetAttachedEntities2 .
	IGetAttachedEntityCount	Obsolete. Superseded by IAnnotation::GetAttachedEntityCount2 .
	IGetAttachedEntityTypes	Gets the types of all entities attached to this annotation.
	IGetDisplayData	Gets the display data for the annotation.
	IGetLeaderPointsAtIndex	Gets coordinate information about a specified leader on this annotation.
	IGetMultiJogLeaders	Gets the multi-jog leaders on this annotation.
	IGetNext	Obsolete. Superseded by IAnnotation::GetNext3 .
	IGetNext2	Obsolete. Superseded by IAnnotation::GetNext3 .
	IGetPosition	Gets the position of this annotation.

 IGetSpecificAnnotation	Gets the specific underlying object associated with this annotation.
 IGetTextFormat	Gets the text format for the specified text in this annotation.
 IGetVisualProperties	Gets the visual properties of this annotation.
 IsDangling	Gets whether this annotation is dangling.
 IsDimXpert	Gets whether the annotation is a DimXpert annotation.
 ISetAttachedEntities	Attaches this annotation to the specified entities.
 ISetTextFormat	Sets the text format information for the specified text within this annotation.
 LoadStyle	Loads the specified style.
 SaveStyle	Saves the specified style.
 Select	Obsolete. Superseded by IAnnotation::Select3 .
 Select2	Obsolete. Superseded by IAnnotation::Select3 .
 Select3	Selects this annotation and marks it.
 SelectByMark	Obsolete. Superseded by IAnnotation::Select3 .
 SetArrowHeadSizeAtIndex	Sets the size of the arrow head of the specified leader on this annotation.
 SetArrowHeadStyleAtIndex	Sets the arrow head style of a specific leader on this annotation.
 SetAttachedEntities	Attaches this annotation to the specified entities.
 SetLeader	Obsolete. Superseded by IAnnotation::SetLeader3 .
 SetLeader2	Obsolete. Superseded by IAnnotation::SetLeader3 .
 SetLeader3	Sets the leader characteristics for this annotation.
 SetLeaderAttachmentPointAtIndex	Sets the specified attachment point of a leader for an annotation with the specified index.
 SetName	Sets the name of this annotation.
 SetPosition	Obsolete. Superseded by IAnnotation::SetPosition2 .
 SetPosition2	Sets the position of this annotation.
 SetStyleName	Sets the style for this annotation.
 SetTextFormat	Sets the text format for the specified text in this annotation.

[Top](#)

See Also

[IAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetObjectID Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotation Interface

The following tables list the members exposed by [IAnnotation](#).

Public Properties

Name	Description
 AnnotationView	Gets the annotation view for this annotation.
 BentLeaderLength	Gets or sets the length of the bent leader for this annotation.
 Color	Gets or sets the color of this annotation. Annotation color is supported only in SOLIDWORKS drawings.
 FrameLineStyle	Gets or sets the frame's line style for this annotation.
 FrameThickness	Gets or sets the frame's line thickness for this annotation.
 FrameThicknessCustom	Gets or sets the frame's line thickness for this annotation.
 Layer	Gets or sets the layer used by this annotation. Layers are supported only in SOLIDWORKS drawings.

		
	LayerOverride	Gets or sets whether the annotation has properties that override the default properties of the layer.
	LeaderLineStyle	Gets or sets the leader's lines style for this annotation.
	LeaderThickness	Gets or sets the leader's line thickness for this annotation.
	LeaderThicknessCustom	Gets or sets the leader's custom line thickness for this annotation.
	Owner	Gets the owner of this annotation. NOTE: This property is a get-only property. Set is not implemented.
	OwnerType	Gets the type of owner of this annotation. NOTE: This property is a get-only property. Set is not implemented.
	Style	Gets or sets the line style for this annotation.
	UseDocDispFrame	Gets or sets whether to use the document's frame's line style and thickness or a specified line style and thickness for this annotation.
	UseDocDisplLeader	Gets or sets whether to use the document's leader's line style and thickness or a specified line style and thickness for this annotation.
	Visible	Gets or sets the visibility state of this annotation.
	Width	Gets or sets the line width enumeration value for this annotation.

[Top](#)

Public Methods

Name	Description
 AddOrUpdateStyle	Adds or updates the annotation linked to the specified style.
 ApplyDefaultStyleAttributes	Applies the default style attribute to this annotation.
 CanShowInAnnotationView	Gets whether this annotation can be shown in the specified annotation view .
 CanShowInMultipleAnnotationViews	Gets whether this annotation can be shown in multiple annotation views .
 CheckSpelling	Spell checks the text in this annotation.
 ConvertToMultiJog	Converts a note with a leader to a note with a multi-jog leader.
 DeleteStyle	Deletes the specified style.
 DeSelect	Deselects this annotation.
 GetArrowHeadCount	Gets the number of arrowheads on this symbol.
 GetArrowHeadSizeAtIndex	Gets the arrow head size of the specified leader on this annotation.
 GetArrowHeadStyleAtIndex	Gets the arrow head style of a specific leader on this annotation.
 GetAttachedEntities	Obsolete. Superseded by IAnnotation::GetAttachedEntities2.
 GetAttachedEntities2	Obsolete. Superseded by IAnnotation::GetAttachedEntities3.
 GetAttachedEntities3	Gets the entities to which this annotation is attached.
 GetAttachedEntityCount2	Obsolete. Superseded by IAnnotation::GetAttachedEntityCount3.
 GetAttachedEntityCount3	Gets the number of entities to which this annotation is attached.
 GetAttachedEntityTypes	Gets the types of entities attached to this annotation.
 GetBentLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle.
 GetDashedLeader	Gets whether this leader is a dashed line or a solid line.
 GetDimXpertFeature	Gets the DimXpert feature associated with this annotation.
 GetDimXpertName	Gets the DimXpert name for this annotation.
 GetDisplayData	Gets the display data for this annotation.
 GetFlipPlaneTransform	Gets the transformation matrix of the annotation plane in the opposite direction.
 GetLeader	Obsolete. Superseded by IAnnotation::GetLeaderStyle.
 GetLeaderAllAround	Gets the setting for all-around symbol display of this annotation.

	GetLeaderCount	Gets the number of leaders on this annotation.
	GetLeaderPerpendicular	Gets the perpendicular bent leader display setting for this annotation.
	GetLeaderPointsAtIndex	Gets coordinate information about a specified leader on this annotation.
	GetLeaderSide	Gets the leader attachment side setting for this annotation.
	GetLeaderStyle	Gets the style of this leader.
	GetMultiJogLeaderCount	Gets the number of multi-jog leaders on this annotation.
	GetMultiJogLeaders	Gets the multi-jog leaders on this annotation.
	GetName	Gets the name of this annotation.
	GetNext	Obsolete. Superseded by IAnnotation::GetNext3 .
	GetNext2	Obsolete. Superseded by IAnnotation::GetNext3 .
	GetNext3	Gets the next annotation.
	GetParagraphs	Gets the paragraphs in this note annotation.
	GetPlane	Gets the rotation matrix of the annotation relative to the X-Y plane of the model.
	GetPMIData	Gets the Product and Manufacturing Information (PMI) feature data object for this STEP 242 annotation.
	GetPMIType	Gets the type of Product and Manufacturing Information (PMI) associated with this STEP 242 annotation.
	GetPosition	Gets the position of this annotation.
	GetSmartArrowHeadStyle	Gets the setting for smart arrowhead style for this annotation.
	GetSpecificAnnotation	Gets the specific underlying object associated with this annotation.
	GetStyleName	Gets the name of the style applied to this annotation.
	GetTextFormat	Gets the text format for the specified text in this annotation.
	GetTextFormatCount	Gets the number of text formats for this annotation.
	GetType	Gets the type of the annotation.
	GetUseDocTextFormat	Gets whether SOLIDWORKS is currently using the document default text format setting for this annotation.
	GetVisualProperties	Gets the visual properties of this annotation.
	IGetAttachedEntities	Obsolete. Superseded by IAnnotation::GetAttachedEntities2 .
	IGetAttachedEntityCount	Obsolete. Superseded by IAnnotation::GetAttachedEntityCount2 .
	IGetAttachedEntityTypes	Gets the types of all entities attached to this annotation.
	IGetDisplayData	Gets the display data for the annotation.
	IGetLeaderPointsAtIndex	Gets coordinate information about a specified leader on this annotation.
	IGetMultiJogLeaders	Gets the multi-jog leaders on this annotation.
	IGetNext	Obsolete. Superseded by IAnnotation::GetNext3 .
	IGetNext2	Obsolete. Superseded by IAnnotation::GetNext3 .
	IGetPosition	Gets the position of this annotation.
	IGetSpecificAnnotation	Gets the specific underlying object associated with this annotation.
	IGetTextFormat	Gets the text format for the specified text in this annotation.
	IGetVisualProperties	Gets the visual properties of this annotation.
	IsDangling	Gets whether this annotation is dangling.
	IsDimXpert	Gets whether the annotation is a DimXpert annotation.
	ISetAttachedEntities	Attaches this annotation to the specified entities.
	ISetTextFormat	Sets the text format information for the specified text within this annotation.
	LoadStyle	Loads the specified style.
	SaveStyle	Saves the specified style.
	Select	Obsolete. Superseded by IAnnotation::Select3 .

 Select2	Obsolete. Superseded by IAnnotation::Select3 .
 Select3	Selects this annotation and marks it.
 SelectByMark	Obsolete. Superseded by IAnnotation::Select3 .
 SetArrowHeadSizeAtIndex	Sets the size of the arrow head of the specified leader on this annotation.
 SetArrowHeadStyleAtIndex	Sets the arrow head style of a specific leader on this annotation.
 SetAttachedEntities	Attaches this annotation to the specified entities.
 SetLeader	Obsolete. Superseded by IAnnotation::SetLeader3 .
 SetLeader2	Obsolete. Superseded by IAnnotation::SetLeader3 .
 SetLeader3	Sets the leader characteristics for this annotation.
 SetLeaderAttachmentPointAtIndex	Sets the specified attachment point of a leader for an annotation with the specified index.
 SetName	Sets the name of this annotation.
 SetPosition	Obsolete. Superseded by IAnnotation::SetPosition2 .
 SetPosition2	Sets the position of this annotation.
 SetStyleName	Sets the style for this annotation.
 SetTextFormat	Sets the text format for the specified text in this annotation.

[Top](#)

See Also

[IAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetObjectById Method\(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) ; IAnnotation Interface

For a list of all members of this type, see [IAnnotation members](#).

Public Properties

Name	Description
 AnnotationView	Gets the annotation view for this annotation.
 BentLeaderLength	Gets or sets the length of the bent leader for this annotation.
 Color	Gets or sets the color of this annotation. Annotation color is supported only in SOLIDWORKS drawings.
 FrameLineStyle	Gets or sets the frame's line style for this annotation.
 FrameThickness	Gets or sets the frame's line thickness for this annotation.
 FrameThicknessCustom	Gets or sets the frame's line thickness for this annotation.
 Layer	Gets or sets the layer used by this annotation. Layers are supported only in SOLIDWORKS drawings.
 LayerOverride	Gets or sets whether the annotation has properties that override the default properties of the layer.
 LeaderLineStyle	Gets or sets the leader's lines style for this annotation.
 LeaderThickness	Gets or sets the leader's line thickness for this annotation.
 LeaderThicknessCustom	Gets or sets the leader's custom line thickness for this annotation.
 Owner	Gets the owner of this annotation. NOTE: This property is a get-only property. Set is not implemented.
 OwnerType	Gets the type of owner of this annotation. NOTE: This property is a get-only property. Set is not implemented.
 Style	Gets or sets the line style for this annotation.

	UseDocDispFrame	Gets or sets whether to use the document's frame's line style and thickness or a specified line style and thickness for this annotation.
	UseDocDispLeader	Gets or sets whether to use the document's leader's line style and thickness or a specified line style and thickness for this annotation.
	Visible	Gets or sets the visibility state of this annotation.
	Width	Gets or sets the line width enumeration value for this annotation.

[Top](#)

See Also

[IAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetObjectID Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddOrUpdateStyle Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : AddOrUpdateStyle Method (IAnnotation)

Adds or updates the annotation linked to the specified style.

.NET Syntax

Visual Basic (Declaration)

```
Function AddOrUpdateStyle( _
    ByVal StyleName As System.String, _
    ByVal BreakLinks As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim StyleName As System.String
Dim BreakLinks As System.Boolean
Dim value As System.Boolean

value = instance.AddOrUpdateStyle(StyleName, BreakLinks)
```

C#

```
System.bool AddOrUpdateStyle(
    System.string StyleName,
    System.bool BreakLinks
)
```

C++/CLI

```
System.bool AddOrUpdateStyle(
    & System.String^ StyleName,
    & System.bool BreakLinks
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName
Name of the style to add or update
BreakLinks
True to break all links to this style, false to not

Return Value

Ture if the operation succeeds, false if it fails

Visual Basic for Applications (VBA) Syntax

See [Annotation::AddOrUpdateStyle](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::ApplyDefaultStyleAttributes Method](#)
[IAnnotation::DeleteStyle Method](#)
[IAnnotation::GetStyleName Method](#)
[IAnnotation::LoadStyle Method](#)
[IAnnotation::SaveStyle Method](#)
[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AnnotationView Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : AnnotationView Property (IAnnotation)

Gets the annotation view for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property AnnotationView As AnnotationView
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As AnnotationView  
  
value = instance.AnnotationView
```

C#

```
AnnotationView AnnotationView {get;}
```

C++/CLI

```
property AnnotationView^ AnnotationView {  
    AnnotationView^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Annotation view](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::AnnotationView](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplyDefaultStyleAttributes Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : ApplyDefaultStyleAttributes Method (IAnnotation)

Applies the default style attribute to this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function ApplyDefaultStyleAttributes() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.ApplyDefaultStyleAttributes()
```

C#

```
System.bool ApplyDefaultStyleAttributes()
```

C++/CLI

```
System.bool ApplyDefaultStyleAttributes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the operation succeeds, false if it fails

Visual Basic for Applications (VBA) Syntax

See [Annotation::ApplyDefaultStyleAttributes](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::AddOrUpdateStyle Method](#)
[IAnnotation::DeleteStyle Method](#)
[IAnnotation::GetStyleName Method](#)
[IAnnotation::LoadStyle Method](#)
[IAnnotation::SaveStyle Method](#)
[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BentLeaderLength Property (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : BentLeaderLength Property (IAnnotation)

Gets or sets the length of the bent leader for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property BentLeaderLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Double  
  
instance.BentLeaderLength = value  
value = instance.BentLeaderLength
```

C#

```
System.double BentLeaderLength {get; set;}
```

C++/CLI

```
property System.double BentLeaderLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of the bent leader or -1 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::BentLeaderLength](#).

Example

[Insert GTol \(C#\)](#)
[Insert GTol \(VB.NET\)](#)
[Insert GTol \(VBA\)](#)

Remarks

This property returns -1 if:

- this [type](#) of annotation does not support bent leaders,
- this annotation does not have a bent leader, or
- the length of the bent leader is set by a [document property](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CanShowInAnnotationView Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : CanShowInAnnotationView Method (IAnnotation)

Gets whether this annotation can be shown in the specified [annotation view](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CanShowInAnnotationView( _  
    ByVal AnnotationViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim AnnotationViewName As System.String
Dim value As System.Boolean

value = instance.CanShowInAnnotationView(AnnotationViewName)
```

C#

```
System.bool CanShowInAnnotationView(
    System.string AnnotationViewName
)
```

C++/CLI

```
System.bool CanShowInAnnotationView(
    & System.String^ AnnotationViewName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AnnotationViewName
Name of annotation view in which to show this annotation (see **Remarks**)

Return Value

True if this annotation can be shown in the specified annotation view, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::CanShowInAnnotationView](#).

Example

[Get Where Annotations Can Be Shown \(C#\)](#)
[Get Where Annotations Can Be Shown \(VB.NET\)](#)
[Get Where Annotations Can Be Shown \(VBA\)](#)

Remarks

Use [IFeature::Name](#) to get the name of the annotation view. See the examples for details.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::CanShowInMultipleAnnotationViews Method \(\)](#)
[IAnnotationView::Hide Method \(\)](#)
[IAnnotationView::IsShown Method \(\)](#)
[IAnnotationView::Show Method \(\)](#)

Availability

SOLIDWORKS 2015 SP1, Revision Number 23.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

CanShowInMultipleAnnotationViews Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : CanShowInMultipleAnnotationViews Method (IAnnotation)

Gets whether this annotation can be shown in multiple [annotation views](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CanShowInMultipleAnnotationViews() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.CanShowInMultipleAnnotationViews()
```

C#

```
System.bool CanShowInMultipleAnnotationViews()
```

C++/CLI

```
System.bool CanShowInMultipleAnnotationViews();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this annotation can be shown in multiple annotation views, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::CanShowInMultipleAnnotationViews](#).

Example

[Get Where Annotations Can Be Shown \(C#\)](#)
[Get Where Annotations Can Be Shown \(VB.NET\)](#)
[Get Where Annotations Can Be Shown \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::CanShowInAnnotationView Method \(\)](#)
[IAnnotationView::Hide Method \(\)](#)
[IAnnotationView::IsShown Method \(\)](#)
[IAnnotationView::Show Method \(\)](#)

Availability

SOLIDWORKS 2015 SP1, Revision Number 23.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

CheckSpelling Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : CheckSpelling Method (IAnnotation)

Spell checks the text in this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function CheckSpelling( _  
    ByVal Options As System.Integer, _  
    ByVal Dictionary As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Options As System.Integer  
Dim Dictionary As System.String  
Dim value As System.Object  
  
value = instance.CheckSpelling(Options, Dictionary)
```

C#

```
System.object CheckSpelling(  
    System.int Options,  
    System.string Dictionary  
)
```

C++/CLI

```
System.Object^ CheckSpelling(  
& System.int Options,  
& System.String^ Dictionary  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Options

Spell-check options as defined in [swCheckSpellingOptions_e](#)

Dictionary

Full path and filename of user dictionary to use (see **Remarks**)

Return Value

Array of the misspelled words in this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::CheckSpelling](#).

Remarks

The SOLIDWORKS spell checker always uses a main dictionary, which is language specific. Use the Dictionary argument to specify an additional dictionary. If Dictionary is left blank, then no additional user dictionary is used.

You can also specify additional custom dictionaries by adding them in the appropriate location in the SOLIDWORKS registry.

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

Color Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Color Property (IAnnotation)

Gets or sets the color of this annotation. Annotation color is supported only in SOLIDWORKS drawings.

.NET Syntax

Visual Basic (Declaration)

```
Property Color As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#



```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

COLORREF value for the color of this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::Color](#).

Remarks

In Drawing documents, you can create annotations on a layer that has specific visual properties. The color value specified with this property overrides the layer color.

Use [IAnnotation::LayerOverride](#) to determine whether this annotation is using its default layer color.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConvertToMultiJog Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : ConvertToMultiJog Method (IAnnotation)

Converts a note with a leader to a note with a multi-jog leader.

.NET Syntax

Visual Basic (Declaration)

```
Function ConvertToMultiJog( _  
    ByVal LeaderNumber As System.Integer, _  
    ByVal NumberOfPoints As System.Integer, _  
    ByVal PointsData As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim LeaderNumber As System.Integer  
Dim NumberOfPoints As System.Integer  
Dim PointsData As System.Object  
Dim value As System.Boolean  
  
value = instance.ConvertToMultiJog(LeaderNumber, NumberOfPoints, PointsData)
```

C#

```
System.bool ConvertToMultiJog(  
    System.int LeaderNumber,  
    System.int NumberOfPoints,
```

```
System.Object PointsData
)
```

C++/CLI

```
System.bool ConvertToMultiJog(
& System.int LeaderNumber,
& System.int NumberOfPoints,
& System.Object^ PointsData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LeaderNumber

Number of the leader to convert in the 0-based list of leaders

NumberOfPoints

Number of jog points

PointsData

Array of doubles, whose size is 3*NumberOfPoints, that specify the points where to locate the jogs; the points are in sheet space

Return Value

True if the leader is converted to a multi-jog leader, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::ConvertToMultiJog](#).

Example

Visual Basic for Applications (VBA)

```
' Convert the first leader of the note to a two-point multi-jog leader
...
Dim vPointData as Variant
Dim nPoints (0 to 6) as Double
    nPoints(0) = 0.189013
    nPoints(1) = 0.248742
    nPoints(2) = -1.75647E-15
    nPoints(3) = 0.252176
    nPoints(4) = 0.186859
    nPoints(5) = -1.32434E-15
    ...
vPointData = nPoints
boolstatus = Annotation.ConvertToMultiJog(0, 2, (vPointData))
...
```

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

Deletes the specified style.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteStyle( _  
    ByVal StyleName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim StyleName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteStyle(StyleName)
```

C#

```
System.bool DeleteStyle(  
    System.string StyleName  
)
```

C++/CLI

```
System.bool DeleteStyle(  
& System.String^ StyleName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName
Name of the style to delete

Return Value

True if the operation succeeds, false if it fails

Visual Basic for Applications (VBA) Syntax

See [Annotation::DeleteStyle](#).

Remarks

The current style is set to **<NONE>**. Dimensions and annotations retain the properties previously applied by the style unless the items are [reset to the document default](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::AddOrUpdateStyle Method](#)
[IAnnotation::ApplyDefaultStyleAttributes Method](#)
[IAnnotation::GetStyleName Method](#)
[IAnnotation::LoadStyle Method](#)
[IAnnotation::SaveStyle Method](#)
[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0



Visual Basic Syntax

Visual Basic (Declaration)

```
Function DeSelect() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.DeSelect()
```

C#

```
System.bool DeSelect()
```

C++/CLI

```
System.bool DeSelect();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the feature object was successfully deselected, false otherwise

Visual Basic for Applications (VBA) Syntax

See [Annotation::DeSelect](#).

Remarks

Use [IModelDoc2::DeSelectByID](#) instead of using this method. This method does not work well when a PropertyManager page is open or a command is running. IModelDoc2::DeSelectByID handles selection correctly whether or not a command is running.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameLineStyle Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : FrameLineStyle Property (IAnnotation)

Gets or sets the frame's line style for this annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property FrameLineStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
instance.FrameLineStyle = value  
  
value = instance.FrameLineStyle
```

C#

```
System.int FrameLineStyle {get; set;}
```

C++/CLI

```
property System.int FrameLineStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Frame's line style as defined by [swLineStyles_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::FrameLineStyle](#).

Remarks

[IAnnotation::UseDocDispFrame](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::FrameThickness Property](#)
[IAnnotation::FrameThicknessCustom Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FrameThickness Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : FrameThickness Property (IAnnotation)

Gets or sets the frame's line thickness for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameThickness As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
instance.FrameThickness = value  
  
value = instance.FrameThickness
```

C#

```
System.int FrameThickness {get; set;}
```

C++/CLI

```
property System.int FrameThickness {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Frame's line thickness as defined by [swLineWeights](#) e

Visual Basic for Applications (VBA) Syntax

See [Annotation::FrameThickness](#).

Remarks

[IAnnotation::UseDocDispFrame](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::FrameLineStyle Property](#)
[IAnnotation::FrameThicknessCustom Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

FrameThicknessCustom Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : FrameThicknessCustom Property (IAnnotation)

Gets or sets the frame's line thickness for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property FrameThicknessCustom As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Double  
  
instance.FrameThicknessCustom = value  
  
value = instance.FrameThicknessCustom
```

C#

```
System.double FrameThicknessCustom {get; set;}
```

C++/CLI

```
property System.double FrameThicknessCustom {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of frame's line thickness

Visual Basic for Applications (VBA) Syntax

See [Annotation::FrameThicknessCustom](#).

Remarks

[IAnnotation::UseDocDispFrame](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::FrameLineStyle Property](#)
[IAnnotation::FrameThickness Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadCount Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetArrowHeadCount Method (IAnnotation)

Gets the number of arrowheads on this symbol.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of arrowheads on this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetArrowHeadCount](#).

Remarks

This method works with traditional leaders on annotations and [multijog leaders](#).

Call this method before calling [IAnnotation::GetArrowHeadSizeAtIndex](#) to specify the annotation for which to get the arrow head size.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetArrowHeadSizeAtIndex Method](#)
[IAnnotation::GetArrowHeadStyleAtIndex Method](#)
[IAnnotation::SetArrowHeadStyleAtIndex Method](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadSizeAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetArrowHeadSizeAtIndex Method (IAnnotation)

Gets the arrow head size of the specified leader on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadSizeAtIndex( _  
    ByVal Index As System.Integer, _  
    ByRef UseDoc As System.Boolean, _  
    ByRef Length As System.Double, _  
    ByRef Width As System.Double, _  
    ByRef Height As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim UseDoc As System.Boolean  
Dim Length As System.Double  
Dim Width As System.Double  
Dim Height As System.Double  
Dim value As System.Boolean  
  
value = instance.GetArrowHeadSizeAtIndex(Index, UseDoc, Length, Width, Height)
```

C#

```
System.bool GetArrowHeadSizeAtIndex(  
    System.int Index,  
    out System.bool UseDoc,  
    out System.double Length,  
    out System.double Width,  
    out System.double Height  
)
```

C++/CLI

```
System.bool GetArrowHeadSizeAtIndex(  
& System.int Index,  
& [Out] System.bool UseDoc,  
& [Out] System.double Length,  
& [Out] System.double Width,  
& [Out] System.double Height  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of leader on this annotation

UseDoc

TRUE indicates that the document default setting for arrow head size was used, FALSE indicates that the Length, Width, and Height values were specified

Length

Length of arrow head

Width

Width of arrow head

Height

Height of arrow head

Return Value

True if the method succeeds, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetArrowHeadSizeAtIndex](#).

Remarks

The index value is 0-based. Therefore, a valid index value is greater than or equal to 0, but less than the number of leaders on this annotation. Use [IAnnotation::GetArrowHeadCount](#) to find the number of leaders on this annotation. If the index value is invalid, SOLIDWORKS returns the arrowhead style as -1, and returns an S_FALSE status (COM interface).

Use [IAnnotation::SetArrowHeadSizeAtIndex](#) to set the arrow head size of a specific leader.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetArrowHeadStyleAtIndex Method](#)
[IAnnotation::SetArrowHeadStyleAtIndex Method](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetArrowHeadStyleAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetArrowHeadStyleAtIndex Method (IAnnotation)

Gets the arrow head style of a specific leader on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadStyleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetArrowHeadStyleAtIndex(Index)
```

C#

```
System.int GetArrowHeadStyleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetArrowHeadStyleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of leader within this annotation (see **Remarks**)

Return Value

Arrowhead style as defined in [swArrowStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetArrowHeadStyleAtIndex](#).

Remarks

The index value is 0-based. Therefore, a valid index value is greater than or equal to 0, but less than the number of leaders on this annotation. Use [IAnnotation::GetArrowHeadCount](#) to find the number of leaders on this annotation. If the index value is invalid, SOLIDWORKS returns the arrowhead style as -1, and returns an S_FALSE status (COM interface).

Use [IAnnotation::SetArrowHeadStyleAtIndex](#) to set the arrow head style of a specific leader.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetArrowHeadStyleAtIndex Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachedEntities Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntities Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetAttachedEntities2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntities() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetAttachedEntities()
```

C#

```
System.object GetAttachedEntities()
```

C++/CLI

```
System.Object^ GetAttachedEntities();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntities](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachedEntities2 Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntities2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetAttachedEntities3](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntities2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetAttachedEntities2()
```

C#

```
System.Object GetAttachedEntities2()
```

C++/CLI

```
System.Object^ GetAttachedEntities2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of objects

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntities2](#).

Example

[Get Types of Entities for Selected Dimension \(VBA\)](#)
[Get BOM Balloon Properties \(C#\)](#)
[Get BOM Balloon Properties \(VB.NET\)](#)
[Get BOM Balloon Properties \(VBA\)](#)

Remarks

This method now supports all annotation types. See [IAnnotation::GetType](#) to determine the type of annotation.

The array returned by this function may contain one or more objects of varying type. To determine the corresponding object type in the [IAnnotation::GetAttachedEntities2](#) array, see [IAnnotation::GetAttachedEntityTypes](#). COM applications can use [QueryInterface](#) to obtain the specific object from the LPUNKNOWN pointer.

Object Type	Object Returned
swSelFACES	IFace2
swSelEDGES	IEdge
swSelVERTICES	IVertex
swSelSKETCHSEGS	ISketchSegment
swSelSKETCHPOINTS	ISketchPoint
swSelNOTHING	NULL (annotation is dangling or unsupported)

You can associate annotations with some items not listed in the previous table (for example, origins). If this annotation is attached to one or more of those entities, then SOLIDWORKS returns a corresponding NULL in one of the array positions and [IAnnotation::GetAttachedEntityTypes](#) indicates the unsupported entity by returning a corresponding [swSelNOTHING](#) value. COM applications that call [IAnnotation::GetAttachedEntityCount2](#) include the NULL value in the total count of associated entities.

Likewise, if an annotation has become disassociated from its geometry, then SOLIDWORKS returns a corresponding NULL in one of the array positions and [IAnnotation::GetAttachedEntityTypes](#) indicates the dangling item by returning a corresponding [swSelNOTHING](#) value.

If this annotation is not associated with any geometry (for example, a note without a leaderline), then SOLIDWORKS returns an empty array.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetAttachedEntityCount2 Method](#)
[IAnnotation::GetAttachedEntityTypes Method](#)
[IAnnotation::GetNext3 Method](#)
[IAnnotation::GetType Method](#)
[IAnnotation::SetAttachedEntities Method](#)
[IAttribute::GetEntity Method](#)

[IAttribute::IGetEntity2 Method](#)
[IAttribute::GetEntityState Method](#)
[IEntity Interface](#)
[IEntity::GetSafeEntity Method](#)
[IFaultEntity::Entity2 Property](#)
[IModelDocExtension::GetCorrespondingEntity Method](#)
[IPartDoc::GetEntityName Method](#)
[IPartDoc::GetNamedEntities Method](#)
[IView::GetVisibleEntities Method](#)
[IAnnotation::SetAttachedEntities Method](#)
[IAnnotation::ISetAttachedEntities Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachedEntities3 Method (IAnnotation)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntities3 Method (IAnnotation)

Gets the entities to which this annotation is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntities3() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetAttachedEntities3()
```

C#

```
System.object GetAttachedEntities3()
```

C++/CLI

```
System.Object^ GetAttachedEntities3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of objects

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntities3](#).

Example

[Get Types of Entities Attached to Selected Annotation \(VBA\)](#)
[Get Types of Entities Attached to Selected Annotation \(VB.NET\)](#)
[Get Types of Entities Attached to Selected Annotation \(C#\)](#)
[Select Silhouette Edge Attached to Note \(C#\)](#)
[Select Silhouette Edge Attached to Note \(VB.NET\)](#)
[Select Silhouette Edge Attached to Note \(VBA\)](#)
[Attach Annotation to Entity \(C#\)](#)
[Attach Annotation to Entity \(VB.NET\)](#)
[Attach Annotation to Entity \(VBA\)](#)

Remarks

This method now supports all annotation types. See [IAnnotation::GetType](#) to determine the type of annotation.

The array returned by this function may contain one or more objects of varying type. To determine the corresponding object type in the IAnnotation::GetAttachedEntites3 array, see [IAnnotation::GetAttachedEntityTypes](#) or [IAnnotation::IGetAttachedEntityTypes](#). COM applications can use QueryInterface to obtain the specific object from the LPUNKNOWN pointer.

Object Type

Object Returned

swSelFACES	IFace2
swSelEDGES	IEdge
swSelVERTICES	IVertex
swSelSKETCHSEGS	ISketchSegment
swSelSKETCHPOINTS	ISketchPoint
swSelSilhouettes	ISilhouetteEdge
swSelNOTHING	NULL (annotation is dangling or unsupported)

You can associate annotations with some items not listed in the previous table (for example, origins). If this annotation is attached to one or more of those entities, then SOLIDWORKS returns a corresponding NULL in one of the array positions and `IAnnotation::GetAttachedEntityTypes` indicates the unsupported entity by returning a corresponding `swSelNOTHING` value. COM applications that call [IAnnotation::GetAttachedEntityCount3](#) include the NULL value in the total count of associated entities.

Likewise, if an annotation has become disassociated from its geometry, then SOLIDWORKS returns a corresponding NULL in one of the array positions and [IAnnotation::GetAttachedEntityTypes](#) indicates the dangling item by returning a corresponding `swSelNOTHING` value.

If this annotation is not associated with any geometry (for example, a note without a leaderline), then SOLIDWORKS returns an empty array.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetNext3 Method](#)
[IAnnotation::ISetAttachedEntities Method](#)
[IAnnotation::SetAttachedEntities Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachedEntityCount2 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntityCount2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetAttachedEntityCount3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntityCount2() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Integer

value = instance.GetAttachedEntityCount2()
```

C#

```
System.int GetAttachedEntityCount2()
```

C++/CLI

```
System.int GetAttachedEntityCount2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities to which this annotation is attached

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntityCount2](#).

Remarks

This method supports all annotation types. See [IAnnotation::GetType](#) to determine the type of annotation.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation Interface](#)
[IAnnotation::GetAttachedEntities2 Method](#)
[IAnnotation::GetAttachedEntityTypes Method](#)
[IAnnotation::GetNext3 Method](#)
[IAnnotation::GetType Method](#)
[IAnnotation::ISetAttachedEntities Method](#)
[IAnnotation::IGetAttachedEntityTypes Method](#)
[IAnnotation::SetAttachedEntities Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAttachedEntityCount3 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntityCount3 Method (IAnnotation)

Gets the number of entities to which this annotation is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntityCount3() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetAttachedEntityCount3()
```

C#

```
System.int GetAttachedEntityCount3()
```

C++/CLI

```
System.int GetAttachedEntityCount3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities to which this annotation is attached

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntityCount3](#).

Remarks

This method supports all annotation types. See [IAnnotation::GetType](#) to determine the type of annotation.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetAttachedEntities3 Method](#)
[IAnnotation::GetAttachedEntityTypes Method](#)
[IAnnotation::GetNext3 Method](#)
[IAnnotation::GetType Method](#)
[IAnnotation::IGetAttachedEntityTypes Method](#)
[IAnnotation::ISetAttachedEntities Method](#)
[IAnnotation::SetAttachedEntities Method](#)

Availability

GetAttachedEntityTypes Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetAttachedEntityTypes Method (IAnnotation)

Gets the types of entities attached to this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttachedEntityTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.GetAttachedEntityTypes()
```

C#

```
System.object GetAttachedEntityTypes()
```

C++/CLI

```
System.Object^ GetAttachedEntityTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers (see [Long vs. Integer](#)) that indicate the attached entity types as defined in [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetAttachedEntityTypes](#).

Example

[Attach Annotation to Entity \(C#\)](#)
[Attach Annotation to Entity \(VB.NET\)](#)
[Attach Annotation to Entity \(VBA\)](#)

Remarks

This method supports all annotation types. Use [IAnnotation::GetType](#) to determine the annotation type.

This method returns an array of longs or integers indicating object types. The list of object types corresponds to the list of objects returned by [IAnnotation::GetAttachedEntities3](#).

You can associate annotations with additional items not listed in [swSelectType_e](#). If this annotation is attached to one or more entities not listed in [swSelectType_e](#), then this method and [IAnnotation::GetAttachedEntityTypes](#) return [swSelNOTHING](#) in a position in the array corresponding to the unlisted item. [IAnnotation::GetAttachedEntities3](#) indicates an unsupported entity by returning a null value in the position in the array corresponding to the unsupported entity. COM applications that call [IAnnotation::GetAttachedEntityCount3](#) include the null value in the total count of associated entities.

If an annotation is disassociated from its geometry (i.e., dangling), then [IAnnotation::GetAttachedEntities3](#) returns a null value in the position in the array corresponding to the dangling item, and this method returns [swSelNOTHING](#) in the position in the array corresponding to the dangling item.

NOTE: If this annotation is not associated with any geometry, then this method and [IAnnotation::GetAttachedEntities3](#) return empty arrays.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetAttachedEntities Method](#)

Availability

GetBentLeader Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetBentLeader Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetLeaderStyle](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBentLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.GetBentLeader()
```

C#

```
System.bool GetBentLeader()
```

C++/CLI

```
System.bool GetBentLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetBentLeader](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

GetDashedLeader Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetDashedLeader Method (IAnnotation)

Gets whether this leader is a dashed line or a solid line.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDashedLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.GetDashedLeader()
```

C#

```
System.bool GetDashedLeader()
```

C++/CLI

```
System.bool GetDashedLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if leader is dashed line, false if it is solid line

 Visual Basic for Applications (VBA) Syntax

See [Annotation::GetDashedLeader](#).

 Remarks

A datum target symbol is the only type of annotation that uses dashed leaders. For all other types of annotations, this method returns false, which indicates that the leader is a solid line.

Use...	To...
IAnnotation::GetLeaderStyle	Get leader characteristics
IAnnotation::SetLeader3	Set leader characteristics

 See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)

 Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimXpertFeature Method (IAnnotation)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetDimXpertFeature Method (IAnnotation)

Gets the DimXpert feature associated with this annotation.

 .NET Syntax

Visual Basic (Declaration)
<pre>Function GetDimXpertFeature() As System.Object</pre>
Visual Basic (Usage)
<pre>Dim instance As IAnnotation Dim value As System.Object value = instance.GetDimXpertFeature()</pre>
C#
<pre>System.object GetDimXpertFeature()</pre>
C++/CLI
<pre>System.Object^ GetDimXpertFeature();</pre>

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[DimXpert feature](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetDimXpertFeature](#).

Example

[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

If an annotation is a display dimension, then use [IAnnotation::IsDimXpert](#) to determine if it is a DimXpert annotation. If it is, then use [IAnnotation::GetDimXpertFeature](#) to access the DimXpert feature, which provides access to the display dimension information.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IDisplayDimension::IsDimXpert Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDimXpertName Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetDimXpertName Method (IAnnotation)

Gets the DimXpert name for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimXpertName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.String  
  
value = instance.GetDimXpertName()
```

C#

```
System.string GetDimXpertName()
```

C++/CLI

```
System.String^ GetDimXpertName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

DimXpert name

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetDimXpertName](#).

Example

[Get DimXpert Display Dimensions and Features \(C#\)](#)
[Get DimXpert Display Dimensions and Features \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Features \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetName Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayData Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetDisplayData Method (IAnnotation)

Gets the display data for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.GetDisplayData()
```

C#

```
System.object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Object for the display data

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetDisplayData](#).

Example

[Get Centerline Annotation Information \(VBA\)](#)
[Get Weld Bead Symbol Data \(VBA\)](#)
[Get Weld Bead Symbol Data \(VB.NET\)](#)
[Get Weld Bead Symbol Data \(C#\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IDisplayData Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFlipPlaneTransform Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetFlipPlaneTransform Method (IAnnotation)

Gets the transformation matrix of the annotation plane in the opposite direction.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFlipPlaneTransform() As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As MathTransform  
  
value = instance.GetFlipPlaneTransform()
```

C#

```
MathTransform GetFlipPlaneTransform()
```

C++/CLI

```
MathTransform^ GetFlipPlaneTransform();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Transformation matrix](#) of the annotation plane in the opposite direction

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetFlipPlaneTransform](#).

Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2015 SP1, Revision Number 23.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeader Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeader Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetLeaderStyle](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.GetLeader()
```

C#

```
System.bool GetLeader()
```

C++/CLI

```
System.bool GetLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeader](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderAllAround Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderAllAround Method (IAnnotation)

Gets the setting for all-around symbol display of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderAllAround() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Boolean

value = instance.GetLeaderAllAround()
```

C#

```
System.bool GetLeaderAllAround()
```

C++/CLI

```
System.bool GetLeaderAllAround();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this annotation has the all-around symbol enabled, false if this annotation has the all-around symbol disabled

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderAllAround](#).

Remarks

The all-around display flag is a characteristic of the annotation, not of individual leaders. You can get or set it whether leaders are displayed.

If bent leaders are disabled for this annotation, you can still get or set the all-around display flag. However, SOLIDWORKS does not use it to display the annotation.

The all-around symbol applies only to geometric tolerances and weld symbols. For all other types of annotations, this method returns false.

Use...

[IAnnotation::GetLeaderStyle](#)

[IAnnotation::SetLeader3](#)

To...

Get leader characteristics

Set leader characteristics

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDispLeader Property \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLeaderCount Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderCount Method (IAnnotation)

Gets the number of leaders on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer
```

```
value = instance.GetLeaderCount()
```

C#

```
System.int GetLeaderCount()
```

C++/CLI

```
System.int GetLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of leaders

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderCount](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)

Remarks

If leader display is disabled for this annotation, then the number of leaders is 0.

Use...	To...
IAnnotation::GetLeaderStyle	Get leader characteristics
IAnnotation::SetLeader3	Set leader characteristics

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide \(\)](#)

[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)
[IAnnotation::SetLeaderAttachmentPointAtIndex Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderPerpendicular Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderPerpendicular Method (IAnnotation)

Gets the perpendicular bent leader display setting for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderPerpendicular() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.GetLeaderPerpendicular()
```

C#

```
System.bool GetLeaderPerpendicular()
```

C++/CLI

```
System.bool GetLeaderPerpendicular();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this annotation has perpendicular bent leader display enabled, false if this annotation has perpendicular bent leader display disabled

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderPerpendicular](#).

Remarks

The perpendicular bent leader display flag is a characteristic of the annotation, not individual leaders. You can get or set it whether leaders are displayed.

If this annotation has bent leaders disabled, then you can still get or set the perpendicular bent leader flag. However, SOLIDWORKS does not use it to display the annotation.

The perpendicular bent leader display flag applies only to geometric tolerances. For all other types of annotations, this method returns false.

Use...	To...
IAnnotation::GetLeaderStyle	Get leader characteristics
IAnnotation::SetLeader3	Set leader characteristics

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)

GetLeaderPointsAtIndex Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderPointsAtIndex Method (IAnnotation)

Gets coordinate information about a specified leader on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderPointsAtIndex( _
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLeaderPointsAtIndex(Index)
```

C#

```
System.object GetLeaderPointsAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLeaderPointsAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of leader within this annotation (see **Remarks**)

Return Value

Array of objects (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderPointsAtIndex](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)

Remarks

The index value is 0-based. Therefore, a valid index value is $\geq 0 < \text{number of leaders on this annotation}$.

Use [IAnnotation::GetLeaderCount](#) to find out how many leaders are on this annotation. If the index value is invalid in Visual Basic for Applications (VBA), SOLIDWORKS returns an empty SafeArray or S_false.

You must determine the number of points in the leader to use the data returned by this method. The number of points is a function of the number of segments in the leader. There can be one or two segments in a leader line, depending on whether or not it is a straight, bent, or underlined leader. Use [IAnnotation::GetLeaderStyle](#) to determine the number of points in the leader.

- If IAnnotation::GetLeaderStyle returns swNO_LEADER, then the number of points = 0.
- If IAnnotation::GetLeaderStyle returns swSTRAIGHT and swUNDERLINED then the number of points = 2.
- If IAnnotation::GetLeaderStyle returns swBENT, then the number of points = 3.

Additionally, for the COM interface, you must determine the number of points to allocate the appropriate size array for the return value. The number of points must also be passed to the method to help prevent overwrite problems if you have not allocated an array that is the correct size. If the number of points passed does not match what is found, SOLIDWORKS does not return any point information and returns S_false.

The format of the return array is:

retval[0] = X-coordinate of first leader point

retval[1] = Y-coordinate of first leader point

retval[2] = Z-coordinate of first leader point

retval[3] = X-coordinate of second leader point

retval[4] = Y-coordinate of second leader point

retval[5] = Z-coordinate of second leader point

retval[6] = X-coordinate of third leader point

retval[7] = Y-coordinate of third leader point

retval[8] = Z-coordinate of third leader point

You cannot directly set the leader coordinate information. The leader coordinates are computed based on the annotations text and attachment points. Use [IAnnotation::GetPosition](#) and [IAnnotation::SetPosition](#) to get and set the text point.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::IGetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)
[IAnnotation::SetLeaderAttachmentPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderSide Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderSide Method (IAnnotation)

Gets the leader attachment side setting for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderSide() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetLeaderSide()
```

C#

```
System.int GetLeaderSide()
```

C++/CLI

```
System.int GetLeaderSide();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Leader side as define in [swLeaderSide](#) e

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderSide](#).

Remarks

The leader attachment side setting is a characteristic of the annotation, not of individual leaders. Therefore, you can get or set it regardless of whether leaders are currently displayed.

Use...	To...
IAnnotation::GetLeaderStyle	Get leader characteristics
IAnnotation::SetLeader3	Set leader characteristics

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeaderStyle Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetLeaderStyle Method (IAnnotation)

Gets the style of this leader.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderStyle() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetLeaderStyle()
```

C#

```
System.int GetLeaderStyle()
```

C++/CLI

```
System.int GetLeaderStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Style of the leader as defined by [swLeaderStyle](#) e

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetLeaderStyle](#).

Remarks

Use [IAnnotation::SetLeader3](#) to set the leader style.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDisplLeader Property \(\)](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMultiJogLeaderCount Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetMultiJogLeaderCount Method (IAnnotation)

Gets the number of multi-jog leaders on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMultiJogLeaderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetMultiJogLeaderCount()
```

C#

```
System.int GetMultiJogLeaderCount()
```

C++/CLI

```
System.int GetMultiJogLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetMultiJogLeaderCount](#).

Remarks

Call this method before calling [IAnnotation::GetMultiJogLeaders](#) to determine the size of the array for that method.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)

[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDispLeader Property \(\)](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMultiJogLeaders Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetMultiJogLeaders Method (IAnnotation)

Gets the multi-jog leaders on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMultiJogLeaders() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetMultiJogLeaders()
```

C#

```
System.Object GetMultiJogLeaders()
```

C++/CLI

```
System.Object^ GetMultiJogLeaders();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the [multi-jog leaders](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetMultiJogLeaders](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::IGetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDispLeader Property \(\)](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

GetName Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetName Method (IAnnotation)

Gets the name of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetName](#).

Example

[Change Text Format \(VBA\)](#)
[Get Display Dimensions, Gtols, and Surface-finish Symbols \(VBA\)](#)
[Get Table Annotation and Contents \(VBA\)](#)
[Get Types of Entities for Selected Dimension \(VBA\)](#)
[Set BOM Balloon \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetName Method](#)
[IAnnotation::GetDimXpertName Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

GetNext Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetNext Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetNext3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetNext](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext2 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetNext2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetNext3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext2() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetNext2()
```

C#

```
System.object GetNext2()
```

C++/CLI

```
System.Object^ GetNext2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetNext2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

GetNext3 Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetNext3 Method (IAnnotation)

Gets the next annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext3() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As Annotation  
  
value = instance.GetNext3()
```

C#

```
Annotation GetNext3()
```

C++/CLI

```
Annotation^ GetNext3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAnnotation](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetNext3](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Entities Attached to Cosmetic Thread \(VBA\)](#)
[Show Dimensions in Drawing Sheet \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

This method:

- retrieves all display dimensions, including suppressed, hidden, and dangling dimensions, on the sheet and on the sheet format if it is visible. See [ISheet::SheetFormatVisible](#) for details
- retrieves all instances of a dimension. For example, if a (4X) instance dimension is visible in the user interface, this method gets the 4X dimension and each of its four dimension instances.
- retrieves an annotation, even if it is on a layer that is not displayed.

A dimension is suppressed or hidden when you:

- specifically select a dimension and hide it.

- or -

- select a feature and hide all dimensions.

If you need to filter out suppressed or hidden dimensions, use [IAnnotation::Visible](#) to check the visibility status.

To get the first annotation on the sheet, call [IView::GetFirstAnnotation3](#) before calling this method.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IView::GetFirstAnnotation3 Method](#)

Availability

GetParagraphs Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetParagraphs Method (IAnnotation)

Gets the paragraphs in this note annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParagraphs() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.GetParagraphs()
```

C#

```
System.object GetParagraphs()
```

C++/CLI

```
System.Object^ GetParagraphs();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IParagraphs](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetParagraphs](#).

Example

[Get and Set Paragraph Properties \(VBA\)](#)
[Get and Set Paragraph Properties \(VB.NET\)](#)
[Get and Set Paragraph Properties \(C#\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

GetPlane Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetPlane Method (IAnnotation)

Gets the rotation matrix of the annotation relative to the X-Y plane of the model.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPlane() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object  
  
value = instance.GetPlane()
```

C#

```
System.object GetPlane()
```

C++/CLI

```
System.Object^ GetPlane();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of 9 doubles of the rotation matrix of the annotation relative to the X-Y plane of the model

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetPlane](#).

Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotationView::GetViewRotation Method \(\)](#)
[IAnnotationView::IGetViewRotation Method \(\)](#)
[IDisplayData::GetTextPlaneAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0