

SOLIDWORKS API (.NET, VBA, C#) — Reference (10/337): IAnnotation (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IAnnotation (part 2 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPMIData Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetPMIData Method (IAnnotation)

Gets the Product and Manufacturing Information (PMI) feature data object for this STEP 242 annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPMIData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.GetPMIData()
```

C#

```
System.Object GetPMIData()
```

C++/CLI

```
System.Object^ GetPMIData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPMIDatumData](#), [IPMIDimensionData](#), [IPMIGtolData](#); null or Nothing if the model is a drawing or no PMI data is associated with this annotation (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetPMIData](#).

Example

[Get PMI Data \(VBA\)](#)
[Get PMI Data \(C#\)](#)

Remarks

This method is not valid for drawings.

Use [IAnnotation::GetPMIType](#) to determine the feature data object returned by this method.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPMIType Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetPMIType Method (IAnnotation)

Gets the type of Product and Manufacturing Information (PMI) associated with this STEP 242 annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPMIType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetPMIType()
```

C#

```
System.int GetPMIType()
```

C++/CLI

```
System.int GetPMIType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

PMI type for this annotation as defined in [swPMIType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetPMIType](#).

Example

See the [IAnnotation::GetPMIData](#) example.

Remarks

This API does not yet support note annotations.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetPMIData Method \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPosition Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetPosition Method (IAnnotation)

Gets the position of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPosition() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object
```

```
value = instance.GetPosition()
```

C#

```
System.Object GetPosition()
```

C++/CLI

```
System.Object^ GetPosition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetPosition](#).

Example

[Insert Autoballoons \(VBA\)](#)
[Traverse Annotations \(C#\)](#)
[Traverse Annotations \(VB.NET\)](#)
[Traverse Annotations \(VBA\)](#)

Remarks

The retval is an array of 3 doubles, the x, y, z origin of the annotation.

If this method is not successful in retrieving the position of the annotation in Visual Basic for Applications (VBA), then the VARIANT SafeArray is empty (OLE Automation only), or the status value is S_false (COM only). Make sure that you check this value before using the returned position.

The following table lists the types of annotations that this method supports and the position of the x, y, z origin. In a drawing, the x, y, z origin is relative to the origin of the drawing sheet (the lower-left corner of the sheet).

Type of Annotation	Position of XYZ Origin
Datum Feature Symbols	Point where leader hits symbol
Datum Target Symbols	Centerpoint of the circle that is attached to the leader
Display Dimensions	Point of leader attachment centered on a text box border / center point of bottom border of text box
Geometric Tolerances	Upper-left corner of the symbol
Notes	Upper-left corner of the text box
Surface Finish Symbols	Lower-left point of symbol
Table Annotation	Position of x,y,z determined by TableAnnotation.AnchorType
Weld Symbols	Left endpoint of the main horizontal line in the symbol

If you use this method on any other types of annotations, SOLIDWORKS takes no action and returns false.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetPosition Method](#)
[IAnnotation::SetPosition Method](#)
[INote::LockPosition Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0.

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSmartArrowHeadStyle Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetSmartArrowHeadStyle Method (IAnnotation)

Gets the setting for smart arrowhead style for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSmartArrowHeadStyle() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Boolean

value = instance.GetSmartArrowHeadStyle()
```

C#

```
System.bool GetSmartArrowHeadStyle()
```

C++/CLI

```
System.bool GetSmartArrowHeadStyle();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the smart arrowhead style setting is enabled, false if the smart arrowhead style setting is disabled

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetSmartArrowHeadStyle](#).

Remarks

The smart arrowhead style flag is a characteristic of the annotation, not individual leaders. You can get or set it whether or not leaders are currently displayed.

Use...	To...
IAnnotation::GetLeaderStyle	Get leader characteristics
IAnnotation::SetLeader3	Set leader characteristics

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSpecificAnnotation Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetSpecificAnnotation Method (IAnnotation)

Gets the specific underlying object associated with this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSpecificAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.GetSpecificAnnotation()
```

C#

```
System.Object GetSpecificAnnotation()
```

C++/CLI

```
System.Object^ GetSpecificAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Specific object underlying this annotation or null (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetSpecificAnnotation](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

If this annotation contains only Product and Manufacturing Information (PMI), then this method returns null. In that case, use [IAnnotation::GetPMIType](#) and [IAnnotation::GetPMIData](#) to obtain the PMI data associated with this annotation.

If this annotation is a note, then this method returns the underlying [INote](#).

Dispatch applications can use [IAnnotation::GetType](#) to determine the type of underlying object supported. For example, if the return value from [IAnnotation::GetType](#) is `swWeldSymbol`, then you know that you can use the Dispatch pointer returned from this method with the [IWeldSymbol](#) class.

COM applications can also use [IAnnotation::GetType](#) to determine the underlying object supported. Or, COM applications can use [QueryInterface](#) to determine which object is supported and get the interface from the `LPUNKNOWN` return value.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[ICenterLine Interface](#)
[ICenterMark Interface](#)
[ICThread Interface](#)
[IDatumOrigin Interface](#)
[IDatumTag Interface](#)
[IDatumTargetSym Interface](#)
[IDisplayDimension Interface](#)
[IDowelSymbol Interface](#)
[IGtol Interface](#)
[IMultiJogLeader Interface](#)
[INote Interface](#)
[ISFSymbol Interface](#)
[ITableAnnotation Interface](#)
[IWeldBead Interface](#)
[IWeldSymbol Interface](#)
[IGetSpecificAnnotation Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStyleName Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetStyleName Method (IAnnotation)

Gets the name of the style applied to this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStyleName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.String
```

```
value = instance.GetStyleName()
```

C#

```
System.string GetStyleName()
```

C++/CLI

```
System.String^ GetStyleName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of style

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetStyleName](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::AddOrUpdateStyle Method](#)
[IAnnotation::ApplyDefaultStyleAttributes Method](#)
[IAnnotation::DeleteStyle Method](#)
[IAnnotation::LoadStyle Method](#)
[IAnnotation::SaveStyle Method](#)
[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextFormat Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetTextFormat Method (IAnnotation)

Gets the text format for the specified text in this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextFormat( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTextFormat(Index)
```

C#

```
System.object GetTextFormat(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextFormat(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating which text within this annotation to check

Return Value

[ITextFormat](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetTextFormat](#).

Example

[Change Text Format \(VBA\)](#)
[Get Whether Note Contains Rich Embedded Text \(VBA\)](#)
[Increase Width of Text \(VBA\)](#)
[Modify and Reload Sheet Format Template \(C#\)](#)
[Modify and Reload Sheet Format Template \(VB.NET\)](#)
[Modify and Reload Sheet Format Template \(VBA\)](#)

Remarks

The behavior of this method differs depending on the type of annotation.

- [Datum target](#) and [Datum feature symbols](#)

These symbols always use the document default setting for dimension text format to display text within the symbol. The index argument is not used and should be set to 0.

- [Geometric Tolerance](#), [display dimensions](#), [simple notes](#), [surface finish](#), and [weld symbols](#)

These symbols can either use the document default setting to display text within the symbol (dimension text setting for the geometric tolerance symbols and display dimensions, or note text setting for notes) or they can use a local format. The index argument is not used and should be set to 0.

- [Blocks](#) (and compound notes for documents created in SOLIDWORKS 2015 and earlier)

These symbols might contain several different pieces of text; each piece can use the document default setting for notes or a local format. The index argument identifies the text. The index value is 0-based. If the index value is invalid, then this method returns a Nothing or null pointer. To get the number of text or [ITextFormat](#) objects, use [IAnnotation::GetTextFormatCount](#).

- Rich text format

If a note contains embedded rich text information in the string, then this method returns a text format that does not necessarily reflect what is displayed on the screen for that note. Use [INote::HasMultipleFonts](#) to determine if the note contains embedded rich text information.

[ITextFormat](#) is returned if it is for a local setting or for the document default setting. To determine whether or not this annotation is using the document default settings for text format, use [IAnnotation::GetUseDocTextFormat](#). To set the text format information, use [IAnnotation::SetTextFormat](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::ITextFormat Method](#)
[IAnnotation::GetTextFormatCount Method](#)
[IAnnotation::SetTextFormat Method](#)
[IAnnotation::ITextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0.

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTextFormatCount Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetTextFormatCount Method (IAnnotation)

Gets the number of text formats for this annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetTextFormatCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetTextFormatCount()
```

C#

```
System.int GetTextFormatCount()
```

C++/CLI

```
System.int GetTextFormatCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of text formats

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetTextFormatCount](#).

Remarks

The value returned by this method is intended to be used with [IAnnotation::GetUseDocTextFormat](#), [IAnnotation::GetTextFormat](#), [IAnnotation::IGetTextFormat](#), [IAnnotation::SetTextFormat](#), and [IAnnotation::ISetTextFormat](#). The index input argument for these methods must be less than the number returned by this method.

This value is not necessarily the same as the number of text objects within a symbol. For example, there are multiple text objects in a geometric tolerance symbol, but they all share the same text format so SOLIDWORKS returns 1. In fact, for all of the annotations except blocks (and compound notes in documents created in SOLIDWORKS 2015 and earlier), this method should return 1. For blocks and compound notes, each piece of text within the symbol has its own text format, so the return value should match the number of TextFormat objects.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetTextFormat Method](#)
[IAnnotation::IGetTextFormat Method](#)
[IAnnotation::ISetTextFormat Method](#)
[IAnnotation::SetTextFormat Method](#)
[IAnnotation::GetUseDocTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0.

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetType Method (IAnnotation)

Gets the type of the annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of the annotation as defined in [swAnnotationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetType](#).

Example

[Change Text Format \(VBA\)](#)
[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Entities Attached to Cosmetic Thread \(VBA\)](#)
[Get Types of Entities for Selected Dimension \(VBA\)](#)
[Show Dimensions in Drawing Sheet \(VBA\)](#)
[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

If this annotation contains only Product and Manufacturing Information (PMI), then this method returns swAnnotationType_e.swPMIOnly. In that case, use [IAnnotation::GetPMIType](#) and [IAnnotation::GetPMIData](#) to obtain the PMI data associated with this annotation.

This method is useful when the IAnnotation object is obtained with [IAnnotation::GetSpecificAnnotation](#) or [IAnnotation::IGetSpecificAnnotation](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetUseDocTextFormat Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetUseDocTextFormat Method (IAnnotation)

Gets whether SOLIDWORKS is currently using the document default text format setting for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseDocTextFormat( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetUseDocTextFormat(Index)
```

C#

```
System.bool GetUseDocTextFormat(  
    System.int Index  
)
```

C++/CLI

```
System.bool GetUseDocTextFormat(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating which text within this annotation to check (see **Remarks**)

Return Value

True if the setting is a document default setting, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::GetUseDocTextFormat](#).

Remarks

The behavior of this method differs slightly depending on the type of annotation.

- [Weld](#), [Datum Target](#), [Datum Feature](#), and [Surface Finish](#) Symbols

These symbols always use the document default setting for dimension text format of the text objects within the symbol. Therefore, this method always returns True for these annotation types. The index argument is not used and should be set to 0.

- [Geometric Tolerance](#) Symbols, [Display Dimensions](#), and [Simple Notes](#)

These symbols can use the document default setting to display all of the text objects within the symbol (dimension text setting for the geometric tolerance symbols and display dimensions, or note text setting for notes), in which case this method returns True. They can also use a local format, in which case this method returns false. The index argument is not used and should be set to 0.

- [Blocks](#) (and compound notes created in SOLIDWORKS 2015 and earlier)

These symbols can contain several different pieces of text, each individually using the document default setting for notes or a local format. The index argument identifies the text. The index value is 0-based. If the index value is invalid, this method returns True. To get the number of text or text format objects, use [IAnnotation::GetTextFormatCount](#).

To get the text format object for this annotation, use [IAnnotation::GetTextFormat](#), [IAnnotation::!GetTextFormat](#), [IAnnotation::SetTextFormat](#), or [IAnnotation::!SetTextFormat](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVisualProperties Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : GetVisualProperties Method (IAnnotation)

Gets the visual properties of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVisualProperties() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim value As System.Object
```



```
value = instance.GetVisualProperties()
```

C#

```
System.Object GetVisualProperties()
```

C++/CLI

```
System.Object^ GetVisualProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of five longs or five integers (see [Long vs. Integer](#) and see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [Annotation::GetVisualProperties](#).

 Remarks

The return value is the following array:

[color, style, width, layerID, layerOverride]

where:

color	COLORREF returned as an integer. Return value can be 0 or -1 for default color.
style	Line style as defined in swLineStyles_e .
width	Line width as defined in swLineWeights_e .
layerID	Integer value indicating which layer holds this entity. The Layer object can be obtained by passing this integer value to ILayerMgr::GetLayerById or ILayerMgr::IGetLayerById .
layerOverride	Integer with bit flags set to determine which properties, if any, have been overridden with respect to the layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if layerOverride was returned as 3, we know the color and style have been specifically set for this annotation and might not match the default values associated with this annotations layer.

 See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::IGetVisualProperties Method](#)

 Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAttachedEntities Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetAttachedEntities Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetAttachedEntities2](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetAttachedEntities() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Object
```

```
value = instance.IGetAttachedEntities()
```

C#

```
System.object IGetAttachedEntities()
```

C++/CLI

```
System.Object^ IGetAttachedEntities();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetAttachedEntities](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAttachedEntityCount Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetAttachedEntityCount Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetAttachedEntityCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAttachedEntityCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.IGetAttachedEntityCount()
```

C#

```
System.int IGetAttachedEntityCount()
```

C++/CLI

```
System.int IGetAttachedEntityCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetAttachedEntityCount](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAttachedEntityTypes Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetAttachedEntityTypes Method (IAnnotation)

Gets the types of all entities attached to this annotation.

.NET Syntax

```
Function IGetAttachedEntityTypes() As System.Integer
```



```
Dim instance As IAnnotation
Dim value As System.Integer

value = instance.IGetAttachedEntityTypes()
```

```
System.int IGetAttachedEntityTypes()
```

```
System.int IGetAttachedEntityTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, in-process, unmanaged C++: Pointer to an array of longs that indicate the types of all entities attached to this annotation as defined in [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

This method supports all annotation types. Use [IAnnotation::GetType](#) to determine the annotation type.

This method returns an array of longs or integers indicating object types. The list of object types corresponds to the list of objects returned by [IAnnotation::IGetAttachedEntities](#).

You can associate annotations with additional items not listed in [swSelectType_e](#). If this annotation is attached to one or more entities not listed in [swSelectType_e](#), then this method and [IAnnotation::GetAttachedEntityTypes](#) return [swSelNOTHING](#) in a position in the array corresponding to the unlisted item. [IAnnotation::IGetAttachedEntities](#) indicates an unsupported entity by returning a null value in the position in the array corresponding to the unsupported entity. COM applications that call [IAnnotation::GetAttachedEntityCount3](#) include the null value in the total count of associated entities.

If an annotation is disassociated from its geometry (i.e., dangling), then [IAnnotation::IGetAttachedEntities](#) returns a null value in the position in the array corresponding to the dangling item, and this method returns [swSelNOTHING](#) in the position in the array corresponding to the dangling item.

NOTE: If this annotation is not associated with any geometry, then this method and [IAnnotation::IGetAttachedEntities](#) return empty arrays.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDisplayData Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetDisplayData Method (IAnnotation)

Gets the display data for the annotation.

.NET Syntax

```
Function IGetDisplayData() As DisplayData
```



```
Dim instance As IAnnotation  
Dim value As DisplayData  
  
value = instance.IGetDisplayData()
```

C#

```
DisplayData IGetDisplayData()
```

C++/CLI

```
DisplayData^ IGetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IDisplayData](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetDisplayData](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetLeaderPointsAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetLeaderPointsAtIndex Method (IAnnotation)

Gets coordinate information about a specified leader on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderPointsAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal PointCount As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim PointCount As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLeaderPointsAtIndex(Index, PointCount)
```

C#

```
System.double IGetLeaderPointsAtIndex(  
    System.int Index,  
    System.int PointCount  
)
```

C++/CLI

```
System.double IGetLeaderPointsAtIndex(  
& System.int Index,  
& System.int PointCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of leader within this annotation (see **Remarks**)

PointCount

Number of (x,y,z) points to return in the array

Return Value

- in-process, in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

The index value is 0-based. Therefore, a valid index value is greater than or equal to 0, but less than the number of leaders on this annotation.

Use [IAnnotation::GetLeaderCount](#) to find out how many leaders are on this annotation. If the index value is invalid in Visual Basic for Application (VBA), then SOLIDWORKS returns an empty SafeArray or S_false.

You must determine the number of points in the leader to use the data returned by this method. The number of points is a function of the number of segments in the leader. There can be one or two segments in a leader line, depending on whether or not it is a straight, bent, or underlined leader. Use [IAnnotation::GetLeaderStyle](#) to determine the number of points in the leader.

- If IAnnotation::GetLeaderStyle returns swNO_LEADER, then the number of points = 0.
- If IAnnotation::GetLeaderStyle returns swSTRAIGHT and swUNDERLINED then the number of points = 2.
- If IAnnotation::GetLeaderStyle returns swBENT, then the number of points = 3.

Additionally, for the COM interface, you must determine the number of points to allocate the appropriate size array for the return value. The number of points must also be passed to the method to help prevent overwrite problems if you have not allocated an array that is the correct size. If the number of points passed does not match what is found, SOLIDWORKS does not return any point information and returns S_false.

The format of the return array is:

retval[0] = X-coordinate of first leader point

retval[1] = Y-coordinate of first leader point

retval[2] = Z-coordinate of first leader point

retval[3] = X-coordinate of second leader point

retval[4] = Y-coordinate of second leader point

retval[5] = Z-coordinate of second leader point

retval[6] = X-coordinate of third leader point

retval[7] = Y-coordinate of third leader point

retval[8] = Z-coordinate of third leader point

You cannot directly set the leader coordinate information. The leader coordinates are computed based on the annotations text and attachment points. Use [IAnnotation::GetPosition](#) and [IAnnotation::SetPosition](#) to get and set the text point.

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

[IAnnotation::GetLeaderPointsAtIndex Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMultiJogLeaders Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetMultiJogLeaders Method (IAnnotation)

Gets the multi-jog leaders on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMultiJogLeaders( _  
    ByVal Count As System.Integer _  
) As MultiJogLeader
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Count As System.Integer  
Dim value As MultiJogLeader  
  
value = instance.IGetMultiJogLeaders(Count)
```

C#

```
MultiJogLeader IGetMultiJogLeaders(  
    System.int Count  
)
```

C++/CLI

```
MultiJogLeader^ IGetMultiJogLeaders(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of multi-jog leaders on this annotation

Return Value

- in-process, unmanaged C++: Pointer to an array of the [multi-jog leaders](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IAnnotation::GetMultiJogLeaderCount](#) to get Count.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetMultiJogLeaders Method](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetNext Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetNext3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As Annotation
```

```
value = instance.IGetNext()
```

C#

```
Annotation IGetNext()
```

C++/CLI

```
Annotation^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetNext](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext2 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetNext2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::GetNext3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext2() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As Annotation
```

```
value = instance.IGetNext2()
```

C#

```
Annotation IGetNext2()
```

C++/CLI

```
Annotation^ IGetNext2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetNext2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPosition Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetPosition Method (IAnnotation)

Gets the position of this annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetPosition() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Double  
  
value = instance.IGetPosition()
```

C#

```
System.double IGetPosition()
```

C++/CLI

```
System.double IGetPosition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to an array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetPosition](#).

Remarks

The return value is an array of 3 doubles, the x, y, z origin of the annotation.

If this method is not successful in retrieving the position of the annotation, the status value is `S_false` (COM only). Make sure that you check this value before using the returned position.

The following table lists the types of annotations that this method supports and the position of the x, y, z origin. In a drawing, the x, y, z origin is relative to the origin of the drawing sheet (the lower-left corner of the sheet).

Type of Annotation	Position of XYZ Origin
Datum Feature Symbols	Point where leader hits symbol
Datum Target Symbols	Centerpoint of the circle that is attached to the leader
Dimensions	Upper-left corner of the text box of the dimension
Geometric Tolerances	Upper-left corner of the symbol
Notes	Upper-left corner of the text box
Surface Finish Symbols	Lower-left point of symbol
Table Annotations	Position of x,y,z determined by ITableAnnotation.AnchorType
Weld Symbols	Left endpoint of the main horizontal line in the symbol

If you use this method on any other types of annotations, SOLIDWORKS takes no action and returns false.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetPosition Method](#)
[SetPosition Method](#)
[INote::LockPosition Property](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0



Gets the specific underlying object associated with this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSpecificAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

value = instance.IGetSpecificAnnotation()
```

C#

```
System.object IGetSpecificAnnotation()
```

C++/CLI

```
System.Object^ IGetSpecificAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the IUnknown interface for the specific underlying annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetSpecificAnnotation](#).

Remarks

If this annotation is a note, then this method returns the underlying [INote](#).

Dispatch applications can use [IAnnotation::GetType](#) to determine the type of underlying object supported. For example, if the return value from IAnnotation::GetType is swWeldSymbol, then you know that you can use the Dispatch pointer returned from this method with the [IWeldSymbol](#) class.

COM applications can also use IAnnotation::GetType to determine the underlying object supported. Or, COM applications can use QueryInterface to determine which object is supported and get the interface from the LPUNKNOWN return value.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[ICThread Interface](#)
[IDatumTag Interface](#)
[IDatumTargetSym Interface](#)
[IDisplayDimension Interface](#)
[IGtol Interface](#)
[IMultiJogLeader Interface](#)
[INote Interface](#)
[ISFSymbol Interface](#)
[IWeldBead Interface](#)
[IWeldSymbol Interface](#)
[ICenterLine Interface](#)
[ICenterMark Interface](#)
[IDatumOrigin Interface](#)
[IDowelSymbol Interface](#)
[ITableAnnotation Interface](#)
[GetSpecificAnnotation Method](#)

IGetTextFormat Method (IAnnotation)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IAnnotation Interface : IGetTextFormat Method (IAnnotation)

Gets the text format for the specified text in this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextFormat(  
    ByVal Index As System.Integer _  
) As TextFormat
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim value As TextFormat  
  
value = instance.IGetTextFormat(Index)
```

C#

```
TextFormat IGetTextFormat(  
    System.int Index  
)
```

C++/CLI

```
TextFormat^ IGetTextFormat(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating which text within this annotation to check

Return Value

Pointer to [ITextFormat](#) of the specified piece of text

Visual Basic for Applications (VBA) Syntax

See [Annotation::IGetTextFormat](#).

Remarks

The behavior of this method differs depending on the type of annotation.

- [Datum Target](#) and [Datum Feature Symbols](#)
These symbols always use the document default setting for dimension text format to display text within the symbol. The index argument is not used and should be set to 0.
- [Geometric Tolerance](#), [Display Dimensions](#), [Simple Notes](#), [Surface Finish](#), and [Weld Symbols](#)
These symbols can either use the document default setting to display text within the symbol (dimension text setting for the geometric tolerance symbols and display dimensions, or note text setting for notes) or they can use a local format. The index argument is not used and should be set to 0.
- [Blocks](#) (and compound notes in documents created in SOLIDWORKS 2015 and earlier)
These symbols might contain several different pieces of text; each piece can use the document default setting for notes or a local format. The index argument identifies the text. The index value is 0-based. If the index value is invalid, then this method returns a NULL pointer. To get the number of text or [ITextFormat](#) objects, use [IAnnotation::GetTextFormatCount](#).
- Rich Text Format
If a note contains embedded rich text information in the string, this method returns a text format that does not necessarily reflect what is displayed on the screen for that note. Use [INote::HasMultipleFonts](#) to determine if the note contains embedded rich text information.

ITextFormat is returned if it is for a local setting or for the document default setting. To determine whether or not this annotation is using the document default settings for text format, use [IAnnotation::GetUseDocTextFormat](#). To set the text format information, use [IAnnotation::SetTextFormat](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetTextFormat Method](#)
[ITextFormat Interface](#)

[IAnnotation::GetTextFormatCount Method](#)
[IAnnotation::ISetTextFormat Method](#)
[IAnnotation::GetTextFormat Method](#)

 Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0.

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetVisualProperties Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IGetVisualProperties Method (IAnnotation)

Gets the visual properties of this annotation.

 .NET Syntax

Visual Basic (Declaration)

Function IGetVisualProperties() As System.Integer

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer  
  
value = instance.IGetVisualProperties()
```

C#

```
System.int IGetVisualProperties()
```

C++/CLI

```
System.int IGetVisualProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of 5 longs (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

 Remarks

The return value is the following array of longs:

[color, style, width, layerID, layerOverride]

where:

color	COLORREF returned as an integer. Return value can be 0 or -1 for default color.
style	Line style as defined in swLineStyles_e .
width	Line width as defined in swLineWeights_e .
layerID	Integer value indicating which layer holds this entity. The Layer object can be obtained by passing this integer value to ILayerMgr::GetLayerById or ILayerMgr::IGetLayerById .
layerOverride	Integer with bit flags set to determine which properties, if any, have been overridden with respect to the layer default properties. If the bit value is set, then the specific property or properties have been overridden. The bit indicators are: color = 0x1, style = 0x2, and width = 0x4. Therefore, if layerOverride was returned as 3, we know the color and style have been specifically set for this annotation and might not match the default values associated with this annotations layer.

 See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::IGetVisualProperties Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDangling Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IsDangling Method (IAnnotation)

Gets whether this annotation is dangling.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDangling() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.IsDangling()
```

C#

```
System.bool IsDangling()
```

C++/CLI

```
System.bool IsDangling();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the annotation is dangling, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::IsDangling](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDimXpert Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : IsDimXpert Method (IAnnotation)

Gets whether the annotation is a DimXpert annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDimXpert() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
value = instance.IsDimXpert()
```

C#

```
System.bool IsDimXpert()
```

C++/CLI

```
System.bool IsDimXpert();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the annotation is a DimXpert annotation, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::IsDimXpert](#).

Example

[Get DimXpert Display Dimensions and Feature \(C#\)](#)
[Get DimXpert Display Dimensions and Feature \(VB.NET\)](#)
[Get DimXpert Display Dimensions and Feature \(VBA\)](#)

Remarks

Use this method to determine if the annotation is a DimXpert display dimension. If it is, then use [IAnnotation::GetDimXpertFeature](#) to access the DimXpert feature, which provides access to the display dimension information.

DimXpert annotations such as datums and GTols can be hidden, shown, or hidden as a group, which can be important when exporting to a DXF/DWG file.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDimXpertFeature Method](#)

Availability

SOLIDWORKS 2009 SP2, Revision Number 17.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetAttachedEntities Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : ISetAttachedEntities Method (IAnnotation)

Attaches this annotation to the specified entities.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetAttachedEntities( _  
    ByVal Count As System.Integer, _  
    ByRef LpArr As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim Count As System.Integer  
Dim LpArr As System.Object  
Dim value As System.Boolean
```

```
value = instance.ISetAttachedEntities(Count, LpArr)
```

C#



```
System.bool ISetAttachedEntities(
    System.int Count,
    ref System.object LpArr
)
```

C++/CLI

```
System.bool ISetAttachedEntities(
    & System.int Count,
    & System.Object^% LpArr
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities to which to attach this annotation

LpArr

- in-process, unmanaged C++: Pointer to an array of entities to attach this annotation to (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the annotation is attached to the entities, false if not

Remarks

Not all annotations can be attached to a different entity (i.e., face, edge, or vertex). Experiment with this method to determine which annotations can be attached to which entities.

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

[IAnnotation::GetAttachedEntities2 Method](#)

[SetAttachedEntities Method](#)

Availability

2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetTextFormat Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : ISetTextFormat Method (IAnnotation)

Sets the text format information for the specified text within this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetTextFormat( _
    ByVal Index As System.Integer, _
    ByVal UseDoc As System.Boolean, _
    ByVal TextFormat As TextFormat _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim Index As System.Integer
Dim UseDoc As System.Boolean
Dim TextFormat As TextFormat
Dim value As System.Boolean
```

```
value = instance.ISetTextFormat(Index, UseDoc, TextFormat)
```

C#

```
System.bool ISetTextFormat(
    System.int Index,
    System.bool UseDoc,
    TextFormat TextFormat
)
```

C++/CLI

```
System.bool ISetTextFormat(
    & System.int Index,
    & System.bool UseDoc,
    & TextFormat^ TextFormat
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating which text within this annotation to check

UseDoc

True to use the document default setting for text format, false to not

TextFormat

Object to use for the [ITextFormat](#) on the specified piece of text

Return Value

True if this method is successful in setting the text format information, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::ISetTextFormat](#).

Remarks

The behavior of this method differs depending on the type of annotation.

- [Datum Target](#) and [Datum Feature](#) Symbols

These symbols always use the document default setting for dimension text format to display all of the text objects within the symbol. This method has no effect on the annotation.

- [Geometric Tolerance](#), [Display Dimensions](#), [Simple Notes](#), [Surface Finish](#), and [Weld](#) Symbols

These symbols can use the document default setting for display of all text objects within the symbol (dimension text setting for the geometric tolerance symbols and display dimensions, or note text setting for notes) or they can use a local format. The index argument is not used and should be set to 0.

- [Blocks](#) (and compound notes in documents created in SOLIDWORKS 2015 and earlier)

These symbols might contain several different pieces of text; each piece can use the document default setting for notes or a local format. The index argument identifies the text. The index value is 0 based. If the index value is invalid, then this method returns false. To get the number of text or TextFormat objects, use [IAnnotation::GetTextFormatCount](#).

- Rich Text Format

If a notes contains embedded rich text information in the string, then using this method to set a specific text format has no effect and returns false. If you use this method to set the note to use the document default text format, then all of the rich text font information is removed from the string.

To set a specific text format for a note that contains embedded rich text information, perform these two steps. First use this method to set the document default. Then use this method to set the specific text format.

If the useDoc argument is True, then the annotation is set to use the appropriate document default setting and ignores the textFormat argument, which should be set to NULL. To determine whether or not this annotation is using the document default settings for text format, use [IAnnotation::GetUseDocTextFormat](#). To set the text format information, use [IAnnotation::SetTextFormat](#) or [IAnnotation::ISetTextFormat](#).

To see the effects of changing the text format information for this annotation, use [ModelDoc2::GraphicsRedraw2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetTextFormat Method](#)
[IAnnotation::IGetTextFormat Method](#)
[IAnnotation::GetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

Layer Property (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Layer Property (IAnnotation)

Gets or sets the layer used by this annotation. Layers are supported only in SOLIDWORKS drawings.

.NET Syntax

Visual Basic (Declaration)

```
Property Layer As System.String
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.String

instance.Layer = value

value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the layer used for this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::Layer](#).

Example

[Insert Autoballoons \(VBA\)](#)

Remarks

In Drawing documents, annotations can be created on a specific layer. This property allows you to get or set the layer used by this annotation. You can also set an annotation to not be on any layer by specifying "" for theLayer.

NOTE: The return value might be an empty string because an old document might not contain layers. This also occurs if annotations have been generated in a new document that does not have layers defined.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207



Gets or sets whether the annotation has properties that override the default properties of the layer.

.NET Syntax

Visual Basic (Declaration)

```
Property LayerOverride As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Integer

instance.LayerOverride = value

value = instance.LayerOverride
```

C#

```
System.int LayerOverride {get; set;}
```

C++/CLI

```
property System.int LayerOverride {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Properties that have been overridden or should be overridden as defined in [swLayerOverride_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::LayerOverride](#).

Remarks

Layers are currently supported only in SOLIDWORKS drawings.

You should set this property only when you want to reset specific visual properties to the default visual properties of the owning layer. If you want to change or set specific values for the visual property of this item, use [IAnnotation::Color](#), [IAnnotation::Style](#), and [IAnnotation::Width](#).

In drawing documents, annotations can be created on a layer that has specific visual properties. By default, the annotation takes on the visual properties defined by the layer. However, for a specific annotation, you can override these visual properties (color, style, and width).

When the annotation is not on any layer, this property returns an undefined value. You can use the [IAnnotation::Layer](#) property to determine the name of the layer that this annotation is on. If an empty string is returned by the [Annotation::Layer](#) property, then this property is not used.

When you get this property, the returned bit value indicates which property or properties have been overridden. The bit indicators are:

- color = 0x1
- style = 0x2
- width = 0x4

Therefore, if the value was returned as 3, you know color and style have been specifically set for this item and might not match the default value associated with this item's layer.

When you set this property, the input bit value indicates which property or properties should maintain their current override values. Therefore, if the value is passed as 0x4, we know width should keep its current override value, and that color and style should be reset to use the color and style settings for the item's layer. If you pass 0, all visual properties are reset to use the default settings of the item's layer.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

LeaderLineStyle Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : LeaderLineStyle Property (IAnnotation)

Gets or sets the leader's lines style for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderLineStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Integer

instance.LeaderLineStyle = value

value = instance.LeaderLineStyle
```

C#

```
System.int LeaderLineStyle {get; set;}
```

C++/CLI

```
property System.int LeaderLineStyle {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader's line style as defined by [swLineStyles_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::LeaderLineStyle](#).

Remarks

[IAnnotation::UseDocDispLeader](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

LeaderThickness Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : LeaderThickness Property (IAnnotation)

Gets or sets the leader's line thickness for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property LeaderThickness As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Integer

instance.LeaderThickness = value

value = instance.LeaderThickness
```

C#

```
System.int LeaderThickness {get; set;}
```

C++/CLI

```
property System.int LeaderThickness {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Leader's line thickness as defined by [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::LeaderThickness](#).

Remarks

[IAnnotation::UseDocDispLeader](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LeaderThicknessCustom Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : LeaderThicknessCustom Property (IAnnotation)

Gets or sets the leader's custom line thickness for this annotation.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property LeaderThicknessCustom As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Double

instance.LeaderThicknessCustom = value

value = instance.LeaderThicknessCustom
```

C#

```
System.double LeaderThicknessCustom {get; set;}
```

C++/CLI

```
property System.double LeaderThicknessCustom {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for leader's custom line thickness

Visual Basic for Applications (VBA) Syntax

See [Annotation::LeaderThicknessCustom](#).

Remarks

[IAnnotation::UseDocDispLeader](#) must be false for this property to have any effect.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoadStyle Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : LoadStyle Method (IAnnotation)

Loads the specified style.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function LoadStyle( _  
    ByVal PathName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim PathName As System.String  
Dim value As System.Boolean  
  
value = instance.LoadStyle(PathName)
```

C#

```
System.bool LoadStyle(  
    System.string PathName  
)
```

C++/CLI

```
System.bool LoadStyle(  
& System.String^ PathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PathName

Path and filename of the style to load

Return Value

True if the style is loaded, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::LoadStyle](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::AddOrUpdateStyle Method](#)
[IAnnotation::ApplyDefaultStyleAttributes Method](#)
[IAnnotation::DeleteStyle Method](#)
[IAnnotation::GetStyleName Method](#)
[IAnnotation::SaveStyle Method](#)
[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Owner Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Owner Property (IAnnotation)

Gets the owner of this annotation.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property Owner As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Object

instance.Owner = value

value = instance.Owner
```

C#

```
System.Object Owner {get; set;}
```

C++/CLI

```
property System.Object^ Owner {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Object for the view, sheet, or model document

Visual Basic for Applications (VBA) Syntax

See [Annotation::Owner](#).

Remarks

Use [IAnnotation::OwnerType](#) to determine if the annotation is located on a drawing view, drawing sheet, drawing template, assembly, or part.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

OwnerType Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : OwnerType Property (IAnnotation)

Gets the type of owner of this annotation.

NOTE: This property is a get-only property. Set is not implemented.

.NET Syntax

Visual Basic (Declaration)

```
Property OwnerType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim value As System.Integer

instance.OwnerType = value

value = instance.OwnerType
```

C#

```
System.int OwnerType {get; set;}
```

C++/CLI

```
property System.int OwnerType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of owner of this annotation as defined in [swAnnotationOwner_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::OwnerType](#).

Remarks

Use this property to determine if an annotation is located on drawing view, drawing sheet, drawing template, assembly, or part. Use [IAnnotation::Owner](#) to gain access to the owner of the annotation.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveStyle Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SaveStyle Method (IAnnotation)

Saves the specified style.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveStyle( _  
    ByVal StyleName As System.String, _  
    ByVal PathName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAnnotation  
Dim StyleName As System.String  
Dim PathName As System.String  
Dim value As System.Boolean
```

```
value = instance.SaveStyle(StyleName, PathName)
```

C#

```
System.bool SaveStyle(  
    System.string StyleName,  
    System.string PathName  
)
```

C++/CLI

```
System.bool SaveStyle(  
& System.String^ StyleName,  
& System.String^ PathName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName

Name of the style

PathName

Path and filename to which to save the style

Visual Basic for Applications (VBA) Syntax

See [Annotation::SaveStyle](#).

Remarks

See SOLIDWORKS Help for the filename extensions to use for styles.

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

[IAnnotation::AddOrUpdateStyle Method](#)

[IAnnotation::ApplyDefaultStyleAttributes Method](#)

[IAnnotation::DeleteStyle Method](#)

[IAnnotation::GetStyleName Method](#)

[IAnnotation::LoadStyle Method](#)

[IAnnotation::SetStyleName Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Select Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::Select3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal AppendFlag As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim AppendFlag As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.Select(AppendFlag)
```

C#

```
System.bool Select(  
    System.bool AppendFlag  
)
```

C++/CLI

```
System.bool Select(  
& System.bool AppendFlag
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Visual Basic for Applications (VBA) Syntax

See [Annotation::Select](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select2 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Select2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::Select3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select2( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean
```

```
value = instance.Select2(Append, Mark)
```

C#

```
System.bool Select2(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Visual Basic for Applications (VBA) Syntax

See [Annotation::Select2](#).

See Also

Select3 Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Select3 Method (IAnnotation)

Selects this annotation and marks it.

.NET Syntax

Visual Basic (Declaration)

```
Function Select3( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select3(Append, Data)
```

C#

```
System.bool Select3(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select3(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends this selection to the current selection list, false replaces the current selection list with this selection

Data

Pointer to the [ISelectData](#) object

Return Value

True if the annotation was selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::Select3](#).

Example

[Get Corresponding Note in Assembly \(VBA\)](#)
[Get Corresponding Note in Part \(VBA\)](#)
[Insert Model Annotations \(C#\)](#)
[Insert Model Annotations \(VB.NET\)](#)
[Insert Model Annotations \(VBA\)](#)
[Select All Center Marks \(C#\)](#)
[Select All Center Marks \(VB.NET\)](#)
[Select All Center Marks \(VBA\)](#)

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

SelectByMark Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SelectByMark Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::Select3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SelectByMark( _  
    ByVal AppendFlag As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim AppendFlag As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SelectByMark(AppendFlag, Mark)
```

C#

```
System.bool SelectByMark(  
    System.bool AppendFlag,  
    System.int Mark  
)
```

C++/CLI

```
System.bool SelectByMark(  
& System.bool AppendFlag,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Mark

Visual Basic for Applications (VBA) Syntax

See [Annotation::SelectByMark](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetArrowHeadSizeAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetArrowHeadSizeAtIndex Method (IAnnotation)

Sets the size of the arrow head of the specified leader on this annotation.

.NET Syntax

```

Function SetArrowHeadSizeAtIndex( _
    ByVal Index As System.Integer, _
    ByVal UseDoc As System.Boolean, _
    ByVal Length As System.Double, _
    ByVal Width As System.Double, _
    ByVal Height As System.Double _
) As System.Boolean

```

```

Dim instance As IAnnotation
Dim Index As System.Integer
Dim UseDoc As System.Boolean
Dim Length As System.Double
Dim Width As System.Double
Dim Height As System.Double
Dim value As System.Boolean

value = instance.SetArrowHeadSizeAtIndex(Index, UseDoc, Length, Width, Height)

```

```

System.bool SetArrowHeadSizeAtIndex(
    System.int Index,
    System.bool UseDoc,
    System.double Length,
    System.double Width,
    System.double Height
)

```

```

System.bool SetArrowHeadSizeAtIndex(
    & System.int Index,
    & System.bool UseDoc,
    & System.double Length,
    & System.double Width,
    & System.double Height
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of leader on this annotation

UseDoc

True to use the document default setting for arrow head size, false to use the specified Length, Width, and Height values

Length

Length of leader on this annotation

Width

Width of leader on this annotation

Height

Height of leader on this annotation

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetArrowHeadSizeAtIndex](#).

Remarks

Use [IAnnotation::GetArrowHeadSizeAtIndex](#) to get the arrow head size of a specific leader.

See Also

[IAnnotation Interface](#)

[IAnnotation Members](#)

[IAnnotation::GetArrowHeadCount Method](#)

[IAnnotation::GetArrowHeadStyleAtIndex Method](#)

[IAnnotation::SetArrowHeadStyleAtIndex Method](#)

Availability

SOLIDWORKS 2008 SP1, Revision Number 16.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetArrowHeadStyleAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetArrowHeadStyleAtIndex Method (IAnnotation)

Sets the arrow head style of a specific leader on this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetArrowHeadStyleAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal ArrowHeadStyle As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim ArrowHeadStyle As System.Integer  
Dim value As System.Integer  
  
value = instance.SetArrowHeadStyleAtIndex(Index, ArrowHeadStyle)
```

C#

```
System.int SetArrowHeadStyleAtIndex(  
    System.int Index,  
    System.int ArrowHeadStyle  
)
```

C++/CLI

```
System.int SetArrowHeadStyleAtIndex(  
& System.int Index,  
& System.int ArrowHeadStyle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index of leader within this annotation (see **Remarks**)

ArrowHeadStyle

Arrowhead style as defined in [swArrowStyle_e](#)

Return Value

Return status (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetArrowHeadStyleAtIndex](#).

Remarks

A valid index value is greater than or equal to 0, but less than the number of leaders on this annotation. Use [IAnnotation::GetArrowHeadCount](#) to find out how many leaders are on this annotation. An index value of -1 is also valid, and indicates that this arrowhead style should be applied to all leaders on this annotation. If the index value is invalid, SOLIDWORKS returns a retval of -2.

If smart arrowhead style is enabled on this annotation, then this method cannot change the arrowhead style of individual leaders, and retval is -3. Use [IAnnotation::GetSmartArrowHeadStyle](#) to determine if this flag is enabled or disabled.

The return status of this method can have the following values:

If value equals...	Then the arrowhead style was...
0	Successfully set
-1	Not set because of an unknown error
-2	Not set because of an invalid index value
-3	Not set because of smart arrowhead styles being enabled
-4	Not set because of an invalid arrowhead style value

If leader display is enabled, then this method changes the visible model. To see those changes, use [IModelDoc2::GraphicsRedraw2](#) to redraw the graphics window.

Use [IAnnotation::GetArrowHeadStyleAtIndex](#) to get the arrow head style of a specific leader.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetArrowHeadSizeAtIndex Method](#)
[IAnnotation::GetArrowHeadSizeAtIndex Method](#)
[IAnnotation::GetArrowHeadStyleAtIndex Method](#)
[IAnnotation::GetArrowHeadCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetAttachedEntities Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetAttachedEntities Method (IAnnotation)

Attaches this annotation to the specified entities.

NET Syntax

Visual Basic (Declaration)

```
Function SetAttachedEntities( _
    ByVal AttachedEnts As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAnnotation
Dim AttachedEnts As System.Object
Dim value As System.Boolean
```

```
value = instance.SetAttachedEntities(AttachedEnts)
```

C#

```
System.bool SetAttachedEntities(
    System.object AttachedEnts
)
```

C++/CLI

```
System.bool SetAttachedEntities(
    & System.Object^ AttachedEnts
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AttachedEnts
Array of entities to attach this annotation to (see **Remarks**)

Return Value

True if the annotation is attached to the entities, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetAttachedEntities](#).

Example

[Attach Annotation to Entity \(C#\)](#)
[Attach Annotation to Entity \(VB.NET\)](#)
[Attach Annotation to Entity \(VBA\)](#)

Remarks

Not all annotations can be attached to a different entity (i.e., face, edge, or vertex). Experiment with this method to determine which annotations can be attached to which entities.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::ISetAttachedEntities Method](#)
[IAnnotation::GetAttachedEntities2 Method](#)

Availability

2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLeader Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetLeader Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::SetLeader3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetLeader( _  
    ByVal Leader As System.Boolean, _  
    ByVal LeaderSide As System.Integer, _  
    ByVal SmartArrowHeadStyle As System.Boolean, _  
    ByVal BentLeader As System.Boolean _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Leader As System.Boolean  
Dim LeaderSide As System.Integer  
Dim SmartArrowHeadStyle As System.Boolean  
Dim BentLeader As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetLeader(Leader, LeaderSide, SmartArrowHeadStyle, BentLeader)
```

C#

```
System.int SetLeader(  
    System.bool Leader,  
    System.int LeaderSide,  
    System.bool SmartArrowHeadStyle,  
    System.bool BentLeader  
    )
```

C++/CLI

```
System.int SetLeader(
& System.bool Leader,
& System.int LeaderSide,
& System.bool SmartArrowHeadStyle,
& System.bool BentLeader
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Leader

LeaderSide

SmartArrowHeadStyle

BentLeader

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetLeader](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLeader2 Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetLeader2 Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::SetLeader3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetLeader2( _
    ByVal Leader As System.Boolean, _
    ByVal LeaderSide As System.Integer, _
    ByVal SmartArrowHeadStyle As System.Boolean, _
    ByVal BentLeader As System.Boolean, _
    ByVal Perpendicular As System.Boolean, _
    ByVal AllAround As System.Boolean _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation
Dim Leader As System.Boolean
Dim LeaderSide As System.Integer
Dim SmartArrowHeadStyle As System.Boolean
Dim BentLeader As System.Boolean
Dim Perpendicular As System.Boolean
Dim AllAround As System.Boolean
Dim value As System.Integer
```

```
value = instance.SetLeader2(Leader, LeaderSide, SmartArrowHeadStyle, BentLeader, Perpendicular, AllAround)
```

C#

```
System.int SetLeader2(
    System.bool Leader,
    System.int LeaderSide,
    System.bool SmartArrowHeadStyle,
    System.bool BentLeader,
```

```
System.bool Perpendicular,  
System.bool AllAround  
)
```

C++/CLI

```
System.int SetLeader2(  
& System.bool Leader,  
& System.int LeaderSide,  
& System.bool SmartArrowHeadStyle,  
& System.bool BentLeader,  
& System.bool Perpendicular,  
& System.bool AllAround  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Leader

LeaderSide

SmartArrowHeadStyle

BentLeader

Perpendicular

AllAround

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetLeader2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetLeader3 Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetLeader3 Method (IAnnotation)

Sets the leader characteristics for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLeader3(  
    ByVal LeaderStyle As System.Integer, _  
    ByVal LeaderSide As System.Integer, _  
    ByVal SmartArrowHeadStyle As System.Boolean, _  
    ByVal Perpendicular As System.Boolean, _  
    ByVal AllAround As System.Boolean, _  
    ByVal Dashed As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim LeaderStyle As System.Integer  
Dim LeaderSide As System.Integer  
Dim SmartArrowHeadStyle As System.Boolean  
Dim Perpendicular As System.Boolean  
Dim AllAround As System.Boolean  
Dim Dashed As System.Boolean  
Dim value As System.Integer
```

```
value = instance.SetLeader3(LeaderStyle, LeaderSide, SmartArrowHeadStyle, Perpendicular, AllAround, Dashed)
```

C#

```
System.int SetLeader3(  
    System.int LeaderStyle,  
    System.int LeaderSide,  
    System.bool SmartArrowHeadStyle,  
    System.bool Perpendicular,  
    System.bool AllAround,  
    System.bool Dashed  
)
```

C++/CLI

```
System.int SetLeader3(  
& System.int LeaderStyle,  
& System.int LeaderSide,  
& System.bool SmartArrowHeadStyle,  
& System.bool Perpendicular,  
& System.bool AllAround,  
& System.bool Dashed  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

LeaderStyle

Leader style as defined in [swLeaderStyle_e](#) (see **Remarks**)

LeaderSide

Leader side as defined in [swLeaderSide_e](#) (see **Remarks**)

SmartArrowHeadStyle

True to enable smart arrowhead style, false to disable it (see **Remarks**)

Perpendicular

True to enable perpendicular bent leader display, false to disable it (see **Remarks**)

AllAround

True to enable all around (weld, surface finish, or GTol) symbol display, false to disable it (see **Remarks**)

Dashed

True to enable dashed line leader display; false to enable solid-line leader (see **Remarks**)

Return Value

Indicates whether the operation was successful (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [Annotation::SetLeader3](#).

 Example

[Insert GTol \(C#\)](#)

[Insert GTol \(VB.NET\)](#)

[Insert GTol \(VBA\)](#)

 Remarks

Not all annotations support all styles of leaders or leader characteristics. Only notes, GTols, surface finish symbols, weld symbols, datum target symbols, and block instances support leaders of any kind.

- Weld symbol leaders can be hidden, but are always bent; straight leaders (swSTRAIGHT) are not supported.
- Datum target symbols can have straight or bent leaders, but cannot be hidden (swNO_LEADER is not supported).
- Only notes support underline leaders (swUNDERLINED).
- GTols are the only type of annotation that supports perpendicular bent leaders.
- GTols and weld symbols are the only types of annotations that support all around leader symbols.
- Datum target symbols are the only type of annotation that supports dashed leaders.

This method sets the characteristics of the annotation, not the individual leaders. You can get or set these characteristics whether leaders are displayed.

Use...

[IAnnotation::GetDashedLeader](#)

To...

Determine whether this leader is a dashed line or a solid line.

[IAnnotation::GetLeaderAllAround](#)

Determine whether all around symbol display is enabled or disabled.

IAnnotation::GetLeaderPerpendicular	Determine whether perpendicular bent leader display is enabled or disabled.
IAnnotation::GetLeaderSide	Get the leader attachment side setting.
IAnnotation::GetLeaderStyle	Get style of leader (hidden, straight, bent, or underline).
IAnnotation::GetSmartArrowHeadStyle	Determine whether smart arrowhead style is enabled or disabled.

You can set the leader side, smart arrowhead style, and bent leader values at any time. However, if leader display is disabled, you cannot affect the display of the annotation by setting these values. You can also set the perpendicular bent leader and all around symbol display at any time, but if bent leaders are disabled, you cannot affect the display of the annotation by setting these values.

The return status of this operation can have the following values:

- 0 = Leader characteristics were successfully set
- -1 = Leader characteristics were not set because of an unknown error
- -2 = Leader attachment side setting is invalid
- -3 = Leaders are not supported on this type of annotation
- -4 = Leaders cannot be disabled on this type of annotation
- -5 = Bent leaders cannot be disabled on this type of annotation
- -6 = Underline style leaders are not allowed on this type of annotation

If leader display is enabled, then this method changes the visible model.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetLeader Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)
[IAnnotation::UseDocDispLeader Property \(\)](#)
[IAnnotation::SetLeaderAttachmentPointAtIndex Method \(\)](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLeaderAttachmentPointAtIndex Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetLeaderAttachmentPointAtIndex Method (IAnnotation)

Sets the specified attachment point of a leader for an annotation with the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLeaderAttachmentPointAtIndex( _
    ByVal Index As System.Integer, _
    ByVal X As System.Double, _
    ByVal Y As System.Double, _
    ByVal Z As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAnnotation
Dim Index As System.Integer
Dim X As System.Double
Dim Y As System.Double
Dim Z As System.Double
Dim value As System.Boolean
```



```
value = instance.SetLeaderAttachmentPointAtIndex(Index, X, Y, Z)
```

C#

```
System.bool SetLeaderAttachmentPointAtIndex(  
    System.int Index,  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool SetLeaderAttachmentPointAtIndex(  
& System.int Index,  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of annotation (see **Remarks**)
X
x-coordinate of attachment point
Y
y-coordinate of attachment point
Z
z-coordinate of attachment point

Return Value

True if leader attached successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetLeaderAttachmentPointAtIndex](#).

Example

```
'VBA example  
'Open a drawing.  
'Select a view with one note annotation.  
'No other annotations are present.  
'If there are other annotations, modify Index in the  
'method call below to point to the note annotation.  
=====
```

```
Option Explicit  
Dim swApp As SldWorks.SldWorks  
Dim swModel As SldWorks.ModelDoc2  
Dim swDrawing As SldWorks.DrawingDoc  
Dim swAnnot As SldWorks.Annotation  
Dim vAnnotations As Variant  
Dim swView As SldWorks.View  
Dim i As Integer  
Dim bRet As Boolean  
Dim cnt As Long  
Sub main()  
    Set swApp = Application.SldWorks  
    Set swModel = swApp.ActiveDoc  
  
    Set swDrawing = swModel  
    Set swView = swDrawing.ActiveDrawingView  
  
    Debug.Assert Not swView Is Nothing  
    Debug.Print "Name of drawing view: " & swView.GetName2  
  
    vAnnotations = swView.GetAnnotations
```

```

For i = 0 To UBound(vAnnotations)
    Set swAnnot = vAnnotations(i)
    swAnnot.Select3 True, Nothing

    cnt = swAnnot.GetLeaderCount
    If cnt = 1 Then
        bRet = swAnnot.SetLeaderAttachmentPointAtIndex(0, 0.687021207260901, 0.599975917260352,
250.03275)
        If (bRet) Then
            Debug.Print "Leader attached successfully"
        End If
    End If
Next i
End Sub

```

Remarks

The annotation must be of a type that supports leaders. Only notes, GTols, surface finish symbols, weld symbols, datum target symbols, and block instances support leaders of any kind.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::SetLeader3 Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)

Availability

SOLIDWORKS 2018 SP02, Revision Number 26.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetName Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetName Method (IAnnotation)

Sets the name of this annotation.

.NET Syntax

Visual Basic (Declaration)

```

Function SetName( _
    ByVal NameIn As System.String _
) As System.Boolean

```

Visual Basic (Usage)

```

Dim instance As IAnnotation
Dim NameIn As System.String
Dim value As System.Boolean

value = instance.SetName(NameIn)

```

C#

```

System.bool SetName(
    System.string NameIn
)

```

C++/CLI

```

System.bool SetName(
    & System.String^ NameIn
)

```



NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn

New and unique name for this annotation

Return Value

True if the name was successfully changed, false if the name was not successfully changed

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetName](#).

Example

[Get and Set Name of Note \(VBA\)](#)

Remarks

This method verifies that the name is unique before attempting to set the name.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetName Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic](#).

SetPosition Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetPosition Method (IAnnotation)

Obsolete. Superseded by [IAnnotation::SetPosition2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetPosition( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean
```

```
value = instance.SetPosition(X, Y, Z)
```

C#

```
System.bool SetPosition(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

```
System.bool SetPosition(
& System.double X,
& System.double Y,
& System.double Z
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
x origin of the annotation

Y
y origin of the annotation

Z
z origin of the annotation

Return Value

True if the position of the annotation was set, false if the operation was not successful

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetPosition](#).

Remarks

The following table lists the types of annotations that this method supports and the position of the x, y, z origin. In a drawing, the x, y, z origin is relative to the origin of the drawing sheet (the lower-left corner of the sheet).

Type of Annotation	Position of XYZ Origin
Datum Feature Symbols	Point where leader hits symbol
Datum Target Symbols	Centerpoint of the circle that is attached to the leader
Display dimensions	Upper-left corner of the text box of the display dimension
Geometric Tolerances	Upper-left corner of the symbol
Notes	Upper-left corner of the text box
Revision Clouds	Position of x,y,z determined by IRevisionCloud::Shape
Surface Finish Symbols	Lower-left point of symbol
Table Annotations	Position of x,y,z determined by ITableAnnotation::AnchorType
Weld Symbols	Left endpoint of the main horizontal line in the symbol

If you use this method on any other types of annotations, SOLIDWORKS takes no action and returns false.

The position of an annotation can be subject to certain restrictions. These restrictions apply to setting the position through the user interface and using this method. One example of a restriction is a surface-finish symbol that is inserted directly on a face (that is, no leaders). It can only be moved within the borders of that face. If it is inserted directly on an edge, it can only be moved along that edge or extensions of that edge. Datum feature symbols have similar restrictions. If this method attempts to set a position of an annotation that violates any restrictions, the annotation is placed as near as possible to the specified position.

The position of table annotations cannot be set if the table is anchored. Use [ITableAnnotation::Anchored](#) to determine if the table is anchored.

If a dimension has offset text , and you want to move...	Then...
Dimension text, dimension line, and extension lines	1. Turn offset text off. 2. Use this method to move the dimension text, dimension line, and extension lines. 3. Turn offset text back on.
Dimension text only	Use this method to move the dimension text. The dimension line and extension lines will not move.

Because radial and diametric dimensions are already attached to the end of a leader, this property is not available for these types of dimensions

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetPosition Method](#)
[IAnnotation::IGetPosition Method](#)
[INote::LockPosition Property](#)

Availability

SetPosition2 Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetPosition2 Method (IAnnotation)

Sets the position of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPosition2( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Z As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim X As System.Double  
Dim Y As System.Double  
Dim Z As System.Double  
Dim value As System.Boolean  
  
value = instance.SetPosition2(X, Y, Z)
```

C#

```
System.bool SetPosition2(  
    System.double X,  
    System.double Y,  
    System.double Z  
)
```

C++/CLI

```
System.bool SetPosition2(  
& System.double X,  
& System.double Y,  
& System.double Z  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X
X coordinate of the origin of the annotation
Y
Y coordinate of the origin of the annotation
Z
Z coordinate of the origin of the annotation

Return Value

True if the position of the annotation is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetPosition2](#).

Example

[Insert a Note \(VBA\)](#)
[Insert a Note \(VB.NET\)](#)
[Insert a Note \(C#\)](#)
[Traverse Annotations \(C#\)](#)
[Traverse Annotations \(VB.NET\)](#)
[Traverse Annotations \(VBA\)](#)

Remarks

The following table lists the types of annotations that this method supports and the position of the x, y, z origin. In a drawing, the x, y, z origin is relative to the origin of the drawing sheet (the lower-left corner of the sheet).

Type of Annotation	Position of XYZ Origin
Datum Feature Symbols	Point where leader hits symbol
Datum Target Symbols	Center point of the circle that is attached to the leader
Display dimensions	Point of leader attachment centered on a text box border / center point of bottom border of text box
Geometric Tolerances	Upper-left corner of the symbol
Notes	Upper-left corner of the text box
Revision Clouds	Position of x,y,z determined by IRevisionCloud::Shape
Surface Finish Symbols	Lower-left point of symbol
Table Annotations	Position of x,y,z determined by ITableAnnotation::AnchorType
Weld Symbols	Left endpoint of the main horizontal line in the symbol

If you use this method on any other types of annotations, SOLIDWORKS takes no action and returns false.

The position of an annotation can be subject to certain restrictions. These restrictions apply to setting the position through the user interface and using this method. One example of a restriction is a surface-finish symbol that is inserted directly on a face (that is, no leaders). It can only be moved within the borders of that face. If it is inserted directly on an edge, it can only be moved along that edge or extensions of that edge. Datur feature symbols have similar restrictions. If this method attempts to set a position of an annotation that violates any restrictions, the annotation is placed as near as possible to the specified position.

The position of table annotations cannot be set if the table is anchored. Use [ITableAnnotation::Anchored](#) to determine if the table is anchored.

If a dimension has offset text , and you want to move...	Then...
Dimension text, dimension line, and extension lines	1. Turn offset text off. 2. Use this method to move the dimension text, dimension line, and extension lines. 3. Turn offset text back on.
Dimension text only	Use this method to move the dimension text. The dimension line and extension lines will not move.

Because radial and diametric dimensions are already attached to the end of a leader, this property is not available for these types of dimensions

 See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetPosition Method \(\)](#)
[INote::LockPosition Property \(\)](#)

 Availability

SOLIDWORKS 2014 SP3, Revision Number 22.3

SOLIDWORKS API Help [Send comments on this topic.](#)

SetStyleName Method (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetStyleName Method (IAnnotation)

Sets the style for this annotation.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetStyleName( _  
    ByVal StyleName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim StyleName As System.String  
Dim value As System.Boolean  
  
value = instance.SetStyleName(StyleName)
```

C#

```
System.bool SetStyleName(  
    System.string StyleName  
)
```

C++/CLI

```
System.bool SetStyleName(  
&    System.String^ StyleName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StyleName
Name of the style

Return Value

True if the style is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetStyleName](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::AddOrUpdateStyle Method](#)
[IAnnotation::ApplyDefaultStyleAttributes Method](#)
[IAnnotation::DeleteStyle Method](#)
[IAnnotation::GetStyleName Method](#)
[IAnnotation::LoadStyle Method](#)
[IAnnotation::SaveStyle Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0