

SOLIDWORKS API (.NET, VBA, C#) — Reference (11/337): IAnnotation (part 3 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IAnnotation (part 3 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextFormat Method (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : SetTextFormat Method (IAnnotation)

Sets the text format for the specified text in this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextFormat( _  
    ByVal Index As System.Integer, _  
    ByVal UseDoc As System.Boolean, _  
    ByVal TextFormat As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim Index As System.Integer  
Dim UseDoc As System.Boolean  
Dim TextFormat As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetTextFormat(Index, UseDoc, TextFormat)
```

C#

```
System.bool SetTextFormat(  
    System.int Index,  
    System.bool UseDoc,  
    System.object TextFormat  
)
```

C++/CLI

```
System.bool SetTextFormat(  
& System.int Index,  
& System.bool UseDoc,  
& System.Object^ TextFormat  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Number indicating which text in this annotation to check

UseDoc

True to use the document default setting for text format, false to not

TextFormat

Object to use for the [text format](#) on the specified piece of text

Return Value

True if this method is successful in setting the text format information, false if not

Visual Basic for Applications (VBA) Syntax

See [Annotation::SetTextFormat](#).

Example

[Change Text Format \(VBA\)](#)
[Increase Width of Text \(VBA\)](#)
[Get Corresponding Objects in Assembly Component \(C#\)](#)

Remarks

The behavior of this method differs depending on the type of annotation.

- [Datum target](#) and [Datum feature](#) symbols
 - These symbols always use the document default setting for dimension text format to display all of the text objects within the symbol. This method has no effect on the annotation
 - [Geometric tolerance](#), [Display dimensions](#), [Simple notes](#), [Surface finish](#), and [weld](#) symbols.
- These symbols can use the document default setting for display of all text objects within the symbol (dimension text setting for the geometric tolerance symbols and display dimensions, or note text setting for notes) or they can use a local format. The index argument is not used and should be set to 0.
- [Blocks](#) (and compound notes in documents created in SOLIDWORKS 2015 and earlier)
- These symbols might contain several different pieces of text; each piece can use the document default setting for notes or a local format. The index argument identifies the text. The index value is 0-based. If the index value is invalid, then this method returns false. To get the number of text or TextFormat objects, use [IAnnotation::GetTextFormatCount](#).
- Rich text format
- If a note contains embedded rich text information in the string, then using this method to set a specific text format has no effect and returns false. If you use this method to set the note to use the document default text format, then all of the rich text font information is removed from the string.
- To set a specific text format for a note that contains embedded rich text information, perform these two steps. First use this method to set the document default. Then use this method to set the specific text format.

If the useDoc argument is true, then the annotation is set to use the appropriate document default setting and ignores the textFormat argument, which should be set to Nothing or null. To determine whether or not this annotation is using the document default settings for text format, use [IAnnotation::GetUseDocTextFormat](#). To set the text format information, use [IAnnotation::SetTextFormat](#) or [IAnnotation::!SetTextFormat](#).

To see the effects of changing the text format information for this annotation, use [ModelDoc2::GraphicsRedraw2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetTextFormat Method](#)
[IAnnotation::!SetTextFormat Method](#)
[IAnnotation::!GetTextFormat Method](#)

Availability

SOLIDWORKS 2000 FCS, Revision Number 8.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Style Property (IAnnotation)

Gets or sets the line style for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line style as defined in [swLineStyles_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::Style](#).

Remarks

Annotation style is currently supported only in SOLIDWORKS drawings.

In drawing documents, annotations can be created on a layer that has specific visual properties. By default, the annotation takes on the visual properties defined by the layer. The style value specified with this property allows you to override the default layer style.

Use [IAnnotation::LayerOverride](#) to determine whether or not this annotation is currently using its default layer line style.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDocDispFrame Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : UseDocDispFrame Property (IAnnotation)

Gets or sets whether to use the document's frame's line style and thickness or a specified line style and thickness for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDocDispFrame As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
instance.UseDocDispFrame = value  
  
value = instance.UseDocDispFrame
```

C#

```
System.bool UseDocDispFrame {get; set;}
```

C++/CLI

```
property System.bool UseDocDispFrame {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the document's frame's line style and thickness, false to use a specified line style and thickness

Visual Basic for Applications (VBA) Syntax

See [Annotation::UseDocDispFrame](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::FrameLineStyle Property](#)
[IAnnotation::FrameThickness Property](#)
[IAnnotation::FrameThicknessCustom Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseDocDispLeader Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : UseDocDispLeader Property (IAnnotation)

Gets or sets whether to use the document's leader's line style and thickness or a specified line style and thickness for this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDocDispLeader As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Boolean  
  
instance.UseDocDispLeader = value  
value = instance.UseDocDispLeader
```

C#

```
System.bool UseDocDispLeader {get; set;}
```

C++/CLI

```
property System.bool UseDocDispLeader {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the document's leaders' line style and thickness, false to use a specified line style and thickness

Visual Basic for Applications (VBA) Syntax

See [Annotation::UseDocDispLeader](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)
[IAnnotation::GetDashedLeader Method \(\)](#)
[IAnnotation::GetLeaderAllAround Method \(\)](#)
[IAnnotation::GetLeaderCount Method \(\)](#)
[IAnnotation::GetLeaderPerpendicular Method \(\)](#)
[IAnnotation::GetLeaderPointsAtIndex Method \(\)](#)
[IAnnotation::GetLeaderSide Method \(\)](#)
[IAnnotation::GetLeaderStyle Method \(\)](#)
[IAnnotation::GetMultiJogLeaderCount Method \(\)](#)
[IAnnotation::GetMultiJogLeaders Method \(\)](#)
[IAnnotation::SetLeader3 Method \(\)](#)

[IAnnotation::BentLeaderLength Property \(\)](#)
[IAnnotation::LeaderLineStyle Property \(\)](#)
[IAnnotation::LeaderThickness Property \(\)](#)
[IAnnotation::LeaderThicknessCustom Property \(\)](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Visible Property (IAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Visible Property (IAnnotation)

Gets or sets the visibility state of this annotation.

.NET Syntax

Visual Basic (Declaration)

```
Property Visible As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.int Visible {get; set;}
```

C++/CLI

```
property System.int Visible {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Visibility state as defined in [swAnnotationVisibilityState_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::Visible](#).

Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

Remarks

There are several reasons why an annotation might or might not be visible on the screen.

This property determines whether an annotation has been individually displayed or hidden if you selected and specifically hid the annotation or if you selected and specifically hid the dimensions of a feature. This property cannot determine whether an annotation is hidden if it is on a layer that is hidden (all annotations of this type are hidden) or if the feature that owns it is suppressed. Therefore, even though this method indicates that an annotation is visible, it might not necessarily be visible on the screen.

If an annotation's visibility is set to swAnnotationHalfHidden, then that annotation is in a half-hidden state, which is not a permanent state. For example, during a **Hide/Show Annotations** operation in a drawing, a half-hidden annotation is displayed in gray if the interactive user selects to show all annotations. Any annotation set to swAnnotationHalfHidden is hidden when the interactive user finishes using **Hide/Show Annotations**.

When you use this property to change the visibility of an annotation, you also cause changes to the visible model. To see those changes, redraw

the graphics window using [IModelDoc2::GraphicsRedraw2](#).

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99 SP05 datecode 1999313

SOLIDWORKS API Help

[Send comments on this topic.](#)

Width Property (IAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotation Interface](#) : Width Property (IAnnotation)

Gets or sets the line width enumeration value for this annotation.

.NET Syntax

Visual Basic (Declaration)

Property Width As System.Integer

Visual Basic (Usage)



```
Dim instance As IAnnotation  
Dim value As System.Integer
```

```
instance.Width = value
```

```
value = instance.Width
```

C#

```
System.int Width {get; set;}
```

C++/CLI

```
property System.int Width {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Line style as defined in [swLineWeights_e](#)

Visual Basic for Applications (VBA) Syntax

See [Annotation::Width](#).

Remarks

Annotation width is currently supported only in SOLIDWORKS drawings.

In drawing documents, you can create annotations on a layer that has specific visual properties. By default, the annotation takes on the visual properties defined by the layer. The line width value specified with this property allows you to override the default layer width.

Use the [IAnnotation::LayerOverride](#) to determine if this annotation is using its default layer line width.

See Also

[IAnnotation Interface](#)
[IAnnotation Members](#)

Availability

SOLIDWORKS 99, datecode 1999207