

# SOLIDWORKS API (.NET VBA C#) — Reference (12/337): IAnnotationView-IAppearanceSetting

SOLIDWORKS API Documentation (converted from CHM)

# IAnnotationView (Type)

## IAnnotationView Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotationView Interface

Allows access to annotation views in parts and assemblies.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

Public Interface IAnnotationView

Visual Basic (Usage)



Dim instance As [IAnnotationView](#)

C#

public interface IAnnotationView

C++/CLI

public interface class IAnnotationView

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### Accessors

- [IAnnotation::AnnotationView](#)
- [IModelDocExtension::AnnotationViews](#)
- [IModelDocExtension::GetActiveAnnotationView](#)
- [IModelDocExtension::IGetAnnotationViews](#)
- [IModelDocExtension::InsertAnnotationView](#)
- [IView3D::AnnotationViews](#)

### Access Diagram

[AnnotationView](#)

### See Also

[IAnnotationView Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IAnnotation Interface](#)

## IAnnotationView Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotationView Interface

For a list of all members of this type, see [IAnnotationView members](#).

## Public Methods

| Name                                                                                                                  | Description                                                                             |
|-----------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
|  <a href="#">Activate</a>            | Activates this annotation view.                                                         |
|  <a href="#">ActivateAndReorient</a> | Activates and reorients this annotation view.                                           |
|  <a href="#">GetAnnotations2</a>     | Gets the annotations in this annotation view.                                           |
|  <a href="#">GetViewRotation</a>     | Gets the rotation matrix of the annotation view relative to the X-Y plane of the model. |
|  <a href="#">Hide</a>                | Hides the annotations in an annotation view that is not activated.                      |
|  <a href="#">IGetAnnotations</a>     | Obsolete. Superseded by <a href="#">IAnnotationView.GetAnnotations2</a> .               |
|  <a href="#">IGetViewRotation</a>    | Gets the rotation matrix of the annotation view relative to the X-Y plane of the model. |
|  <a href="#">IsShown</a>             | Gets whether the annotations in this annotation view are shown.                         |
|  <a href="#">MoveAnnotations</a>     | Moves the specified annotations to this annotation view.                                |
|  <a href="#">Orient</a>              | Orients this annotation view.                                                           |
|  <a href="#">Show</a>                | Shows the annotations in an annotation view that is not activated.                      |

[Top](#)

## See Also

[IAnnotationView Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IAnnotationView Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotationView Interface

The following tables list the members exposed by [IAnnotationView](#).

## Public Properties

| Name                                                                                                                            | Description                                                               |
|---------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">Always2D</a>                    | Gets whether to display annotations in 2D or 3D.                          |
|  <a href="#">AngleMadeWithViewHorizontal</a> | Gets the angle used to make the annotation view horizontal.               |
|  <a href="#">AnnotationCount</a>             | Gets the number of <a href="#">annotations</a> in this annotation view.   |
|  <a href="#">Annotations</a>                 | Obsolete. Superseded by <a href="#">IAnnotationView.GetAnnotations2</a> . |
|  <a href="#">FlatPatternView</a>             | Gets whether this annotation view is a flat-pattern view.                 |
|  <a href="#">UnassignedView</a>              | Gets whether this annotation view is assigned to a 3D View.               |

[Top](#)

## Public Methods

| Name                                                                                                                    | Description                                                                             |
|-------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|
|  <a href="#">Activate</a>            | Activates this annotation view.                                                         |
|  <a href="#">ActivateAndReorient</a> | Activates and reorients this annotation view.                                           |
|  <a href="#">GetAnnotations2</a>     | Gets the annotations in this annotation view.                                           |
|  <a href="#">GetViewRotation</a>     | Gets the rotation matrix of the annotation view relative to the X-Y plane of the model. |
|  <a href="#">Hide</a>                | Hides the annotations in an annotation view that is not activated.                      |
|  <a href="#">IGetAnnotations</a>     | Obsolete. Superseded by <a href="#">IAnnotationView.GetAnnotations2</a> .               |
|  <a href="#">IGetViewRotation</a>    | Gets the rotation matrix of the annotation view relative to the X-Y plane of the model. |
|  <a href="#">IsShown</a>             | Gets whether the annotations in this annotation view are shown.                         |

|                                                                                   |                                 |                                                                    |
|-----------------------------------------------------------------------------------|---------------------------------|--------------------------------------------------------------------|
|   | <a href="#">MoveAnnotations</a> | Moves the specified annotations to this annotation view.           |
|  | <a href="#">Orient</a>          | Orients this annotation view.                                      |
|  | <a href="#">Show</a>            | Shows the annotations in an annotation view that is not activated. |

[Top](#)

 **See Also**

[IAnnotationView Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IAnnotationView Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAnnotationView Interface

For a list of all members of this type, see [IAnnotationView members](#).

 **Public Properties**

| Name                                                                                                                          | Description                                                               |
|-------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------|
|  <a href="#">Always2D</a>                    | Gets whether to display annotations in 2D or 3D.                          |
|  <a href="#">AngleMadeWithViewHorizontal</a> | Gets the angle used to make the annotation view horizontal.               |
|  <a href="#">AnnotationCount</a>             | Gets the number of <a href="#">annotations</a> in this annotation view.   |
|  <a href="#">Annotations</a>                 | Obsolete. Superseded by <a href="#">IAnnotationView.GetAnnotations2</a> . |
|  <a href="#">FlatPatternView</a>             | Gets whether this annotation view is a flat-pattern view.                 |
|  <a href="#">UnassignedView</a>             | Gets whether this annotation view is assigned to a 3D View.               |

[Top](#)

 **See Also**

[IAnnotationView Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)  
[IAnnotation Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Activate Method (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : Activate Method (IAnnotationView)

Activates this annotation view.

 **.NET Syntax**

Visual Basic (Declaration)

Function Activate() As System.Boolean

Visual Basic (Usage)

```
Dim instance As IAnnotationView  
Dim value As System.Boolean  
  
value = instance.Activate()
```

C#

```
System.bool Activate()
```

C++/CLI

```
System.bool Activate();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the annotation view is activated, false if not

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Activate](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::ActivateAndReorient Method](#)  
[IAnnotationView::Hide Method](#)  
[IAnnotationView::Show Method](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## ActivateAndReorient Method (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : ActivateAndReorient Method (IAnnotationView)

Activates and reorients this annotation view.

### .NET Syntax

Visual Basic (Declaration)

```
Function ActivateAndReorient() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean  
  
value = instance.ActivateAndReorient()
```

C#

```
System.bool ActivateAndReorient()
```

C++/CLI

```
System.bool ActivateAndReorient();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the annotation view is activated and reoriented, false if not

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::ActivateAndReorient](#).

### Remarks

The annotation view is oriented normal to its plane.

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Activate Method](#)  
[IAnnotationView::Orient Method](#)  
[IAnnotationView::Hide Method](#)  
[IAnnotationView::Show Method](#)

## Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Always2D Property (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : Always2D Property (IAnnotationView)

Gets whether to display annotations in 2D or 3D.

## .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Always2D As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView
Dim value As System.Boolean

value = instance.Always2D
```

C#

```
System.bool Always2D {get;}
```

C++/CLI

```
property System.bool Always2D {
    System.bool get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True to display annotations in 2D, false to display them in 3D

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Always2D](#).

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## AngleMadeWithViewHorizontal Property (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : AngleMadeWithViewHorizontal Property (IAnnotationView)

Gets the angle used to make the annotation view horizontal.

## Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property AngleMadeWithViewHorizontal As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView
Dim value As System.Double

value = instance.AngleMadeWithViewHorizontal
```

C#

```
System.double AngleMadeWithViewHorizontal {get;}
```

C++/CLI

```
property System.double AngleMadeWithViewHorizontal {
    System.double get();
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Angle

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::AngleMadeWithViewHorizontal](#).

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)

## Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## AnnotationCount Property (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : AnnotationCount Property (IAnnotationView)

Gets the number of [annotations](#) in this annotation view.

## Visual Basic Syntax

Visual Basic (Declaration)

```
ReadOnly Property AnnotationCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView
Dim value As System.Integer

value = instance.AnnotationCount
```

C#

```
System.int AnnotationCount {get;}
```

C++/CLI

```
property System.int AnnotationCount {  
    System.int get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Number of annotations

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::AnnotationCount](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### Remarks

Call this method before calling [IAnnotationView::IGetAnnotations](#) to get the size of the array for that method.

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Annotations Property](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Annotations Property (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : Annotations Property (IAnnotationView)

Obsolete. Superseded by [IAnnotationView::GetAnnotations2](#).

### .NET Syntax

Visual Basic (Declaration)

ReadOnly Property Annotations As System.Object

Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Object
```

```
value = instance.Annotations
```

C#

```
System.object Annotations {get;}
```

C++/CLI

```
property System.Object^ Annotations {  
    System.Object^ get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

[Annotations](#)

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Annotations](#).

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::GetAnnotations Method](#)  
[IAnnotationView::AnnotationCount Property](#)

## Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## FlatPatternView Property (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : FlatPatternView Property (IAnnotationView)

Gets whether this annotation view is a flat-pattern view.

## .NET Syntax

### Visual Basic (Declaration)

```
ReadOnly Property FlatPatternView As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean
```

```
value = instance.FlatPatternView
```

### C#

```
System.bool FlatPatternView {get;}
```

### C++/CLI

```
property System.bool FlatPatternView {  
    System.bool get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

True if this annotation view is a flat-pattern view, false if not

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::FlatPatternView](#).

## Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::UnassignedView Property \(\)](#)

## Availability

## GetAnnotations2 Method (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : GetAnnotations2 Method (IAnnotationView)

Gets the annotations in this annotation view.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetAnnotations2( _
    ByVal DimXpertOnly As System.Boolean, _
    ByVal UnassignedInPlane As System.Boolean _
) As System.Object
```

#### Visual Basic (Usage)



```
Dim instance As IAnnotationView
Dim DimXpertOnly As System.Boolean
Dim UnassignedInPlane As System.Boolean
Dim value As System.Object

value = instance.GetAnnotations2(DimXpertOnly, UnassignedInPlane)
```

#### C#

```
System.object GetAnnotations2(
    System.bool DimXpertOnly,
    System.bool UnassignedInPlane
)
```

#### C++/CLI

```
System.Object^ GetAnnotations2(
    & System.bool DimXpertOnly,
    & System.bool UnassignedInPlane
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

##### *DimXpertOnly*

True to get only DimXpert annotations, false to get all annotations

##### *UnassignedInPlane*

True to get annotations on all planes, including annotations on unassigned planes; false to get annotations on all planes, except annotations on unassigned planes

#### Return Value

[Annotations](#)

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::GetAnnotations2](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::AnnotationCount Property \(\)](#)

### Availability

## GetViewRotation Method (IAnnotationView)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : GetViewRotation Method (IAnnotationView)

Gets the rotation matrix of the annotation view relative to the X-Y plane of the model.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function GetViewRotation() As System.Object
```

#### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Object  
  
value = instance.GetViewRotation()
```

#### C#

```
System.object GetViewRotation()
```

#### C++/CLI

```
System.Object^ GetViewRotation();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

Array of 9 doubles of the rotation matrix of the annotation view relative to the X-Y plane of the model

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::GetViewRotation](#).

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotation::IGetViewRotation Method](#)  
[IAnnotation::GetPlane Method](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

## Hide Method (IAnnotationView)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : Hide Method (IAnnotationView)

Hides the annotations in an annotation view that is not activated.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function Hide() As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean
```

```
value = instance.Hide()
```

C#

```
System.bool Hide()
```

C++/CLI

```
System.bool Hide();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the annotations in an annotation view that is not activated are hidden (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Hide](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### Remarks

This method returns false if the annotation view is activated.

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Show Method](#)  
[IAnnotationView::IsShown Method](#)  
[IAnnotationView::Activate Method](#)  
[IAnnotationView::ActivateAndReorient Method](#)  
[IAnnotation::CanShowInAnnotationView Method](#)  
[IAnnotation::CanShowInMultipleAnnotationViews Method](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## IGetAnnotations Method (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : IGetAnnotations Method (IAnnotationView)

Obsolete. Superseded by [IAnnotationView::GetAnnotations2](#).

### .NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotations( _  
    ByVal AnnotationCount As System.Integer _  
) As Annotation
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim AnnotationCount As System.Integer  
Dim value As Annotation  
  
value = instance.IGetAnnotations(AnnotationCount)
```

C#

```
Annotation IGetAnnotations(  
    System.int AnnotationCount  
)
```

C++/CLI

```
Annotation^ IGetAnnotations(  
&    System.int AnnotationCount  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*AnnotationCount*  
Number of annotations

#### Return Value

- in-process, unmanaged C++: Pointer to an array of [annotations](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

#### Remarks

Before calling this method, call [IAnnotationView::AnnotationCount](#) to get the value for AnnotationCount.

#### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Annotations Property](#)

#### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IGetViewRotation Method (IAnnotationView)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : IGetViewRotation Method (IAnnotationView)

Gets the rotation matrix of the annotation view relative to the X-Y plane of the model.

#### .NET Syntax

Visual Basic (Declaration)

```
Function IGetViewRotation() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Double  
  
value = instance.IGetViewRotation()
```

C#

```
System.double IGetViewRotation()
```

C++/CLI

```
System.double IGetViewRotation();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

- in-process, unmanaged C++: Pointer to an array of 9 doubles of the rotation matrix of the annotation view relative to the X-Y plane of the model
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotation::GetViewRotation Method](#)  
[IAnnotation::GetPlane Method](#)

## Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## IsShown Method (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : IsShown Method (IAnnotationView)

Gets whether the annotations in this annotation view are shown.

## .NET Syntax

Visual Basic (Declaration)

```
Function IsShown() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView
Dim value As System.Boolean

value = instance.IsShown()
```

C#

```
System.bool IsShown()
```

C++/CLI

```
System.bool IsShown();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

True if the annotations are shown, false if not

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::IsShown](#).

## Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Hide Method \(\)](#)  
[IAnnotationView::Show Method \(\)](#)  
[IAnnotation::CanShowInAnnotationView Method \(\)](#)  
[IAnnotation::CanShowInMultipleAnnotationViews Method \(\)](#)

## Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

## MoveAnnotations Method (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : MoveAnnotations Method (IAnnotationView)

Moves the specified annotations to this annotation view.

### .NET Syntax

#### Visual Basic (Declaration)

```
Function MoveAnnotations( _  
    ByVal AnnotationsToMove As System.Object _  
) As System.Boolean
```

#### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim AnnotationsToMove As System.Object  
Dim value As System.Boolean  
  
value = instance.MoveAnnotations(AnnotationsToMove)
```

#### C#

```
System.bool MoveAnnotations(  
    System.object AnnotationsToMove  
)
```

#### C++/CLI

```
System.bool MoveAnnotations(  
& System.Object^ AnnotationsToMove  
)
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Parameters

*AnnotationsToMove*  
Annotations to move

#### Return Value

True if the specified annotations are moved, false if not

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::MoveAnnotations](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

## Orient Method (IAnnotationView)

[See Also](#)



Orients this annotation view.

## .NET Syntax

### Visual Basic (Declaration)

```
Function Orient() As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean
```

```
value = instance.Orient()
```

### C#

```
System.bool Orient()
```

### C++/CLI

```
System.bool Orient();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Return Value

True if the annotation view is oriented, false if not

## Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Orient](#).

## Remarks

The annotation view is oriented normal to its plane.

## See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::ActivateAndReorient Method](#)  
[IAnnotationView::Activate Method](#)

## Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## Show Method (IAnnotationView)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IAnnotationView Interface : Show Method (IAnnotationView)

Shows the annotations in an annotation view that is not activated.

## .NET Syntax

### Visual Basic (Declaration)

```
Function Show() As System.Boolean
```

### Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean
```

```
value = instance.Show()
```

C#

```
System.bool Show()
```

C++/CLI

```
System.bool Show();
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Return Value

True if the annotations in an annotation view that is not activated are shown (see **Remarks**)

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::Show](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### Remarks

This method returns false if the annotation view is activated.

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IAnnotationView::Hide Method](#)  
[IAnnotationView::IsShown Method](#)  
[IAnnotationView::Activate Method](#)  
[IAnnotationView::ActivateAndReorient Method](#)  
[IAnnotation::CanShowInAnnotationView Method](#)  
[IAnnotation::CanShowInMultipleAnnotationViews Method](#)

### Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

## UnassignedView Property (IAnnotationView)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAnnotationView Interface](#) : UnassignedView Property (IAnnotationView)

Gets whether this annotation view is assigned to a 3D View.

### .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property UnassignedView As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAnnotationView  
Dim value As System.Boolean
```

```
value = instance.UnassignedView
```

C#

```
System.bool UnassignedView {get;}
```

C++/CLI

```
property System.bool UnassignedView {  
    System.bool get();  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True if this annotation view is not assigned to a 3D View, false if it is

### Visual Basic for Applications (VBA) Syntax

See [AnnotationView::UnassignedView](#).

### Example

[Move Annotations to Notes Area Annotation View \(C#\)](#)  
[Move Annotations to Notes Area Annotation View \(VB.NET\)](#)  
[Move Annotations to Notes Area Annotation View \(VBA\)](#)

### See Also

[IAnnotationView Interface](#)  
[IAnnotationView Members](#)  
[IView3D Interface](#)  
[IAnnotationView::FlatPatternView Property \(\)](#)

### Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

# IAppearanceSetting (Type)

## IAppearanceSetting Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAppearanceSetting Interface

Allows access to visual property settings.

**NOTE:** Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

### .NET Syntax

Visual Basic (Declaration)

Public Interface IAppearanceSetting

Visual Basic (Usage)

Dim instance As [IAppearanceSetting](#)

C#

public interface IAppearanceSetting

C++/CLI

public interface class IAppearanceSetting

### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting](#).

### Example

[Change Color of Component in Specific Display State \(C#\)](#)  
[Change Color of Component in Specific Display State \(VB.NET\)](#)  
[Change Color of Component in Specific Display State \(VBA\)](#)

### Remarks

After implementing this interface:

1. Set one or more properties in the IAppearanceSetting object.
2. Call [IModelDocExtension::GetDisplayStateSetting](#) to obtain an [IDisplayStateSetting](#) object.
3. Call [IDisplayStateSetting::Names](#) or [IDisplayStateSetting::SetNames](#) to specify the display states.
4. Call [IDisplayStateSetting::Entities](#) or [IDisplayStateSetting::SetEntities](#) to specify the components.
5. Call [IDisplayStateSetting::Option](#) to specify the display state scope of the setting.
6. Get or set the visual properties for the specified display states, components, and scope using [IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#).

### Accessors

[IModelDocExtension::GetAppearanceSetting](#)  
[IModelDocExtension::DisplayStateSpecMaterialPropertyValues](#)  
[ISwScene::FloorSelection](#)

### Access Diagram

[AppearanceSetting](#)

### See Also

[IAppearanceSetting Members](#)  
[SolidWorks.Interop.sldworks Namespace](#)

[See Also](#) [Properties](#)

[SolidWorks.Interop.sldworks Namespace](#) : IAppearanceSetting Interface

The following tables list the members exposed by [IAppearanceSetting](#).

 **Public Properties**

| Name                                                                                                               | Description                                                                                                                    |
|--------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">BlurryReflection</a> | Gets or sets whether to blur the reflections of surfaces.                                                                      |
|  <a href="#">Color</a>            | Gets or sets the color.                                                                                                        |
|  <a href="#">Diffuse</a>          | Gets or sets the intensity of light on a surface.                                                                              |
|  <a href="#">DoubleSided</a>      | Gets or sets whether to enable shading from both sides of a surface when rendering a model using a ray-trace rendering engine. |
|  <a href="#">Luminous</a>         | Gets or sets the brightness emitted from the surface.                                                                          |
|  <a href="#">Reflection</a>       | Gets or sets the reflectivity of a surface.                                                                                    |
|  <a href="#">RoundSharpEdges</a>  | Gets or sets the value by which to round sharp edges when rendering a model using a ray-trace rendering engine.                |
|  <a href="#">Specular</a>         | Gets or sets the intensity of highlights on surfaces.                                                                          |
|  <a href="#">SpecularColor</a>    | Gets or sets the color of reflected highlights for a specular component.                                                       |
|  <a href="#">SpecularSpread</a>   | Gets or sets the blurriness of reflections on a surface.                                                                       |
|  <a href="#">Transparent</a>      | Gets or sets the degree to which light can pass through a surface.                                                             |

[Top](#)

 **See Also**

[IAppearanceSetting Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

**IAppearanceSetting Interface Properties**

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IAppearanceSetting Interface

For a list of all members of this type, see [IAppearanceSetting members](#).

 **Public Properties**

| Name                                                                                                                 | Description                                                                                                                    |
|----------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
|  <a href="#">BlurryReflection</a> | Gets or sets whether to blur the reflections of surfaces.                                                                      |
|  <a href="#">Color</a>            | Gets or sets the color.                                                                                                        |
|  <a href="#">Diffuse</a>          | Gets or sets the intensity of light on a surface.                                                                              |
|  <a href="#">DoubleSided</a>      | Gets or sets whether to enable shading from both sides of a surface when rendering a model using a ray-trace rendering engine. |
|  <a href="#">Luminous</a>         | Gets or sets the brightness emitted from the surface.                                                                          |
|  <a href="#">Reflection</a>       | Gets or sets the reflectivity of a surface.                                                                                    |
|  <a href="#">RoundSharpEdges</a>  | Gets or sets the value by which to round sharp edges when rendering a model using a ray-trace rendering engine.                |
|  <a href="#">Specular</a>         | Gets or sets the intensity of highlights on surfaces.                                                                          |
|  <a href="#">SpecularColor</a>    | Gets or sets the color of reflected highlights for a specular component.                                                       |
|  <a href="#">SpecularSpread</a>   | Gets or sets the blurriness of reflections on a surface.                                                                       |
|  <a href="#">Transparent</a>      | Gets or sets the degree to which light can pass through a surface.                                                             |

[Top](#)

 **See Also**

[IAppearanceSetting Interface](#)  
[SolidWorks.Interop.sldworks Namespace](#)

## BlurryReflection Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : BlurryReflection Property (IAppearanceSetting)

Gets or sets whether to blur the reflections of surfaces.

### .NET Syntax

Visual Basic (Declaration)

Property BlurryReflection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting  
Dim value As System.Boolean
```

```
instance.BlurryReflection = value
```

```
value = instance.BlurryReflection
```

C#

```
System.bool BlurryReflection {get; set;}
```

C++/CLI

```
property System.bool BlurryReflection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to blur reflections, false to not

### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::BlurryReflection](#).

### Remarks

See SOLIDWORKS Help for more information about appearances.

### See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

### Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

## Color Property (IAppearanceSetting)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Color Property (IAppearanceSetting)

Gets or sets the color.

### .NET Syntax

Visual Basic (Declaration)

## Property Color As System.Integer

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting  
Dim value As System.Integer
```

```
instance.Color = value
```

```
value = instance.Color
```

C#

```
System.int Color {get; set;}
```

C++/CLI

```
property System.int Color {  
    System.int get();  
    void set ( & System.int value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Color value (see **Remarks**)

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting.Color](#).

## Example

[Change Color of Component in Specific Display State \(C#\)](#)  
[Change Color of Component in Specific Display State \(VB.NET\)](#)  
[Change Color of Component in Specific Display State \(VBA\)](#)

## Remarks

$color\_value = \text{MAX}(\text{MIN}(red\_rgb\_value, 255), 0) + \text{MAX}(\text{MIN}(green\_rgb\_value, 255), 0) * 16 * 16 + \text{MAX}(\text{MIN}(blue\_rgb\_value, 255), 0) * 16 * 16 * 16$

See SOLIDWORKS Help for more information about appearances.

## See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Diffuse Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Diffuse Property (IAppearanceSetting)

Gets or sets the intensity of light on a surface.

## .NET Syntax

Visual Basic (Declaration)

Property Diffuse As System.Double

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Double

instance.Diffuse = value

value = instance.Diffuse
```

C#

```
System.double Diffuse {get; set;}
```

C++/CLI

```
property System.double Diffuse {
    System.double get();
    void set ( &    System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

0 <= *diffuseness* <= 1

### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::Diffuse](#).

### Remarks

See SOLIDWORKS Help for more information about appearances.

### See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

### Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## DoubleSided Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : DoubleSided Property (IAppearanceSetting)

Gets or sets whether to enable shading from both sides of a surface when rendering a model using a ray-trace rendering engine.

### .NET Syntax

Visual Basic (Declaration)

```
Property DoubleSided As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Boolean

instance.DoubleSided = value

value = instance.DoubleSided
```

C#

```
System.bool DoubleSided {get; set;}
```

C++/CLI

```
property System.bool DoubleSided {
    System.bool get();
    void set ( & System.bool value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

True to enable shading from both sides, false to not

### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::DoubleSided](#).

### Remarks

This method is only available when a ray-trace rendering engine is loaded.

#### NOTES:

- When this property is disabled, surfaces that do not face the camera seem invisible.
- Double-sided surfaces can cause rendering errors. Use sparingly.

### See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

### Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Luminous Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Luminous Property (IAppearanceSetting)

Gets or sets the brightness emitted from the surface.

### .NET Syntax

Visual Basic (Declaration)

```
Property Luminous As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Double
```

```
instance.Luminous = value
```

```
value = instance.Luminous
```

C#

```
System.double Luminous {get; set;}
```

C++/CLI

```
property System.double Luminous {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

0 <= luminosity <= 1

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::Luminous](#).

## Remarks

See SOLIDWORKS Help for more information about appearances.

## See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Reflection Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Reflection Property (IAppearanceSetting)

Gets or sets the reflectivity of a surface.

## .NET Syntax

Visual Basic (Declaration)

Property Reflection As System.Double

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Double
```

```
instance.Reflection = value
```

```
value = instance.Reflection
```

C#

```
System.double Reflection {get; set;}
```

C++/CLI

```
property System.double Reflection {
    System.double get();
    void set ( & System.double value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

0 <= *reflectivity* <= 1, where 0 is for no reflection, and 1 is for a mirror reflection

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::Reflection](#).

## Remarks

See SOLIDWORKS Help for more information about appearances.

## See Also

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## RoundSharpEdges Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : RoundSharpEdges Property (IAppearanceSetting)

Gets or sets the value by which to round sharp edges when rendering a model using a ray-trace rendering engine.

## .NET Syntax

### Visual Basic (Declaration)

Property RoundSharpEdges As System.Double

### Visual Basic (Usage)



```
Dim instance As IAppearanceSetting  
Dim value As System.Double
```

```
instance.RoundSharpEdges = value
```

```
value = instance.RoundSharpEdges
```

### C#

```
System.double RoundSharpEdges {get; set;}
```

### C++/CLI

```
property System.double RoundSharpEdges {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

Value by which to round sharp edges

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting.RoundSharpEdges](#).

## Remarks

This method:

- is only available when a ray-trace rendering engine is loaded.
- does not change model geometry.

## See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

## Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Specular Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Specular Property (IAppearanceSetting)

Gets or sets the intensity of highlights on surfaces.

## .NET Syntax

### Visual Basic (Declaration)

Property Specular As System.Double

### Visual Basic (Usage)



```
Dim instance As IAppearanceSetting  
Dim value As System.Double
```

```
instance.Specular = value
```

```
value = instance.Specular
```

### C#

```
System.double Specular {get; set;}
```

### C++/CLI

```
property System.double Specular {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

### Property Value

0 <= specular\_value <= 1; valid only when [IAppearanceSetting::SpecularSpread](#) > 0

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::Specular](#).

## Remarks

See SOLIDWORKS Help for more information about appearances.

## See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SpecularColor Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : SpecularColor Property (IAppearanceSetting)

Gets or sets the color of reflected highlights for a specular component.

## .NET Syntax

### Visual Basic (Declaration)

Property SpecularColor As System.Integer

### Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Integer

instance.SpecularColor = value
value = instance.SpecularColor
```

C#

```
System.int SpecularColor {get; set;}
```

C++/CLI

```
property System.int SpecularColor {
    System.int get();
    void set ( & System.int value);
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

Color of reflected highlights; valid only when [IAppearanceSetting::SpecularSpread](#) > 0 and [IAppearanceSetting::Specular](#) > 0 (see **Remarks**)

#### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::SpecularColor](#).

#### Remarks

$specular\_color = MAX(MIN(red\_rgb\_value, 255), 0) + MAX(MIN(green\_rgb\_value, 255), 0) * 16 * 16 + MAX(MIN(blue\_rgb\_value, 255), 0) * 16 * 16 * 16$   
See SOLIDWORKS Help for more information about appearances.

#### See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

#### Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## SpecularSpread Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : SpecularSpread Property (IAppearanceSetting)

Gets or sets the blurriness of reflections on a surface.

#### .NET Syntax

Visual Basic (Declaration)

```
Property SpecularSpread As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting
Dim value As System.Double

instance.SpecularSpread = value
value = instance.SpecularSpread
```

C#

```
System.double SpecularSpread {get; set;}
```

C++/CLI

```
property System.double SpecularSpread {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

0 <= specular\_spread <= 1; valid only when [IAppearanceSetting::Specular](#) > 0 and [IAppearanceSetting::SpecularColor](#) > 0 (not black)

### Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::SpecularSpread](#).

### Remarks

See SOLIDWORKS Help for more information about appearances.

### See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

### Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

## Transparent Property (IAppearanceSetting)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAppearanceSetting Interface](#) : Transparent Property (IAppearanceSetting)

Gets or sets the degree to which light can pass through a surface.

### .NET Syntax

Visual Basic (Declaration)

```
Property Transparent As System.Double
```

Visual Basic (Usage)



```
Dim instance As IAppearanceSetting  
Dim value As System.Double
```

```
instance.Transparent = value
```

```
value = instance.Transparent
```

C#

```
System.double Transparent {get; set;}
```

C++/CLI

```
property System.double Transparent {  
    System.double get();  
    void set ( & System.double value);  
}
```

**NOTE:** See [Differences Between Unmanaged C++ and C++/CLI Code](#).

#### Property Value

0 <= *transparency* <= 100, where 0 is for total opaqueness, and 100 is for total transparency

## Visual Basic for Applications (VBA) Syntax

See [AppearanceSetting::Transparent](#).

## Remarks

See SOLIDWORKS Help for more information about appearances.

## See Also

[IAppearanceSetting Interface](#)  
[IAppearanceSetting Members](#)

## Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0