

SOLIDWORKS API (.NET VBA C#) — Reference (17/337): IAssemblyDoc (part 5 of 5)

SOLIDWORKS API Documentation (converted from CHM)

IAssemblyDoc (part 5 of 5) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowExploded Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ShowExploded Method (IAssemblyDoc)

Obsolete. Superseded by [IAssemblyDoc::ShowExploded2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ShowExploded( _  
    ByVal ShowIt As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim ShowIt As System.Boolean  
Dim value As System.Boolean  
  
value = instance.ShowExploded>ShowIt)
```

C#

```
System.bool ShowExploded(  
    System.bool ShowIt  
)
```

C++/CLI

```
System.bool ShowExploded(  
& System.bool ShowIt  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowIt

True if you want to show the existing exploded state for the current assembly configuration, false if you want to show the assembly in the collapsed state

Return Value

True if successful in displaying the existing exploded assembly state, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ShowExploded](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::AutoExplode Method](#)
[ViewCollapseAssembly Method](#)
[ViewExplodeAssembly Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowExploded2 Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ShowExploded2 Method (IAssemblyDoc)

Displays the specified exploded view for the current assembly configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function ShowExploded2( _  
    ByVal ShowIt As System.Boolean, _  
    ByVal ExplodeViewName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim ShowIt As System.Boolean  
Dim ExplodeViewName As System.String  
Dim value As System.Boolean  
  
value = instance.ShowExploded2(ShowIt, ExplodeViewName)
```

C#

```
System.bool ShowExploded2(  
    System.bool ShowIt,  
    System.string ExplodeViewName  
)
```

C++/CLI

```
System.bool ShowExploded2(  
& System.bool ShowIt,  
& System.String^ ExplodeViewName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ShowIt

True if you want to show ExplodeViewName in its exploded state, false if you want to show it in its collapsed state

ExplodeViewName

Name of the exploded view to show

Return Value

True if the exploded view displays, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ShowExploded2](#).

Example

[Create Exploded Views of an Assembly \(VBA\)](#)
[Create Exploded Views of an Assembly \(VB.NET\)](#)
[Create Exploded Views of an Assembly \(C#\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::AutoExplode Method \(\)](#)
[IAssemblyDoc::CreateExplodedView Method \(\)](#)
[IAssemblyDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IAssemblyDoc::GetExplodedViewCount2 Method \(\)](#)
[IAssemblyDoc::GetExplodedViewNames2 Method \(\)](#)
[IAssemblyDoc::ViewCollapseAssembly Method \(\)](#)
[IAssemblyDoc::ViewExplodeAssembly Method \(\)](#)
[IModelDocExtension::IsExploded Method \(\)](#)
[IView::IsExploded Method \(\)](#)
[IView::ShowExploded Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : TemporaryFixGroup Method (IAssemblyDoc)

Temporarily fix or group selected components during such operations as drag, move, rotate, etc.

.NET Syntax

Visual Basic (Declaration)

```
Sub TemporaryFixGroup()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
instance.TemporaryFixGroup()
```

C#

```
void TemporaryFixGroup()
```

C++/CLI

```
void TemporaryFixGroup();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::TemporaryFixGroup](#).

Example

[Temporarily Fix and Group Components \(C#\)](#)
[Temporarily Fix and Group Components \(VB.NET\)](#)
[Temporarily Fix and Group Components \(VBA\)](#)

Remarks

Use the following selection marks with [IModelDocExtension::SelectByID2](#) to select the components:

- 0 = Components to fix
- 2 = Components to group

Call [IAssemblyDoc::TemporaryFixGroupExit](#) to change the components back to floating or ungrouped.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IComponent2::IsFixed Method \(\)](#)
[IAssemblyDoc::FixComponent Method \(\)](#)
[IAssemblyDoc::UnfixComponent Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TemporaryFixGroupExit Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : TemporaryFixGroupExit Method (IAssemblyDoc)

Changes components that were temporarily fixed or grouped back to floating or ungrouped after such operations as drag, move, rotate, etc.

.NET Syntax

Visual Basic (Declaration)

Sub TemporaryFixGroupExit()

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.TemporaryFixGroupExit()
```

C#

```
void TemporaryFixGroupExit()
```

C++/CLI

```
void TemporaryFixGroupExit();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::TemporaryFixGroupExit](#).

Example

[Temporarily Fix and Group Components \(C#\)](#)
[Temporarily Fix and Group Components \(VB.NET\)](#)
[Temporarily Fix and Group Components \(VBA\)](#)

Remarks

To temporarily change floating or ungrouped components to fixed or grouped, call [IAssemblyDoc::TemporaryFixGroup](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IComponent2::IsFixed Method \(\)](#)
[IAssemblyDoc::FixComponent Method \(\)](#)
[IAssemblyDoc::UnfixComponent Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ToolsCheckInterference Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ToolsCheckInterference Method (IAssemblyDoc)

Obsolete. Superseded by [IAssemblyDoc::ToolsCheckInterference2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ToolsCheckInterference()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.ToolsCheckInterference()
```

C#

```
void ToolsCheckInterference()
```

C++/CLI

```
void ToolsCheckInterference();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ToolsCheckInterference](#).

Remarks

Opens the Interference Detection PropertyManager.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ToolsCheckInterference2 Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ToolsCheckInterference2 Method (IAssemblyDoc)

Checks for interference between parts in this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Sub ToolsCheckInterference2( _  
    ByVal NumComponents As System.Integer, _  
    ByVal LpComponents As System.Object, _  
    ByVal CoincidentInterference As System.Boolean, _  
    ByRef PComp As System.Object, _  
    ByRef PFace As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim NumComponents As System.Integer  
Dim LpComponents As System.Object  
Dim CoincidentInterference As System.Boolean  
Dim PComp As System.Object  
Dim PFace As System.Object  
  
instance.ToolsCheckInterference2(NumComponents, LpComponents, CoincidentInterference, PComp, PFace)
```

C#

```
void ToolsCheckInterference2(  
    System.int NumComponents,  
    System.object LpComponents,  
    System.bool CoincidentInterference,  
    out System.object PComp,  
    out System.object PFace  
)
```

C++/CLI

```
void ToolsCheckInterference2(  
& System.int NumComponents,  
& System.Object^ LpComponents,  
& System.bool CoincidentInterference,  
& [Out] System.Object^ PComp,
```

```
& [Out] System.Object^ PFace  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumComponents

Number of components to check

LpComponents

Array of [components](#) being checked for interference

CoincidentInterference

True to treat coincident entities as interference, false to not

PComp

Array of components where interferences have been found

PFace

Array of [faces](#) where interferences have been found

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ToolsCheckInterference2](#).

Example

[Check Interference \(VBA\)](#)

Remarks

This method returns:

- an empty array of faces for components that have coincident faces that touch.
- an array of components for components that touch.

For each face that intersects, there is a corresponding component.

NOTE: The obsolete method, `IAssemblyDoc::ToolsCheckInterference`, displays the Interference Detection PropertyManager, but this method does not.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ToolsCheckInterference3 Method](#)
[InterferenceDetectionMgr Interface](#)
[Interference Interface](#)
[IModeler::CheckInterferenceCount3 Method](#)
[IModeler::CheckInterference3 Method](#)
[IModeler::CheckInterference3 Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TranslateComponent Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : TranslateComponent Method (IAssemblyDoc)

Displays the Move Component PropertyManager page.

.NET Syntax

Visual Basic (Declaration)

```
Sub TranslateComponent()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
instance.TranslateComponent()
```

C#

```
void TranslateComponent()
```

C++/CLI

```
void TranslateComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::TranslateComponent](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

UnfixComponent Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UnfixComponent Method (IAssemblyDoc)

Floats the selected component; i.e., makes it movable.

.NET Syntax

Visual Basic (Declaration)

```
Sub UnfixComponent()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
instance.UnfixComponent()
```

C#

```
void UnfixComponent()
```

C++/CLI

```
void UnfixComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UnfixComponent](#).

Example

[Switch Edit Context \(VBA\)](#)
[Switch Edit Context \(VB.NET\)](#)
[Switch Edit Context \(C#\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::FixComponent Method \(\)](#)
[IAssemblyDoc::TemporaryFixGroup Method \(\)](#)
[IAssemblyDoc::TemporaryFixGroupExit Method \(\)](#)
[IComponent2::IsFixed Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

UngroupComponents Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UngroupComponents Method (IAssemblyDoc)

Ungroups the grouped components in the selected folder in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Function UngroupComponents() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean  
  
value = instance.UngroupComponents()
```

C#

```
System.bool UngroupComponents()
```

C++/CLI

```
System.bool UngroupComponents();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the grouped components in the selected folder in the FeatureManager design tree are ungrouped, false if not

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UngroupComponents](#).

Example

[Group and Ungroup Components \(C#\)](#)
[Group and Ungroup Components \(VB.NET\)](#)
[Group and Ungroup Components \(VBA\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IFeatureManager::GroupComponentInstances Property\(\)](#)
[IAssemblyDoc::ReorderComponents Method \(\)](#)
[IAssemblyDoc::ReorganizeComponents Method \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateBox Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UpdateBox Method (IAssemblyDoc)

Updates the bounding box for this assembly.

.NET Syntax

Visual Basic (Declaration)

```
Sub UpdateBox()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
instance.UpdateBox()
```

C#

```
void UpdateBox()
```

C++/CLI

```
void UpdateBox();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UpdateBox](#).

Example

[Recalculate Bounding Box \(C#\)](#)
[Recalculate Bounding Box \(VB.NET\)](#)
[Recalculate Bounding Box \(VBA\)](#)

Remarks

Use this method to help avoid clipping in shaded display mode if the assembly bounds change; for example, if you modify a component location using [IComponent2::Transform2](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::GetBox Method](#)
[IAssemblyDoc::IGetBox Method](#)
[IModelDocExtension::SetVisibleBox Method](#)
[IModelDocExtension::RemoveVisibleBox Method](#)
[IModelDocExtension::GetVisibleBox Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

UpdateFeatureScope Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UpdateFeatureScope Method (IAssemblyDoc)

Updates the feature scope and rebuilds the currently selected assembly feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub UpdateFeatureScope()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc
```

```
instance.UpdateFeatureScope()
```

C#

```
void UpdateFeatureScope()
```

C++/CLI

```
void UpdateFeatureScope();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UpdateFeatureScope](#).

Remarks

You can use assembly features to create a feature that affects multiple components in an assembly. For example, if you need a hole through two blocks to bolt them together, you can create a hole as an assembly feature that goes through both of the blocks.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::AddToFeatureScope Method](#)
[IAssemblyDoc::GetFeatureScope Method](#)
[IAssemblyDoc::GetFeatureScopeCount Method](#)
[IAssemblyDoc::RemoveFromFeatureScope Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateSpeedPak Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UpdateSpeedPak Method (IAssemblyDoc)

Updates out-of-date SpeedPak configurations for the selected subassemblies.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateSpeedPak() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.UpdateSpeedPak()
```

C#

```
System.bool UpdateSpeedPak()
```

C++/CLI

```
System.bool UpdateSpeedPak();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if out-of-date SpeedPak configurations are updated for the selected subassemblies, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UpdateSpeedPak](#).

Remarks

If no out-of-date SpeedPak configurations exist for the selected subassemblies, then this method returns false.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::CreateSpeedPak Method \(\)](#)
[IAssemblyDoc::SetSpeedPakConfigurations Method \(\)](#)
[IAssemblyDoc::SetSpeedPakToParent Method \(\)](#)
[IAssemblyDoc::UseSpeedPak Method \(\)](#)
[IComponent2::IsSpeedPak Property \(\)](#)
[IConfiguration::UpdateSpeedPak Method \(\)](#)

Availability

UpdateToolboxComponent Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UpdateToolboxComponent Method (IAssemblyDoc)

Updates SOLIDWORKS Toolbox components in the specified assembly level using the current information in Toolbox settings.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateToolboxComponent( _  
    ByVal AssemblyLevelToUpdate As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim AssemblyLevelToUpdate As System.Integer  
Dim value As System.Integer  
  
value = instance.UpdateToolboxComponent(AssemblyLevelToUpdate)
```

C#

```
System.int UpdateToolboxComponent(  
    System.int AssemblyLevelToUpdate  
)
```

C++/CLI

```
System.int UpdateToolboxComponent(  
& System.int AssemblyLevelToUpdate  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AssemblyLevelToUpdate

Level in which to update SOLIDWORKS Toolbox components as defined in [swAssemblyLevelToUpdate_e](#)

Return Value

Status of updating the SOLIDWORKS Toolbox components as defined in [swAssemblyUpdateToolboxComponentStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UpdateToolboxComponent](#).

Example

[Update All Toolbox Components \(C#\)](#)
[Update All Toolbox Components \(VB.NET\)](#)
[Update All Toolbox Components \(VBA\)](#)

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

UseSpeedPak Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : UseSpeedPak Method (IAssemblyDoc)

Sets whether to switch the selected subassemblies whose active configuration is the parent configuration of a SpeedPak configuration to the SpeedPak configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function UseSpeedPak() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim value As System.Boolean
```

```
value = instance.UseSpeedPak()
```

C#

```
System.bool UseSpeedPak()
```

C++/CLI

```
System.bool UseSpeedPak();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the selected subassemblies whose active configuration is the parent configuration of the SpeedPak configuration switch to the SpeedPak configuration, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::UseSpeedPak](#).

Example

[Create SpeedPak for Subassemblies \(C#\)](#)
[Create SpeedPak for Subassemblies \(VB.NET\)](#)
[Create SpeedPak for Subassemblies \(VBA\)](#)

Remarks

This method is only valid if the selected subassemblies are [set to the parent configuration of the SpeedPak configuration](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::CreateSpeedPak Method \(\)](#)
[IAssemblyDoc::SetSpeedPakConfigurations Method \(\)](#)
[IAssemblyDoc::UpdateSpeedPak Method \(\)](#)
[IComponent2::IsSpeedPak Property \(\)](#)
[IDocumentSpecification::UseSpeedPak Property \(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewCollapseAssembly Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ViewCollapseAssembly Method (IAssemblyDoc)

Collapses the selected exploded view on the Configuration tab of the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Sub ViewCollapseAssembly()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.ViewCollapseAssembly()
```

C#

```
void ViewCollapseAssembly()
```

C++/CLI

```
void ViewCollapseAssembly();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ViewCollapseAssembly](#).

Example

[Access Assembly \(C++\)](#)
[Create Exploded Views of an Assembly \(VBA\)](#)
[Create Exploded Views of an Assembly \(VB.NET\)](#)
[Create Exploded Views of an Assembly \(C#\)](#)

Remarks

Use this method with [IAssemblyDoc::ViewExplodeAssembly](#) to toggle the display of the exploded assembly view.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::AutoExplode Method \(\)](#)
[IAssemblyDoc::CreateExplodedView Method \(\)](#)
[IAssemblyDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IAssemblyDoc::GetExplodedViewCount2 Method \(\)](#)
[IAssemblyDoc::GetExplodedViewNames2 Method \(\)](#)
[IAssemblyDoc::ShowExploded2 Method \(\)](#)
[IModelDocExtension::IsExploded Method \(\)](#)
[IView::IsExploded Method \(\)](#)
[IView::ShowExploded Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ViewExplodeAssembly Method (IAssemblyDoc)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ViewExplodeAssembly Method (IAssemblyDoc)

Explodes the selected exploded view on the Configuration tab of the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Sub ViewExplodeAssembly()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.ViewExplodeAssembly()
```

C#

```
void ViewExplodeAssembly()
```

C++/CLI

```
void ViewExplodeAssembly();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ViewExplodeAssembly](#).

Example

[Create Exploded Views of an Assembly \(VBA\)](#)
[Create Exploded Views of an Assembly \(VB.NET\)](#)
[Create Exploded Views of an Assembly \(C#\)](#)

Remarks

Use this method with [IAssemblyDoc::ViewCollapseAssembly](#) to toggle the display of the exploded assembly view.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::AutoExplode Method \(\)](#)
[IAssemblyDoc::CreateExplodedView Method \(\)](#)
[IAssemblyDoc::GetExplodedViewConfigurationName Method \(\)](#)
[IAssemblyDoc::GetExplodedViewCount2 Method \(\)](#)
[IAssemblyDoc::GetExplodedViewNames2 Method \(\)](#)
[IAssemblyDoc::ShowExploded2 Method \(\)](#)
[IModelDocExtension::IsExploded Method \(\)](#)
[IView::IsExploded Method \(\)](#)
[IView::ShowExploded Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ViewFeatureManagerByDependencies Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ViewFeatureManagerByDependencies Method (IAssemblyDoc)

Obsolete. Superseded by [IFeatureManager::ViewDependencies](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ViewFeatureManagerByDependencies()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.ViewFeatureManagerByDependencies()
```

C#

```
void ViewFeatureManagerByDependencies()
```

C++/CLI

```
void ViewFeatureManagerByDependencies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ViewFeatureManagerByDependencies](#).

Remarks

Use this method with [IAssemblyDoc::ViewFeatureManagerByFeatures](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ViewFeatureManagerFeatureDetail Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ViewFeatureManagerByFeatures Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ViewFeatureManagerByFeatures Method (IAssemblyDoc)

Obsolete. Superseded by [IFeatureManager::ViewFeatures](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ViewFeatureManagerByFeatures()
```

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
  
instance.ViewFeatureManagerByFeatures()
```

C#

```
void ViewFeatureManagerByFeatures()
```

C++/CLI

```
void ViewFeatureManagerByFeatures();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ViewFeatureManagerByFeatures](#).

Remarks

Use this method with [IAssemblyDoc::ViewFeatureManagerByDependencies](#).

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ViewFeatureManagerFeatureDetail Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ViewFeatureManagerFeatureDetail Method (IAssemblyDoc)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAssemblyDoc Interface](#) : ViewFeatureManagerFeatureDetail Method (IAssemblyDoc)

Obsolete. Superseded by [IFeatureManager::ShowFeatureDetails](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ViewFeatureManagerFeatureDetail( _  
    ByVal Detail As System.Boolean _
```

)

Visual Basic (Usage)



```
Dim instance As IAssemblyDoc  
Dim Detail As System.Boolean  
  
instance.ViewFeatureManagerFeatureDetail(Detail)
```

C#

```
void ViewFeatureManagerFeatureDetail(  
    System.bool Detail  
)
```

C++/CLI

```
void ViewFeatureManagerFeatureDetail(  
&    System.bool Detail  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Detail

True to show feature detail, false to hide it

Visual Basic for Applications (VBA) Syntax

See [AssemblyDoc::ViewFeatureManagerFeatureDetail](#).

Remarks

This method affects the FeatureManager design tree view of the current configuration of the assembly. It does not affect other configurations.

See Also

[IAssemblyDoc Interface](#)
[IAssemblyDoc Members](#)
[IAssemblyDoc::ViewFeatureManagerByDependencies Method](#)
[IAssemblyDoc::ViewFeatureManagerByFeatures Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0