

SOLIDWORKS API (.NET VBA C#) — Reference

(18/337): IAttribute-IAttributeDef

SOLIDWORKS API Documentation (converted from CHM)

IAttribute (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAttribute Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAttribute Interface

Allows access to an attribute's values.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAttribute
```

Visual Basic (Usage)



```
Dim instance As IAttribute
```

C#

```
public interface IAttribute
```

C++/CLI

```
public interface class IAttribute
```

Visual Basic for Applications (VBA) Syntax

See [Attribute](#).

Example

[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Delete Attribute \(C#\)](#)
[Delete Attribute \(VB.NET\)](#)
[Delete Attribute \(VBA\)](#)

Remarks

An attribute is a piece of information that can be stored on a [body](#), [component](#), [entity](#) ([face](#), [edge](#), [vertex](#), [loop2](#), or [feature](#)), and [model](#) if null.

After you place an attribute on an object, you can get the IAttribute object and get or set its parameter values. For example, you can place an attribute containing NC machining information on a face. You can then use that attribute in automation on the shop floor to know what feed or speed to use during the machining process.

You can also add attributes to a [document object](#).

From the attribute instance you can get the:

- Attribute definition
- Associated entity
- Parameter values
- Instance name

Accessors

[IAttributeDef::CreateInstance5 Method](#)

[IBody2::FindAttribute Method](#)

[IComponent2::FindAttribute](#) and [IComponent2::IFindAttribute Method](#)

[IEntity::FindAttribute](#) and [IEntity::IFindAttribute Method](#)

[IFeature::GetSpecificFeature2 Method](#)

Access Diagram

[Attribute](#)

See Also

[IAttribute Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAttribute Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAttribute Interface

The following tables list the members exposed by [IAttribute](#).

Public Properties

Name	Description
 IncludeInLibraryFeature	Gets or sets whether this attribute is included in the library feature.

[Top](#)

Public Methods

Name	Description
 Delete	Deletes an attribute and lets you indicate whether or not to update the FeatureManager design tree if the deleted attribute appears in it.
 GetBody	Gets the body to which this attribute is attached, if any.
 GetComponent	Returns the component to which this attribute is attached.
 GetDefinition	Gets the definition of this attribute.
 GetEntity	Gets the entity to which this attribute was originally associated.
 GetEntityState	Returns the state of the associated entity.
 GetName	Gets the name of the attribute.
 GetParameter	Gets the specified parameter on this attribute.
 IGetComponent	Obsolete. Superseded by IAttribute.IGetComponent2 .
 IGetComponent2	Returns the component to which this attribute is attached.
 IGetDefinition	Gets the definition of this attribute.
 IGetEntity	Obsolete. Superseded by IAttribute.IGetEntity2 .
 IGetEntity2	Gets the entity to which this attribute was originally associated.
 IGetParameter	Gets the specified parameter on this attribute.

[Top](#)

See Also

[IAttribute Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAttribute Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAttribute Interface

For a list of all members of this type, see [IAttribute members](#).

Public Methods

Name	Description
 Delete	Deletes an attribute and lets you indicate whether or not to update the FeatureManager design tree if the deleted attribute appears in it.

		
	GetBody	Gets the body to which this attribute is attached, if any.
	GetComponent	Returns the component to which this attribute is attached.
	GetDefinition	Gets the definition of this attribute.
	GetEntity	Gets the entity to which this attribute was originally associated.
	GetEntityState	Returns the state of the associated entity.
	GetName	Gets the name of the attribute.
	GetParameter	Gets the specified parameter on this attribute.
	IGetComponent	Obsolete. Superseded by IAttribute.IGetComponent2 .
	IGetComponent2	Returns the component to which this attribute is attached.
	IGetDefinition	Gets the definition of this attribute.
	IGetEntity	Obsolete. Superseded by IAttribute.IGetEntity2 .
	IGetEntity2	Gets the entity to which this attribute was originally associated.
	IGetParameter	Gets the specified parameter on this attribute.

[Top](#)

See Also

[IAttribute Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAttribute Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAttribute Interface

For a list of all members of this type, see [IAttribute members](#).

Public Properties

Name	Description
 IncludeInLibraryFeature	Gets or sets whether this attribute is included in the library feature.

[Top](#)

See Also

[IAttribute Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Delete Method (IAttribute)

[See Also](#) [Example](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : Delete Method (IAttribute)

Deletes an attribute and lets you indicate whether or not to update the FeatureManager design tree if the deleted attribute appears in it.

.NET Syntax

Visual Basic (Declaration)

```
Function Delete( _  
    ByVal BuildTree As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IAttribute  
Dim BuildTree As System.Boolean
```



```
Dim value As System.Boolean

value = instance.Delete(BuildTree)
```

C#

```
System.bool Delete(
    System.bool BuildTree
)
```

C++/CLI

```
System.bool Delete(
    & System.bool BuildTree
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BuildTree

True to update the FeatureManager design tree, false to not

Return Value

True if the attribute is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [Attribute.Delete](#).

Example

[Delete Faces \(VBA\)](#)
[Delete Attribute \(C#\)](#)
[Delete Attribute \(VB.NET\)](#)
[Delete Attribute \(VBA\)](#)
[Delete Blended Faces \(C#\)](#)
[Delete Blended Faces \(VB.NET\)](#)
[Delete Blended Faces \(VBA\)](#)

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBody Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetBody Method (IAttribute)

Gets the body to which this attribute is attached, if any.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBody() As Body2
```

Visual Basic (Usage)



```
Dim instance As IAttribute
Dim value As Body2

value = instance.GetBody()
```

C#

```
Body2 GetBody()
```

C++/CLI

```
Body2^ GetBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBody2](#)

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetBody](#).

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponent Method (IAttribute)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetComponent Method (IAttribute)

Returns the component to which this attribute is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponent() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As System.Object  
  
value = instance.GetComponent()
```

C#

```
System.object GetComponent()
```

C++/CLI

```
System.Object^ GetComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Object for the component

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetComponent](#).

Example

[Cut Body in Half using Macro Feature \(VBA\)](#)

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::GetComponent2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDefinition Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetDefinition Method (IAttribute)

Gets the definition of this attribute.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDefinition() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As System.Object  
  
value = instance.GetDefinition()
```

C#

```
System.object GetDefinition()
```

C++/CLI

```
System.Object^ GetDefinition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Object for the attribute definition

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetDefinition](#).

Remarks

SOLIDWORKS generates all attribute instances from an [IAttribute](#) object. The object is the mold that gives the attribute its parameters and default values.

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::GetDefinition Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEntity Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetEntity Method (IAttribute)

Gets the entity to which this attribute was originally associated.

.NET Syntax

```
Function GetEntity() As System.Object
```



```
Dim instance As IAttribute
Dim value As System.Object

value = instance.GetEntity()
```

```
System.object GetEntity()
```

```
System.Object^ GetEntity();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Object for the entity or NULL (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetEntity](#).

Remarks

This method returns NULL when the attribute is associated with:

- the document
- an invalid entity
- a suppressed entity

When this method returns NULL, use [IAttribute::GetEntityState](#) to determine which of these situations you have encountered.

When the [IAttribute](#) object is suppressed, this method returns NULL.

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::IGetEntity2 Method](#)
[IAttribute::GetName Method](#)
[IAttribute::GetParameter Method](#)
[IAttributeDef::CreateInstance5 Method](#)
[IBody2::FindAttribute Method](#)
[IEntity::FindAttribute Method](#)
[IEntity::IFindAttribute Method](#)
[IFeature::GetSpecificFeature2 Method](#)
[ISldWorks::DefineAttribute Method](#)

GetEntityState Method (IAttribute)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetEntityState Method (IAttribute)

Returns the state of the associated entity.

.NET Syntax

```
Function GetEntityState( _
    ByVal WhichState As System.Integer _
) As System.Boolean
```



```
Dim instance As IAttribute
Dim WhichState As System.Integer
```

```
Dim value As System.Boolean

value = instance.GetEntityState(WhichState)
```

C#

```
System.bool GetEntityState(
    System.int WhichState
)
```

C++/CLI

```
System.bool GetEntityState(
    & System.int WhichState
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichState

Entity state are defined in [swAssociatedEntityStates_e](#)

Return Value

True if the query state matches WhichState, false if not

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetEntityState](#).

Example

[Find Attribute \(C#\)](#)
[Find Attribute \(VB.NET\)](#)
[Find Attribute \(VBA\)](#)

Remarks

If the attribute is not associated to any entity (that is, it is associated to the document), all queries return false.

The WhichState argument can take any of the values in the swAssociatedEntityStates_e, where:

- swIsEntityInvalid is a general query. It returns true when the associated entity is not valid due to a suppression or modeling operation.
- swIsEntitySuppressed is a more specific query. It returns true only if the associated entity is not valid due to a suppression.

[IAttribute::GetEntity](#) and [IAttribute::IGetEntity2](#) return Nothing or null when the attribute is associated with:

- document
- invalid entity
- suppressed entity

For example, if an attribute is applied to a face on a boss feature and then that boss feature is suppressed, your application might make the following calls:

- IAttribute::GetEntity - Returns Nothing or null
- IAttribute::GetEntityState(*swIsEntityInvalid*) - Returns true to indicate possibly a suppressed or deleted entity
- IAttribute::GetEntityState(*swIsEntitySuppressed*) - Returns true to indicate that the entity is currently suppressed

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAnnotation::GetAttachedEntities2 Method](#)
[IAnnotation::IGetAttachedEntities Method](#)
[IAttribute::GetDefinition Method](#)
[IAttribute::IGetDefinition Method](#)
[IAttribute::GetName Method](#)
[IAttribute::GetParameter Method](#)
[IAttribute::IGetParameter Method](#)
[IAttributeDef::CreateInstance5 Method](#)
[IComponent2::FindAttribute Method](#)
[IComponent2::IFindAttribute Method](#)
[IEntity::FindAttribute Method](#)
[IEntity::IFindAttribute Method](#)
[IEntity::GetSafeEntity Method](#)
[IEntity::GetType Method](#)
[IFaultEntity::Entity Property](#)
[IFeature::GetSpecificFeature2 Method](#)
[IModelDocExtension::GetCorrespondingEntity Method](#)
[IPartDoc::GetEntityByName Method](#)
[IPartDoc::IGetEntityByName Method](#)
[IPartDoc::GetNamedEntities Method](#)
[IPartDoc::IGetNamedEntities Method](#)
[IView::GetVisibleEntities Method](#)
[IView::IGetVisibleEntities Method](#)

GetName Method (IAttribute)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetName Method (IAttribute)

Gets the name of the attribute.

.NET Syntax

Visual Basic (Declaration)

```
Function GetName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As System.String  
  
value = instance.GetName()
```

C#

```
System.string GetName()
```

C++/CLI

```
System.String^ GetName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of attribute

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetName](#).

Example

[Get Info on Plane-Axis \(C++\)](#)
[Get Sketches \(C++\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Delete Attribute \(C#\)](#)
[Delete Attribute \(VB.NET\)](#)
[Delete Attribute \(VBA\)](#)

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

GetParameter Method (IAttribute)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : GetParameter Method (IAttribute)

Gets the specified parameter on this attribute.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParameter( _  
    ByVal NameIn As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttribute
Dim NameIn As System.String
Dim value As System.Object

value = instance.GetParameter(NameIn)
```

C#

```
System.Object GetParameter(
    System.string NameIn
)
```

C++/CLI

```
System.Object^ GetParameter(
    & System.String^ NameIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Name of the parameter

Return Value

Object for the parameter

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetParameter](#).

Example

[Create Attribute \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::IGetParameter Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetComponent Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetComponent Method (IAttribute)

Obsolete. Superseded by [IAttribute::IGetComponent2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponent() As Component
```

Visual Basic (Usage)



```
Dim instance As IAttribute
Dim value As Component

value = instance.IGetComponent()
```

C#

```
Component IGetComponent()
```

C++/CLI

```
Component^ GetComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetComponent](#).

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetComponent2 Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetComponent2 Method (IAttribute)

Returns the component to which this attribute is attached.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponent2() As Component2
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As Component2  
  
value = instance.GetComponent2()
```

C#

```
Component2 GetComponent2()
```

C++/CLI

```
Component2^ GetComponent2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IComponent2](#)

Visual Basic for Applications (VBA) Syntax

See [Attribute::GetComponent2](#).

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[Attribute::GetComponent Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDefinition Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetDefinition Method (IAttribute)

Gets the definition of this attribute.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDefinition() As AttributeDef
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As AttributeDef  
  
value = instance.IGetDefinition()
```

C#

```
AttributeDef IGetDefinition()
```

C++/CLI

```
AttributeDef^ IGetDefinition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IAttributeDef](#)

Visual Basic for Applications (VBA) Syntax

See [Attribute::IGetDefinition](#).

Remarks

SOLIDWORKS generates all attribute instances from an [IAttribute](#) object. The object is the mold that gives the attribute its parameters and default values.

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEntity Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetEntity Method (IAttribute)

Obsolete. Superseded by [IAttribute::IGetEntity2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntity() As Entity
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As Entity  
  
value = instance.IGetEntity()
```

C#

```
Entity IGetEntity()
```

C++/CLI

```
Entity^ IGetEntity();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Attribute::IGetEntity](#).

See Also

[IAttribute Interface](#)
[IAttribute Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEntity2 Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetEntity2 Method (IAttribute)

Gets the entity to which this attribute was originally associated.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntity2() As Entity
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As Entity  
  
value = instance.IGetEntity2()
```

C#

```
Entity IGetEntity2()
```

C++/CLI

```
Entity^ IGetEntity2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IEntity](#) or NULL (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Attribute::IGetEntity2](#).

Remarks

This method returns NULL when the attribute is associated with:

- the document
- an invalid entity
- a suppressed entity

When this method returns NULL, use [IAttribute::GetEntityState](#) to determine which of these situations you have encountered.

When the [IAttribute](#) object is suppressed, this method returns NULL.

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::GetEntity Method](#)
[IAttribute::GetEntityState Method](#)
[IBody2::FindAttribute Method](#)

[IComponent2::FindAttribute Method](#)
[IEntity::FindAttribute Method](#)
[IEntity::FindAttribute Method](#)
[IFeature::GetSpecificFeature2 Method](#)
[ISldWorks::DefineAttribute Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetParameter Method (IAttribute)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IGetParameter Method (IAttribute)

Gets the specified parameter on this attribute.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetParameter( _  
    ByVal NameIn As System.String _  
) As Parameter
```

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim NameIn As System.String  
Dim value As Parameter  
  
value = instance.IGetParameter(NameIn)
```

C#

```
Parameter IGetParameter(  
    System.string NameIn  
)
```

C++/CLI

```
Parameter^ IGetParameter(  
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Name of the parameter

Return Value

[IParameter](#)

Visual Basic for Applications (VBA) Syntax

See [Attribute::IGetParameter](#).

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[IAttribute::GetParameter Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IncludeInLibraryFeature Property (IAttribute)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttribute Interface](#) : IncludeInLibraryFeature Property (IAttribute)

Gets or sets whether this attribute is included in the library feature.

.NET Syntax

Visual Basic (Declaration)

Property IncludeInLibraryFeature As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAttribute  
Dim value As System.Boolean  
  
instance.IncludeInLibraryFeature = value  
  
value = instance.IncludeInLibraryFeature
```

C#

```
System.bool IncludeInLibraryFeature {get; set;}
```

C++/CLI

```
property System.bool IncludeInLibraryFeature {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the attribute is included in the library feature, false if not

Visual Basic for Applications (VBA) Syntax

See [Attribute::IncludeInLibraryFeature](#).

Example

[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)

Remarks

Attributes included in a library feature are propagated to each instance of that library feature. However, If an entity (e.g., face, edge, etc.) is shared among features and all of these features are not included in the library feature, then the attribute is not propagated.

See Also

[IAttribute Interface](#)
[IAttribute Members](#)
[ILibraryFeatureData Interface](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

IAttributeDef (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAttributeDef Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAttributeDef Interface

Allows access to an attribute definition.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAttributeDef
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef
```

C#

```
public interface IAttributeDef
```

C++/CLI

```
public interface class IAttributeDef
```

Visual Basic for Applications (VBA) Syntax

See [AttributeDef](#).

Example

[Create Attribute \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)

Remarks

An attribute definition is an application-specific data packet that is automatically saved with the SOLIDWORKS file and reloaded when the file is opened. An application can create [attribute](#) data that is attached to an entity in a SOLIDWORKS document.

The attribute definition describes a template for the data packet. The definition contains the names of the parameters in the attribute, their types and default values. It also allows you to create instances of the definition on entities in your model.

The general sequence of steps in IAttribute creation is to:

1. Create an attribute definition ([ISldWorks::DefineAttribute](#))
2. Add parameters to the attribute definition ([IAttributeDef::AddParameter](#))
3. Register the attribute definition ([IAttributeDef::Register](#))
4. Create instances of the attribute definition on objects throughout the model ([IAttributeDef::CreateInstance5](#))

Perform Steps 1 through 3 only once for each working session. In other words, perform Steps 1 through 3 when your DLL or EXE is initially loaded or run. Until the DLL is unloaded or the EXE is closed, you can create an unlimited number of instances of the attribute definition.

Accessors

[IAttribute::GetDefinition](#) and [IAttribute::IGetDefinition Method](#)

[ISldWorks::DefineAttribute](#) and [ISldWorks::IDefineAttribute Method](#)

Access Diagram

[AttributeDef](#)

See Also

IAttributeDef Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IAttributeDef Interface

For a list of all members of this type, see [IAttributeDef members](#).

Public Methods

Name	Description
 AddParameter	Adds a parameter to the attribute definition using the specified name and default value.
 CreateInstance	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance2	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance3	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance4	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance5	Creates an instance of this attribute on the specified object with the specified options.
 ICreateInstance	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance2	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance3	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance4	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 Register	Registers an AttributeDef object as the final part of its creation.

[Top](#)

See Also

[IAttributeDef Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IAttributeDef Interface Members

[See Also](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IAttributeDef Interface

The following tables list the members exposed by [IAttributeDef](#).

Public Methods

Name	Description
 AddParameter	Adds a parameter to the attribute definition using the specified name and default value.
 CreateInstance	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance2	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance3	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance4	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 CreateInstance5	Creates an instance of this attribute on the specified object with the specified options.
 ICreateInstance	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance2	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance3	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 ICreateInstance4	Obsolete. Superseded by IAttributeDef.CreateInstance5 .
 Register	Registers an AttributeDef object as the final part of its creation.

[Top](#)

See Also

[IAttributeDef Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddParameter Method (IAttributeDef)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : AddParameter Method (IAttributeDef)

Adds a parameter to the attribute definition using the specified name and default value.

.NET Syntax

Visual Basic (Declaration)

```
Function AddParameter( _  
    ByVal NameIn As System.String, _  
    ByVal Type As System.Integer, _  
    ByVal DefaultValue As System.Double, _  
    ByVal Options As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim NameIn As System.String  
Dim Type As System.Integer  
Dim DefaultValue As System.Double  
Dim Options As System.Integer  
Dim value As System.Boolean  
  
value = instance.AddParameter(NameIn, Type, DefaultValue, Options)
```

C#

```
System.bool AddParameter(  
    System.string NameIn,  
    System.int Type,  
    System.double DefaultValue,  
    System.int Options  
)
```

C++/CLI

```
System.bool AddParameter(  
& System.String^ NameIn,  
& System.int Type,  
& System.double DefaultValue,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NameIn
Name to be given to the parameter (see **Remarks**)
Type
Parameter type as defined in [swParamType_e](#)
DefaultValue
Default value (see **Remarks**)
Options
Not used

Return Value

True if the parameter is added successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::AddParameter](#).

Example

[Create Attribute \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Find Attribute \(C#\)](#)
[Find Attribute \(VB.NET\)](#)
[Find Attribute \(VBA\)](#)

Remarks

Parameters cannot be added after the attribute definition is registered.

The name of the parameter given by NameIn must be unique in the attribute definition.

For parameters of type swParamTypeDouble, the DefaultValue argument allows a default value to be placed in the attribute definition parameter. This value is assigned to the parameters of newly created attribute instances.

NOTE: There is no way to get or set integer parameters in attributes. Instead, use [IParameter::GetDoubleValue](#) and [IParameter::SetDoubleValue2](#) to get and set values for integer parameters. If you need to store a negative value, define your attribute parameter as type double. SOLIDWORKS does not allow negative integer values.

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)
[IAttribute::Register Method](#)
[ISldWorks::DefineAttribute Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateInstance Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : CreateInstance Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateInstance( _  
    ByVal OwnerDoc As System.Object, _  
    ByVal OwnerEntity As System.Object, _  
    ByVal NameIn As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As System.Object  
Dim OwnerEntity As System.Object  
Dim NameIn As System.String  
Dim value As System.Object
```

```
value = instance.CreateInstance(OwnerDoc, OwnerEntity, NameIn)
```

C#

```
System.object CreateInstance(  
    System.object OwnerDoc,  
    System.object OwnerEntity,  
    System.string NameIn  
)
```

C++/CLI

```
System.Object^ CreateInstance(  
& System.Object^ OwnerDoc,  
& System.Object^ OwnerEntity,
```

```
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerEntity

NameIn

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance](#).

See Also

[IAttributeDef Interface](#)

[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateInstance2 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : CreateInstance2 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateInstance2( _  
    ByVal OwnerDoc As System.Object, _  
    ByVal OwnerEntity As System.Object, _  
    ByVal NameIn As System.String, _  
    ByVal Options As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As System.Object  
Dim OwnerEntity As System.Object  
Dim NameIn As System.String  
Dim Options As System.Integer  
Dim value As System.Object  
  
value = instance.CreateInstance2(OwnerDoc, OwnerEntity, NameIn, Options)
```

C#

```
System.object CreateInstance2(  
    System.object OwnerDoc,  
    System.object OwnerEntity,  
    System.string NameIn,  
    System.int Options  
)
```

C++/CLI

```
System.Object^ CreateInstance2(  
& System.Object^ OwnerDoc,  
& System.Object^ OwnerEntity,  
& System.String^ NameIn,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerEntity

NameIn

Options

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance2](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateInstance3 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : CreateInstance3 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateInstance3( _  
    ByVal OwnerDoc As System.Object, _  
    ByVal OwnerComp As System.Object, _  
    ByVal OwnerEntity As System.Object, _  
    ByVal NameIn As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal ConfigurationOption As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As System.Object  
Dim OwnerComp As System.Object  
Dim OwnerEntity As System.Object  
Dim NameIn As System.String  
Dim Options As System.Integer  
Dim ConfigurationOption As System.Integer  
Dim value As System.Object  
  
value = instance.CreateInstance3(OwnerDoc, OwnerComp, OwnerEntity, NameIn, Options,  
ConfigurationOption)
```

C#

```
System.object CreateInstance3(  
    System.object OwnerDoc,  
    System.object OwnerComp,  
    System.object OwnerEntity,  
    System.string NameIn,  
    System.int Options,  
    System.int ConfigurationOption  
)
```

C++/CLI

```
System.Object^ CreateInstance3(  
& System.Object^ OwnerDoc,  
& System.Object^ OwnerComp,  
& System.Object^ OwnerEntity,
```

```
& System.String^ NameIn,
& System.int Options,
& System.int ConfigurationOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerComp

OwnerEntity

NameIn

Options

ConfigurationOption

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance3](#).

See Also

[IAttributeDef Interface](#)

[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateInstance4 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : CreateInstance4 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function CreateInstance4( _
    ByVal OwnerDoc As ModelDoc2, _
    ByVal OwnerObj As System.Object, _
    ByVal NameIn As System.String, _
    ByVal Options As System.Integer, _
    ByVal ConfigurationOption As System.Integer _
) As Attribute
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef
Dim OwnerDoc As ModelDoc2
Dim OwnerObj As System.Object
Dim NameIn As System.String
Dim Options As System.Integer
Dim ConfigurationOption As System.Integer
Dim value As Attribute
```

```
value = instance.CreateInstance4(OwnerDoc, OwnerObj, NameIn, Options, ConfigurationOption)
```

C#

```
Attribute CreateInstance4(
    ModelDoc2 OwnerDoc,
    System.object OwnerObj,
    System.string NameIn,
    System.int Options,
    System.int ConfigurationOption
)
```

C++/CLI

```
Attribute^ CreateInstance4(
& ModelDoc2^ OwnerDoc,
& System.Object^ OwnerObj,
& System.String^ NameIn,
& System.int Options,
& System.int ConfigurationOption
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerObj

NameIn

Options

ConfigurationOption

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance4](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CreateInstance5 Method (IAttributeDef)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : CreateInstance5 Method (IAttributeDef)

Creates an instance of this attribute on the specified object with the specified options.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateInstance5( _
    ByVal OwnerDoc As ModelDoc2, _
    ByVal OwnerObj As System.Object, _
    ByVal NameIn As System.String, _
    ByVal Options As System.Integer, _
    ByVal ConfigurationOption As System.Integer _
) As Attribute
```

Visual Basic (Usage)

```
Dim instance As IAttributeDef
Dim OwnerDoc As ModelDoc2
Dim OwnerObj As System.Object
Dim NameIn As System.String
Dim Options As System.Integer
Dim ConfigurationOption As System.Integer
Dim value As Attribute
```

```
value = instance.CreateInstance5(OwnerDoc, OwnerObj, NameIn, Options, ConfigurationOption)
```

C#

```
Attribute CreateInstance5(
    ModelDoc2 OwnerDoc,
    System.object OwnerObj,
    System.string NameIn,
    System.int Options,
```



```
System.int ConfigurationOption  
)
```

C++/CLI

```
Attribute^ CreateInstance5(  
& ModelDoc2^ OwnerDoc,  
& System.Object^ OwnerObj,  
& System.String^ NameIn,  
& System.int Options,  
& System.int ConfigurationOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

Document whose FeatureManager design tree to which to add this attribute

OwnerObj

Component or entity to which to add this attribute:

- [IBODY2](#)
- [ICOMPONENT2](#)
- [IDENTITY](#), which can be a face, loop, edge, vertex, or feature
- [MODELDOC2](#) if NULL

NameIn

Name to assign to this attribute instance (see **Remarks**)

Options

Creation control options (see **Remarks**)

ConfigurationOption

Configuration options as defined in [swInConfigurationOpts_e](#)

Return Value

Newly created [IAttribute](#) object

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance5](#).

Example

[Create Attribute \(VBA\)](#)

[Delete Faces \(VBA\)](#)

[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)

[Add Attribute to Feature and Include in Library Feature \(C#\)](#)

[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)

[Delete Blended Faces \(C#\)](#)

[Delete Blended Faces \(VB.NET\)](#)

[Delete Blended Faces \(VBA\)](#)

Remarks

When you add an attribute to a feature, the FeatureManager design tree might not reflect the new state of the model. This discrepancy exists for performance reasons (rebuilding the FeatureManager design tree is very time-consuming). You can request a rebuild after you have added a number of attributes to save time.

The attribute is created as a feature and displayed in the FeatureManager design tree, which means that the name specified in *nameIn* must be unique in the FeatureManager design tree for the document.

You can create attributes on entity objects such as faces and edges, on features, or on the document itself. Do not use this method to set an attribute to or get an attribute from an assembly body. Instead, use [IFace2::SetFaceId](#) or [IFace2::GetFaceId](#) to set or get the attribute.

Setting or clearing bits in the options argument controls the creation of the attribute:

Bit	Value	Meaning
1	1	Attribute is created hidden in the FeatureManager design tree (see IFeature::SetUIState)
1	0	Attribute is created visible in the FeatureManager design tree

For example, options = 1 creates an attribute that is hidden in the FeatureManager design tree.

NOTE: By default, SOLIDWORKS adds attributes only to the active configuration. SOLIDWORKS adds the attribute to all other configurations a suppressed feature. You can unsuppress the attribute by selecting it with [IModelDocExtension::SelectByID2](#) and calling [IModelDoc2::EditUnsuppressDependent2](#). If you want to add your attributes to a non-active configuration, then the user must edit the properties of that particular configuration and make sure that the **Suppress New Features** option is disabled.

If you add an attribute to an entity, SOLIDWORKS strips the attribute feature from the entity if the entity is included in your export to a library feature or library feature part. See the SOLIDWORKS Help for more information about library features.

NOTE: An attribute is a feature; thus, this method respects the [IConfiguration::SuppressNewFeatures](#) setting.

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateInstance Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : ICreateInstance Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateInstance(  
    ByVal OwnerDoc As ModelDoc, _  
    ByVal OwnerEntity As Entity, _  
    ByVal NameIn As System.String _  
) As Attribute
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As ModelDoc  
Dim OwnerEntity As Entity  
Dim NameIn As System.String  
Dim value As Attribute
```

```
value = instance.ICreateInstance(OwnerDoc, OwnerEntity, NameIn)
```

C#

```
Attribute ICreateInstance(  
    ModelDoc OwnerDoc,  
    Entity OwnerEntity,  
    System.string NameIn  
)
```

C++/CLI

```
Attribute^ ICreateInstance(  
& ModelDoc^ OwnerDoc,  
& Entity^ OwnerEntity,  
& System.String^ NameIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerEntity

NameIn

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::ICreateInstance](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateInstance2 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : ICreateInstance2 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateInstance2( _  
    ByVal OwnerDoc As ModelDoc, _  
    ByVal OwnerEntity As Entity, _  
    ByVal NameIn As System.String, _  
    ByVal Options As System.Integer _  
    ) As Attribute
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As ModelDoc  
Dim OwnerEntity As Entity  
Dim NameIn As System.String  
Dim Options As System.Integer  
Dim value As Attribute  
  
value = instance.ICreateInstance2(OwnerDoc, OwnerEntity, NameIn, Options)
```

C#

```
Attribute ICreateInstance2(  
    ModelDoc OwnerDoc,  
    Entity OwnerEntity,  
    System.string NameIn,  
    System.int Options  
)
```

C++/CLI

```
Attribute^ ICreateInstance2(  
& ModelDoc^ OwnerDoc,  
& Entity^ OwnerEntity,  
& System.String^ NameIn,  
& System.int Options  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerEntity

NameIn

Options

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::ICreateInstance2](#).

See Also

ICreateInstance3 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : ICreateInstance3 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateInstance3( _  
    ByVal OwnerDoc As ModelDoc, _  
    ByVal OwnerComp As Component, _  
    ByVal OwnerEntity As Entity, _  
    ByVal NameIn As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal ConfigurationOption As System.Integer _  
    ) As Attribute
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As ModelDoc  
Dim OwnerComp As Component  
Dim OwnerEntity As Entity  
Dim NameIn As System.String  
Dim Options As System.Integer  
Dim ConfigurationOption As System.Integer  
Dim value As Attribute  
  
value = instance.ICreateInstance3(OwnerDoc, OwnerComp, OwnerEntity, NameIn, Options,  
ConfigurationOption)
```

C#

```
Attribute ICreateInstance3(  
    ModelDoc OwnerDoc,  
    Component OwnerComp,  
    Entity OwnerEntity,  
    System.string NameIn,  
    System.int Options,  
    System.int ConfigurationOption  
)
```

C++/CLI

```
Attribute^ ICreateInstance3(  
& ModelDoc^ OwnerDoc,  
& Component^ OwnerComp,  
& Entity^ OwnerEntity,  
& System.String^ NameIn,  
& System.int Options,  
& System.int ConfigurationOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc

OwnerComp

OwnerEntity

NameIn

Options

ConfigurationOption

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::ICreateInstance3](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateInstance4 Method (IAttributeDef)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : ICreateInstance4 Method (IAttributeDef)

Obsolete. Superseded by [IAttributeDef::CreateInstance5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateInstance4( _  
    ByVal OwnerDoc As ModelDoc2, _  
    ByVal OwnerComp As Component2, _  
    ByVal OwnerEntity As Entity, _  
    ByVal NameIn As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal ConfigurationOption As System.Integer _  
    ) As Attribute
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim OwnerDoc As ModelDoc2  
Dim OwnerComp As Component2  
Dim OwnerEntity As Entity  
Dim NameIn As System.String  
Dim Options As System.Integer  
Dim ConfigurationOption As System.Integer  
Dim value As Attribute  
  
value = instance.ICreateInstance4(OwnerDoc, OwnerComp, OwnerEntity, NameIn, Options,  
ConfigurationOption)
```

C#

```
Attribute ICreateInstance4(  
    ModelDoc2 OwnerDoc,  
    Component2 OwnerComp,  
    Entity OwnerEntity,  
    System.string NameIn,  
    System.int Options,  
    System.int ConfigurationOption  
)
```

C++/CLI

```
Attribute^ ICreateInstance4(  
& ModelDoc2^ OwnerDoc,  
& Component2^ OwnerComp,  
& Entity^ OwnerEntity,  
& System.String^ NameIn,  
& System.int Options,  
& System.int ConfigurationOption  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OwnerDoc
OwnerComp
OwnerEntity
NameIn
Options
ConfigurationOption

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::CreateInstance4](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Register Method (IAttributeDef)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAttributeDef Interface](#) : Register Method (IAttributeDef)

Registers an [AttributeDef](#) object as the final part of its creation.

.NET Syntax

Visual Basic (Declaration)

```
Function Register() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAttributeDef  
Dim value As System.Boolean  
  
value = instance.Register()
```

C#

```
System.bool Register()
```

C++/CLI

```
System.bool Register();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the AttributeDef object is registered successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [AttributeDef::Register](#).

Example

[Create Attribute \(VBA\)](#)
[Delete Faces \(VBA\)](#)
[Add Attribute to Feature and Include in Library Feature \(C#\)](#)
[Add Attribute to Feature and Include in Library Feature \(VB.NET\)](#)
[Add Attribute to Feature and Include in Library Feature \(VBA\)](#)
[Delete Blended Faces \(C#\)](#)
[Delete Blended Faces \(VB.NET\)](#)
[Delete Blended Faces \(VBA\)](#)

Remarks

Call this method after the AttributeDef object is created using [ISldWorks::DefineAttribute](#) and after all parameters are added to the attribute definition using [IAttributeDef::AddParameter](#).

See Also

[IAttributeDef Interface](#)
[IAttributeDef Members](#)