

SOLIDWORKS API (.NET VBA C#) — Reference (19/337): IAutoBalloonOptions-IBalloonStack

SOLIDWORKS API Documentation (converted from CHM)

IAutoBalloonOptions (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAutoBalloonOptions Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAutoBalloonOptions Interface

Allows access to auto balloon options.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IAutoBalloonOptions
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
```

C#

```
public interface IAutoBalloonOptions
```

C++/CLI

```
public interface class IAutoBalloonOptions
```

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions](#).

Example

[Add Auto Balloons to Drawing \(VBA\)](#)
[Add Auto Balloons to Drawing \(VB.NET\)](#)
[Add Auto Balloons to Drawing \(C#\)](#)

Remarks

To automatically create BOM balloons:

1. Select one or more views or sheets for which to automatically create BOM balloons.
2. Call [IDrawingDoc::CreateAutoBalloonOptions](#) to create IAutoBalloonOptions object.
3. Set the properties on IAutoBalloonOptions.
4. Pass IAutoBalloonOptions in a call to [IDrawingDoc::AutoBalloon5](#).

Accessors

[IDrawingDoc::CreateAutoBalloonOptions](#)

Access Diagram

[AutoBalloonOptions](#)

See Also

[IAutoBalloonOptions Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBalloonOptions Interface](#)
[IStackedBalloonOptions Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAutoBalloonOptions Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IAutoBalloonOptions Interface

The following tables list the members exposed by [IAutoBalloonOptions](#).

 Public Properties

Name	Description
 CustomSize	Gets and sets the user-defined size of the balloons.
 EditBalloonOption	Gets and sets edit balloon options.
 EditBalloons	Gets and sets whether to use edit balloon options when creating the auto balloon.
 FirstItem	Gets and sets the first balloon item.
 IgnoreMultiple	Gets and sets whether to create balloons for multiple instances of an item.
 InsertMagneticLine	Gets and sets whether to insert magnetic lines with balloons.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.
 ItemOrder	Gets and sets item ordering.
 Layername	Gets and sets the name of the layer on which to create balloons.
 Layout	Gets and sets the style of the layout of balloons.
 LeaderAttachmentToFaces	Gets and sets whether to attach balloons to faces.
 LowerText	Gets and sets the lower text of the balloons.
 LowerTextContent	Gets and sets the style of the lower text of the balloons.
 ReverseDirection	Gets and sets whether to reverse the item ordering of the balloons.
 Size	Gets and sets the size of the balloons.
 Style	Gets and sets the style of the balloons.
 UpperText	Gets and sets the upper text of the balloons.
 UpperTextContent	Gets and sets the style of the upper text of the balloons.

[Top](#)

 See Also

- [IAutoBalloonOptions Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IBalloonOptions Interface](#)
- [IStackedBalloonOptions Interface](#)

IAutoBalloonOptions Interface Properties

[See Also](#)


SolidWorks.Interop.sldworks Namespace : IAutoBalloonOptions Interface

For a list of all members of this type, see [IAutoBalloonOptions members](#).

 Public Properties

Name	Description
 CustomSize	Gets and sets the user-defined size of the balloons.
 EditBalloonOption	Gets and sets edit balloon options.
 EditBalloons	Gets and sets whether to use edit balloon options when creating the auto balloon.
 FirstItem	Gets and sets the first balloon item.
 IgnoreMultiple	Gets and sets whether to create balloons for multiple instances of an item.
 InsertMagneticLine	Gets and sets whether to insert magnetic lines with balloons.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.

 ItemOrder	Gets and sets item ordering.
 Layername	Gets and sets the name of the layer on which to create balloons.
 Layout	Gets and sets the style of the layout of balloons.
 LeaderAttachmentToFaces	Gets and sets whether to attach balloons to faces.
 LowerText	Gets and sets the lower text of the balloons.
 LowerTextContent	Gets and sets the style of the lower text of the balloons.
 ReverseDirection	Gets and sets whether to reverse the item ordering of the balloons.
 Size	Gets and sets the size of the balloons.
 Style	Gets and sets the style of the balloons.
 UpperText	Gets and sets the upper text of the balloons.
 UpperTextContent	Gets and sets the style of the upper text of the balloons.

[Top](#)

See Also

[IAutoBalloonOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBalloonOptions Interface](#)
[IStackedBalloonOptions Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomSize Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : CustomSize Property (IAutoBalloonOptions)

Gets and sets the user-defined size of the balloons.

.NET Syntax

Visual Basic (Declaration)

Property CustomSize As System.Double

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
Dim value As System.Double

instance.CustomSize = value

value = instance.CustomSize
```

C#

```
System.double CustomSize {get; set;}
```

C++/CLI

```
property System.double CustomSize {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

User-defined size of the balloons; valid only when [IAutoBalloonOptions::Size](#) is set to [swBalloonFit_e.swBF_UserDef](#)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::CustomSize](#).

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditBalloonOption Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : EditBalloonOption Property (IAutoBalloonOptions)

Gets and sets edit balloon options.

.NET Syntax

Visual Basic (Declaration)

Property EditBalloonOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer
```

```
instance.EditBalloonOption = value
```

```
value = instance.EditBalloonOption
```

C#

```
System.int EditBalloonOption {get; set;}
```

C++/CLI

```
property System.int EditBalloonOption {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Edit balloon option as specified in [swEditBalloonOption](#) e; valid only if [IAutoBalloonOptions::EditBalloons](#) is true

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::EditBalloonOption](#).

Example

See [IAutoBalloonOptions](#) examples.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

EditBalloons Property (IAutoBalloonOptions)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : EditBalloons Property (IAutoBalloonOptions)

Gets and sets whether to use edit balloon options when creating the auto balloon.

.NET Syntax

Visual Basic (Declaration)

Property EditBalloons As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
Dim value As System.Boolean

instance.EditBalloons = value

value = instance.EditBalloons
```

C#

```
System.bool EditBalloons {get; set;}
```

C++/CLI

```
property System.bool EditBalloons {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use edit balloon option as specified in [IAutoBalloonOption::EditBalloonOption](#), false to not

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::EditBalloons](#).

Example

See [IAutoBalloonOptions](#) examples.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

FirstItem Property (IAutoBalloonOptions)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : FirstItem Property (IAutoBalloonOptions)

Gets and sets the first balloon item.

.NET Syntax

Visual Basic (Declaration)

Property FirstItem As System.Object

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Object  
  
instance.FirstItem = value  
  
value = instance.FirstItem
```

C#

```
System.object FirstItem {get; set;}
```

C++/CLI

```
property System.Object^ FirstItem {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IComponent2](#)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::FirstItem](#).

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreMultiple Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : IgnoreMultiple Property (IAutoBalloonOptions)

Gets and sets whether to create balloons for multiple instances of an item.

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreMultiple As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Boolean  
  
instance.IgnoreMultiple = value  
  
value = instance.IgnoreMultiple
```

C#

```
System.bool IgnoreMultiple {get; set;}
```

C++/CLI

```
property System.bool IgnoreMultiple {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to create a balloon for only one instance of an item, false to create multiple balloons for multiple instances of an item

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::CustomSize](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

InsertMagneticLine Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : InsertMagneticLine Property (IAutoBalloonOptions)

Gets and sets whether to insert magnetic lines with balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property InsertMagneticLine As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Boolean  
  
instance.InsertMagneticLine = value  
value = instance.InsertMagneticLine
```

C#

```
System.bool InsertMagneticLine {get; set;}
```

C++/CLI

```
property System.bool InsertMagneticLine {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to insert magnetic lines, false to not; only valid when [IAutoBalloonOptions::Layout](#) is not set to [swBalloonLayoutType_e.swDetailingBalloonLayout_Circle](#)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::InsertMagneticLine](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemNumberIncrement Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : ItemNumberIncrement Property (IAutoBalloonOptions)

Gets and sets the item number increment.

.NET Syntax

Visual Basic (Declaration)

Property ItemNumberIncrement As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer
```

```
instance.ItemNumberIncrement = value
```

```
value = instance.ItemNumberIncrement
```

C#

```
System.int ItemNumberIncrement {get; set;}
```

C++/CLI

```
property System.int ItemNumberIncrement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item number increment

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::ItemNumberIncrement](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemNumberStart Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : ItemNumberStart Property (IAutoBalloonOptions)

Gets and sets the starting item number.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemNumberStart As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer  
  
instance.ItemNumberStart = value  
value = instance.ItemNumberStart
```

C#

```
System.int ItemNumberStart {get; set;}
```

C++/CLI

```
property System.int ItemNumberStart {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting item number

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::ItemNumberStart](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemOrder Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : ItemOrder Property (IAutoBalloonOptions)

Gets and sets item ordering.

.NET Syntax

Visual Basic (Declaration)

Property ItemOrder As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer
```

```
instance.ItemOrder = value
```

```
value = instance.ItemOrder
```

C#

```
System.int ItemOrder {get; set;}
```

C++/CLI

```
property System.int ItemOrder {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item ordering as defined in [swBalloonItemNumbersOrder_e](#)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::ItemOrder](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layername Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : Layername Property (IAutoBalloonOptions)

Gets and sets the name of the layer on which to create balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property Layername As System.String
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.String
```

```
instance.Layername = value
```

```
value = instance.Layername
```

C#

```
System.string Layername {get; set;}
```

C++/CLI

```
property System.String^ Layername {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::LayerName](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Layout Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : Layout Property (IAutoBalloonOptions)

Gets and sets the style of the layout of balloons.

.NET Syntax

Visual Basic (Declaration)

Property Layout As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer  
  
instance.Layout = value  
  
value = instance.Layout
```

C#

```
System.int Layout {get; set;}
```

C++/CLI

```
property System.int Layout {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the balloon layout as defined in [swBalloonLayoutType_e](#); specify -1 to use the document default layout style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::Layout](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

To get or set the document default values for Layout...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingAutoBalloonLayout, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonLayoutType_e.<Value>)

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

LeaderAttachmentToFaces Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : LeaderAttachmentToFaces Property (IAutoBalloonOptions)

Gets and sets whether to attach balloons to faces.

.NET Syntax

Visual Basic (Declaration)

Property LeaderAttachmentToFaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Boolean  
  
instance.LeaderAttachmentToFaces = value  
  
value = instance.LeaderAttachmentToFaces
```

C#

```
System.bool LeaderAttachmentToFaces {get; set;}
```

C++/CLI

```
property System.bool LeaderAttachmentToFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to attach balloons to faces; false to attach balloons to edges

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions.LeadersAttachmentToFaces](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerText Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : LowerText Property (IAutoBalloonOptions)

Gets and sets the lower text of the balloons.

Visual Basic Syntax

Visual Basic (Declaration)

Property LowerText As System.String

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.String
```

```
instance.LowerText = value
```

```
value = instance.LowerText
```

C#

```
System.string LowerText {get; set;}
```

C++/CLI

```
property System.String^ LowerText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Lower text of the balloons (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::LowerText](#).

Remarks

This property is valid only when [IAutoBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#).

You can only get or set the lower text in a BOM balloon using [INote::GetBomBalloonText](#) or [INote::SetBomBalloonText](#) after [inserting a BOM balloon](#).

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerTextContent Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : LowerTextContent Property (IAutoBalloonOptions)

Gets and sets the style of the lower text of the balloons.

Visual Basic Syntax

Visual Basic (Declaration)

Property LowerTextContent As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
Dim value As System.Integer

instance.LowerTextContent = value

value = instance.LowerTextContent
```

C#

```
System.int LowerTextContent {get; set;}
```

C++/CLI

```
property System.int LowerTextContent {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the lower text as defined in [swBalloonTextContent_e](#); specify -1 to use the document default lower text style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::LowerTextContent](#).

Remarks

This property is valid only when [IAutoBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#).

To get or set document default values for LowerTextContent...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : ReverseDirection Property (IAutoBalloonOptions)

Gets and sets whether to reverse the item ordering of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
Dim value As System.Boolean
```

```
instance.ReverseDirection = value  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the item ordering, false to not; only valid when [IAutoBalloonOptions::ItemOrder](#) is set to [swBalloonItemNumbersOrder_e.swBalloonItemNumbers_OrderSequentially](#)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::ReverseDirection](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : Size Property (IAutoBalloonOptions)

Gets and sets the size of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property Size As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer
```

```
instance.Size = value  
value = instance.Size
```

C#

```
System.int Size {get; set;}
```

```
property System.int Size {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Size of the balloons as defined in [swBalloonFit_e](#); specify -1 to use the document default balloon size (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::Size](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

To get or set document default values for Size...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : Style Property (IAutoBalloonOptions)

Gets and sets the style of the balloons.

.NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the balloons as defined in [swBalloonStyle_e](#); specify -1 to use the document default balloon style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::Style](#).

Example

See [IAutoBalloonOptions](#) examples.

Remarks

To get or set document default values for Style...

Use...

To get or set document default values for Style...	Use...
Get	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set	IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonStyle_e.<Value>)
-----	---

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpperText Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : UpperText Property (IAutoBalloonOptions)

Gets and sets the upper text of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property UpperText As System.String
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.String
```

```
instance.UpperText = value
```

```
value = instance.UpperText
```

C#

```
System.string UpperText {get; set;}
```

C++/CLI

```
property System.String^ UpperText {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Upper text of the balloons

Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::UpperText](#).

Remarks

You can only get or set the upper text in a BOM autoballoon using [INote::GetBomBalloonText](#) or [INote::SetBomBalloonText](#) after [inserting a BOM balloon](#).

See the SOLIDWORKS Help for additional details about autoballoons.

See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpperTextContent Property (IAutoBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IAutoBalloonOptions Interface](#) : UpperTextContent Property (IAutoBalloonOptions)

Gets and sets the style of the upper text of the balloons.

.NET Syntax

Visual Basic (Declaration)

```
Property UpperTextContent As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IAutoBalloonOptions  
Dim value As System.Integer
```

```
instance.UpperTextContent = value
```

```
value = instance.UpperTextContent
```

C#

```
System.int UpperTextContent {get; set;}
```

C++/CLI

```
property System.int UpperTextContent {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the upper text as defined in [swBalloonTextContent_e](#); specify -1 to use the document default upper text style (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [AutoBalloonOptions::UpperTextContent](#).

 Example

See [IAutoBalloonOptions](#) examples.

 Remarks

To get or set document default values for UpperTextContent...	Use...
Get	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified)
Set	IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See the SOLIDWORKS Help for additional details about autoballoons.

 See Also

[IAutoBalloonOptions Interface](#)
[IAutoBalloonOptions Members](#)

 Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IBalloonOptions (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBalloonOptions Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBalloonOptions Interface

Allows access to balloon options.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBalloonOptions
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
```

C#

```
public interface IBalloonOptions
```

C++/CLI

```
public interface class IBalloonOptions
```

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions](#).

Example

'VBA

'This example demonstrates how to get the balloon options for a ballooned note in a drawing.

'-----

' Preconditions:

' 1. Open any SOLIDWORKS drawing containing a ballooned note.

' 2. Select a balloon.

' 3. Open an Immediate window.

'

'Postconditions: Inspect the Immediate window.

'-----

```
Dim swApp As SldWorks.SldWorks
```

```
Dim swModel As SldWorks.ModelDoc2
```

```
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
```

```
    Set swModel = swApp.ActiveDoc
```

```
    Dim selMgr As SldWorks.SelectionMgr
```

```
    Set selMgr = swModel.SelectionManager
```

```
    Dim Note1 As SldWorks.Note
```

```
    Set Note1 = selMgr.GetSelectedObject6(1, -1)
```

```
    Dim balloonOptions As SldWorks.balloonOptions
```

```
    Set balloonOptions = Note1.GetBalloonOptions()
```

```
    Debug.Print "Balloon Options"
```

```
    Debug.Print ""
```

```
    Debug.Print "Custom size: " & balloonOptions.CustomSize
```

```
    Debug.Print "Size as defined by swBalloonFit_e: " & balloonOptions.Size
```

```
    Debug.Print "Style as defined by swBalloonStyle_e: " & balloonOptions.Style
```

```

Debug.Print "Upper text: " & balloonOptions.UpperText
Debug.Print "Upper text style as defined by swBalloonTextContent_e: " & balloonOptions.UpperTextContent

Debug.Print "Lower text: " & balloonOptions.LowerText
Debug.Print "Lower text style as defined by swBalloonTextContent_e: " & balloonOptions.LowerTextContent

Debug.Print "Item quantity label: " & balloonOptions.QuantityDenotationText
Debug.Print "Override the item quantity? " & balloonOptions.QuantityOverride
Debug.Print "Override item quantity value: " & balloonOptions.QuantityOverrideValue
Debug.Print "Placement of the item quantity as defined by swBalloonQuantityPlacement_e"; " & balloonOptions.QuantityPlacement"
Debug.Print "Display the item quantity? " & balloonOptions.ShowQuantity

' Item-related options are valid only for drawings and need to be extracted from linked BOM feature instead of from IBalloonOptions (see
below)
'Debug.Print "Item number increment from IBalloonOptions: " & balloonOptions.ItemNumberIncrement
'Debug.Print "Item number start from IBalloonOptions:" & balloonOptions.ItemNumberStart
'Debug.Print "Item order from IBalloonOptions: " & balloonOptions.ItemOrder

' Layername option is valid only for drawings; empty string for parts and assemblies; empty string for drawings where the layer name is -None
Debug.Print "Layer name: " & balloonOptions.Layername

' Item-related options are valid only for drawings
If (swModel.GetType() = swDocDRAWING) Then

    Dim swDraw As SldWorks.DrawingDoc
    Set swDraw = swModel

    Dim annot As SldWorks.Annotation
    Set annot = Note1.GetAnnotation()

    Dim view1 As SldWorks.View
    Set view1 = annot.Owner

    Dim bomTableName1 As String
    bomTableName1 = view1.GetKeepLinkedToBOMName()

    If bomTableName1 = "" Then

        Debug.Print "No BOM table, no item-related properties"

    Else
        Dim Feat1 As SldWorks.Feature
        Set Feat1 = swDraw.FeatureByName(bomTableName1)

        Debug.Print "BOM table name: " & bomTableName1

        Dim bomFeat As SldWorks.BomFeature
        Set bomFeat = Feat1.GetSpecificFeature2()

        Debug.Print "Keep current BOM item numbers: " & bomFeat.KeepCurrentItemNumbers
        Debug.Print "Follow assembly item order: " & bomFeat.FollowAssemblyOrder2
        Debug.Print "Item start number: " & bomFeat.SequenceStartNumber
    End If

End If

End Sub

```

Example

[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(C#\)](#)

Remarks

To create a BOM balloon:

1. Select an item for which to create a BOM balloon.
2. Call [IModelDocExtension::CreateBalloonOptions](#) to create an IBalloonOptions object.
3. Set the properties on the IBalloonOptions object.
4. Pass the IBalloonOptions object in a call to [IModelDocExtension::InsertBOMBalloon2](#).

Accessors

[IModelDocExtension::CreateBalloonOptions](#)
[INote::GetBalloonOptions](#)

Access Diagram

[BalloonOptions](#)

See Also

[IBalloonOptions Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IStackedBalloonOptions Interface](#)
[IAutoBalloonOptions Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBalloonOptions Interface Members

[See Also](#) [Properties](#)

[SolidWorks.Interop.sldworks Namespace](#) : IBalloonOptions Interface

The following tables list the members exposed by [IBalloonOptions](#).

Public Properties

Name	Description
 CustomSize	Gets and sets the user-defined size of the balloon.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.
 ItemOrder	Gets and sets item ordering.
 Lavename	Gets and sets the name of the layer on which to create the balloon.
 LowerText	Gets and sets the lower text of the balloon.
 LowerTextContent	Gets and sets the style of the lower text of the balloon.
 QuantityDenotationText	Gets and sets the label of the BOM item quantity.
 QuantityOverride	Gets and sets whether to override the BOM item quantity.
 QuantityOverrideValue	Gets and sets the override value for the BOM item quantity.
 QuantityPlacement	Gets and sets the placement of the BOM item quantity with respect to its balloon.
 ShowQuantity	Gets and sets whether to display the BOM item quantity.
 Size	Gets and sets the size of the balloon.
 Style	Gets and sets the style of the balloon.
 UpperText	Gets and sets the upper text of the balloon.
 UpperTextContent	Gets and sets the style of the upper text of the balloon.

[Top](#)

See Also

[IBalloonOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IStackedBalloonOptions Interface](#)
[IAutoBalloonOptions Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBalloonOptions Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IBalloonOptions Interface

For a list of all members of this type, see [IBalloonOptions members](#).

Public Properties

Name	Description
------	-------------

 CustomSize	Gets and sets the user-defined size of the balloon.
 ItemNumberIncrement	Gets and sets the item number increment.
 ItemNumberStart	Gets and sets the starting item number.
 ItemOrder	Gets and sets item ordering.
 Layername	Gets and sets the name of the layer on which to create the balloon.
 LowerText	Gets and sets the lower text of the balloon.
 LowerTextContent	Gets and sets the style of the lower text of the balloon.
 QuantityDenotationText	Gets and sets the label of the BOM item quantity.
 QuantityOverride	Gets and sets whether to override the BOM item quantity.
 QuantityOverrideValue	Gets and sets the override value for the BOM item quantity.
 QuantityPlacement	Gets and sets the placement of the BOM item quantity with respect to its balloon.
 ShowQuantity	Gets and sets whether to display the BOM item quantity.
 Size	Gets and sets the size of the balloon.
 Style	Gets and sets the style of the balloon.
 UpperText	Gets and sets the upper text of the balloon.
 UpperTextContent	Gets and sets the style of the upper text of the balloon.

[Top](#)

See Also

[IBalloonOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IStackedBalloonOptions Interface](#)
[IAutoBalloonOptions Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomSize Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : CustomSize Property (IBalloonOptions)

Gets and sets the user-defined size of the balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property CustomSize As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
Dim value As System.Double

instance.CustomSize = value
value = instance.CustomSize
```

C#

```
System.double CustomSize {get; set;}
```

C++/CLI

```
property System.double CustomSize {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

User-defined size of balloons; valid only when [IBalloonOptions::Size](#) is set to [swBalloonFit](#) e.swBF_UserDef

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::CustomSize](#).

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemNumberIncrement Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : ItemNumberIncrement Property (IBalloonOptions)

Gets and sets the item number increment.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemNumberIncrement As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer  
  
instance.ItemNumberIncrement = value  
value = instance.ItemNumberIncrement
```

C#

```
System.int ItemNumberIncrement {get; set;}
```

C++/CLI

```
property System.int ItemNumberIncrement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item number increment

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::ItemNumberIncrement](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemNumberStart Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : ItemNumberStart Property (IBalloonOptions)

Gets and sets the starting item number.

.NET Syntax

Visual Basic (Declaration)

Property ItemNumberStart As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer
```

```
instance.ItemNumberStart = value
```

```
value = instance.ItemNumberStart
```

C#

```
System.int ItemNumberStart {get; set;}
```

C++/CLI

```
property System.int ItemNumberStart {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting item number

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::ItemNumberStart](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ItemOrder Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : ItemOrder Property (IBalloonOptions)

Gets and sets item ordering.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemOrder As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer  
  
instance.ItemOrder = value  
value = instance.ItemOrder
```

C#

```
System.int ItemOrder {get; set;}
```

C++/CLI

```
property System.int ItemOrder {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item ordering as defined in [swBalloonItemNumbersOrder_e](#)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::ItemOrder](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Layername Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : Layername Property (IBalloonOptions)

Gets and sets the name of the layer on which to create the balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property Layername As System.String
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.String
```

```
instance.Layername = value
```

```
value = instance.Layername
```

C#

```
System.string Layername {get; set;}
```

C++/CLI

```
property System.String^ Layername {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Layer name

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::LayerName](#).

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerText Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : LowerText Property (IBalloonOptions)

Gets and sets the lower text of the balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property LowerText As System.String
```

```
Dim instance As IBalloonOptions  
Dim value As System.String  
  
instance.LowerText = value  
  
value = instance.LowerText
```

C#

```
System.string LowerText {get; set;}
```

C++/CLI

```
property System.String^ LowerText {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Lower text of balloons (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::LowerText](#).

Remarks

This property is valid only when [IBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#).

You can only get or set the lower text in a BOM balloon using [INote::GetBomBalloonText](#) or [INote::SetBomBalloonText](#) after [inserting a BOM balloon](#).

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LowerTextContent Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : LowerTextContent Property (IBalloonOptions)

Gets and sets the style of the lower text of the balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property LowerTextContent As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IBalloonOptions
Dim value As System.Integer

instance.LowerTextContent = value

value = instance.LowerTextContent
```

C#

```
System.int LowerTextContent {get; set;}
```

C++/CLI

```
property System.int LowerTextContent {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the lower text as defined in [swBalloonTextContent_e](#); specify -1 to use the document default lower text style (See **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::LowerTextContent](#).

Remarks

This property is valid only when [IBalloonOptions::Style](#) is set to [swBalloonStyle_e.swBS_SplitCirc](#).

To get or set document default values...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMLowerText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See:

- [INote::PropertyLinkedText](#) for examples of link strings usable with swBalloonTextContent_e.swBalloonTextCustomProperties.
- SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityDenotationText Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : QuantityDenotationText Property (IBalloonOptions)

Gets and sets the label of the BOM item quantity.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityDenotationText As System.String
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
Dim value As System.String

instance.QuantityDenotationText = value

value = instance.QuantityDenotationText
```

C#

```
System.string QuantityDenotationText {get; set;}
```

C++/CLI

```
property System.String^ QuantityDenotationText {
    System.String^ get();
    void set ( &    System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Item quantity label

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions.QuantityDenotationText](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityOverride Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : QuantityOverride Property (IBalloonOptions)

Gets and sets whether to override the BOM item quantity.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
Dim value As System.Boolean

instance.QuantityOverride = value

value = instance.QuantityOverride
```

C#

```
System.bool QuantityOverride {get; set;}
```

C++/CLI

```
property System.bool QuantityOverride {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the BOM item quantity, false to not

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions.QuantityOverride](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityOverrideValue Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : QuantityOverrideValue Property (IBalloonOptions)

Gets and sets the override value for the BOM item quantity.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityOverrideValue As System.String
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.String  
  
instance.QuantityOverrideValue = value  
value = instance.QuantityOverrideValue
```

C#

```
System.string QuantityOverrideValue {get; set;}
```

C++/CLI

```
property System.String^ QuantityOverrideValue {  
    System.String^ get();
```

```
void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

BOM item quantity override value; valid only when [IBalloonOptions::QuantityOverride](#) is true

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::QuantityOverrideValue](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

QuantityPlacement Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : QuantityPlacement Property (IBalloonOptions)

Gets and sets the placement of the BOM item quantity with respect to its balloon.

.NET Syntax

Visual Basic (Declaration)

```
Property QuantityPlacement As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer  
  
instance.QuantityPlacement = value  
value = instance.QuantityPlacement
```

C#

```
System.int QuantityPlacement {get; set;}
```

C++/CLI

```
property System.int QuantityPlacement {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Placement of the BOM item quantity as defined in [swBalloonQuantityPlacement_e](#)

Visual Basic for Applications (VBA) Syntax

See [IBalloonOptions::QuantityPlacement](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowQuantity Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : ShowQuantity Property (IBalloonOptions)

Gets and sets whether to display the BOM item quantity.

.NET Syntax

Visual Basic (Declaration)

Property ShowQuantity As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Boolean
```

```
instance.ShowQuantity = value  
value = instance.ShowQuantity
```

C#

```
System.bool ShowQuantity {get; set;}
```

C++/CLI

```
property System.bool ShowQuantity {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show the BOM item quantity, false to not

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::ShowQuantity](#).

Example

See [IBalloonOptions](#) examples.

Remarks

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : Size Property (IBalloonOptions)

Gets and sets the size of the balloon.

.NET Syntax

Visual Basic (Declaration)

Property Size As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer
```

```
instance.Size = value
```

```
value = instance.Size
```

C#

```
System.int Size {get; set;}
```

C++/CLI

```
property System.int Size {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Balloon size as defined in [swBalloonFit e](#); specify -1 to use the document default balloon size (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::Size](#).

Example

See [IBalloonOptions](#) examples.

Remarks

To get or set document default values for Size...	Use...

Get	IModelDocExtension::GetUserPreferenceInteger ((swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified)
Set	IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonFit, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonFit_e.<Value>)

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : Style Property (IBalloonOptions)

Gets and sets the style of the balloon.

.NET Syntax

Visual Basic (Declaration)

Property Style As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Balloon style as defined in [swBalloonStyle_e](#); specify -1 to use the document default balloon style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::Style](#).

Example

See [IBalloonOptions](#) examples.

Remarks

To get or set document default values for Style...	Use...
Get	IModelDocExtension::GetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified)
Set	IModelDocExtension::SetUserPreferenceInteger (swUserPreferenceIntegerValue_e.swDetailingBOMBalloonStyle, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonStyle_e.<Value>)

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpperText Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : UpperText Property (IBalloonOptions)

Gets and sets the upper text of the balloon.

.NET Syntax

Visual Basic (Declaration)

Property UpperText As System.String

Visual Basic (Usage)



```
Dim instance As IBalloonOptions
Dim value As System.String
```

```
instance.UpperText = value
```

```
value = instance.UpperText
```

C#

```
System.string UpperText {get; set;}
```

C++/CLI

```
property System.String^ UpperText {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Upper text of the balloon (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::UpperText](#).

Remarks

You can only get or set the upper text in a BOM balloon using [INote::GetBomBalloonText](#) or [INote::SetBomBalloonText](#) after [inserting a BOM balloon](#).

See the SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpperTextContent Property (IBalloonOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonOptions Interface](#) : UpperTextContent Property (IBalloonOptions)

Gets and sets the style of the upper text of the balloon.

.NET Syntax

Visual Basic (Declaration)

Property UpperTextContent As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonOptions  
Dim value As System.Integer
```

```
instance.UpperTextContent = value
```

```
value = instance.UpperTextContent
```

C#

```
System.int UpperTextContent {get; set;}
```

C++/CLI

```
property System.int UpperTextContent {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Style of the upper text as defined in [swBalloonTextContent_e](#); specify -1 to use the document default upper text style (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BalloonOptions::UpperTextContent](#).

Example

See [IBalloonOptions](#) examples.

Remarks

To get or set document default values...

Use...

Get

[IModelDocExtension::GetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMUpperText swUserPreferenceOption_e.swDetailingNoOptionSpecified)

Set

[IModelDocExtension::SetUserPreferenceInteger](#)(swUserPreferenceIntegerValue_e.swDetailingBOMUpperText, swUserPreferenceOption_e.swDetailingNoOptionSpecified, swBalloonTextContent_e.<Value>)

See:

- [I>Note::PropertyLinkedText](#) for examples of link strings usable with swBalloonTextContent_e.swBalloonTextCustomProperties.
- SOLIDWORKS Help for additional details about balloons.

See Also

[IBalloonOptions Interface](#)
[IBalloonOptions Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

IBalloonStack (Type)

IBalloonStack Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBalloonStack Interface

Allows access to the properties that apply to a balloon stack, such as the direction of the stack.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBalloonStack
```

Visual Basic (Usage)

```
Dim instance As IBalloonStack
```

C#

```
public interface IBalloonStack
```

C++/CLI

```
public interface class IBalloonStack
```

Visual Basic for Applications (VBA) Syntax

See [BalloonStack](#).

Example

[Add Balloon to Stacked Balloon \(C#\)](#)
[Add Balloon to Stacked Balloon \(VB.NET\)](#)
[Add Balloon to Stacked Balloon \(VBA\)](#)

Remarks

Each of the notes in a balloon stack are individual notes. You must use the [INote](#) interface to get and set properties of individual notes, such as the text itself.

Accessors

[INote::GetBalloonStack Method](#)

Access Diagram

[BalloonStack](#)

See Also

[IBalloonStack Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::InsertStackedBalloon Method](#)

IBalloonStack Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBalloonStack Interface

The following tables list the members exposed by [IBalloonStack](#).

Public Properties

Name	Description
 Count	Gets the number of stacked notes in this balloon stack, excluding the master balloon.
 Direction	Gets or sets the direction of this balloon stack.
 Length	Gets or sets the number of notes that can be stacked before another row is started.
 Master	Gets the master note in this balloon stack.
 Stack	Gets the stacked notes in this balloon stack, excluding the master balloon.

[Top](#)

Public Methods

Name	Description
 AddTo	Adds a balloon note to this balloon stack.
 IGetStack	Gets the stacked notes in this balloon stack, excluding the master balloon.

[Top](#)

See Also

[IBalloonStack Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::InsertStackedBalloon Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IBalloonStack Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBalloonStack Interface

For a list of all members of this type, see [IBalloonStack members](#).

Public Methods

Name	Description
 AddTo	Adds a balloon note to this balloon stack.
 IGetStack	Gets the stacked notes in this balloon stack, excluding the master balloon.

[Top](#)

See Also

[IBalloonStack Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::InsertStackedBalloon Method](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IBalloonStack Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBalloonStack Interface

For a list of all members of this type, see [IBalloonStack members](#).

Public Properties

Name	Description
 Count	Gets the number of stacked notes in this balloon stack, excluding the master balloon.
 Direction	Gets or sets the direction of this balloon stack.
 Length	Gets or sets the number of notes that can be stacked before another row is started.
 Master	Gets the master note in this balloon stack.
 Stack	Gets the stacked notes in this balloon stack, excluding the master balloon.

[Top](#)

See Also

[IBalloonStack Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::InsertStackedBalloon Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddTo Method (IBalloonStack)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : AddTo Method (IBalloonStack)

Adds a balloon note to this balloon stack.

.NET Syntax

Visual Basic (Declaration)

```
Function AddTo( _  
    ByVal UpperTextStyle As System.Integer, _  
    ByVal UpperText As System.String, _  
    ByVal LowerTextStyle As System.Integer, _  
    ByVal LowerText As System.String _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim UpperTextStyle As System.Integer  
Dim UpperText As System.String  
Dim LowerTextStyle As System.Integer  
Dim LowerText As System.String  
Dim value As Note  
  
value = instance.AddTo(UpperTextStyle, UpperText, LowerTextStyle, LowerText)
```

C#

```
Note AddTo(  
    System.int UpperTextStyle,  
    System.string UpperText,  
    System.int LowerTextStyle,  
    System.string LowerText  
)
```

C++/CLI

```
Note^ AddTo(  
& System.int UpperTextStyle,  
& System.String^ UpperText,  
& System.int LowerTextStyle,  
& System.String^ LowerText  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UpperTextStyle
Text style for the text of the balloon as defined in [swBalloonTextContent_e](#)

UpperText
Text in the balloon

LowerTextStyle
Text style for the text of the balloon as defined in [swBalloonTextContent_e](#)

LowerText
Text in the lower part of the balloon (when Style = swBS_SplitCirc)

Return Value

[INote](#)

Visual Basic for Applications (VBA) Syntax

See [BalloonStack::AddTo](#).

Example

[Add Balloon to Stacked Balloon \(C#\)](#)
[Add Balloon to Stacked Balloon \(VB.NET\)](#)
[Add Balloon to Stacked Balloon \(VBA\)](#)

Remarks

This method adds a balloon note that is attached to the preselected entity to this stack. It returns an INote object, which you can then use to access the note (for example, to set the font of the note text). The balloon style and size are the same as the initial balloon in this stack.

If the balloon style is split circle, this method uses both the lower and upper text arguments. If the balloon style is anything other than split circle, this method uses the upper text arguments and ignores the lower text arguments.

If the text style is item number or quantity, SOLIDWORKS uses the note text to determine the preselected entity that this note is attached to, and ignores the corresponding text argument. If the preselection is a location on the drawing instead of an entity, you must specify the text style and text.

Use [INote::GetBalloonStack](#) to get a balloon stack interface from an existing note.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)
[INote::MakeStackedBalloon Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Count Property (IBalloonStack)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : Count Property (IBalloonStack)

Gets the number of stacked notes in this balloon stack, excluding the master balloon.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Count As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim value As System.Integer
```

```
value = instance.Count
```

C#

```
System.int Count {get;}
```

C++/CLI

```
property System.int Count {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of balloons in this balloon stack, excluding the master balloon

Visual Basic for Applications (VBA) Syntax

See [BalloonStack::Count](#).

Remarks

This property does not count the master balloon in the stack, only the other stacked notes. Us [IBalloonStack::Master](#) to get the master balloon of the stack.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Direction Property (IBalloonStack)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : Direction Property (IBalloonStack)

Gets or sets the direction of this balloon stack.

.NET Syntax

Visual Basic (Declaration)

Property Direction As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim value As System.Integer
```

```
instance.Direction = value
```

```
value = instance.Direction
```

C#

```
System.int Direction {get; set;}
```

C++/CLI

```
property System.int Direction {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Balloon stacking direction as defined in [swStackedBalloonDirection_e](#)

Visual Basic for Applications (VBA) Syntax

See [BalloonStack::Direction](#).

Remarks

If you specify an invalid value for Direction, SOLIDWORKS does not change the balloon stack.

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetStack Method (IBalloonStack)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : IGetStack Method (IBalloonStack)

Gets the stacked notes in this balloon stack, excluding the master balloon.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetStack( _  
    ByVal Count As System.Integer _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim Count As System.Integer  
Dim value As Note
```

```
value = instance.IGetStack(Count)
```

C#

```
Note IGetStack(  
    System.int Count  
)
```

C++/CLI

```
Note^ IGetStack(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of balloons

Return Value

- in-process, unmanaged C++: Pointer to an array of stacked [notes](#) of size Count in the balloon stack
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Use [IBalloonStack::Count](#) to get the number of balloons in the balloon stack.

This method does not return the master balloon in the stack, only the other stacked notes. Use [IBalloonStack::Master](#) to get the master balloon in the stack.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)
[IBalloonStack::Stack Property](#)

Availability

Length Property (IBalloonStack)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : Length Property (IBalloonStack)

Gets or sets the number of notes that can be stacked before another row is started.

.NET Syntax

Visual Basic (Declaration)

Property Length As System.Integer

Visual Basic (Usage)



```
Dim instance As IBalloonStack
Dim value As System.Integer
```

```
instance.Length = value
```

```
value = instance.Length
```

C#

```
System.int Length {get; set;}
```

C++/CLI

```
property System.int Length {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum number of balloons in one row of the stack; valid values are from 2 to 100

Visual Basic for Applications (VBA) Syntax

See [BalloonStack.Length](#).

Remarks

Valid values are from 2 to 100. If you specify an invalid value for Length, SOLIDWORKS does not change the balloon stack.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Master Property (IBalloonStack)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : Master Property (IBalloonStack)

Gets the master note in this balloon stack.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Master As Note

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim value As Note
```

```
value = instance.Master
```

C#

```
Note Master {get;}
```

C++/CLI

```
property Note^ Master {  
    Note^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Master [note](#) in this balloon stack

Visual Basic for Applications (VBA) Syntax

See [BalloonStack.Master](#).

Remarks

Use [IBalloonStack::Stack](#) or [IBalloonStack::IGetStack](#) to get all of the other balloons in this balloon stack.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Stack Property (IBalloonStack)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBalloonStack Interface](#) : Stack Property (IBalloonStack)

Gets the stacked notes in this balloon stack, excluding the master balloon.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Stack As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBalloonStack  
Dim value As System.Object
```

```
value = instance.Stack
```

C#

```
System.object Stack {get;}
```

C++/CLI

```
property System.Object^ Stack {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array notes in the balloon stack

Visual Basic for Applications (VBA) Syntax

See [BalloonStack::Stack](#).

Remarks

This method does not return the master balloon in the stack, only the other stacked notes. Use [IBalloonStack::Master](#) to get the master balloon in the stack.

See Also

[IBalloonStack Interface](#)
[IBalloonStack Members](#)
[IBalloonStack::GetStack Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0