

SOLIDWORKS API (.NET VBA C#) — Reference

(20/337): IBaseFlangeFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IBaseFlangeFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBaseFlangeFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBaseFlangeFeatureData Interface

Allows access to a sheet metal base flange feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBaseFlangeFeatureData

Visual Basic (Usage)

Dim instance As [IBaseFlangeFeatureData](#)

C#

public interface IBaseFlangeFeatureData

C++/CLI

public interface class IBaseFlangeFeatureData

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData](#).

Example

```
'VBA
'=====
'Preconditions:
'1. Ensure the specified part template exists.
'2. Open the Immediate window.
'
'Postconditions:
'1. Creates a flange profile sketch.
'2. Creates Base-Flange1 in the FeatureManager design tree.
'3. Inspect the Immediate window, graphics area,
'   and FeatureManager design tree.
'=====
Dim swApp As SldWorks.SldWorks
Dim Part As SldWorks.ModelDoc2
Dim swPart As PartDoc
Dim swModel As SldWorks.ModelDoc2
Dim swSKFeat As SldWorks.Feature
Dim skSegment As SldWorks.SketchSegment
Dim swBaseFlangeFeat As SldWorks.BaseFlangeFeatureData
Dim baseFlangeFeatData As SldWorks.BaseFlangeFeatureData
Dim cba As SldWorks.CustomBendAllowance
Dim var As Variant
Dim parent As SldWorks.Feature
Dim SHFeat As SldWorks.Feature
Dim smFeatData As SldWorks.SheetMetalFeatureData
Dim cba1 As SldWorks.CustomBendAllowance
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long

Option Explicit

Sub main()

    Set swApp = Application.SldWorks
    Set Part = swApp.ActiveDoc
```

```

Dim swSheetWidth As Double
swSheetWidth = 0
Dim swSheetHeight As Double
swSheetHeight = 0

Set Part = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS 2022\templates\Part.prt", 0, swSheetWidth, swSheetHeight)
Set swPart = Part
Set swModel = swApp.ActiveDoc

boolstatus = Part.Extension.SelectByID2("Top", "PLANE", -5.98881514598713E-02, 3.93749830258702E-02, 4.85137895479469E-03, False, 0, Nothing, 0)
Part.SketchManager.InsertSketch True
Part.ClearSelection2 True

Set skSegment = Part.SketchManager.CreateLine(-0.140779, 0.050824, 0#, -0.106481, -0.06735, 0#)
Set skSegment = Part.SketchManager.CreateLine(-0.106481, -0.06735, 0#, 0.084966, -0.049265, 0#)
Set skSegment = Part.SketchManager.CreateLine(0.084966, -0.049265, 0#, 0.143274, 0.063608, 0#)
Part.ClearSelection2 True
Part.SketchManager.InsertSketch True

Set swSKFeat = swModel.SelectionManager.GetSelectedObject6(1, -1)
Debug.Print "Flange profile name : " & swSKFeat.Name & " and type : " & swSKFeat.GetTypeName2

Set swBaseFlangeFeat = swModel.FeatureManager.CreateDefinition(swFmBaseFlange)

Set cba = swBaseFlangeFeat.GetCustomBendAllowance()

cba.Type = swBendAllowanceDirect
cba.BendAllowance = 0.05

swBaseFlangeFeat.D1EndConditionType = 1
swBaseFlangeFeat.D1EndConditionDistance = 0.02
swBaseFlangeFeat.ReverseDirection = True
swBaseFlangeFeat.OffsetDirections = 2
swBaseFlangeFeat.D2EndConditionType = 1
swBaseFlangeFeat.D2EndConditionDistance = 0.05
swBaseFlangeFeat.OverrideDefaultSheetMetalParameters = True
swBaseFlangeFeat.Thickness = 0.035

'Initialize the base flange feature
'Initialize(
'UseMaterialSheetMetalParameters=False,
'UseDefaultBendAllowance=False,
'CustomBendAllowance,
'UseDefaultBendRelief=False,
'ReliefType=swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular,
'UseReliefRatio=True,
'ReliefRatio=0.8m,
'ReliefWidth,
'ReliefDepth)

Call swBaseFlangeFeat.Initialize(False, False, cba, False, swSheetMetalReliefRectangular, True, 0.8, 0#, 0#)

Set SHFeat = swModel.FeatureManager.CreateFeature(swBaseFlangeFeat)

Set baseFlangeFeatData = SHFeat.GetDefinition()

Debug.Print "Use material sheet metal parameters? " & baseFlangeFeatData.UseMaterialSheetMetalParameters
Debug.Print "Use default bend allowance? " & baseFlangeFeatData.UseDefaultBendAllowance
Debug.Print "Use default bend relief? " & baseFlangeFeatData.UseDefaultBendRelief
Debug.Print "Use relief ratio? " & baseFlangeFeatData.UseReliefRatio
Debug.Print "Relief type as defined by swSheetMetalReliefTypes_e: " & baseFlangeFeatData.ReliefType
Debug.Print "Relief width: " & baseFlangeFeatData.ReliefWidth
Debug.Print "Relief depth: " & baseFlangeFeatData.ReliefDepth
Debug.Print "Relief ratio: " & baseFlangeFeatData.ReliefRatio

'Modify the relief ratio and override default AutoRelief in the parent sheet metal feature
var = SHFeat.GetParents()
Set parent = var(1)
Debug.Print "Parent type: " & parent.GetTypeName2()

Set smFeatData = parent.GetDefinition()

Set cba1 = smFeatData.GetCustomBendAllowance()

Debug.Print "Custom bend allowance type as defined in swBendAllowanceTypes_e: " & cba1.Type
Debug.Print "Bend allowance: " & cba1.BendAllowance
Debug.Print "Result code for override of AutoRelief as defined by swSheetMetalModifierError_e: " & smFeatData.SetOverrideDefaultParameter2(swSheetMetalOverrideDefaultParameters_AutoRelief, True)
smFeatData.ReliefRatio = 0.7

```

```
Debug.Print "Base flange successfully modified? " & parent.ModifyDefinition(smFeatData, swModel, Nothing)
Debug.Print "Base flange feature name : " & SHFeat.Name & " and type : " & SHFeat.GetTypeName2
```

End Sub

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)
[Create Base Flange Feature \(VB.NET\)](#)
[Create Base Flange Feature \(C#\)](#)

Remarks

For general information about sheet metal base flanges, see the **SOLIDWORKS Design user-interface help > Sheet Metal > Using Sheet Metal Tools > Base Flange/Tab > Base Flange PropertyManager** topic.

Accessors

[IFeature::GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[BaseFlangeFeatureData](#)

See Also

[IBaseFlangeFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBaseFlangeFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IBaseFlangeFeatureData Interface

The following tables list the members exposed by [IBaseFlangeFeatureData](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius of this bend flange feature.
 D1EndConditionDistance	Gets or sets the Direction 1 end condition distance for this base flange feature.
 D1EndConditionReference	Gets or sets the Direction 1 end condition reference for this base flange feature.
 D1EndConditionType	Gets or sets the Direction 1 end condition type for this base flange feature.
 D1OffsetDistance	Obsolete. Superseded by IBaseFlangeFeatureData.D1EndConditionDistance .
 D1OffsetReference	Obsolete. Superseded by IBaseFlangeFeatureData.D1EndConditionReference .
 D1OffsetType	Obsolete. Superseded by IBaseFlangeFeatureData.D1EndConditionType .
 D1ReverseOffset	Gets or sets whether the offset for Direction 1 is reversed for this base flange feature.
 D2EndConditionDistance	Gets or sets the Direction 2 end condition distance for this base flange feature.
 D2EndConditionReference	Gets or sets the Direction 2 end condition reference for this base flange feature.
 D2EndConditionType	Gets or sets the Direction 2 end condition type for this base flange feature.
 D2OffsetDistance	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionDistance .
 D2OffsetReference	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionReference .
 D2OffsetType	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionType .

 D2ReverseOffset	Gets or sets whether the offset for Direction 2 is reversed for this base flange feature.
 GaugeTablePath	Gets or sets the path to a gauge table file for this base flange feature
 KFactor	Gets or sets the K-factor for this base-flange feature.
 OffsetDirections	Gets or sets the number of offset directions for this base flange feature.
 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters for this sheet metal base flange feature.
 OverrideKFactor	Gets or sets whether to override the K-factor value specified in the gauge table for this base flange feature.
 OverrideRadius	Gets or sets whether to override the bend radius value specified in the gauge table for this base flange feature.
 OverrideThickness	Gets or sets whether to override the thickness value specified in the gauge table for this base flange feature.
 ReliefDepth	Gets the bend relief depth for this base flange feature.
 ReliefRatio	Gets the bend relief ratio for this base flange feature.
 ReliefType	Gets the bend relief type for this base flange feature.
 ReliefWidth	Gets the bend relief width for this base flange feature.
 ReverseDirection	Gets or sets whether to reverse the direction of extension of this base flange feature.
 ReverseThickness	Gets or sets the direction in which to thicken the sketch for the base flange feature.
 SymmetricThickness	Gets or sets whether to symmetrically thicken this bi-directional base flange feature.
 TableKFactor	Gets the K-factor to use, if it is not overridden , from the gauge table for this base flange feature.
 TableRadius	Gets or sets the bend radius, if is not overridden , in the gauge table for this base flange feature.
 TableThickness	Gets or sets the thickness, if it is not overridden , in the gauge table for this base flange feature.
 Thickness	Gets or sets the thickness for this base flange feature.
 ThicknessTableName	Gets or sets the name of the thickness from the gauge table, if thickness not overridden , for this base flange feature.
 UseDefaultBendAllowance	Gets whether the bend allowance from the original sheet metal feature is used in this sheet metal base flange feature.
 UseDefaultBendRelief	Gets whether this base flange uses the bend relief from the original sheet metal feature.
 UseGaugeTable	Gets or sets whether to use a gauge table for this base flange feature.
 UseMaterialSheetMetalParameters	Gets whether the properties of the material applied are used when creating this base flange.
 UseReliefRatio	Gets whether the relief ratio is used in this base flange feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this base flange feature.
 GetCustomBendAllowance	Gets the custom bend allowance object associated with this sheet metal base flange feature.
 GetD1OffsetReferenceType	Gets the type of reference geometry for Direction 1 for this base flange feature.
 GetD2OffsetReferenceType	Gets the type of reference geometry for Direction 2 for this base flange feature.
 GetTableRadii	Gets the bend radii from the gauge table for this base flange feature.
 GetTableRadiiCount	Gets the number of bend radii for the thickness names from the gauge table for this base flange feature.
 GetTableThicknesses	Gets the names of the thicknesses from the gauge table for this base flange feature.
 GetTableThicknessesCount	Gets the number of names of the thicknesses in the gauge table for this base flange feature.
 IAccessSelections	Obsolete. Superseded by IBaseFlangeFeatureData::IAccessSelections2
 IAccessSelections2	Allows access to the selections that describe this base flange feature.
 IGetTableRadii	Gets the bend radii from the gauge table for this base flange feature.
 IGetTableThicknesses	Gets the names of the thicknesses from the gauge table for this base flange feature.
 Initialize	Initializes a newly created sheet metal base flange feature with the specified data.
 ReleaseSelectionAccess	Releases access to selections that describe this base flange feature.

[Top](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBaseFlangeFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBaseFlangeFeatureData Interface

For a list of all members of this type, see [IBaseFlangeFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this base flange feature.
 GetCustomBendAllowance	Gets the custom bend allowance object associated with this sheet metal base flange feature.
 GetD1OffsetReferenceType	Gets the type of reference geometry for Direction 1 for this base flange feature.
 GetD2OffsetReferenceType	Gets the type of reference geometry for Direction 2 for this base flange feature.
 GetTableRadii	Gets the bend radii from the gauge table for this base flange feature.
 GetTableRadiiCount	Gets the number of bend radii for the thickness names from the gauge table for this base flange feature.
 GetTableThicknesses	Gets the names of the thicknesses from the gauge table for this base flange feature.
 GetTableThicknessesCount	Gets the number of names of the thicknesses in the gauge table for this base flange feature.
 IAccessSelections	Obsolete. Superseded by IBaseFlangeFeatureData::IAccessSelections2
 IAccessSelections2	Allows access to the selections that describe this base flange feature.
 IGetTableRadii	Gets the bend radii from the gauge table for this base flange feature.
 IGetTableThicknesses	Gets the names of the thicknesses from the gauge table for this base flange feature.
 Initialize	Initializes a newly created sheet metal base flange feature with the specified data.
 ReleaseSelectionAccess	Releases access to selections that describe this base flange feature.

[Top](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBaseFlangeFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBaseFlangeFeatureData Interface

For a list of all members of this type, see [IBaseFlangeFeatureData members](#).

Public Properties

Name	Description
 BendRadius	Gets or sets the bend radius of this bend flange feature.
 D1EndConditionDistance	Gets or sets the Direction 1 end condition distance for this base flange feature.
 D1EndConditionReference	Gets or sets the Direction 1 end condition reference for this base flange feature.
 D1EndConditionType	Gets or sets the Direction 1 end condition type for this base flange feature.
 D1OffsetDistance	Obsolete. Superseded by IBaseFlangeFeatureData::D1EndConditionDistance .
 D1OffsetReference	Obsolete. Superseded by IBaseFlangeFeatureData::D1EndConditionReference .

 D1OffsetType	Obsolete. Superseded by IBaseFlangeFeatureData.D1EndConditionType
 D1ReverseOffset	Gets or sets whether the offset for Direction 1 is reversed for this base flange feature.
 D2EndConditionDistance	Gets or sets the Direction 2 end condition distance for this base flange feature.
 D2EndConditionReference	Gets or sets the Direction 2 end condition reference for this base flange feature.
 D2EndConditionType	Gets or sets the Direction 2 end condition type for this base flange feature.
 D2OffsetDistance	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionDistance
 D2OffsetReference	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionReference
 D2OffsetType	Obsolete. Superseded by IBaseFlangeFeatureData.D2EndConditionType
 D2ReverseOffset	Gets or sets whether the offset for Direction 2 is reversed for this base flange feature.
 GaugeTablePath	Gets or sets the path to a gauge table file for this base flange feature
 KFactor	Gets or sets the K-factor for this base-flange feature.
 OffsetDirections	Gets or sets the number of offset directions for this base flange feature.
 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters for this sheet metal base flange feature.
 OverrideKFactor	Gets or sets whether to override the K-factor value specified in the gauge table for this base flange feature.
 OverrideRadius	Gets or sets whether to override the bend radius value specified in the gauge table for this base flange feature.
 OverrideThickness	Gets or sets whether to override the thickness value specified in the gauge table for this base flange feature.
 ReliefDepth	Gets the bend relief depth for this base flange feature.
 ReliefRatio	Gets the bend relief ratio for this base flange feature.
 ReliefType	Gets the bend relief type for this base flange feature.
 ReliefWidth	Gets the bend relief width for this base flange feature.
 ReverseDirection	Gets or sets whether to reverse the direction of extension of this base flange feature.
 ReverseThickness	Gets or sets the direction in which to thicken the sketch for the base flange feature.
 SymmetricThickness	Gets or sets whether to symmetrically thicken this bi-directional base flange feature.
 TableKFactor	Gets the K-factor to use, if it is not overridden , from the gauge table for this base flange feature.
 TableRadius	Gets or sets the bend radius, if it is not overridden , in the gauge table for this base flange feature.
 TableThickness	Gets or sets the thickness, if it is not overridden , in the gauge table for this base flange feature.
 Thickness	Gets or sets the thickness for this base flange feature.
 ThicknessTableName	Gets or sets the name of the thickness from the gauge table, if thickness not overridden , for this base flange feature.
 UseDefaultBendAllowance	Gets whether the bend allowance from the original sheet metal feature is used in this sheet metal base flange feature.
 UseDefaultBendRelief	Gets whether this base flange uses the bend relief from the original sheet metal feature.
 UseGaugeTable	Gets or sets whether to use a gauge table for this base flange feature.
 UseMaterialSheetMetalParameters	Gets whether the properties of the material applied are used when creating this base flange.
 UseReliefRatio	Gets whether the relief ratio is used in this base flange feature.

[Top](#)

 See Also

[IBaseFlangeFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISheetMetalFeatureData Interface](#)

AccessSelections Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : AccessSelections Method (IBaseFlangeFeatureData)

Allows access to the selections that describe this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBaseFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::AccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendRadius Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : BendRadius Property (IBaseFlangeFeatureData)

Gets or sets the bend radius of this bend flange feature.

.NET Syntax

Visual Basic (Declaration)

Property BendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Double
```

```
instance.BendRadius = value
```

```
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the bend radius

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::BendRadius](#).

Example

See [IBaseFlangeFeatureData](#) examples.

Remarks

The setter of this property is valid only if [IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true and [IBaseFlangeFeatureData::UseMaterialSheetMetalParameters](#) is false.

This property gets a:

- Default bend radius if:
 - IBaseFlangeFeatureData::UseMaterialSheetMetalParameters is true,
 - and -
 - IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters is false.
- Custom bend radius if:
 - IBaseFlangeFeatureData::UseDefaultRadius is false,
 - and -
 - IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters is true.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1EndConditionDistance Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1EndConditionDistance Property (IBaseFlangeFeatureData)

Gets or sets the Direction 1 end condition distance for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D1EndConditionDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double
```

```
instance.D1EndConditionDistance = value
```

```
value = instance.D1EndConditionDistance
```

C#

```
System.double D1EndConditionDistance {get; set;}
```

C++/CLI

```
property System.double D1EndConditionDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1EndConditionDistance](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1EndConditionReference Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1EndConditionReference Property (IBaseFlangeFeatureData)

Gets or sets the Direction 1 end condition reference for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D1EndConditionReference As System.Object

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Object

instance.D1EndConditionReference = value

value = instance.D1EndConditionReference
```

C#

```
System.Object D1EndConditionReference {get; set;}
```

C++/CLI

```
property System.Object^ D1EndConditionReference {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition reference

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1EndConditionReference](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1EndConditionType Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1EndConditionType Property (IBaseFlangeFeatureData)

Gets or sets the Direction 1 end condition type for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D1EndConditionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Integer

instance.D1EndConditionType = value
```

```
value = instance.D1EndConditionType
```

C#

```
System.int D1EndConditionType {get; set;}
```

C++/CLI

```
property System.int D1EndConditionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition type as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1EndConditionType](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

D1OffsetDistance Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1OffsetDistance Property (IBaseFlangeFeatureData)

Obsolete. Superseded by [IBaseFlangeFeatureData::D1EndConditionDistance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property D1OffsetDistance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double  
  
instance.D1OffsetDistance = value  
  
value = instance.D1OffsetDistance
```

C#

```
System.double D1OffsetDistance {get; set;}
```

C++/CLI

```
property System.double D1OffsetDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance value

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1OffsetDistance](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D2OffsetDistance Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

D1OffsetReference Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1OffsetReference Property (IBaseFlangeFeatureData)

Obsolete. Superseded by [IBaseFlangeFeatureData::D1EndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

Property D1OffsetReference As System.Object

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Object
```

```
instance.D1OffsetReference = value
```

```
value = instance.D1OffsetReference
```

C#

```
System.Object D1OffsetReference {get; set;}
```

C++/CLI

```
property System.Object^ D1OffsetReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the offset reference

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1OffsetReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D2OffsetReference Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1OffsetType Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1OffsetType Property (IBaseFlangeFeatureData)

Obsolete. Superseded by [IBaseFlangeFeatureData::D1EndConditionType](#).

.NET Syntax

Visual Basic (Declaration)

Property D1OffsetType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Integer
```

```
instance.D1OffsetType = value
```

```
value = instance.D1OffsetType
```

C#

```
System.int D1OffsetType {get; set;}
```

C++/CLI

```
property System.int D1OffsetType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset type as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1OffsetType](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D2OffsetType Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1ReverseOffset Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D1ReverseOffset Property (IBaseFlangeFeatureData)

Gets or sets whether the offset for Direction 1 is reversed for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D1ReverseOffset As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Boolean

instance.D1ReverseOffset = value

value = instance.D1ReverseOffset
```

C#

```
System.bool D1ReverseOffset {get; set;}
```

C++/CLI

```
property System.bool D1ReverseOffset {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the offset, false does not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D1ReverseOffset](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D2ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

D2EndConditionDistance Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2EndConditionDistance Property (IBaseFlangeFeatureData)

Gets or sets the Direction 2 end condition distance for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D2EndConditionDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Double

instance.D2EndConditionDistance = value

value = instance.D2EndConditionDistance
```

C#

```
System.double D2EndConditionDistance {get; set;}
```

C++/CLI

```
property System.double D2EndConditionDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Distance

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2EndConditionDistance](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2EndConditionReference Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2EndConditionReference Property (IBaseFlangeFeatureData)

Gets or sets the Direction 2 end condition reference for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2EndConditionReference As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Object  
  
instance.D2EndConditionReference = value  
value = instance.D2EndConditionReference
```

C#

```
System.object D2EndConditionReference {get; set;}
```

C++/CLI

```
property System.Object^ D2EndConditionReference {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition reference

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2EndConditionReference](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2EndConditionType Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2EndConditionType Property (IBaseFlangeFeatureData)

Gets or sets the Direction 2 end condition type for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property D2EndConditionType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer
```

```
instance.D2EndConditionType = value
```

```
value = instance.D2EndConditionType
```

C#

```
System.int D2EndConditionType {get; set;}
```

C++/CLI

```
property System.int D2EndConditionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

End condition type as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2EndConditionType](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

D2OffsetDistance Property (IBaseFlangeFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2OffsetDistance Property (IBaseFlangeFeatureData)**Obsolete.** Superseded by [IBaseFlangeFeatureData::D2EndConditionDistance](#).

.NET Syntax

Visual Basic (Declaration)

Property D2offsetDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Double
```

```
instance.D2offsetDistance = value
```

```
value = instance.D2offsetDistance
```

C#

```
System.double D2offsetDistance {get; set;}
```

C++/CLI

```
property System.double D2offsetDistance {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset distance value

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2OffsetDistance](#).

See Also

[IBaseFlangeFeatureData Interface](#)[IBaseFlangeFeatureData Members](#)[IBaseFlangeFeatureData::D1OffsetDistance Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

D2OffsetReference Property (IBaseFlangeFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2OffsetReference Property (IBaseFlangeFeatureData)**Obsolete.** Superseded by [IBaseFlangeFeatureData::D2EndConditionReference](#).

.NET Syntax

Visual Basic (Declaration)

Property D2offsetReference As System.Object

```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Object

instance.D20ffsetReference = value

value = instance.D20ffsetReference
```

C#

```
System.Object D20ffsetReference {get; set;}
```

C++/CLI

```
property System.Object^ D20ffsetReference {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the offset reference

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2OffsetReference](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D1OffsetReference Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

D2OffsetType Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2OffsetType Property (IBaseFlangeFeatureData)

Obsolete. Superseded by [IBaseFlangeFeatureData::D2EndConditionType](#).

.NET Syntax

Visual Basic (Declaration)

```
Property D20ffsetType As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Integer

instance.D20ffsetType = value

value = instance.D20ffsetType
```

C#

```
System.int D2OffsetType {get; set;}
```

C++/CLI

```
property System.int D2OffsetType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Offset type as defined in [swFlangeOffsetTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2OffsetType](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D1OffsetType Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2ReverseOffset Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : D2ReverseOffset Property (IBaseFlangeFeatureData)

Gets or sets whether the offset for Direction 2 is reversed for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2ReverseOffset As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.D2ReverseOffset = value
```

```
value = instance.D2ReverseOffset
```

C#

```
System.bool D2ReverseOffset {get; set;}
```

C++/CLI

```
property System.bool D2ReverseOffset {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the offset false does not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::D2ReverseOffset](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::D1ReverseOffset Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GaugeTablePath Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GaugeTablePath Property (IBaseFlangeFeatureData)

Gets or sets the path to a gauge table file for this base flange feature

.NET Syntax

Visual Basic (Declaration)

Property GaugeTablePath As System.String

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.String
```

```
instance.GaugeTablePath = value
```

```
value = instance.GaugeTablePath
```

C#

```
System.string GaugeTablePath {get; set;}
```

C++/CLI

```
property System.String^ GaugeTablePath {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fully qualified path to a gauge table file

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GaugeTablePath](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

GetCustomBendAllowance Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetCustomBendAllowance Method (IBaseFlangeFeatureData)

Gets the custom bend allowance object associated with this sheet metal base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Object  
  
value = instance.GetCustomBendAllowance()
```

C#

```
System.object GetCustomBendAllowance()
```

C++/CLI

```
System.Object^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetCustomBendAllowance](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This method is valid only if [IBaseFlangeFeatureData::UseDefaultBendAllowance](#) is false.

You can change the custom bend allowance after it has been [initialized](#). Access the parent sheet metal to do so. See the Examples.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

GetD1OffsetReferenceType Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetD1OffsetReferenceType Method (IBaseFlangeFeatureData)

Gets the type of reference geometry for Direction 1 for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetD10ffsetReferenceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.GetD10ffsetReferenceType()
```

C#

```
System.int GetD10ffsetReferenceType()
```

C++/CLI

```
System.int GetD10ffsetReferenceType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of reference geometry as defined in [swSelectionReferenceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetD1OffsetReferenceType](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetD2OffsetReferenceType Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetD2OffsetReferenceType Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetD2OffsetReferenceType Method (IBaseFlangeFeatureData)

Gets the type of reference geometry for Direction 2 for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetD20ffsetReferenceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.GetD20ffsetReferenceType()
```

C#

```
System.int GetD20ffsetReferenceType()
```

C++/CLI

```
System.int GetD20ffsetReferenceType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of reference geometry as defined in [swSelectionReferenceTypes](#) e

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetD2OffsetReferenceType](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetD1OffsetReferenceType Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTableRadii Method (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetTableRadii Method (IBaseFlangeFeatureData)

Gets the bend radii from the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableRadii( _  
    ByVal ThicknessTableName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim ThicknessTableName As System.String  
Dim value As System.Object  
  
value = instance.GetTableRadii(ThicknessTableName)
```

C#

```
System.object GetTableRadii(  
    System.string ThicknessTableName  
)
```

C++/CLI

```
System.Object^ GetTableRadii(  
& System.String^ ThicknessTableName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ThicknessTableName
Gauge table thickness names (see **Remarks**)

Return Value

Array of bend radii

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetTableRadii](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

Remarks

Before calling this method call, [IBaseFlangeFeatureData::GetTableThicknesses](#) to get the names of the thicknesses in the gauge table.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::GetTableRadiiCount Method](#)
[IBaseFlangeFeatureData::OverrideRadius Property](#)
[IBaseFlangeFeatureData::TableRadius Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableRadiiCount Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetTableRadiiCount Method (IBaseFlangeFeatureData)

Gets the number of bend radii for the thickness names from the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableRadiiCount( _  
    ByVal ThicknessTableName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim ThicknessTableName As System.String  
Dim value As System.Integer  
  
value = instance.GetTableRadiiCount(ThicknessTableName)
```

C#

```
System.int GetTableRadiiCount(  
    System.string ThicknessTableName  
)
```

C++/CLI

```
System.int GetTableRadiiCount(  
& System.String^ ThicknessTableName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ThicknessTableName
Thickness names

Return Value

Number of bend radii

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetTableRadiiCount](#).

Remarks

Call this method before calling [IBaseFlangeFeatureData::!GetTableRadii](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::OverrideRadius Property](#)
[IBaseFlangeFeatureData::TableRadius Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableThicknesses Method (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetTableThicknesses Method (IBaseFlangeFeatureData)

Gets the names of the thicknesses from the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableThicknesses() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Object  
  
value = instance.GetTableThicknesses()
```

C#

```
System.object GetTableThicknesses()
```

C++/CLI

```
System.Object^ GetTableThicknesses();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Names of the thicknesses

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::GetTableThicknesses](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::!GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GetTableThicknessesCount Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::TableThickness Property](#)

[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableThicknessesCount Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : GetTableThicknessesCount Method (IBaseFlangeFeatureData)

Gets the number of names of the thicknesses in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableThicknessesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.GetTableThicknessesCount()
```

C#

```
System.int GetTableThicknessesCount()
```

C++/CLI

```
System.int GetTableThicknessesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of names of the thicknesses

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData.GetTableThicknessesCount](#).

Remarks

Call this method before calling [IBaseFlangeFeatureData::IGetTableThicknesses](#) to get the size of the array for that method.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::OverrideThickness Property](#)
[IBaseFlangeFeatureData::TableThickness Property](#)
[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : IAccessSelections Method (IBaseFlangeFeatureData)

Obsolete. Superseded by [IBaseFlangeFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::IAccessSelections](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : IAccessSelections2 Method (IBaseFlangeFeatureData)

Allows access to the selections that describe this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IBaseFlangeFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections2(TopDoc, Component)

```

C#

```

System.bool IAccessSelections2(
    ModelDoc2 TopDoc,
    Component2 Component
)

```

C++/CLI

```

System.bool IAccessSelections2(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData.IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IBaseFlangeFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0



Gets the bend radii from the gauge table for this base flange feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetTableRadii( _  
    ByVal ThicknessTableName As System.String, _  
    ByVal NCount As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim ThicknessTableName As System.String  
Dim NCount As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTableRadii(ThicknessTableName, NCount)
```

C#

```
System.double IGetTableRadii(  
    System.string ThicknessTableName,  
    System.int NCount  
)
```

C++/CLI

```
System.double IGetTableRadii(  
& System.String^ ThicknessTableName,  
& System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ThicknessTableName

Gauge table thickness names (see **Remarks**)

NCount

Number of bend radii (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of bend radii
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method call:

- [IBaseFlangeFeatureData::IGetTableThicknesses](#) to get the names of the thicknesses in the gauge table.
- [IBaseFlangeFeatureData::GetTableRadiiCount](#) to get the value for NCount.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::OverrideThickness Property](#)
[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : IGetTableThicknesses Method (IBaseFlangeFeatureData)

Gets the names of the thicknesses from the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableThicknesses( _  
    ByVal NCount As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim NCount As System.Integer  
Dim value As System.String  
  
value = instance.IGetTableThicknesses(NCount)
```

C#

```
System.string IGetTableThicknesses(  
    System.int NCount  
)
```

C++/CLI

```
System.String^ IGetTableThicknesses(  
&    System.int NCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NCount
Number of thickness names

Return Value

- in-process, unmanaged C++: Pointer to an array of names of the thicknesses
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBaseFlangeFeatureData::GetTableThicknessesCount](#) to get the value for NCount.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::TableThickness Property](#)
[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Initialize Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : Initialize Method (IBaseFlangeFeatureData)

Initializes a newly created sheet metal base flange feature with the specified data.

Visual Basic (Declaration)

```
Sub Initialize( _
    ByVal UseMaterialSheetMetalParameters As System.Boolean, _
    ByVal OverrideDefaultBendAllowance As System.Boolean, _
    ByVal CustomBendAllowance As System.Object, _
    ByVal OverrideDefaultBendRelief As System.Boolean, _
    ByVal ReliefType As System.Integer, _
    ByVal UseReliefRatio As System.Boolean, _
    ByVal ReliefRatio As System.Double, _
    ByVal ReliefWidth As System.Double, _
    ByVal ReliefDepth As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim UseMaterialSheetMetalParameters As System.Boolean
Dim OverrideDefaultBendAllowance As System.Boolean
Dim CustomBendAllowance As System.Object
Dim OverrideDefaultBendRelief As System.Boolean
Dim ReliefType As System.Integer
Dim UseReliefRatio As System.Boolean
Dim ReliefRatio As System.Double
Dim ReliefWidth As System.Double
Dim ReliefDepth As System.Double

instance.Initialize(UseMaterialSheetMetalParameters, OverrideDefaultBendAllowance,
CustomBendAllowance, OverrideDefaultBendRelief, ReliefType, UseReliefRatio, ReliefRatio,
ReliefWidth, ReliefDepth)
```

C#

```
void Initialize(
    System.bool UseMaterialSheetMetalParameters,
    System.bool OverrideDefaultBendAllowance,
    System.object CustomBendAllowance,
    System.bool OverrideDefaultBendRelief,
    System.int ReliefType,
    System.bool UseReliefRatio,
    System.double ReliefRatio,
    System.double ReliefWidth,
    System.double ReliefDepth
)
```

C++/CLI

```
void Initialize(
    & System.bool UseMaterialSheetMetalParameters,
    & System.bool OverrideDefaultBendAllowance,
    & System.Object^ CustomBendAllowance,
    & System.bool OverrideDefaultBendRelief,
    & System.int ReliefType,
    & System.bool UseReliefRatio,
    & System.double ReliefRatio,
    & System.double ReliefWidth,
    & System.double ReliefDepth
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseMaterialSheetMetalParameters

True to use the sheet metal properties of the applied material, false to not

OverrideDefaultBendAllowance

True to override the default bend allowance, false to not

CustomBendAllowance

[ICustomBendAllowance](#): valid only if *OverrideDefaultBendAllowance* is true

OverrideDefaultBendRelief

True to override the default bend relief, false to not

ReliefType

Relief type as defined in [swSheetMetalReliefTypes_e](#); valid only if OverrideDefaultBendRelief is true

UseReliefRatio

True to use ReliefRatio, false to use ReliefWidth and ReliefDepth; valid only if OverrideDefaultBendRelief is true

ReliefRatio

Relief ratio; valid only if UseReliefRatio is true

ReliefWidth

Relief width (numerator of relief ratio); valid only if UseReliefRatio is false

ReliefDepth

Relief depth (denominator of relief ratio); valid only if UseReliefRatio is false

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::Initialize](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

After you call this method to initialize the base flange feature, you cannot change any of the properties associated with this method's parameters. After initialization you can get, but not set, the following using this interface:

- Whether to use default bend allowance
- Whether to use default bend relief
- Whether to use material sheet metal parameters
- Whether to use relief ratio
- Custom bend allowance
- Relief depth
- Relief ratio
- Relief type
- Relief width

You can, however, change any properties associated with the parent sheet metal after calling this method. For example:

- [ISheetMetalFeatureData::SetCustomBendAllowance](#)
- [ISheetMetalFeatureData::SetOverrideDefaultParameter2](#)
- [ISheetMetalFeatureData::AutoReliefType](#)
- [ISheetMetalFeatureData::ReliefRatio](#)
- [ISheetMetalFeatureData::UseMaterialSheetMetalParameters](#)

See the Examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetCustomBendAllowance Method \(\)](#)
[IBaseFlangeFeatureData::ReliefDepth Property \(\)](#)
[IBaseFlangeFeatureData::ReliefRatio Property \(\)](#)
[IBaseFlangeFeatureData::ReliefType Property \(\)](#)
[IBaseFlangeFeatureData::ReliefWidth Property \(\)](#)
[IBaseFlangeFeatureData::UseDefaultBendAllowance Property \(\)](#)
[IBaseFlangeFeatureData::UseDefaultBendRelief Property \(\)](#)
[IBaseFlangeFeatureData::UseMaterialSheetMetalParameters Property \(\)](#)
[IBaseFlangeFeatureData::UseReliefRatio Property \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

KFactor Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : KFactor Property (IBaseFlangeFeatureData)

Gets or sets the K-factor for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property KFactor As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double
```

```
instance.KFactor = value  
value = instance.KFactor
```

C#

```
System.double KFactor {get; set;}
```

C++/CLI

```
property System.double KFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

K-factor

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::KFactor](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::OverrideKFactor Property](#)
[IBaseFlangeFeatureData::TableKFactor Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OffsetDirections Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : OffsetDirections Property (IBaseFlangeFeatureData)

Gets or sets the number of offset directions for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OffsetDirections As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer
```

```
instance.OffsetDirections = value  
value = instance.OffsetDirections
```

C#

```
System.int OffsetDirections {get; set;}
```

C++/CLI

```
property System.int OffsetDirections {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of offset directions

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::OffsetDirections](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultSheetMetalParameters Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : OverrideDefaultSheetMetalParameters Property (IBaseFlangeFeatureData)

Gets or sets whether to override the default sheet metal parameters for this sheet metal base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideDefaultSheetMetalParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Boolean
```

```
instance.OverrideDefaultSheetMetalParameters = value
```

```
value = instance.OverrideDefaultSheetMetalParameters
```

C#

```
System.bool OverrideDefaultSheetMetalParameters {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultSheetMetalParameters {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the default values, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::OverrideDefaultSheetMetalParameters](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid only when creating the base flange in a non-sheet-metal part.

If this property is:

- True, then [IBaseFlangeFeatureData::Thickness](#) and [IBaseFlangeFeatureData::BendRadius](#) get and set user-defined values.
- False, then IBaseFlangeFeatureData::Thickness and IBaseFlangeFeatureData::BendRadius are invalid setters; those properties only get default values.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideKFactor Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : OverrideKFactor Property (IBaseFlangeFeatureData)

Gets or sets whether to override the K-factor value specified in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideKFactor As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.OverrideKFactor = value
```

```
value = instance.OverrideKFactor
```

C#

```
System.bool OverrideKFactor {get; set;}
```

C++/CLI

```
property System.bool OverrideKFactor {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the K-factor value, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::OverrideKFactor](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::KFactor Property](#)
[IBaseFlangeFeatureData::TableKFactor Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OverrideRadius Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : OverrideRadius Property (IBaseFlangeFeatureData)

Gets or sets whether to override the bend radius value specified in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideRadius As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.OverrideRadius = value
```

```
value = instance.OverrideRadius
```

C#

```
System.bool OverrideRadius {get; set;}
```

C++/CLI

```
property System.bool OverrideRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the bend radius value, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::OverrideRadius](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::GetTableRadiiCount Method](#)
[IBaseFlangeFeatureData::!GetTableRadii Method](#)
[IBaseFlangeFeatureData::TableRadius Property](#)

Availability

OverrideThickness Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : OverrideThickness Property (IBaseFlangeFeatureData)

Gets or sets whether to override the thickness value specified in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Boolean
```

```
instance.OverrideThickness = value
```

```
value = instance.OverrideThickness
```

C#

```
System.bool OverrideThickness {get; set;}
```

C++/CLI

```
property System.bool OverrideThickness {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the thickness, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::OverrideThickness](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::IGetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GetTableThicknessesCount Method](#)
[IBaseFlangeFeatureData::TableThickness Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

ReleaseSelectionAccess Method (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReleaseSelectionAccess Method (IBaseFlangeFeatureData)

Releases access to selections that describe this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReleaseSelectionAccess](#).

Remarks

[IBaseFlangeFeatureData::AccessSelections](#) and [IBaseFlangeFeatureData::!AccessSelections2](#) puts the model into a rollback state to allow access to the selections that define the base flange feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefDepth Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReliefDepth Property (IBaseFlangeFeatureData)

Gets the bend relief depth for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReliefDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double  
  
value = instance.ReliefDepth
```

C#

```
System.double ReliefDepth {get;}
```

C++/CLI

```
property System.double ReliefDepth {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief depth

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReliefDepth](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid when:

- [IBaseFlangeFeatureData::UseReliefRatio](#) returns false,
- and -
- [IBaseFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

The relief depth is set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReliefRatio Property (IBaseFlangeFeatureData)

Gets the bend relief ratio for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReliefRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double
```

```
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();
```

```
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ratio of bend relief width to bend relief depth

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReliefRatio](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid when:

- [IBaseFlangeFeatureData::UseReliefRatio](#) returns true,
- and -
- [IBaseFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

The relief ratio is set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefType Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReliefType Property (IBaseFlangeFeatureData)

Gets the bend relief type for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ReliefType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Integer  
  
value = instance.ReliefType
```

C#

```
System.int ReliefType {get;}
```

C++/CLI

```
property System.int ReliefType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief type as defined by [swSheetMetalReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReliefType](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

The relief type is set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefWidth Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReliefWidth Property (IBaseFlangeFeatureData)

Gets the bend relief width for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ReliefWidth As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double
```

```
value = instance.ReliefWidth
```

C#

```
System.double ReliefWidth {get;}
```

C++/CLI

```
property System.double ReliefWidth {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend relief width

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReliefWidth](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid when:

- [IBaseFlangeFeatureData::UseReliefRatio](#) returns false,
 - and -
 - [IBaseFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).
- The relief width is set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReverseDirection Property (IBaseFlangeFeatureData)

Gets or sets whether to reverse the direction of extension of this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseDirection As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction of the feature's extension, false does not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReverseDirection](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseThickness Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ReverseThickness Property (IBaseFlangeFeatureData)

Gets or sets the direction in which to thicken the sketch for the base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property ReverseThickness As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Boolean
```

```
instance.ReverseThickness = value
```

```
value = instance.ReverseThickness
```

C#

```
System.bool ReverseThickness {get; set;}
```

C++/CLI

```
property System.bool ReverseThickness {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True reverses the direction in which to thicken the sketch, false does not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ReverseThickness](#).

Remarks

The setter of this property is valid only if [IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true and [IBaseFlangeFeatureData::UseMaterialSheetMetalParameters](#) is false.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::Thickness Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

SymmetricThickness Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : SymmetricThickness Property (IBaseFlangeFeatureData)

Gets or sets whether to symmetrically thicken this bi-directional base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SymmetricThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean  
  
instance.SymmetricThickness = value  
value = instance.SymmetricThickness
```

C#

```
System.bool SymmetricThickness {get; set;}
```

C++/CLI

```
property System.bool SymmetricThickness {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to thicken symmetrically, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::SymmetricThickness](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

TableKFactor Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : TableKFactor Property (IBaseFlangeFeatureData)

Gets the K-factor to use, if it is not [overridden](#), from the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TableKFactor As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double  
  
value = instance.TableKFactor
```

C#

```
System.double TableKFactor {get;}
```

C++/CLI

```
property System.double TableKFactor {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

K-factor value

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::TableKFactor](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::KFactor Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TableRadius Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : TableRadius Property (IBaseFlangeFeatureData)

Gets or sets the bend radius, if is not [overridden](#), in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property TableRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double  
  
instance.TableRadius = value  
  
value = instance.TableRadius
```

C#

```
System.double TableRadius {get; set;}
```

C++/CLI

```
property System.double TableRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::TableRadius](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

Remarks

If the bend radius is not overridden, then the value for the bend radius is the value returned or set by [IBaseFlangeFeatureData::BendRadius](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::!GetTableRadii Method](#)
[IBaseFlangeFeatureData::GetTableRadiiCount Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::OverrideRadius Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TableThickness Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : TableThickness Property (IBaseFlangeFeatureData)

Gets or sets the thickness, if it is not [overridden](#), in the gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property TableThickness As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Double
```

```
instance.TableThickness = value
```

```
value = instance.TableThickness
```

C#

```
System.double TableThickness {get; set;}
```

C++/CLI

```
property System.double TableThickness {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thickness

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::TableThickness](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

Remarks

If the thickness is not overridden, then the value for thickness is the value returned or set by [IBaseFlangeFeatureData::Thickness](#).

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::IGetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GetTableThicknessesCount Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Thickness Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : Thickness Property (IBaseFlangeFeatureData)

Gets or sets the thickness for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

Property Thickness As System.Double

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Double

instance.Thickness = value

value = instance.Thickness
```

C#

```
System.double Thickness {get; set;}
```

C++/CLI

```
property System.double Thickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value for thickness

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::Thickness](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid only when not creating the base flange on an existing sheet metal feature.

The setter of this property is valid only if [IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters](#) is true and [IBaseFlangeFeatureData::UseMaterialSheetMetalParameters](#) is false.

This property gets:

- Default thickness if IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters is false.
- Custom thickness if IBaseFlangeFeatureData::OverrideDefaultSheetMetalParameters is true.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::ReverseThickness Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

ThicknessTableName Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : ThicknessTableName Property (IBaseFlangeFeatureData)

Gets or sets the name of the thickness from the gauge table, if thickness not [overridden](#), for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThicknessTableName As System.String
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.String
```

```
instance.ThicknessTableName = value  
value = instance.ThicknessTableName
```

C#

```
System.string ThicknessTableName {get; set;}
```

C++/CLI

```
property System.String^ ThicknessTableName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of thickness

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::ThicknessTableName](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::IGetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GetTableThicknessesCount Method](#)

[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::TableThickness Property](#)
[IBaseFlangeFeatureData::UseGaugeTable Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : UseDefaultBendAllowance Property (IBaseFlangeFeatureData)

Gets whether the bend allowance from the original sheet metal feature is used in this sheet metal base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property UseDefaultBendAllowance As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the parent sheet metal bend allowance, false uses a custom bend allowance

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::UseDefaultBendAllowance](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

If this property is false, then use [IBaseFlangeFeatureData::GetCustomBendAllowance](#) to get the custom bend allowance used to [initialize](#) this base flange.

Whether to use the default bend allowance is set during the initialization of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendRelief Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : UseDefaultBendRelief Property (IBaseFlangeFeatureData)

Gets whether this base flange uses the bend relief from the original sheet metal feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property UseDefaultBendRelief As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
value = instance.UseDefaultBendRelief
```

C#

```
System.bool UseDefaultBendRelief {get;}
```

C++/CLI

```
property System.bool UseDefaultBendRelief {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the default bend relief, false uses a custom bend relief (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::UseDefaultBendRelief](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

If this property is false, then you can get the type of bend relief and whether a relief ratio is used. Both were set during [initialization](#) of this base flange:

- [IBaseFlangeFeatureData::ReliefType](#)
- [IBaseFlangeFeatureData::UseReliefRatio](#)

If [IBaseFlangeFeatureData::UseReliefRatio](#) is:

- True, then you can use [IBaseFlangeFeatureData::ReliefRatio](#) to get the relief ratio
- False, then you can use [IBaseFlangeFeatureData::ReliefDepth](#) and [IBaseFlangeFeatureData::ReliefWidth](#) to get the relief depth and width.

Whether to use the default bend relief was set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseGaugeTable Property (IBaseFlangeFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : UseGaugeTable Property (IBaseFlangeFeatureData)

Gets or sets whether to use a gauge table for this base flange feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseGaugeTable As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData
Dim value As System.Boolean

instance.UseGaugeTable = value

value = instance.UseGaugeTable
```

C#

```
System.bool UseGaugeTable {get; set;}
```

C++/CLI

```
property System.bool UseGaugeTable {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use a gauge table, false to not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::UseGaugeTable](#).

Example

[Create Base-Flange Feature Using Gauge Table \(VBA\)](#)

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)
[IBaseFlangeFeatureData::GetTableRadii Method](#)
[IBaseFlangeFeatureData::!GetTableRadii Method](#)
[IBaseFlangeFeatureData::GetTableRadiiCount Method](#)
[IBaseFlangeFeatureData::GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::!GetTableThicknesses Method](#)
[IBaseFlangeFeatureData::GetTableThicknessesCount Method](#)
[IBaseFlangeFeatureData::GaugeTablePath Property](#)
[IBaseFlangeFeatureData::KFactor Property](#)
[IBaseFlangeFeatureData::OverrideKFactor Property](#)
[IBaseFlangeFeatureData::OverrideRadius Property](#)
[IBaseFlangeFeatureData::OverrideThickness Property](#)
[IBaseFlangeFeatureData::TableKFactor Property](#)
[IBaseFlangeFeatureData::TableThickness Property](#)
[IBaseFlangeFeatureData::ThicknessTableName Property](#)
[IBaseFlangeFeatureData::TableRadius Property](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseMaterialSheetMetalParameters Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : UseMaterialSheetMetalParameters Property (IBaseFlangeFeatureData)

Gets whether the properties of the material applied are used when creating this base flange.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property UseMaterialSheetMetalParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean  
  
value = instance.UseMaterialSheetMetalParameters
```

C#

```
System.bool UseMaterialSheetMetalParameters {get;}
```

C++/CLI

```
property System.bool UseMaterialSheetMetalParameters {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the applied material's sheet metal parameters, false does not

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::UseMaterialSheetMetalParameters](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid only:

- when not creating the base flange on an existing sheet metal feature,
- and -
- when [IBaseFlangeFeatureData::UseGaugeTable](#) is false.

If this property returns false, then specify sheet metal parameters using:

- [IBaseFlangeFeatureData::BendRadius](#)
- [IBaseFlangeFeatureData::Thickness](#)
- [IBaseFlangeFeatureData::ReverseThickness](#)

Whether to use the applied material's sheet metal parameters was set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseReliefRatio Property (IBaseFlangeFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBaseFlangeFeatureData Interface](#) : UseReliefRatio Property (IBaseFlangeFeatureData)

Gets whether the relief ratio is used in this base flange feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UseReliefRatio As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBaseFlangeFeatureData  
Dim value As System.Boolean
```

```
value = instance.UseReliefRatio
```

C#

```
System.bool UseReliefRatio {get;}
```

C++/CLI

```
property System.bool UseReliefRatio {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True uses the relief ratio, false uses relief depth / relief width

Visual Basic for Applications (VBA) Syntax

See [BaseFlangeFeatureData::UseReliefRatio](#).

Example

See the [IBaseFlangeFeatureData](#) examples.

Remarks

This property is valid when:

- [IBaseFlangeFeatureData::UseDefaultBendRelief](#) is false,
- and -
- [IBaseFlangeFeatureData::ReliefType](#) is [swSheetMetalReliefTypes_e.swSheetMetalReliefRectangular](#) or [swSheetMetalReliefTypes_e.swSheetMetalReliefObround](#).

If this property is:

- True, then use [IBaseFlangeFeatureData::ReliefRatio](#) to get the relief ratio used to [initialize](#) this base flange.
- False, then use [IBaseFlangeFeatureData::ReliefWidth](#) and [IBaseFlangeFeatureData::ReliefDepth](#) to get the relief width and relief depth used to initialize this base flange.

Whether to use a relief ratio was set during the [initialization](#) of this base flange and cannot be changed.

See Also

[IBaseFlangeFeatureData Interface](#)
[IBaseFlangeFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30