

SOLIDWORKS API (.NET VBA C#) — Reference

(21/337): IBeltChainFeatureData- IBendTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IBeltChainFeatureData (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBeltChainFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBeltChainFeatureData Interface

Allows access to a Belt/Chain assembly feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBeltChainFeatureData

Visual Basic (Usage)



Dim instance As [IBeltChainFeatureData](#)

C#

public interface IBeltChainFeatureData

C++/CLI

public interface class IBeltChainFeatureData

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData](#).

Example

```
'VBA
'=====
'Preconditions: Ensure the specified assembly template and part exist.
'
'Postconditions:
'1. Creates an assembly of two steel discs.
'2. Press F5 to create Belt1 in the FeatureManager design tree.
'   If a Save As dialog appears, click Cancel.
'3. Press F5 to modify Belt1's belt length, belt thickness,
'   and pulley diameters. If a Save As dialog appears, click Cancel.
'=====
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim selMgr As SldWorks.SelectionMgr
Dim beltChainFeatData As SldWorks.BeltChainFeatureData
Dim pulleyComps(1) As Object
Dim pulleyDiams(1) As Double
Dim pulleyFlips(1) As Boolean
Dim pulleyRefsOri As Variant
Dim pulleyDiamsOri As Variant
Dim swFeat As SldWorks.Feature
Dim swFeatData As SldWorks.BeltChainFeatureData
Dim BeltLocationPlane As SldWorks.Face2
Dim beltPart As SldWorks.PartDoc
Dim index As Long
Dim I As Long
Dim J As Long
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long

Option Explicit
Sub main()

    Set swApp = Application.SldWorks

    ' New assembly
```

```

Dim swSheetWidth As Double
swSheetWidth = 0
Dim swSheetHeight As Double
swSheetHeight = 0
Set swModel = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS 2022\templates\Assembly.asmdot", 0, swSheetWidth,
swSheetHeight)
Dim swAssembly As AssemblyDoc
Set swAssembly = swModel

' Insert steel disc component

Dim AssemblyTitle As String
AssemblyTitle = swModel.GetTitle
Dim tmpObj As ModelDoc2
Dim errors As Long
Set tmpObj = swApp.OpenDoc6("C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS 2022\samples\tutorial\api\AdvancedMates\steel
disc.sldprt", 1, 1, "", errors, longwarnings)
Set swModel = swApp.ActivateDoc3(AssemblyTitle, True, 0, errors)
Dim swInsertedComponent As Component2
Set swInsertedComponent = swModel.AddComponent5("C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS
2022\samples\tutorial\api\AdvancedMates\steel disc.sldprt", 0, "", False, "", 4.04421078452853E-03, 4.04421078422676E-03,
1.22628871084471E-02)
swApp.CloseDoc "C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS 2021\samples\tutorial\api\AdvancedMates\steel disc.sldprt"

' Insert steel disc component

AssemblyTitle = swModel.GetTitle
Set tmpObj = swApp.OpenDoc6("C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS 2022\samples\tutorial\api\AdvancedMates\steel
disc.sldprt", 1, 1, "", errors, longwarnings)
Set swModel = swApp.ActivateDoc3(AssemblyTitle, True, 0, errors)
Set swInsertedComponent = swModel.AddComponent5("C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS
2022\samples\tutorial\api\AdvancedMates\steel disc.sldprt", 0, "", False, "", 2.00044210784528E-02, 2.00044210784227E-02,
1.22628871084471E-02)
swApp.CloseDoc "C:\Users\Public\Documents\SOLIDWORKS\SOLIDWORKS 2021\samples\tutorial\api\AdvancedMates\steel disc.sldprt"

' Float the components

boolstatus = swModel.Extension.SelectByID2("steel disc-1", "COMPONENT", 0, 0, 0, False, 0, Nothing, 0)
swModel.UnfixComponent
swModel.ClearSelection2 True
boolstatus = swModel.Extension.SelectByID2("steel disc-2", "COMPONENT", 0, 0, 0, False, 0, Nothing, 0)
swModel.UnfixComponent
swModel.ClearSelection2 True

' Move one disc

boolstatus = swModel.Extension.SelectByID2("steel disc-2@Assem14", "COMPONENT", 0, 0, 0, False, 0, Nothing, 0)
boolstatus = swModel.Extension.SelectByID2("Unknown", "MANIPULATOR", 3.40009836225566E-02, -3.52899570186584E-03,
-1.15173288530189E-02, False, 0, Nothing, 0)
swModel.ClearSelection2 True
boolstatus = swModel.Extension.SelectByID2("steel disc-2@Assem14", "COMPONENT", 0, 0, 0, False, 0, Nothing, 0)
Dim TransformData() As Double
ReDim TransformData(0 To 15) As Double
TransformData(0) = 1
TransformData(1) = 0
TransformData(2) = 0
TransformData(3) = 0
TransformData(4) = 1
TransformData(5) = 0
TransformData(6) = 0
TransformData(7) = 0
TransformData(8) = 1
TransformData(9) = 6.64528131333411E-02
TransformData(10) = 4.6349356621274E-03
TransformData(11) = 9.19716533133533E-03
TransformData(12) = 1
TransformData(13) = 0
TransformData(14) = 0
TransformData(15) = 0
Dim TransformDataVariant As Variant
TransformDataVariant = TransformData
Dim swMathUtil As Object
Set swMathUtil = swApp.GetMathUtility()
Dim swTransform As Object
Set swTransform = swMathUtil.CreateTransform((TransformDataVariant))
Dim swComp As Object
Set swComp = swModel.SelectionManager.GetSelectedObjectsComponent4(1, -1)
boolstatus = swComp.SetTransformAndSolve2(swTransform)
boolstatus = swModel.ForceRebuild3(False)
swModel.ClearSelection2 True

```

```

' Select the pulley faces

boolstatus = swModel.Extension.SelectByRay(1.30157615084272E-02, 9.90176398499898E-03, 1.21640119419908E-02,
-0.333333333266778, -0.333333333254022, -0.881917103743329, 9.73554376657825E-04, 2, False, 0, 0)
boolstatus = swModel.Extension.SelectByRay(7.69710902559098E-02, 6.67589089525222E-03, 1.12969076145077E-02,
-0.333333333266778, -0.333333333254022, -0.881917103743329, 9.73554376657825E-04, 2, False, 0, 0)

Set selMgr = swModel.SelectionManager

For I = 0 To UBound(pulleyComps)
Set pulleyComps(I) = selMgr.GetSelectedObject6(I + 1, -1)
Next

' Create Belt/Chain feature

Set beltChainFeatData = swModel.FeatureManager.CreateDefinition(swFmBeltAndChain)

For J = 0 To UBound(pulleyComps)
pulleyDiams(J) = 0.005 * (J + 2)
Next

beltChainFeatData.PulleyComponents = pulleyComps
beltChainFeatData.PulleyDiameters = pulleyDiams

pulleyFlips(0) = False
pulleyFlips(1) = False

beltChainFeatData.FlipSides = pulleyFlips

beltChainFeatData.BeltLocationPlane = selMgr.GetSelectedObject6(3, -1)

beltChainFeatData.DrivingLength = True
beltChainFeatData.BeltLength = 0.59492

beltChainFeatData.UseBeltThickness = True
beltChainFeatData.BeltThickness = 0.003

beltChainFeatData.CreateBeltPart = True
beltChainFeatData.EngageBelt = False

Set swFeat = swModel.FeatureManager.CreateFeature(beltChainFeatData)

Stop

Set swFeatData = swFeat.GetDefinition()

' Modify Belt/Chain feature

boolstatus = swFeatData.AccessSelections(swModel, Nothing)

pulleyDiamsOri = swFeatData.PulleyDiameters
pulleyDiamsOri(0) = 0.02
pulleyDiamsOri(1) = 0.02

swFeatData.PulleyDiameters = pulleyDiamsOri
Debug.Print "Pulley diameters changed to 20 mm"

swFeatData.DrivingLength = True
swFeatData.BeltLength = 0.3
Debug.Print "Belt length (m) changed to " & swFeatData.BeltLength

swFeatData.BeltThickness = 0.002
Debug.Print "Belt thickness (m) changed to " & swFeatData.BeltThickness

boolstatus = swFeat.ModifyDefinition(swFeatData, swModel, Nothing)

End Sub

```

Example

[Create Belt/Chain Feature \(VB.NET\)](#)
[Create Belt/Chain Feature \(C#\)](#)

Remarks

For more information, see the **SOLIDWORKS Design** user-interface help > **Assemblies** > **Other Assembly Techniques** > **Assembly Features** > **Creating Assembly Features** >

- **Creating a Belt/Chain Assembly Feature**
- **Belt/Chain PropertyManager (Assemblies)**

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[BeltChainFeatureData](#)

See Also

[IBeltChainFeatureData Members](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBeltChainFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBeltChainFeatureData Interface

For a list of all members of this type, see [IBeltChainFeatureData members](#).

Public Methods

Name	Description
 AccessBeltPart	Gets the belt part.
 AccessSelections	Gains access to selections used to define this belt/chain assembly feature.
 GetMemberIndex	Gets the index of the specified pulley member.
 ModifyMemberParameters	Changes diameter and whether to flip the belt side of the specified pulley component.
 ReleaseSelectionAccess	Releases access to the selections used to define this belt/chain assembly feature.

[Top](#)

See Also

[IBeltChainFeatureData Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBeltChainFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBeltChainFeatureData Interface

The following tables list the members exposed by [IBeltChainFeatureData](#).

Public Properties

Name	Description
 BeltLength	Gets and sets the belt length.
 BeltLocationPlane	Gets and sets the belt location plane.
 BeltThickness	Gets and sets the belt thickness.
 CreateBeltPart	Gets and sets whether to create a new part that contains the belt sketch.
 DrivingLength	Gets and sets whether belt length can be changed.
 EngageBelt	Gets and sets whether to engage the belt with the pulleys.
 FlipSides	Gets and sets whether to flip the belt to the other side of each pulley.
 PulleyComponents	Gets and sets the components in this belt/chain assembly feature.
 PulleyDiameters	Gets and sets the diameters of the pulleys.
 UseBeltThickness	Gets and sets whether to specify belt thickness.

 Public Methods

Name	Description
 AccessBeltPart	Gets the belt part.
 AccessSelections	Gains access to selections used to define this belt/chain assembly feature.
 GetMemberIndex	Gets the index of the specified pulley member.
 ModifyMemberParameters	Changes diameter and whether to flip the belt side of the specified pulley component.
 ReleaseSelectionAccess	Releases access to the selections used to define this belt/chain assembly feature.

 See Also

[IBeltChainFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

IBeltChainFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBeltChainFeatureData Interface

For a list of all members of this type, see [IBeltChainFeatureData members](#).

 Public Properties

Name	Description
 BeltLength	Gets and sets the belt length.
 BeltLocationPlane	Gets and sets the belt location plane.
 BeltThickness	Gets and sets the belt thickness.
 CreateBeltPart	Gets and sets whether to create a new part that contains the belt sketch.
 DrivingLength	Gets and sets whether belt length can be changed.
 EngageBelt	Gets and sets whether to engage the belt with the pulleys.
 FlipSides	Gets and sets whether to flip the belt to the other side of each pulley.
 PulleyComponents	Gets and sets the components in this belt/chain assembly feature.
 PulleyDiameters	Gets and sets the diameters of the pulleys.
 UseBeltThickness	Gets and sets whether to specify belt thickness.

 See Also

[IBeltChainFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments on this topic.](#)

AccessBeltPart Method (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : AccessBeltPart Method (IBeltChainFeatureData)

Gets the belt part.

 .NET Syntax

Visual Basic (Declaration)

Function AccessBeltPart() As PartDoc

```
Dim instance As IBeltChainFeatureData
Dim value As PartDoc

value = instance.AccessBeltPart()
```

C#

```
PartDoc AccessBeltPart()
```

C++/CLI

```
PartDoc^ AccessBeltPart();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IPartDoc](#)

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::AccessBeltPart](#).

Remarks

This method is valid only if [IBeltChainFeatureData::CreateBeltPart](#) is true.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : AccessSelections Method (IBeltChainFeatureData)

Gains access to selections used to define this belt/chain assembly feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBeltChainFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean
```

```
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
```

```
System.Object Component
)
```

C++/CLI

```
System.bool AccessSelections(
& System.Object^ TopDoc,
& System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top level document (see **Remarks**)

Component

Component for the feature (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::AccessSelections](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [IBeltChainFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBeltChainFeatureData Interface](#)

[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

BeltLength Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : BeltLength Property (IBeltChainFeatureData)

Gets and sets the belt length.

.NET Syntax

Visual Basic (Declaration)

```
Property BeltLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData
Dim value As System.Double
```

```
instance.BeltLength = value  
value = instance.BeltLength
```

C#

```
System.double BeltLength {get; set;}
```

C++/CLI

```
property System.double BeltLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Belt length

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::BeltLength](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

This property can only be set if [IBeltChainFeatureData::DrivingLength](#) is set to true.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

BeltLocationPlane Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : BeltLocationPlane Property (IBeltChainFeatureData)

Gets and sets the belt location plane.

.NET Syntax

Visual Basic (Declaration)

```
Property BeltLocationPlane As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Object
```

```
instance.BeltLocationPlane = value
```

```
value = instance.BeltLocationPlane
```

C#

```
System.object BeltLocationPlane {get; set;}
```

C++/CLI

```
property System.Object^ BeltLocationPlane {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IVertex](#), [IRefPlane](#), or [IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData.BeltLocationPlane](#).

Remarks

The belt sketch plane is normal to the pulley axes.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

BeltThickness Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : BeltThickness Property (IBeltChainFeatureData)

Gets and sets the belt thickness.

.NET Syntax

Visual Basic (Declaration)

Property BeltThickness As System.Double

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData
Dim value As System.Double
```

```
instance.BeltThickness = value
```

```
value = instance.BeltThickness
```

C#

```
System.double BeltThickness {get; set;}
```

C++/CLI

```
property System.double BeltThickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Belt thickness

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::BeltThickness](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

This property is valid only if [BeltChainFeatureData::UseBeltThickness](#) is true. The belt curve is offset from the cylindrical faces of the pulleys by one half the specified belt thickness.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateBeltPart Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : CreateBeltPart Property (IBeltChainFeatureData)

Gets and sets whether to create a new part that contains the belt sketch.

.NET Syntax

Visual Basic (Declaration)

Property CreateBeltPart As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Boolean
```

```
instance.CreateBeltPart = value
```

```
value = instance.CreateBeltPart
```

C#

```
System.bool CreateBeltPart {get; set;}
```

C++/CLI

```
property System.bool CreateBeltPart {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to create a belt part, false to not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::CreateBeltPart](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

If this property is set to true, use [IBeltChainFeatureData::AccessBeltPart](#) to get the belt part.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

DrivingLength Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : DrivingLength Property (IBeltChainFeatureData)

Gets and sets whether belt length can be changed.

.NET Syntax

Visual Basic (Declaration)

Property DrivingLength As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Boolean
```

```
instance.DrivingLength = value
```

```
value = instance.DrivingLength
```

C#

```
System.bool DrivingLength {get; set;}
```

C++/CLI

```
property System.bool DrivingLength {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to allow belt length changes, false to not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::DrivingLength](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

If this property is true, then use [IBeltChainFeatureData::BeltLength](#) to set the belt length. Pulley positions adjust if at least one pulley has an appropriate degree of freedom.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

EngageBelt Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : EngageBelt Property (IBeltChainFeatureData)

Gets and sets whether to engage the belt with the pulleys.

.NET Syntax

Visual Basic (Declaration)

Property EngageBelt As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData
Dim value As System.Boolean

instance.EngageBelt = value
value = instance.EngageBelt
```

C#

```
System.bool EngageBelt {get; set;}
```

C++/CLI

```
property System.bool EngageBelt {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to engage the belt with the pulleys, false to suppress belt mates

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::EngageBelt](#).

Example

See the [IBeltChainFeatureData](#) examples.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

FlipSides Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : FlipSides Property (IBeltChainFeatureData)

Gets and sets whether to flip the belt to the other side of each pulley.

Visual Basic Syntax

Visual Basic (Declaration)

Property FlipSides As System.Object

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Object
```

```
instance.FlipSides = value
```

```
value = instance.FlipSides
```

C#

```
System.Object FlipSides {get; set;}
```

C++/CLI

```
property System.Object^ FlipSides {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of booleans; true to flip pulley sides, false to not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::FlipSides](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

The array maps one-to-one with the arrays of [IBeltChainFeatureData::PulleyComponents](#) and [IBeltChainFeatureData::PulleyDiameters](#).

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMemberIndex Method (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : GetMemberIndex Method (IBeltChainFeatureData)

Gets the index of the specified pulley member.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetMemberIndex( _  
    ByVal PulleyCompObject As System.Object _  
) As System.Integer
```

```
Dim instance As IBeltChainFeatureData
Dim PulleyCompObject As System.Object
Dim value As System.Integer

value = instance.GetMemberIndex(PulleyCompObject)
```

C#

```
System.int GetMemberIndex(
    System.object PulleyCompObject
)
```

C++/CLI

```
System.int GetMemberIndex(
    & System.Object^ PulleyCompObject
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PulleyCompObject
Pulley component

Return Value

Zero-based index value

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::GetMemberIndex](#).

Remarks

To specify PulleyCompObject, use [IBeltChainFeatureData::PulleyComponents](#).

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

ModifyMemberParameters Method (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : ModifyMemberParameters Method (IBeltChainFeatureData)

Changes diameter and whether to flip the belt side of the specified pulley component.

.NET Syntax

Visual Basic (Declaration)

```
Function ModifyMemberParameters( _
    ByVal PulleyCompObject As System.Object, _
    ByVal Diameter As System.Double, _
    ByVal Flip As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBeltChainFeatureData
Dim PulleyCompObject As System.Object
```

```
Dim Diameter As System.Double
Dim Flip As System.Boolean
Dim value As System.Boolean

value = instance.ModifyMemberParameters(PulleyCompObject, Diameter, Flip)
```

C#

```
System.bool ModifyMemberParameters(
    System.object PulleyCompObject,
    System.double Diameter,
    System.bool Flip
)
```

C++/CLI

```
System.bool ModifyMemberParameters(
    & System.Object^ PulleyCompObject,
    & System.double Diameter,
    & System.bool Flip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PulleyCompObject
Pulley component
Diameter
Diameter > 0.0 to change; 0.0 to not change
Flip
True to flip the belt side, false to not

Return Value

True if pulley component successfully modified, false if not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::ModifyMemberParameters](#).

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

PulleyComponents Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : PulleyComponents Property (IBeltChainFeatureData)

Gets and sets the components in this belt/chain assembly feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PulleyComponents As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData
Dim value As System.Object

instance.PulleyComponents = value

value = instance.PulleyComponents
```

C#

```
System.Object PulleyComponents {get; set;}
```

C++/CLI

```
property System.Object^ PulleyComponents {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of pulley members, e.g., cylindrical faces, axes, wheels, gears

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::PulleyComponents](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

The array maps one-to-one with the arrays of [IBeltChainFeatureData::FlipSides](#) and [IBeltChainFeatureData::PulleyDiameters](#).

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

PulleyDiameters Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : PulleyDiameters Property (IBeltChainFeatureData)

Gets and sets the diameters of the pulleys.

.NET Syntax

Visual Basic (Declaration)

```
Property PulleyDiameters As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Object
```

```
instance.PulleyDiameters = value
```

```
value = instance.PulleyDiameters
```

C#

```
System.Object PulleyDiameters {get; set;}
```

C++/CLI

```
property System.Object^ PulleyDiameters {  
    System.Object^ get();
```

```
void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of diameters

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::PulleyDiameters](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

The array maps one-to-one with the arrays of [IBeltChainFeatureData::PulleyComponents](#) and [IBeltChainFeatureData::FlipSides](#).

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : ReleaseSelectionAccess Method (IBeltChainFeatureData)

Releases access to the selections used to define this belt/chain assembly feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::ReleaseSelectionAccess](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

[IBeltChainFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseBeltThickness Property (IBeltChainFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBeltChainFeatureData Interface](#) : UseBeltThickness Property (IBeltChainFeatureData)

Gets and sets whether to specify belt thickness.

.NET Syntax

Visual Basic (Declaration)

```
Property UseBeltThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBeltChainFeatureData  
Dim value As System.Boolean
```

```
instance.UseBeltThickness = value
```

```
value = instance.UseBeltThickness
```

C#

```
System.bool UseBeltThickness {get; set;}
```

C++/CLI

```
property System.bool UseBeltThickness {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to specify belt thickness, false to not

Visual Basic for Applications (VBA) Syntax

See [BeltChainFeatureData::UseBeltThickness](#).

Example

See the [IBeltChainFeatureData](#) examples.

Remarks

If this property is true, use [IBeltChainFeatureData::BeltThickness](#) to specify belt thickness.

See Also

[IBeltChainFeatureData Interface](#)
[IBeltChainFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

IBendsFeatureData (Type)

IBendsFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendsFeatureData Interface

Allows access to a Flatten-Bends/Process-Bends feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBendsFeatureData

Visual Basic (Usage)

Dim instance As [IBendsFeatureData](#)

C#

public interface IBendsFeatureData

C++/CLI

public interface class IBendsFeatureData

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData](#).

Example

[Get Fixed Face of Flatten-Bends Feature \(C#\)](#)
[Get Fixed Face of Flatten-Bends Feature \(VB.NET\)](#)
[Get Fixed Face of Flatten-Bends Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[BendsFeatureData](#)

See Also

[IBendsFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetal3dBend Method](#)

IBendsFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendsFeatureData Interface

For a list of all members of this type, see [IBendsFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this Flatten-Bends/Process-Bends feature.

	GetFixedFace	Gets the fixed face of a flatten-bends feature.
	IAccessSelections	Obsolete. Superseded by IBendsFeatureData.IAccessSelections2 .
	IAccessSelections2	Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.
	ReleaseSelectionAccess	Releases access to the selections that describe this Flatten-Bends/Process-Bends feature.
	SetCustomBendAllowance	Sets the custom bend allowance for the Flatten-Bends/Process-Bends feature.

[Top](#)

See Also

[IBendsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetal3dBend Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBendsFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendsFeatureData Interface

The following tables list the members exposed by [IBendsFeatureData](#).

Public Properties

Name	Description
 BendAllowance	Obsolete. Superseded by IBendsFeatureData.GetCustomBendAllowance and IBendsFeatureData.SetCustomBendAllowance .
 BendAllowanceType	Obsolete. Superseded by IBendsFeatureData.GetCustomBendAllowance and IBendsFeatureData.SetCustomBendAllowance .
 BendRadius	Gets or sets the bend radius for this Flatten-Bends/Process-Bends feature.
 BendTableFile	Obsolete. Superseded by IBendsFeatureData.GetCustomBendAllowance and IBendsFeatureData.SetCustomBendAllowance .
 KFactor	Obsolete. Superseded by IBendsFeatureData.GetCustomBendAllowance and IBendsFeatureData.SetCustomBendAllowance .
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this Flatten-Bends/Process-Bends feature.
 UseDefaultBendRadius	Get or sets whether to use the default bend radius for this Flatten-Bends/Process-Bends feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.
 GetCustomBendAllowance	Gets the custom bend allowance for this Flatten-Bends/Process-Bends feature.
 GetFixedFace	Gets the fixed face of a flatten-bends feature.
 IAccessSelections	Obsolete. Superseded by IBendsFeatureData.IAccessSelections2 .
 IAccessSelections2	Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.
 ReleaseSelectionAccess	Releases access to the selections that describe this Flatten-Bends/Process-Bends feature.
 SetCustomBendAllowance	Sets the custom bend allowance for the Flatten-Bends/Process-Bends feature.

[Top](#)

See Also

[IBendsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetal3dBend Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBendsFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendsFeatureData Interface

For a list of all members of this type, see [IBendsFeatureData members](#).

Public Properties

Name	Description
 BendAllowance	Obsolete. Superseded by IBendsFeatureData::GetCustomBendAllowance and IBendsFeatureData::SetCustomBendAllowance
 BendAllowanceType	Obsolete. Superseded by IBendsFeatureData::GetCustomBendAllowance and IBendsFeatureData::SetCustomBendAllowance
 BendRadius	Gets or sets the bend radius for this Flatten-Bends/Process-Bends feature.
 BendTableFile	Obsolete. Superseded by IBendsFeatureData::GetCustomBendAllowance and IBendsFeatureData::SetCustomBendAllowance
 KFactor	Obsolete. Superseded by IBendsFeatureData::GetCustomBendAllowance and IBendsFeatureData::SetCustomBendAllowance
 UseDefaultBendAllowance	Gets or sets whether to use the default bend allowance for this Flatten-Bends/Process-Bends feature.
 UseDefaultBendRadius	Get or sets whether to use the default bend radius for this Flatten-Bends/Process-Bends feature.

[Top](#)

See Also

[IBendsFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetal3dBend Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

AccessSelections Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : AccessSelections Method (IBendsFeatureData)

Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [IBendsFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the ModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBendsFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAllowance Property (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : BendAllowance Property (IBendsFeatureData)

Obsolete. Superseded by [IBendsFeatureData::GetCustomBendAllowance](#) and [IBendsFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property BendAllowance As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Double
```

```
instance.BendAllowance = value
```

```
value = instance.BendAllowance
```

C#

```
System.double BendAllowance {get; set;}
```

C++/CLI

```
property System.double BendAllowance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::BendAllowance](#).

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendAllowanceType Property (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : BendAllowanceType Property (IBendsFeatureData)

Obsolete. Superseded by [IBendsFeatureData::GetCustomBendAllowance](#) and [IBendsFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property BendAllowanceType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Integer
```

```
instance.BendAllowanceType = value
```

```
value = instance.BendAllowanceType
```

C#

```
System.int BendAllowanceType {get; set;}
```

C++/CLI

```
property System.int BendAllowanceType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of bend allowance as defined in [swBendAllowanceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::BendAllowanceType](#).

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendRadius Property (IBendsFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : BendRadius Property (IBendsFeatureData)

Gets or sets the bend radius for this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Property BendRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Double
```

```
instance.BendRadius = value
```

```
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the radius

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData.BendRadius](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::UseDefaultBendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendTableFile Property (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : BendTableFile Property (IBendsFeatureData)

Obsolete. Superseded by [IBendsFeatureData::GetCustomBendAllowance](#) and [IBendsFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property BendTableFile As System.String

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.String
```

```
instance.BendTableFile = value
```

```
value = instance.BendTableFile
```

C#

```
System.string BendTableFile {get; set;}
```

C++/CLI

```
property System.String^ BendTableFile {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::BendTableFile](#).

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomBendAllowance Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : GetCustomBendAllowance Method (IBendsFeatureData)

Gets the custom bend allowance for this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As CustomBendAllowance
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As CustomBendAllowance
```

```
value = instance.GetCustomBendAllowance()
```

C#

```
CustomBendAllowance GetCustomBendAllowance()
```

C++/CLI

```
CustomBendAllowance^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICustomBendAllowance](#)

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::GetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::SetCustomBendAllowance Method](#)
[IBendsFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFixedFace Method (IBendsFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : GetFixedFace Method (IBendsFeatureData)

Gets the fixed face of a flatten-bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFixedFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Object
```

```
value = instance.GetFixedFace()
```

C#

```
System.object GetFixedFace()
```

C++/CLI

```
System.Object^ GetFixedFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::GetFixedFace](#).

Example

[Get Fixed Face of Flatten-Bends Feature \(VBA\)](#)
[Get Fixed Face of Flatten-Bends Feature \(VB.NET\)](#)
[Get Fixed Face of Flatten-Bends Feature \(C#\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : IAccessSelections Method (IBendsFeatureData)

Obsolete. Superseded by [IBendsFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
    & ModelDoc^ TopDoc,  
    & Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::IAccessSelections](#).

See Also

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections2 Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : IAccessSelections2 Method (IBendsFeatureData)

Allows access to the selections that describe this Flatten-Bends/Process-Bends feature.

VB.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Allows you to gain access to the selections that describe this Flatten-Bends/Process-Bends feature

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::IAccessSelections2](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the ModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IBendsFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KFactor Property (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : KFactor Property (IBendsFeatureData)

Obsolete. Superseded by [IBendsFeatureData::GetCustomBendAllowance](#) and [IBendsFeatureData::SetCustomBendAllowance](#).

.NET Syntax

Visual Basic (Declaration)

Property KFactor As System.Double

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Double
```

```
instance.KFactor = value
```

```
value = instance.KFactor
```

C#

```
System.double KFactor {get; set;}
```

C++/CLI

```
property System.double KFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::KFactor](#).

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : ReleaseSelectionAccess Method (IBendsFeatureData)

Releases access to the selections that describe this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::ReleaseSelectionAccess](#).

Remarks

[IBendsFeatureData::AccessSelections](#) and [IBendsFeatureData::IAccessSelections2](#) puts the model into a rollback state to allow access to the selections that define the Bends feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCustomBendAllowance Method (IBendsFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : SetCustomBendAllowance Method (IBendsFeatureData)

Sets the custom bend allowance for the Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCustomBendAllowance( _  
    ByVal PBendData As CustomBendAllowance _  
)
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim PBendData As CustomBendAllowance  
  
instance.SetCustomBendAllowance(PBendData)
```

C#

```
void SetCustomBendAllowance(  
    CustomBendAllowance PBendData  
)
```

C++/CLI

```
void SetCustomBendAllowance(
& CustomBendAllowance^ PBendData
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[PBendData](#)
[ICustomBendAllowance](#)

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::SetCustomBendAllowance](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::GetCustomBendAllowance Method](#)
[IBendsFeatureData::UseDefaultBendAllowance Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDefaultBendAllowance Property (IBendsFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : UseDefaultBendAllowance Property (IBendsFeatureData)

Gets or sets whether to use the default bend allowance for this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDefaultBendAllowance As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData
Dim value As System.Boolean

instance.UseDefaultBendAllowance = value
value = instance.UseDefaultBendAllowance
```

C#

```
System.bool UseDefaultBendAllowance {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendAllowance {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend allowance, false to not

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::UseDefaultBendAllowance](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::GetCustomBendAllowance Method](#)
[IBendsFeatureData::SetCustomBendAllowance Method](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseDefaultBendRadius Property (IBendsFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendsFeatureData Interface](#) : UseDefaultBendRadius Property (IBendsFeatureData)

Get or sets whether to use the default bend radius for this Flatten-Bends/Process-Bends feature.

.NET Syntax

Visual Basic (Declaration)

Property UseDefaultBendRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBendsFeatureData  
Dim value As System.Boolean  
  
instance.UseDefaultBendRadius = value  
value = instance.UseDefaultBendRadius
```

C#

```
System.bool UseDefaultBendRadius {get; set;}
```

C++/CLI

```
property System.bool UseDefaultBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the default bend radius, false to not

Visual Basic for Applications (VBA) Syntax

See [BendsFeatureData::UseDefaultBendRadius](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

See Also

[IBendsFeatureData Interface](#)
[IBendsFeatureData Members](#)
[IBendsFeatureData::BendRadius Property](#)

Availability

SOLIDWORKS 2001 SP1, Revision Number 9.1

IBendTable (Type)

IBendTable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendTable Interface

Allows access to a bend table feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBendTable
```

Visual Basic (Usage)

```
Dim instance As IBendTable
```

C#

```
public interface IBendTable
```

C++/CLI

```
public interface class IBendTable
```

Visual Basic for Applications (VBA) Syntax

See [BendTable](#).

Example

[Insert Bend Table \(VBA\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(C#\)](#)

Accessors

[IBendTableAnnotation::BendTable](#)

Access Diagram

[BendTable](#)

See Also

[IBendTable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertBendTableEdit Method](#)
[IModelDoc2::InsertBendTableNew Method](#)
[IModelDoc2::InsertBendTableOpen Method](#)

IBendTable Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendTable Interface

For a list of all members of this type, see [IBendTable members](#).

Public Methods

Name	Description
GetFeature	Gets the feature for this bend table.

 GetTableAnnotationCount	Gets the number of bend table annotations.
 GetTableAnnotations	Gets the annotations for this bend table.
 IGetTableAnnotations	Gets the annotations for this bend table.

[Top](#)

See Also

[IBendTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertBendTableEdit Method](#)
[IModelDoc2::InsertBendTableNew Method](#)
[IModelDoc2::InsertBendTableOpen Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBendTable Interface Members

[See Also](#) [Properties](#) [Methods](#)

	SolidWorks.Interop.sldworks Namespace : IBendTable Interface
---	--

The following tables list the members exposed by [IBendTable](#).

Public Properties

Name	Description
 StartingValue	Gets and sets the starting datum tag for this bend table.
 TagStyle	Gets and sets the tag style for this bend table.

[Top](#)

Public Methods

Name	Description
 GetFeature	Gets the feature for this bend table.
 GetTableAnnotationCount	Gets the number of bend table annotations.
 GetTableAnnotations	Gets the annotations for this bend table.
 IGetTableAnnotations	Gets the annotations for this bend table.

[Top](#)

See Also

[IBendTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertBendTableEdit Method](#)
[IModelDoc2::InsertBendTableNew Method](#)
[IModelDoc2::InsertBendTableOpen Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBendTable Interface Properties

[See Also](#)

	SolidWorks.Interop.sldworks Namespace : IBendTable Interface
---	--

For a list of all members of this type, see [IBendTable members](#).

Public Properties

Name	Description
 StartingValue	Gets and sets the starting datum tag for this bend table.
 TagStyle	Gets and sets the tag style for this bend table.

[Top](#)

See Also

[IBendTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

GetFeature Method (IBendTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : GetFeature Method (IBendTable)

Gets the feature for this bend table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IBendTable  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [BendTable::GetFeature](#).

Example

[Insert Bend Table \(C#\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(VBA\)](#)

See Also

[IBendTable Interface](#)
[IBendTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

GetTableAnnotationCount Method (IBendTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : GetTableAnnotationCount Method (IBendTable)

Gets the number of bend table annotations.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBendTable
Dim value As System.Integer

value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bend table annotations (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BendTable::GetTableAnnotationCount](#).

Example

[Insert Bend Table \(VBA\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(C#\)](#)

Remarks

There is usually only one annotation for each bend table. If a bend table is split, there are two annotations associated with it.

See Also

[IBendTable Interface](#)
[IBendTable Members](#)
[IBendTable::GetTableAnnotations Method](#)
[IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTableAnnotations Method (IBendTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : GetTableAnnotations Method (IBendTable)

Gets the annotations for this bend table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBendTable
Dim value As System.Object
```

```
value = instance.GetTableAnnotations()
```

C#

```
System.object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IBendTableAnnotations](#)

Visual Basic for Applications (VBA) Syntax

See [BendTable::GetTableAnnotations](#).

See Also

[IBendTable Interface](#)
[IBendTable Members](#)
[IBendTable::GetTableAnnotationCount Method](#)
[IBendTable::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTableAnnotations Method (IBendTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : IGetTableAnnotations Method (IBendTable)

Gets the annotations for this bend table.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal Count As System.Integer _  
) As BendTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IBendTable  
Dim Count As System.Integer  
Dim value As BendTableAnnotation  
  
value = instance.IGetTableAnnotations(Count)
```

C#

```
BendTableAnnotation IGetTableAnnotations(  
    System.int Count  
)
```

C++/CLI

```
BendTableAnnotation^ IGetTableAnnotations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of bend table annotations

Return Value

- In-process, unmanaged C++: Pointer to an array of [IBendTableAnnotation](#)s
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

 Remarks

Before calling this method, call [IBendTable::GetTableAnnotationCount](#) to populate Count.

 See Also

[IBendTable Interface](#)
[IBendTable Members](#)
[IBendTable::GetTableAnnotations Method](#)

 Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartingValue Property (IBendTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : StartingValue Property (IBendTable)

Gets and sets the starting datum tag for this bend table.

 .NET Syntax

Visual Basic (Declaration)

Property StartingValue As System.String

Visual Basic (Usage)



```
Dim instance As IBendTable
Dim value As System.String

instance.StartingValue = value
value = instance.StartingValue
```

C#

```
System.string StartingValue {get; set;}
```

C++/CLI

```
property System.String^ StartingValue {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Starting datum tag (see **Remarks**)

 Visual Basic for Applications (VBA) Syntax

See [BendTable::StartingValue](#).

 Example

[Insert Bend Table \(C#\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(VBA\)](#)

Remarks

This property returns:

- Letter from A to Z, if [IBendTable::TagStyle](#) is set to [swBendTableTagStyle_e.swBendTable_AlphaNumericTags](#).
- Positive integer, if [IBendTable::TagStyle](#) is set to [swBendTableTagStyle_e.swBendTable_NumericTags](#).

See Also

[IBendTable Interface](#)
[IBendTable Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TagStyle Property (IBendTable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTable Interface](#) : TagStyle Property (IBendTable)

Gets and sets the tag style for this bend table.

.NET Syntax

Visual Basic (Declaration)

```
Property TagStyle As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBendTable  
Dim value As System.Integer
```

```
instance.TagStyle = value  
value = instance.TagStyle
```

C#

```
System.int TagStyle {get; set;}
```

C++/CLI

```
property System.int TagStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Tag style as defined in [swBendTableTagStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [BendTable::TagStyle](#).

Example

[Insert Bend Table \(VBA\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(C#\)](#)

See Also

[IBendTable Interface](#)
[IBendTable Members](#)
[IBendTable::StartingValue Property](#)

IBendTableAnnotation (Type)

IBendTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendTableAnnotation Interface

Allows access to a bend table annotation.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBendTableAnnotation
```

Visual Basic (Usage)

```
Dim instance As IBendTableAnnotation
```

C#

```
public interface IBendTableAnnotation
```

C++/CLI

```
public interface class IBendTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [BendTableAnnotation](#).

Example

[Insert Bend Table \(C#\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(VBA\)](#)

Accessors

[IPartDoc::InsertBendTable](#)
[IView::InsertBendTable](#)

Access Diagram

[BendTableAnnotation](#)

See Also

[IBendTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBendTableAnnotation Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendTableAnnotation Interface

The following tables list the members exposed by [IBendTableAnnotation](#).

Public Properties

Name	Description
BendTable	Gets the bend table feature for this bend table annotation.

[Top](#)

See Also

[IBendTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBendTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBendTableAnnotation Interface

For a list of all members of this type, see [IBendTableAnnotation members](#).

Public Properties

Name	Description
 BendTable	Gets the bend table feature for this bend table annotation.

[Top](#)

See Also

[IBendTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendTable Property (IBendTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBendTableAnnotation Interface](#) : BendTable Property (IBendTableAnnotation)

Gets the bend table feature for this bend table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BendTable As BendTable
```

Visual Basic (Usage)



```
Dim instance As IBendTableAnnotation  
Dim value As BendTable  
  
value = instance.BendTable
```

C#

```
BendTable BendTable {get;}
```

C++/CLI

```
property BendTable^ BendTable {  
    BendTable^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IBendTable](#)

Visual Basic for Applications (VBA) Syntax

See [BendTableAnnotation::BendTable](#).

Example

[Insert Bend Table \(C#\)](#)
[Insert Bend Table \(VB.NET\)](#)
[Insert Bend Table \(VBA\)](#)

See Also

[IBendTableAnnotation Interface](#)
[IBendTableAnnotation Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0