

SOLIDWORKS API (.NET, VBA, C#) — Reference

(22/337): IBlockDefinition-IBlockInstance

SOLIDWORKS API Documentation (converted from CHM)

IBlockDefinition (Type)

IBlockDefinition Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockDefinition Interface

Obsolete. Superseded by [ISketchBlockDefinition](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBlockDefinition

Visual Basic (Usage)

Dim instance As [IBlockDefinition](#)

C#

public interface IBlockDefinition

C++/CLI

public interface class IBlockDefinition

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition](#).

See Also

[IBlockDefinition Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBlockDefinition Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockDefinition Interface

For a list of all members of this type, see [IBlockDefinition members](#).

Public Methods

Name	Description
GetBasePoint	Obsolete. Superseded by ISketchBlockDefinition.InsertionPoint .
GetBlockInstanceCount	Obsolete. Superseded by ISketchBlockDefinition.GetInstanceCount .
GetBlockInstances	Obsolete. Superseded by ISketchBlockDefinition.GetInstances .
GetDimensionCount	Obsolete. Superseded by ISketchBlockDefinition.GetDisplayDimensionCount .
GetDimensions	Obsolete. Superseded by ISketchBlockDefinition.GetDisplayDimensions .
GetExternalFileName	Obsolete. Superseded by ISketchBlockDefinition.FileName .
GetNoteCount	Obsolete. Superseded by ISketchBlockDefinition.GetNoteCount .
GetNotes	Obsolete. Superseded by ISketchBlockDefinition.GetNotes .
GetSketch	Obsolete. Superseded by ISketchBlockDefinition.GetSketch .
GetUseExternalFile	Obsolete. Superseded by ISketchBlockDefinition.LinkToFile .
IGetBasePoint	Obsolete. Superseded by ISketchBlockDefinition.InsertionPoint .
IGetBlockInstances	Obsolete. Superseded by ISketchBlockDefinition.GetInstances .

		
	IGetDimensions	Obsolete. Superseded by ISketchBlockDefinition::GetDisplayDimensions .
	IGetNotes	Obsolete. Superseded by ISketchBlockDefinition::GetNotes .
	InsertInstance	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
	ISetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
	SetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
	SetExternalFileName	Obsolete. Superseded by ISketchBlockDefinition::FileName .
	SetUseExternalFile	Obsolete. Superseded by ISketchBlockDefinition::LinkToFile .

[Top](#)

 See Also

[IBlockDefinition Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBlockDefinition Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockDefinition Interface

The following tables list the members exposed by [IBlockDefinition](#).

 Public Properties

Name	Description
 Name	Obsolete. Not superseded.

[Top](#)

 Public Methods

Name	Description
 GetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
 GetBlockInstanceCount	Obsolete. Superseded by ISketchBlockDefinition::GetInstanceCount .
 GetBlockInstances	Obsolete. Superseded by ISketchBlockDefinition::GetInstances .
 GetDimensionCount	Obsolete. Superseded by ISketchBlockDefinition::GetDisplayDimensionCount .
 GetDimensions	Obsolete. Superseded by ISketchBlockDefinition::GetDisplayDimensions .
 GetExternalFileName	Obsolete. Superseded by ISketchBlockDefinition::FileName .
 GetNoteCount	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount .
 GetNotes	Obsolete. Superseded by ISketchBlockDefinition::GetNotes .
 GetSketch	Obsolete. Superseded by ISketchBlockDefinition::GetSketch .
 GetUseExternalFile	Obsolete. Superseded by ISketchBlockDefinition::LinkToFile .
 IGetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
 IGetBlockInstances	Obsolete. Superseded by ISketchBlockDefinition::GetInstances .
 IGetDimensions	Obsolete. Superseded by ISketchBlockDefinition::GetDisplayDimensions .
 IGetNotes	Obsolete. Superseded by ISketchBlockDefinition::GetNotes .
 InsertInstance	Obsolete. Superseded by ISketchManager::InsertSketchBlockInstance .
 ISetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
 SetBasePoint	Obsolete. Superseded by ISketchBlockDefinition::InsertionPoint .
 SetExternalFileName	Obsolete. Superseded by ISketchBlockDefinition::FileName .
 SetUseExternalFile	Obsolete. Superseded by ISketchBlockDefinition::LinkToFile .

[Top](#)

See Also

[IBlockDefinition Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBlockDefinition Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockDefinition Interface

For a list of all members of this type, see [IBlockDefinition members](#).

Public Properties

Name	Description
 Name	Obsolete. Not superseded.

[Top](#)

See Also

[IBlockDefinition Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBasePoint Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetBasePoint Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::InsertionPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBasePoint() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Object  
  
value = instance.GetBasePoint()
```

C#

```
System.object GetBasePoint()
```

C++/CLI

```
System.Object^ GetBasePoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetBasePoint](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBlockInstanceCount Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetBlockInstanceCount Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetInstanceCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBlockInstanceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition
Dim value As System.Integer

value = instance.GetBlockInstanceCount()
```

C#

```
System.int GetBlockInstanceCount()
```

C++/CLI

```
System.int GetBlockInstanceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetBlockInstanceCount](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBlockInstances Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetBlockInstances Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetInstances](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBlockInstances() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition
Dim value As System.Object

value = instance.GetBlockInstances()
```

C#

```
System.object GetBlockInstances()
```

C++/CLI

```
System.Object^ GetBlockInstances();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetBlockInstances](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensionCount Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetDimensionCount Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetDisplayDimensionCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensionCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Integer  
  
value = instance.GetDimensionCount()
```

C#

```
System.int GetDimensionCount()
```

C++/CLI

```
System.int GetDimensionCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetDimensionCount](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDimensions Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetDimensions Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetDisplayDimensions](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetDimensions() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Object  
  
value = instance.GetDimensions()
```

C#

```
System.object GetDimensions()
```

C++/CLI

```
System.Object^ GetDimensions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetDimensions](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExternalFileName Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetExternalFileName Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::FileName](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetExternalFileName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.String  
  
value = instance.GetExternalFileName()
```

C#

```
System.string GetExternalFileName()
```

C++/CLI

```
System.String^ GetExternalFileName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetExternalFileName](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNoteCount Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetNoteCount Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetNoteCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNoteCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Integer  
  
value = instance.GetNoteCount()
```

C#

```
System.int GetNoteCount()
```

C++/CLI

```
System.int GetNoteCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetNoteCount](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNotes Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetNotes Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNotes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Object  
  
value = instance.GetNotes()
```

C#

```
System.object GetNotes()
```

C++/CLI

```
System.Object^ GetNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetNotes](#).

See Also

GetSketch Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetSketch Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As Sketch
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As Sketch
```

```
value = instance.GetSketch()
```

C#

```
Sketch GetSketch()
```

C++/CLI

```
Sketch^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetSketch](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

GetUseExternalFile Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : GetUseExternalFile Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::LinkToFile](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetUseExternalFile() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Boolean
```

```
value = instance.GetUseExternalFile()
```

C#

```
System.bool GetUseExternalFile()
```

C++/CLI

```
System.bool GetUseExternalFile();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::GetUseExternalFile](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBasePoint Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : IGetBasePoint Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::InsertionPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBasePoint() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.Double
```

```
value = instance.IGetBasePoint()
```

C#

```
System.double IGetBasePoint()
```

C++/CLI

```
System.double IGetBasePoint();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::IGetBasePoint](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBlockInstances Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : IGetBlockInstances Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetInstances](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBlockInstances( _  
    ByVal Count As System.Integer _
```

) As BlockInstance

Visual Basic (Usage)



```
Dim instance As IBlockDefinition
Dim Count As System.Integer
Dim value As BlockInstance

value = instance.IGetBlockInstances(Count)
```

C#

```
BlockInstance IGetBlockInstances(
    System.int Count
)
```

C++/CLI

```
BlockInstance^ IGetBlockInstances(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::IGetBlockInstances](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDimensions Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : IGetDimensions Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetDisplayDimensions](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDimensions( _
    ByVal NumDimensions As System.Integer _
) As DisplayDimension
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition
Dim NumDimensions As System.Integer
Dim value As DisplayDimension

value = instance.IGetDimensions(NumDimensions)
```

C#

```
DisplayDimension IGetDimensions(
    System.int NumDimensions
)
```

C++/CLI

```
DisplayDimension^ IGetDimensions(  
& System.int NumDimensions  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumDimensions

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::IGetDimensions](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNotes Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : IGetNotes Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::GetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNotes( _  
    ByVal NumNotes As System.Integer _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim NumNotes As System.Integer  
Dim value As Note
```

```
value = instance.IGetNotes(NumNotes)
```

C#

```
Note IGetNotes(  
    System.int NumNotes  
)
```

C++/CLI

```
Note^ IGetNotes(  
& System.int NumNotes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumNotes

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::IGetNotes](#).

See Also

InsertInstance Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : InsertInstance Method (IBlockDefinition)

Obsolete. Superseded by [ISketchManager::InsertSketchBlockInstance](#).

.NET Syntax

Visual Basic (Declaration)

```
Function InsertInstance( _  
    ByVal X As System.Double, _  
    ByVal Y As System.Double, _  
    ByVal Angle As System.Double, _  
    ByVal Scale As System.Double _  
) As BlockInstance
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim X As System.Double  
Dim Y As System.Double  
Dim Angle As System.Double  
Dim Scale As System.Double  
Dim value As BlockInstance  
  
value = instance.InsertInstance(X, Y, Angle, Scale)
```

C#

```
BlockInstance InsertInstance(  
    System.double X,  
    System.double Y,  
    System.double Angle,  
    System.double Scale  
)
```

C++/CLI

```
BlockInstance^ InsertInstance(  
& System.double X,  
& System.double Y,  
& System.double Angle,  
& System.double Scale  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

X

Y

Angle

Scale

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::InsertInstance](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

ISetBasePoint Method (IBlockDefinition)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : ISetBasePoint Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::InsertionPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetBasePoint( _  
    ByRef BasePoint As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim BasePoint As System.Double  
Dim value As System.Boolean  
  
value = instance.ISetBasePoint(BasePoint)
```

C#

```
System.bool ISetBasePoint(  
    ref System.double BasePoint  
)
```

C++/CLI

```
System.bool ISetBasePoint(  
& System.double% BasePoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BasePoint

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::SetBasePoint](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

Name Property (IBlockDefinition)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : Name Property (IBlockDefinition)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::Name](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBasePoint Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : SetBasePoint Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::InsertionPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetBasePoint( _  
    ByVal BasePoint As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim BasePoint As System.Object  
Dim value As System.Boolean  
  
value = instance.SetBasePoint(BasePoint)
```

C#

```
System.bool SetBasePoint(  
    System.object BasePoint  
)
```

C++/CLI

```
System.bool SetBasePoint(  
& System.Object^ BasePoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BasePoint

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::SetBasePoint](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetExternalFileName Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : SetExternalFileName Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::FileName](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetExternalFileName( _  
    ByVal FileName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim FileName As System.String  
Dim value As System.Integer  
  
value = instance.SetExternalFileName(FileName)
```

C#

```
System.int SetExternalFileName(  
    System.string FileName  
)
```

C++/CLI

```
System.int SetExternalFileName(  
& System.String^ FileName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::SetExternalFileName](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetUseExternalFile Method (IBlockDefinition)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockDefinition Interface](#) : SetUseExternalFile Method (IBlockDefinition)

Obsolete. Superseded by [ISketchBlockDefinition::LinkToFile](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetUseExternalFile( _  
    ByVal UseFile As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockDefinition  
Dim UseFile As System.Boolean  
Dim value As System.Integer  
  
value = instance.SetUseExternalFile(UseFile)
```

C#

```
System.int SetUseExternalFile(  
    System.bool UseFile  
)
```

C++/CLI

```
System.int SetUseExternalFile(  
& System.bool UseFile  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseFile

Visual Basic for Applications (VBA) Syntax

See [BlockDefinition::SetUseExternalFile](#).

See Also

[IBlockDefinition Interface](#)
[IBlockDefinition Members](#)

IBlockInstance (Type)

 

[SolidWorks.Interop.sldworks Namespace](#) : IBlockInstance Interface

Obsolete. Superseded by [ISketchBlockInstance](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBlockInstance

Visual Basic (Usage)

Dim instance As [IBlockInstance](#)

C#

public interface IBlockInstance

C++/CLI

public interface class IBlockInstance

Visual Basic for Applications (VBA) Syntax

See [BlockInstance](#).

See Also

[IBlockInstance Members](#)
[SolidWorks.Interop.sldworks Namespace](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockInstance Interface

The following tables list the members exposed by [IBlockInstance](#).

Public Properties

Name	Description
 Angle	Obsolete. Superseded by ISketchBlockInstance::Angle .
 Definition	Obsolete. Superseded by ISketchBlockInstance::Definition .
 Scale2	Obsolete. Superseded by ISketchBlockInstance::Scale .
 TextDisplay	Obsolete. Superseded by ISketchBlockInstance::TextDisplay .

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Obsolete. Not superseded.
 GetAttributeCount	Obsolete. Superseded by ISketchBlockInstance::GetAttributeCount .
 GetAttributes	Obsolete. Superseded by ISketchBlockInstance::GetAttributes .
 GetAttributeValue	Obsolete. Superseded by ISketchBlockInstance::GetAttributeValue .

 GetNext	Obsolete. Not superseded.
 IGetAttributes	Obsolete. Superseded by ISketchBlockInstance::IGetAttributes .
 SetAttributeValue	Obsolete. Superseded by ISketchBlockInstance::SetAttributeValue .

[Top](#)

See Also

[IBlockInstance Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBlockInstance Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockInstance Interface

For a list of all members of this type, see [IBlockInstance members](#).

Public Methods

Name	Description
 GetAnnotation	Obsolete. Not superseded.
 GetAttributeCount	Obsolete. Superseded by ISketchBlockInstance::GetAttributeCount .
 GetAttributes	Obsolete. Superseded by ISketchBlockInstance::GetAttributes .
 GetAttributeValue	Obsolete. Superseded by ISketchBlockInstance::GetAttributeValue .
 GetNext	Obsolete. Not superseded.
 IGetAttributes	Obsolete. Superseded by ISketchBlockInstance::IGetAttributes .
 SetAttributeValue	Obsolete. Superseded by ISketchBlockInstance::SetAttributeValue .

[Top](#)

See Also

[IBlockInstance Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBlockInstance Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBlockInstance Interface

For a list of all members of this type, see [IBlockInstance members](#).

Public Properties

Name	Description
 Angle	Obsolete. Superseded by ISketchBlockInstance::Angle .
 Definition	Obsolete. Superseded by ISketchBlockInstance::Definition .
 Scale2	Obsolete. Superseded by ISketchBlockInstance::Scale .
 TextDisplay	Obsolete. Superseded by ISketchBlockInstance::TextDisplay .

[Top](#)

See Also

[IBlockInstance Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Angle Property (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : Angle Property (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::Angle](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Angle As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim value As System.Double
```

```
instance.Angle = value
```

```
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::Angle](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Definition Property (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : Definition Property (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::Definition](#).

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Definition As BlockDefinition
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim value As BlockDefinition
```

```
value = instance.Definition
```

C#

```
BlockDefinition Definition {get;}
```

C++/CLI

```
property BlockDefinition^ Definition {  
    BlockDefinition^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::Definition](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : GetAnnotation Method (IBlockInstance)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim value As Annotation
```

```
value = instance.GetAnnotation()
```

C#

```
Annotation GetAnnotation()
```

C++/CLI

```
Annotation^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::GetAnnotation](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAttributeCount Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : GetAttributeCount Method (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::GetAttributeCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttributeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance
Dim value As System.Integer

value = instance.GetAttributeCount()
```

C#

```
System.int GetAttributeCount()
```

C++/CLI

```
System.int GetAttributeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::GetAttributeCount](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAttributes Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : GetAttributes Method (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::GetAttributes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttributes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance
Dim value As System.Object

value = instance.GetAttributes()
```

C#

```
System.object GetAttributes()
```

C++/CLI

```
System.Object^ GetAttributes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::GetAttributes](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

GetAttributeValue Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : GetAttributeValue Method (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::GetAttributeValue](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAttributeValue( _  
    ByVal TagName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim TagName As System.String  
Dim value As System.String  
  
value = instance.GetAttributeValue(TagName)
```

C#

```
System.string GetAttributeValue(  
    System.string TagName  
)
```

C++/CLI

```
System.String^ GetAttributeValue(  
& System.String^ TagName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TagName

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::GetAttributeValue](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

GetNext Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : GetNext Method (IBlockInstance)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As BlockInstance
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim value As BlockInstance
```

```
value = instance.GetNext()
```

C#

```
BlockInstance GetNext()
```

C++/CLI

```
BlockInstance^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::GetNext](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAttributes Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : IGetAttributes Method (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::IGetAttributes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAttributes( _  
    ByVal NumAttribs As System.Integer _  
) As Note
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim NumAttribs As System.Integer  
Dim value As Note  
  
value = instance.IGetAttributes(NumAttribs)
```

C#

```
Note IGetAttributes(  
    System.int NumAttribs  
)
```

C++/CLI

```
Note^ IGetAttributes(  
&    System.int NumAttribs  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumAttribs

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::IGetAttributes](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Scale2 Property (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : Scale2 Property (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::Scale](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Scale2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance  
Dim value As System.Double
```

```
instance.Scale2 = value
```

```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::Scale2](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAttributeValue Method (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : SetAttributeValue Method (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::SetAttributeValue](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetAttributeValue( _  
    ByVal TagName As System.String, _  
    ByVal Value As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance
Dim TagName As System.String
Dim Value As System.String
Dim value As System.Boolean

value = instance.SetAttributeValue(TagName, Value)
```

C#

```
System.bool SetAttributeValue(
    System.string TagName,
    System.string Value
)
```

C++/CLI

```
System.bool SetAttributeValue(
    & System.String^ TagName,
    & System.String^ Value
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TagName

Value

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::SetAttributeValue](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextDisplay Property (IBlockInstance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBlockInstance Interface](#) : TextDisplay Property (IBlockInstance)

Obsolete. Superseded by [ISketchBlockInstance::TextDisplay](#).

.NET Syntax

Visual Basic (Declaration)

```
Property TextDisplay As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBlockInstance
Dim value As System.Integer

instance.TextDisplay = value

value = instance.TextDisplay
```

C#

```
System.int TextDisplay {get; set;}
```

C++/CLI

```
property System.int TextDisplay {
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BlockInstance::TextDisplay](#).

See Also

[IBlockInstance Interface](#)
[IBlockInstance Members](#)