

SOLIDWORKS API (NET VBA C#) — Reference

(24/337): IBody (part 2 of 3)

SOLIDWORKS API Documentation (converted from CHM)

IBody (part 2 of 3) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetType Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : GetType Method (IBody)

Obsolete. Superseded by [IBody2::GetType](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As System.Integer  
  
value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::GetType](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Hide Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : Hide Method (IBody)

Obsolete. Superseded by [IBody2::Hide](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Hide(  
    ByVal Part As System.Object  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Part As System.Object  
  
instance.Hide(Part)
```

C#

```
void Hide(  
    System.Object Part  
)
```

C++/CLI

```
void Hide(  
&    System.Object^ Part  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Part

Visual Basic for Applications (VBA) Syntax

See [Body.Hide](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileArc Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileArc Method (IBody)

Obsolete. Superseded by [IBody2.IAddProfileArc](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileArc( _  
    ByVal Center As System.Object, _  
    ByVal Axis As System.Object, _  
    ByVal Radius As System.Double, _  
    ByVal StartPoint As System.Object, _  
    ByVal EndPoint As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Center As System.Object  
Dim Axis As System.Object  
Dim Radius As System.Double  
Dim StartPoint As System.Object  
Dim EndPoint As System.Object  
Dim value As Curve
```

```
value = instance.IAddProfileArc(Center, Axis, Radius, StartPoint, EndPoint)
```

C#

```
Curve IAddProfileArc(  
    System.object Center,  
    System.object Axis,  
    System.double Radius,  
    System.object StartPoint,  
    System.object EndPoint  
)
```

C++/CLI

```
Curve^ IAddProfileArc(
& System.Object^ Center,
& System.Object^ Axis,
& System.double Radius,
& System.Object^ StartPoint,
& System.Object^ EndPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Center

Axis

Radius

StartPoint

EndPoint

Visual Basic for Applications (VBA) Syntax

See [Body::IAddProfileArc](#).

See Also

[IBody Interface](#)

[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileArcDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileArcDLL Method (IBody)

Obsolete. Superseded by [IBody2::IAddProfileArcDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileArcDLL( _
    ByRef Center As System.Double, _
    ByRef Axis As System.Double, _
    ByVal Radius As System.Double, _
    ByRef StartPoint As System.Double, _
    ByRef EndPoint As System.Double _
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody
Dim Center As System.Double
Dim Axis As System.Double
Dim Radius As System.Double
Dim StartPoint As System.Double
Dim EndPoint As System.Double
Dim value As Curve
```

```
value = instance.IAddProfileArcDLL(Center, Axis, Radius, StartPoint, EndPoint)
```

C#

```
Curve IAddProfileArcDLL(
    ref System.double Center,
    ref System.double Axis,
    System.double Radius,
    ref System.double StartPoint,
```

```
    ref System.double EndPoint  
)
```

C++/CLI

```
Curve^ IAddProfileArcDLL(  
& System.double% Center,  
& System.double% Axis,  
& System.double Radius,  
& System.double% StartPoint,  
& System.double% EndPoint  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Center

Axis

Radius

StartPoint

EndPoint

Visual Basic for Applications (VBA) Syntax

See [Body:IAddProfileArcDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileBspline Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileBspline Method (IBody)

Obsolete. Superseded by [IBody2:IAddProfileBspline](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileBspline( _  
    ByVal Props As System.Object, _  
    ByVal Knots As System.Object, _  
    ByVal CtrlPtCoords As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Props As System.Object  
Dim Knots As System.Object  
Dim CtrlPtCoords As System.Object  
Dim value As Curve
```

```
value = instance.IAddProfileBspline(Props, Knots, CtrlPtCoords)
```

C#

```
Curve IAddProfileBspline(  
    System.object Props,  
    System.object Knots,  
    System.object CtrlPtCoords  
)
```

C++/CLI

```
Curve^ IAddProfileBspline(  
& System.Object^ Props,  
& System.Object^ Knots,  
& System.Object^ CtrlPtCoords  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Props

Knots

CtrlPtCoords

Visual Basic for Applications (VBA) Syntax

See [Body::IAddProfileBspline](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileBsplineDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileBsplineDLL Method (IBody)

Obsolete. Superseded by [IBody2::IAddProfileBsplineDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileBsplineDLL( _  
    ByRef Properties As System.Integer, _  
    ByRef KnotArray As System.Double, _  
    ByRef ControlPointCoordArray As System.Double _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Properties As System.Integer  
Dim KnotArray As System.Double  
Dim ControlPointCoordArray As System.Double  
Dim value As Curve  
  
value = instance.IAddProfileBsplineDLL(Properties, KnotArray, ControlPointCoordArray)
```

C#

```
Curve IAddProfileBsplineDLL(  
    ref System.int Properties,  
    ref System.double KnotArray,  
    ref System.double ControlPointCoordArray  
)
```

C++/CLI

```
Curve^ IAddProfileBsplineDLL(  
& System.int% Properties,  
& System.double% KnotArray,  
& System.double% ControlPointCoordArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Properties

KnotArray

ControlPointCoordArray

Visual Basic for Applications (VBA) Syntax

See [Body::IAddProfileBsplinesDLL](#).

See Also

[IBody Interface](#)

[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileLine Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileLine Method (IBody)

Obsolete. Superseded by [IBody2::IAddProfileLine](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileLine( _  
    ByVal RootPoint As System.Object, _  
    ByVal Direction As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim RootPoint As System.Object  
Dim Direction As System.Object  
Dim value As Curve
```

```
value = instance.IAddProfileLine(RootPoint, Direction)
```

C#

```
Curve IAddProfileLine(  
    System.object RootPoint,  
    System.object Direction  
)
```

C++/CLI

```
Curve^ IAddProfileLine(  
& System.Object^ RootPoint,  
& System.Object^ Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint

Direction

Visual Basic for Applications (VBA) Syntax

See [Body::IAddProfileLine](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileLineDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddProfileLineDLL Method (IBody)

Obsolete. Superseded by [IBody2::IAddProfileLineDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileLineDLL( _  
    ByRef RootPoint As System.Double, _  
    ByRef Direction As System.Double _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim RootPoint As System.Double  
Dim Direction As System.Double  
Dim value As Curve
```

```
value = instance.IAddProfileLineDLL(RootPoint, Direction)
```

C#

```
Curve IAddProfileLineDLL(  
    ref System.double RootPoint,  
    ref System.double Direction  
)
```

C++/CLI

```
Curve^ IAddProfileLineDLL(  
& System.double% RootPoint,  
& System.double% Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint

Direction

Visual Basic for Applications (VBA) Syntax

See [Body::IAddProfileLineDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddVertexPoint Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IAddVertexPoint Method (IBody)

Obsolete. Superseded by [IBody2::IAddVertexPoint](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAddVertexPoint( _  
    ByRef Point As System.Double _  
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Point As System.Double  
Dim value As Vertex  
  
value = instance.IAddVertexPoint(Point)
```

C#

```
Vertex IAddVertexPoint(  
    ref System.double Point  
)
```

C++/CLI

```
Vertex^ IAddVertexPoint(  
& System.double% Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point

Visual Basic for Applications (VBA) Syntax

See [Body.IAddVertexPoint](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICombineVolumes Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICombineVolumes Method (IBody)

Obsolete. Superseded by [IBody2.ICombineVolumes](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICombineVolumes(  
    ByVal ToolBody As Body _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ToolBody As Body  
  
instance.ICombineVolumes(ToolBody)
```

C#

```
void ICombineVolumes(  
    Body ToolBody  
)
```

C++/CLI

```
void ICombineVolumes(  
&    Body^ ToolBody  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ToolBody

Visual Basic for Applications (VBA) Syntax

See [Body::ICombineVolumes](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICopy Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICopy Method (IBody)

Obsolete. Superseded by [IBody2::ICopy](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICopy() As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Body
```

```
value = instance.ICopy()
```

C#

```
Body ICopy()
```

C++/CLI

```
Body^ ICopy();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::ICopy](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBaseFeature Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBaseFeature Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBaseFeature](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBaseFeature( _  
    ByVal BodyIn As Body _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim BodyIn As Body  
Dim value As System.Boolean  
  
value = instance.ICreateBaseFeature(BodyIn)
```

C#

```
System.bool ICreateBaseFeature(  
    Body BodyIn  
)
```

C++/CLI

```
System.bool ICreateBaseFeature(  
& Body^ BodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBaseFeature](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBlendSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBlendSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBlendSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBlendSurface( _  
    ByVal Surface1 As Surface, _  
    ByVal Range1 As System.Double, _  
    ByVal Surface2 As Surface, _  
    ByVal Range2 As System.Double, _  
    ByRef StartVec As System.Double, _  
    ByRef EndVec As System.Double, _  
    ByVal HaveHelpVec As System.Integer, _  
    ByRef HelpVec As System.Double, _
```

```

    ByVal HaveHelpBox As System.Integer, _
    ByRef HelpBox As System.Double _
) As Surface

```

Visual Basic (Usage)



```

Dim instance As IBody
Dim Surface1 As Surface
Dim Range1 As System.Double
Dim Surface2 As Surface
Dim Range2 As System.Double
Dim StartVec As System.Double
Dim EndVec As System.Double
Dim HaveHelpVec As System.Integer
Dim HelpVec As System.Double
Dim HaveHelpBox As System.Integer
Dim HelpBox As System.Double
Dim value As Surface

```

```

value = instance.ICreateBlendSurface(Surface1, Range1, Surface2, Range2, StartVec, EndVec,
HaveHelpVec, HelpVec, HaveHelpBox, HelpBox)

```

C#

```

Surface ICreateBlendSurface(
    Surface Surface1,
    System.double Range1,
    Surface Surface2,
    System.double Range2,
    ref System.double StartVec,
    ref System.double EndVec,
    System.int HaveHelpVec,
    ref System.double HelpVec,
    System.int HaveHelpBox,
    ref System.double HelpBox
)

```

C++/CLI

```

Surface^ ICreateBlendSurface(
    & Surface^ Surface1,
    & System.double Range1,
    & Surface^ Surface2,
    & System.double Range2,
    & System.double% StartVec,
    & System.double% EndVec,
    & System.int HaveHelpVec,
    & System.double% HelpVec,
    & System.int HaveHelpBox,
    & System.double% HelpBox
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Surface1

Range1

Surface2

Range2

StartVec

EndVec

HaveHelpVec

HelpVec

HaveHelpBox

HelpBox

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBlendSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBodyFromFaces Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBodyFromFaces Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBodyFromFaces](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBodyFromFaces( _  
    ByVal NumOfFaces As System.Integer, _  
    ByVal FaceList As System.Object _  
) As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As System.Object  
Dim value As Body
```

```
value = instance.ICreateBodyFromFaces(NumOfFaces, FaceList)
```

C#

```
Body ICreateBodyFromFaces(  
    System.int NumOfFaces,  
    System.object FaceList  
)
```

C++/CLI

```
Body^ ICreateBodyFromFaces(  
& System.int NumOfFaces,  
& System.Object^ FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBodyFromFaces](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBoundedSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBoundedSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBoundedSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateBoundedSurface( _  
    ByVal UOpt As System.Boolean, _  
    ByVal VOpt As System.Boolean, _  
    ByRef UvParams As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim UOpt As System.Boolean  
Dim VOpt As System.Boolean  
Dim UvParams As System.Double  
  
instance.ICreateBoundedSurface(UOpt, VOpt, UvParams)
```

C#

```
void ICreateBoundedSurface(  
    System.bool UOpt,  
    System.bool VOpt,  
    ref System.double UvParams  
)
```

C++/CLI

```
void ICreateBoundedSurface(  
& System.bool UOpt,  
& System.bool VOpt,  
& System.double% UvParams  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UOpt

VOpt

UvParams

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBoundedSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBsplineSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBsplineSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBsplineSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBsplineSurface( _
    ByVal Props As System.Object, _
    ByVal UKnots As System.Object, _
    ByVal VKnots As System.Object, _
    ByVal CtrlPtCoords As System.Object _
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody
Dim Props As System.Object
Dim UKnots As System.Object
Dim VKnots As System.Object
Dim CtrlPtCoords As System.Object
Dim value As Surface

value = instance.ICreateBsplineSurface(Props, UKnots, VKnots, CtrlPtCoords)
```

C#

```
Surface ICreateBsplineSurface(
    System.object Props,
    System.object UKnots,
    System.object VKnots,
    System.object CtrlPtCoords
)
```

C++/CLI

```
Surface^ ICreateBsplineSurface(
    & System.Object^ Props,
    & System.Object^ UKnots,
    & System.Object^ VKnots,
    & System.Object^ CtrlPtCoords
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Props

UKnots

VKnots

CtrlPtCoords

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBsplineSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBsplineSurfaceDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateBsplineSurfaceDLL Method (IBody)

Obsolete. Superseded by [IBody2::ICreateBsplineSurfaceDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBsplineSurfaceDLL( _
    ByRef Properties As System.Integer, _
    ByRef UKnotArray As System.Double, _
    ByRef VKnotArray As System.Double, _
    ByRef ControlPointCoordArray As System.Double _
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody
Dim Properties As System.Integer
Dim UKnotArray As System.Double
Dim VKnotArray As System.Double
Dim ControlPointCoordArray As System.Double
Dim value As Surface

value = instance.ICreateBsplineSurfaceDLL(Properties, UKnotArray, VKnotArray,
ControlPointCoordArray)
```

C#

```
Surface ICreateBsplineSurfaceDLL(
    ref System.int Properties,
    ref System.double UKnotArray,
    ref System.double VKnotArray,
    ref System.double ControlPointCoordArray
)
```

C++/CLI

```
Surface^ ICreateBsplineSurfaceDLL(
    & System.int% Properties,
    & System.double% UKnotArray,
    & System.double% VKnotArray,
    & System.double% ControlPointCoordArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Properties

UKnotArray

VKnotArray

ControlPointCoordArray

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateBsplineSurfaceDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateExtrusionSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateExtrusionSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateExtrusionSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateExtrusionSurface( _  
    ByVal ProfileCurve As Curve, _  
    ByVal AxisDirection As System.Object _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ProfileCurve As Curve  
Dim AxisDirection As System.Object  
Dim value As Surface  
  
value = instance.ICreateExtrusionSurface(ProfileCurve, AxisDirection)
```

C#

```
Surface ICreateExtrusionSurface(  
    Curve ProfileCurve,  
    System.object AxisDirection  
)
```

C++/CLI

```
Surface^ ICreateExtrusionSurface(  
& Curve^ ProfileCurve,  
& System.Object^ AxisDirection  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve

AxisDirection

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateExtrusionSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateExtrusionSurfaceDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateExtrusionSurfaceDLL Method (IBody)

Obsolete. Superseded by [IBody2::ICreateExtrusionSurfaceDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateExtrusionSurfaceDLL( _  
    ByVal ProfileCurve As Curve, _  
    ByRef AxisDirection As System.Double _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ProfileCurve As Curve  
Dim AxisDirection As System.Double  
Dim value As Surface
```

```
value = instance.ICreateExtrusionSurfaceDLL(ProfileCurve, AxisDirection)
```

C#

```
Surface ICreateExtrusionSurfaceDLL(  
    Curve ProfileCurve,  
    ref System.double AxisDirection  
)
```

C++/CLI

```
Surface^ ICreateExtrusionSurfaceDLL(  
& Curve^ ProfileCurve,  
& System.double% AxisDirection  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve

AxisDirection

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateExtrusionSurfaceDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateNewSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateNewSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateNewSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateNewSurface() As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Surface
```

```
value = instance.ICreateNewSurface()
```

C#

```
Surface ICreateNewSurface()
```

C++/CLI

```
Surface^ ICreateNewSurface();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateNewSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateOffsetSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateOffsetSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateOffsetSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateOffsetSurface( _  
    ByVal SurfaceIn As Surface, _  
    ByVal Distance As System.Double _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim SurfaceIn As Surface  
Dim Distance As System.Double  
Dim value As Surface
```

```
value = instance.ICreateOffsetSurface(SurfaceIn, Distance)
```

C#

```
Surface ICreateOffsetSurface(  
    Surface SurfaceIn,  
    System.double Distance  
)
```

C++/CLI

```
Surface^ ICreateOffsetSurface(  
& Surface^ SurfaceIn,  
& System.double Distance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SurfaceIn

Distance

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateOffsetSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreatePlanarSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreatePlanarSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreatePlanarSurface](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreatePlanarSurface( _  
    ByVal VRootPoint As System.Object, _  
    ByVal VNormal As System.Object _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim VRootPoint As System.Object  
Dim VNormal As System.Object  
Dim value As Surface  
  
value = instance.ICreatePlanarSurface(VRootPoint, VNormal)
```

C#

```
Surface ICreatePlanarSurface(  
    System.object VRootPoint,  
    System.object VNormal  
)
```

C++/CLI

```
Surface^ ICreatePlanarSurface(  
& System.Object^ VRootPoint,  
& System.Object^ VNormal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VRootPoint

VNormal

Visual Basic for Applications (VBA) Syntax

See [Body::ICreatePlanarSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreatePlanarSurfaceDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreatePlanarSurfaceDLL Method (IBody)

Obsolete. Superseded by [IBody2::ICreatePlanarSurfaceDLL](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreatePlanarSurfaceDLL( _  
    ByRef RootPoint As System.Double, _  
    ByRef Normal As System.Double _  
) As Surface
```

Visual Basic (Usage)



```

Dim instance As IBody
Dim RootPoint As System.Double
Dim Normal As System.Double
Dim value As Surface

value = instance.ICreatePlanarSurfaceDLL(RootPoint, Normal)

```

C#

```

Surface ICreatePlanarSurfaceDLL(
    ref System.double RootPoint,
    ref System.double Normal
)

```

C++/CLI

```

Surface^ ICreatePlanarSurfaceDLL(
    & System.double% RootPoint,
    & System.double% Normal
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint

Normal

Visual Basic for Applications (VBA) Syntax

See [Body::ICreatePlanarSurfaceDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreatePsplineSurfaceDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreatePsplineSurfaceDLL Method (IBody)

Obsolete. Superseded by [IBody2::ICreatePsplineSurfaceDLL](#).

.NET Syntax

Visual Basic (Declaration)

```

Function ICreatePsplineSurfaceDLL( _
    ByVal Dim As System.Integer, _
    ByVal UOrder As System.Integer, _
    ByVal VOrder As System.Integer, _
    ByVal Ncol As System.Integer, _
    ByVal Nrow As System.Integer, _
    ByRef Coeffs As System.Double, _
    ByVal Basis As System.Integer, _
    ByRef Xform As System.Double, _
    ByVal ScaleFactor As System.Double _
) As Surface

```

Visual Basic (Usage)

```

Dim instance As IBody
Dim Dim As System.Integer
Dim UOrder As System.Integer
Dim VOrder As System.Integer
Dim Ncol As System.Integer

```



```
Dim Nrow As System.Integer
Dim Coeffs As System.Double
Dim Basis As System.Integer
Dim Xform As System.Double
Dim ScaleFactor As System.Double
Dim value As Surface
```

```
value = instance.ICreatePsplineSurfaceDLL(Dim, UOrder, VOrder, Ncol, Nrow, Coeffs, Basis, Xform,
ScaleFactor)
```

C#

```
Surface ICreatePsplineSurfaceDLL(
    System.int Dim,
    System.int UOrder,
    System.int VOrder,
    System.int Ncol,
    System.int Nrow,
    ref System.double Coeffs,
    System.int Basis,
    ref System.double Xform,
    System.double ScaleFactor
)
```

C++/CLI

```
Surface^ ICreatePsplineSurfaceDLL(
    & System.int Dim,
    & System.int UOrder,
    & System.int VOrder,
    & System.int Ncol,
    & System.int Nrow,
    & System.double% Coeffs,
    & System.int Basis,
    & System.double% Xform,
    & System.double ScaleFactor
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dim

UOrder

VOrder

Ncol

Nrow

Coeffs

Basis

Xform

ScaleFactor

Visual Basic for Applications (VBA) Syntax

See [Body::ICreatePsplineSurfaceDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateRevolutionSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateRevolutionSurface Method (IBody)

Obsolete. Superseded by [IBody2::ICreateRevolutionSurface](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICreateRevolutionSurface( _  
    ByVal ProfileCurve As Curve, _  
    ByVal AxisPoint As System.Object, _  
    ByVal AxisDirection As System.Object, _  
    ByVal ProfileEndPtParams As System.Object _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ProfileCurve As Curve  
Dim AxisPoint As System.Object  
Dim AxisDirection As System.Object  
Dim ProfileEndPtParams As System.Object  
Dim value As Surface  
  
value = instance.ICreateRevolutionSurface(ProfileCurve, AxisPoint, AxisDirection,  
ProfileEndPtParams)
```

C#

```
Surface ICreateRevolutionSurface(  
    Curve ProfileCurve,  
    System.object AxisPoint,  
    System.object AxisDirection,  
    System.object ProfileEndPtParams  
)
```

C++/CLI

```
Surface^ ICreateRevolutionSurface(  
& Curve^ ProfileCurve,  
& System.Object^ AxisPoint,  
& System.Object^ AxisDirection,  
& System.Object^ ProfileEndPtParams  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve

AxisPoint

AxisDirection

ProfileEndPtParams

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateRevolutionSurface](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateRevolutionSurfaceDLL Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateRevolutionSurfaceDLL Method (IBody)

Obsolete. Superseded by [IBody2::ICreateRevolutionSurfaceDLL](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICreateRevolutionSurfaceDLL( _  
    ByVal ProfileCurve As Curve, _  
    ByRef AxisPoint As System.Double, _  
    ByRef AxisDirection As System.Double, _  
    ByRef ProfileEndPtParams As System.Double _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ProfileCurve As Curve  
Dim AxisPoint As System.Double  
Dim AxisDirection As System.Double  
Dim ProfileEndPtParams As System.Double  
Dim value As Surface  
  
value = instance.ICreateRevolutionSurfaceDLL(ProfileCurve, AxisPoint, AxisDirection,  
ProfileEndPtParams)
```

C#

```
Surface ICreateRevolutionSurfaceDLL(  
    Curve ProfileCurve,  
    ref System.double AxisPoint,  
    ref System.double AxisDirection,  
    ref System.double ProfileEndPtParams  
)
```

C++/CLI

```
Surface^ ICreateRevolutionSurfaceDLL(  
& Curve^ ProfileCurve,  
& System.double% AxisPoint,  
& System.double% AxisDirection,  
& System.double% ProfileEndPtParams  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve

AxisPoint

AxisDirection

ProfileEndPtParams

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateRevolutionSurfaceDLL](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateTempBodyFromSurfaces Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ICreateTempBodyFromSurfaces Method (IBody)

Obsolete. Superseded by [IBody2::ICreateTempBodyFromSurfaces](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateTempBodyFromSurfaces() As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Body  
  
value = instance.ICreateTempBodyFromSurfaces()
```

C#

```
Body ICreateTempBodyFromSurfaces()
```

C++/CLI

```
Body^ ICreateTempBodyFromSurfaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::ICreateTempBodyFromSurfaces](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteBlends Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDeleteBlends Method (IBody)

Obsolete. Superseded by [IBody2::IDeleteBlends2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteBlends( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim value As System.Boolean  
  
value = instance.IDeleteBlends(NumOfFaces, FaceList)
```

C#

```
System.bool IDeleteBlends(  
    System.int NumOfFaces,  
    ref Face FaceList  
)
```

C++/CLI

```
System.bool IDeleteBlends(  
& System.int NumOfFaces,  
& Face^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Visual Basic for Applications (VBA) Syntax

See [Body::IDeleteBlends](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteBlends2 Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDeleteBlends2 Method (IBody)

Obsolete. Superseded by [IBody2::IDeleteBlends2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteBlends2( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face, _  
    ByVal DoLocalCheck As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim DoLocalCheck As System.Boolean  
Dim value As System.Boolean  
  
value = instance.IDeleteBlends2(NumOfFaces, FaceList, DoLocalCheck)
```

C#

```
System.bool IDeleteBlends2(  
    System.int NumOfFaces,  
    ref Face FaceList,  
    System.bool DoLocalCheck  
)
```

C++/CLI

```
System.bool IDeleteBlends2(  
& System.int NumOfFaces,  
& Face^% FaceList,  
& System.bool DoLocalCheck  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

DoLocalCheck

Visual Basic for Applications (VBA) Syntax

See [Body::IDeleteBlends2](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteFaces2 Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDeleteFaces2 Method (IBody)

Obsolete. Superseded by [IBody2::IDeleteFaces3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteFaces2( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face, _  
    ByVal Option As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim Option As System.Integer  
Dim value As System.Integer  
  
value = instance.IDeleteFaces2(NumOfFaces, FaceList, Option)
```

C#

```
System.int IDeleteFaces2(  
    System.int NumOfFaces,  
    ref Face FaceList,  
    System.int Option  
)
```

C++/CLI

```
System.int IDeleteFaces2(  
& System.int NumOfFaces,  
& Face^% FaceList,  
& System.int Option  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Option

Visual Basic for Applications (VBA) Syntax

See [Body::IDeleteFaces2](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteFaces3 Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDeleteFaces3 Method (IBody)

Obsolete. Superseded by [IBody2::IDeleteFaces3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IDeleteFaces3( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face, _  
    ByVal Option As System.Integer, _  
    ByVal DoLocalCheck As System.Boolean, _  
    ByRef LocalCheckResult As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim Option As System.Integer  
Dim DoLocalCheck As System.Boolean  
Dim LocalCheckResult As System.Boolean  
  
instance.IDeleteFaces3(NumOfFaces, FaceList, Option, DoLocalCheck, LocalCheckResult)
```

C#

```
void IDeleteFaces3(  
    System.int NumOfFaces,  
    ref Face FaceList,  
    System.int Option,  
    System.bool DoLocalCheck,  
    ref System.bool LocalCheckResult  
)
```

C++/CLI

```
void IDeleteFaces3(  
& System.int NumOfFaces,  
& Face^% FaceList,  
& System.int Option,  
& System.bool DoLocalCheck,  
& System.bool% LocalCheckResult  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Option

DoLocalCheck

LocalCheckResult

Visual Basic for Applications (VBA) Syntax

See [Body::DeleteFaces3](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Display Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDisplay Method (IBody)

Obsolete. Superseded by [IBody2::Display3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IDisplay( _  
    ByVal Part As PartDoc, _  
    ByVal Color As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Part As PartDoc  
Dim Color As System.Integer  
  
instance.IDisplay(Part, Color)
```

C#

```
void IDisplay(  
    PartDoc Part,  
    System.int Color  
)
```

C++/CLI

```
void IDisplay(  
& PartDoc^ Part,  
& System.int Color  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Part

Color

Visual Basic for Applications (VBA) Syntax

See [Body::IDisplay](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDisplayWireFrameXOR Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDisplayWireFrameXOR Method (IBody)

Obsolete. Superseded by [IBody2::IDisplayWireFromXOR](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IDisplayWireFrameXOR( _  
    ByVal Part As PartDoc, _  
    ByVal Color As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Part As PartDoc  
Dim Color As System.Integer  
  
instance.IDisplayWireFrameXOR(Part, Color)
```

C#

```
void IDisplayWireFrameXOR(  
    PartDoc Part,  
    System.int Color  
)
```

C++/CLI

```
void IDisplayWireFrameXOR(  
& PartDoc^ Part,  
& System.int Color  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Part

Color

Visual Basic for Applications (VBA) Syntax

See [Body::IDisplayWireFrameXOR](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDraftBody Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IDraftBody Method (IBody)

Obsolete. Superseded by [IBody2::IDraftBody2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDraftBody( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face, _  
    ByRef EdgeList As Edge, _  
    ByVal DraftAngle As System.Double, _
```

```
ByRef Dir As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim EdgeList As Edge  
Dim DraftAngle As System.Double  
Dim Dir As System.Double  
Dim value As System.Boolean  
  
value = instance.IDraftBody(NumOfFaces, FaceList, EdgeList, DraftAngle, Dir)
```

C#

```
System.bool IDraftBody(  
    System.int NumOfFaces,  
    ref Face FaceList,  
    ref Edge EdgeList,  
    System.double DraftAngle,  
    ref System.double Dir  
)
```

C++/CLI

```
System.bool IDraftBody(  
& System.int NumOfFaces,  
& Face^% FaceList,  
& Edge^% EdgeList,  
& System.double DraftAngle,  
& System.double% Dir  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

EdgeList

DraftAngle

Dir

Visual Basic for Applications (VBA) Syntax

See [Body::IDraftBody](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetBodyBox Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetBodyBox Method (IBody)

Obsolete. Superseded by [IBody2::IGetBodyBox](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetBodyBox( _  
    ByRef BoxCorners As System.Double _
```

)

Visual Basic (Usage)



```
Dim instance As IBody  
Dim BoxCorners As System.Double  
  
instance.IGetBodyBox(BoxCorners)
```

C#

```
void IGetBodyBox(  
    ref System.double BoxCorners  
)
```

C++/CLI

```
void IGetBodyBox(  
& System.double% BoxCorners  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BoxCorners

Visual Basic for Applications (VBA) Syntax

See [Body.IGetBodyBox](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetExcessBodyArray Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetExcessBodyArray Method (IBody)

Obsolete. Superseded by [IBody2.IGetExcessBodyArray](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExcessBodyArray() As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As System.IntPtr  
  
value = instance.IGetExcessBodyArray()
```

C#

```
System.IntPtr IGetExcessBodyArray()
```

C++/CLI

```
System.IntPtr IGetExcessBodyArray();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetExcessBodyArray](#).

 See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetExcessBodyCount Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetExcessBodyCount Method (IBody)

Obsolete. Superseded by [IBody2::IGetExcessBodyCount](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetExcessBodyCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As System.Integer  
  
value = instance.IGetExcessBodyCount()
```

C#

```
System.int IGetExcessBodyCount()
```

C++/CLI

```
System.int IGetExcessBodyCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [Body::IGetExcessBodyCount](#).

 See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstFace Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetFirstFace Method (IBody)

Obsolete. Superseded by [IBody2::IGetFirstFace](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstFace() As Face
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Face  
  
value = instance.IGetFirstFace()
```

C#

```
Face IGetFirstFace()
```

C++/CLI

```
Face^ IGetFirstFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetFirstFace](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetFirstSelectedFace Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetFirstSelectedFace Method (IBody)

Obsolete. Superseded by [IBody2::IGetFirstSelectedFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFirstSelectedFace() As Face
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Face
```

```
value = instance.IGetFirstSelectedFace()
```

C#

```
Face IGetFirstSelectedFace()
```

C++/CLI

```
Face^ IGetFirstSelectedFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetFirstSelectedFace](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetIntersectionEdgeCount Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetIntersectionEdgeCount Method (IBody)

Obsolete. Superseded by [IBody2::IGetIntersectionEdgeCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetIntersectionEdgeCount( _  
    ByVal ToolBodyIn As Body _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ToolBodyIn As Body  
Dim value As System.Integer  
  
value = instance.IGetIntersectionEdgeCount(ToolBodyIn)
```

C#

```
System.int IGetIntersectionEdgeCount(  
    Body ToolBodyIn  
)
```

C++/CLI

```
System.int IGetIntersectionEdgeCount(  
    & Body^ ToolBodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ToolBodyIn

Visual Basic for Applications (VBA) Syntax

See [Body::IGetIntersectionEdgeCount](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetIntersectionEdges Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetIntersectionEdges Method (IBody)

Obsolete. Superseded by [IBody2::IGetIntersectionEdges](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetIntersectionEdges( _  
    ByVal ToolBodyIn As Body _  
) As System.IntPtr
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim ToolBodyIn As Body  
Dim value As System.IntPtr  
  
value = instance.IGetIntersectionEdges(ToolBodyIn)
```

C#

```
System.IntPtr IGetIntersectionEdges(  
    Body ToolBodyIn
```

)

C++/CLI

```
System.IntPtr IGetIntersectionEdges(  
& Body^ ToolBodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ToolBodyIn

Visual Basic for Applications (VBA) Syntax

See [Body::IGetIntersectionEdges](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetMassProperties Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetMassProperties Method (IBody)

Obsolete. Superseded by [IBody2::IGetMassProperties](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetMassProperties( _  
    ByVal Density As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Density As System.Double  
Dim value As System.Double  
  
value = instance.IGetMassProperties(Density)
```

C#

```
System.double IGetMassProperties(  
    System.double Density  
)
```

C++/CLI

```
System.double IGetMassProperties(  
& System.double Density  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Density

Visual Basic for Applications (VBA) Syntax

See [Body::IGetMassProperties](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNextSelectedFace Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetNextSelectedFace Method (IBody)

Obsolete. Superseded by [IBody2::IGetNextSelectedFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNextSelectedFace() As Face
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Face  
  
value = instance.IGetNextSelectedFace()
```

C#

```
Face IGetNextSelectedFace()
```

C++/CLI

```
Face^ IGetNextSelectedFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetNextSelectedFace](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetProcessedBody Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetProcessedBody Method (IBody)

Obsolete. Superseded by [IBody2::GetProcessedBody2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProcessedBody() As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Body  
  
value = instance.IGetProcessedBody()
```

C#

```
Body IGetProcessedBody()
```

C++/CLI

```
Body^ IGetProcessedBody();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetProcessedBody](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetProcessedBodyWithSelFace Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetProcessedBodyWithSelFace Method (IBody)

Obsolete. Superseded by [IBody2::IGetProcessedBodyWithSelFace](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetProcessedBodyWithSelFace() As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As Body
```

```
value = instance.IGetProcessedBodyWithSelFace()
```

C#

```
Body IGetProcessedBodyWithSelFace()
```

C++/CLI

```
Body^ IGetProcessedBodyWithSelFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IGetProcessedBodyWithSelFace](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSheetBody Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetSheetBody Method (IBody)

Obsolete. Superseded by [IBody2::IGetSheetBody](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSheetBody( _  
    ByVal Index As System.Integer _  
) As Body
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Index As System.Integer  
Dim value As Body  
  
value = instance.IGetSheetBody(Index)
```

C#

```
Body IGetSheetBody(  
    System.int Index  
)
```

C++/CLI

```
Body^ IGetSheetBody(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [Body::IGetSheetBody](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTessellation Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IGetTessellation Method (IBody)

Obsolete. Superseded by [IBody2::IGetTessellation](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTessellation( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face _  
) As Tessellation
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face  
Dim value As Tessellation  
  
value = instance.IGetTessellation(NumOfFaces, FaceList)
```

C#

```
Tessellation IGetTessellation(  
    System.int NumOfFaces,  
    ref Face FaceList  
)
```

C++/CLI

```
Tessellation^ IGetTessellation(  
& System.int NumOfFaces,  
& Face^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Visual Basic for Applications (VBA) Syntax

See [Body::IGetTessellation](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IHide Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IHide Method (IBody)

Obsolete. Superseded by [IBody2::IHide](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IHide( _  
    ByVal Part As PartDoc _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Part As PartDoc  
  
instance.IHide(Part)
```

C#

```
void IHide(  
    PartDoc Part  
)
```

C++/CLI

```
void IHide(  
& PartDoc^ Part  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Part

Visual Basic for Applications (VBA) Syntax

See [Body::IHide](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMatchedBoolean Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IMatchedBoolean Method (IBody)

Obsolete. Superseded by [IBody2::IMatchedBoolean3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IMatchedBoolean(  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As Body, _  
    ByVal NumOfMatchingFaces As System.Integer, _  
    ByRef FaceList1 As Face, _  
    ByRef FaceList2 As Face, _  
    ByRef ErrorCode As System.Integer _  
) As EnumBodies
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim OperationType As System.Integer  
Dim ToolBody As Body  
Dim NumOfMatchingFaces As System.Integer  
Dim FaceList1 As Face  
Dim FaceList2 As Face  
Dim ErrorCode As System.Integer  
Dim value As EnumBodies  
  
value = instance.IMatchedBoolean(OperationType, ToolBody, NumOfMatchingFaces, FaceList1,  
FaceList2, ErrorCode)
```

C#

```
EnumBodies IMatchedBoolean(  
    System.int OperationType,  
    Body ToolBody,  
    System.int NumOfMatchingFaces,  
    ref Face FaceList1,  
    ref Face FaceList2,  
    out System.int ErrorCode  
)
```

C++/CLI

```
EnumBodies^ IMatchedBoolean(  
& System.int OperationType,  
& Body^ ToolBody,  
& System.int NumOfMatchingFaces,  
& Face^% FaceList1,  
& Face^% FaceList2,  
& [Out] System.int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType
ToolBody
NumOfMatchingFaces
FaceList1
FaceList2
ErrorCode

Visual Basic for Applications (VBA) Syntax

See [Body::IMatchedBoolean](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IMaterialPropertyValues Property (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IMaterialPropertyValues Property (IBody)

Obsolete. Superseded by [IBody2::IMaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IMaterialPropertyValues As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim value As System.Double  
  
instance.IMaterialPropertyValues = value  
value = instance.IMaterialPropertyValues
```

C#

```
System.double IMaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.double IMaterialPropertyValues {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body::IMaterialPropertyValues](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IOperations Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IOperations Method (IBody)

Obsolete. Superseded by [IBody2::IOperations2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IOperations( _  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As Body, _  
    ByVal NumMaxSections As System.Integer, _  
    ByRef ResultingBodies As Body _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim OperationType As System.Integer  
Dim ToolBody As Body  
Dim NumMaxSections As System.Integer  
Dim ResultingBodies As Body  
Dim value As System.Integer  
  
value = instance.IOperations(OperationType, ToolBody, NumMaxSections, ResultingBodies)
```

C#

```
System.int IOperations(  
    System.int OperationType,  
    Body ToolBody,  
    System.int NumMaxSections,  
    ref Body ResultingBodies  
)
```

C++/CLI

```
System.int IOperations(  
& System.int OperationType,  
& Body^ ToolBody,  
& System.int NumMaxSections,  
& Body^% ResultingBodies  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType

ToolBody

NumMaxSections

ResultingBodies

Visual Basic for Applications (VBA) Syntax

See [Body::IOperations](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IOperations2 Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IOperations2 Method (IBody)

Obsolete. Superseded by [IBody2::IOperations2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IOperations2( _  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As Body, _  
    ByRef ErrorCode As System.Integer _  
) As EnumBodies
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim OperationType As System.Integer  
Dim ToolBody As Body  
Dim ErrorCode As System.Integer  
Dim value As EnumBodies  
  
value = instance.IOperations2(OperationType, ToolBody, ErrorCode)
```

C#

```
EnumBodies IOperations2(  
    System.int OperationType,  
    Body ToolBody,  
    out System.int ErrorCode  
)
```

C++/CLI

```
EnumBodies^ IOperations2(  
& System.int OperationType,  
& Body^ ToolBody,  
& [Out] System.int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType

ToolBody

ErrorCode

Visual Basic for Applications (VBA) Syntax

See [Body::IOperations2](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IRemoveFacesFromSheet Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : IRemoveFacesFromSheet Method (IBody)

Obsolete. Superseded by [IBody2::IRemoveFacesFromSheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IRemoveFacesFromSheet( _  
    ByVal NumOfFaces As System.Integer, _
```

```
ByVal FacesToRemove As System.IntPtr _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim NumOfFaces As System.Integer  
Dim FacesToRemove As System.IntPtr  
  
instance.RemoveFacesFromSheet(NumOfFaces, FacesToRemove)
```

C#

```
void IRemoveFacesFromSheet(  
    System.int NumOfFaces,  
    System.IntPtr FacesToRemove  
)
```

C++/CLI

```
void IRemoveFacesFromSheet(  
& System.int NumOfFaces,  
& System.IntPtr FacesToRemove  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FacesToRemove

Visual Basic for Applications (VBA) Syntax

See [Body.IRemoveFacesFromSheet](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISave Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ISave Method (IBody)

Obsolete. Superseded by [IBody2::ISave](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ISave( _  
    ByVal StreamIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim StreamIn As System.Object  
  
instance.ISave(StreamIn)
```

C#

```
void ISave(  
    System.Object StreamIn  
)
```

C++/CLI

```
void ISave(  
& System.Object^ StreamIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StreamIn

Visual Basic for Applications (VBA) Syntax

See [Body::ISave](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISectionBySheet Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ISectionBySheet Method (IBody)

Obsolete. Superseded by [IBody2::ISectionBySheet](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISectionBySheet( _  
    ByVal Sheet As Body, _  
    ByVal NumMaxSections As System.Integer, _  
    ByRef SectionedBodies As Body _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim Sheet As Body  
Dim NumMaxSections As System.Integer  
Dim SectionedBodies As Body  
Dim value As System.Integer  
  
value = instance.ISectionBySheet(Sheet, NumMaxSections, SectionedBodies)
```

C#

```
System.int ISectionBySheet(  
    Body Sheet,  
    System.int NumMaxSections,  
    ref Body SectionedBodies  
)
```

C++/CLI

```
System.int ISectionBySheet(  
& Body^ Sheet,  
& System.int NumMaxSections,  
& Body^% SectionedBodies  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Sheet
NumMaxSections
SectionedBodies

 Visual Basic for Applications (VBA) Syntax

See [Body::ISectionBySheet](#).

 See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetCurrentSurface Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ISetCurrentSurface Method (IBody)

Obsolete. Superseded by [IBody2::ISetCurrentSurface](#).

 .NET Syntax

Visual Basic (Declaration)

```
Sub ISetCurrentSurface(  
    ByVal SurfaceIn As Surface _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim SurfaceIn As Surface  
  
instance.ISetCurrentSurface(SurfaceIn)
```

C#

```
void ISetCurrentSurface(  
    Surface SurfaceIn  
)
```

C++/CLI

```
void ISetCurrentSurface(  
& Surface^ SurfaceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SurfaceIn

 Visual Basic for Applications (VBA) Syntax

See [Body::ISetCurrentSurface](#).

 See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetXform Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : ISetXform Method (IBody)

Obsolete. Superseded by [IBody2::ApplyTransform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function ISetXform( _  
    ByRef XformIn As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim XformIn As System.Double  
Dim value As System.Boolean
```

```
value = instance.ISetXform(XformIn)
```

C#

```
System.bool ISetXform(  
    ref System.double XformIn  
)
```

C++/CLI

```
System.bool ISetXform(  
& System.double% XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Visual Basic for Applications (VBA) Syntax

See [Body::ISetXform](#).

See Also

[IBody Interface](#)
[IBody Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MatchedBoolean Method (IBody)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody Interface](#) : MatchedBoolean Method (IBody)

Obsolete. Superseded by [IBody2::MatchedBoolean3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function MatchedBoolean( _  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As System.Object, _  
    ByVal NumOfMatchingFaces As System.Integer, _  
    ByVal FaceList1 As System.Object, _  
    ByVal FaceList2 As System.Object, _
```

```
ByRef ErrorCode As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody  
Dim OperationType As System.Integer  
Dim ToolBody As System.Object  
Dim NumOfMatchingFaces As System.Integer  
Dim FaceList1 As System.Object  
Dim FaceList2 As System.Object  
Dim ErrorCode As System.Integer  
Dim value As System.Object
```

```
value = instance.MatchedBoolean(OperationType, ToolBody, NumOfMatchingFaces, FaceList1, FaceList2,  
ErrorCode)
```

C#

```
System.object MatchedBoolean(  
    System.int OperationType,  
    System.object ToolBody,  
    System.int NumOfMatchingFaces,  
    System.object FaceList1,  
    System.object FaceList2,  
    out System.int ErrorCode  
)
```

C++/CLI

```
System.Object^ MatchedBoolean(  
& System.int OperationType,  
& System.Object^ ToolBody,  
& System.int NumOfMatchingFaces,  
& System.Object^ FaceList1,  
& System.Object^ FaceList2,  
& [Out] System.int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType

ToolBody

NumOfMatchingFaces

FaceList1

FaceList2

ErrorCode

Visual Basic for Applications (VBA) Syntax

See [Body:MatchedBoolean](#).

See Also

[IBody Interface](#)
[IBody Members](#)