

SOLIDWORKS API (.NET, VBA, C#) — Reference

(28/337): IBody2 (part 3 of 5)

SOLIDWORKS API Documentation (converted from CHM)

IBody2 (part 3 of 5) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectedFaceCount Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetSelectedFaceCount Method (IBody2)

Gets the number of selected faces on this body. For use with [IBody2::GetProcessedBodyWithSelfFace](#) and [IBody2::IGetProcoessedBodyWithSelfFace](#) and intended for IGES routines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectedFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Integer  
  
value = instance.GetSelectedFaceCount()
```

C#

```
System.int GetSelectedFaceCount()
```

C++/CLI

```
System.int GetSelectedFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of selected faces

Visual Basic for Applications (VBA) Syntax

See [Body2::GetSelectedFaceCount](#).

Example

[Get Selected Faces on Processed Body \(C#\)](#)
[Get Selected Faces on Processed Body \(VB.NET\)](#)
[Get Selected Faces on Processed Body \(VBA\)](#)

Remarks

Do not use this method for general selection handling. If you want to handle items selected by the user or items selected with [IModelDocExtension::SelectById2](#), use [ISelectionMgr::GetSelectedObjectCount2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetFirstSelectedFace Method](#)
[IBody2::GetNextSelectedFace Method](#)
[IBody2::IGetFirstSelectedFace Method](#)
[IBody2::IGetNextSelectedFace Method](#)
[IBody2::IGetSelectedFaces Method](#)
[IBody2::GetSelectedFaces Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectedFaces Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetSelectedFaces Method (IBody2)

Gets the selected faces. For use with [IBody2::GetProcessedBodyWithSelFace](#) and intended for IGES routines.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSelectedFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Object
```

```
value = instance.GetSelectedFaces()
```

C#

```
System.object GetSelectedFaces()
```

C++/CLI

```
System.Object^ GetSelectedFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of selected [faces](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::GetSelectedFaces](#).

Example

[Get Selected Faces on Processed Body \(C#\)](#)
[Get Selected Faces on Processed Body \(VB.NET\)](#)
[Get Selected Faces on Processed Body \(VBA\)](#)

Remarks

Do not use this method for general selection handling. If you want to handle items selected by the user or items selected with [IModelDocExtension::SelectById2](#), use [ISelectionMgr::GetSelectedObject6](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::IGetSelectedFaces Method](#)
[IBody2::GetFirstSelectedFace Method](#)
[IBody2::GetSelectedFaceCount Method](#)
[IBody2::IGetFirstSelectedFace Method](#)
[IBody2::IGetNextSelectedFace Method](#)
[IBody2::GetNextSelectedFace Method](#)
[IBody2::IGetProcessedBodyWithSelFace Method](#)
[IBody2::GetProcessedBodyWithSelFace Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSelectionId Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetSelectionId Method (IBody2)

Gets the selection ID of the body, if one exists.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSelectionId() As System.String
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.String  
  
value = instance.GetSelectionId()
```

C#

```
System.string GetSelectionId()
```

C++/CLI

```
System.String^ GetSelectionId();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Selection ID of the body

Visual Basic for Applications (VBA) Syntax

See [Body2::GetSelectionId](#).

Example

[Get Names of Bodies in MultiBody Part \(VBA\)](#)
[Select Bodies \(VBA\)](#)
[Set Body for View \(C#\)](#)
[Set Body for View \(VB.NET\)](#)
[Set Body for View \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSheetBody Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetSheetBody Method (IBody2)

Gets a sheet (surface) body in this body.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSheetBody( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Index As System.Integer  
Dim value As System.Object
```

```
value = instance.GetSheetBody(Index)
```

C#

```
System.object GetSheetBody(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetSheetBody(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Index of sheet body

Return Value

Sheet body corresponding to the index

Visual Basic for Applications (VBA) Syntax

See [Body2::GetSheetBody](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::IGetSheetBody Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTessellation Method (IBody2)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetTessellation Method (IBody2)

Gets the [ITessellation](#) object.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTessellation( _  
    ByVal FaceList As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim FaceList As System.Object  
Dim value As System.Object  
  
value = instance.GetTessellation(FaceList)
```

C#

```
System.object GetTessellation(  
    System.object FaceList  
)
```

C++/CLI

```
System.Object^ GetTessellation(  
& System.Object^ FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceList

Array of faces to tessellate; if this is empty, then SOLIDWORKS will tessellate the body

Return Value

Object for the tessellation

Visual Basic for Applications (VBA) Syntax

See [Body2::GetTessellation](#).

Example

[Create and Convert Non-manifold Bodies \(C#\)](#)
[Create and Convert Non-manifold Bodies \(VB.NET\)](#)
[Create and Convert Non-manifold Bodies \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::IGetTessellation Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTexture Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetTexture Method (IBody2)

Gets the texture applied to this body in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTexture( _  
    ByVal Config\_name As System.String _  
) As Texture
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Config_name As System.String  
Dim value As Texture  
  
value = instance.GetTexture(Config_name)
```

C#

```
Texture GetTexture(  
    System.string Config\_name  
)
```

C++/CLI

```
Texture^ GetTexture(  
& System.String^ Config_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of the configuration

Return Value

If texture is...	Then retval is...
Applied to this body in Config_name	Pointer to ITexture object
Not present	NULL

 Visual Basic for Applications (VBA) Syntax

See [Body2::GetTexture](#).

 See Also

- [IBody2 Interface](#)
- [IBody2 Members](#)
- [IBody2::RemoveTexture Method](#)
- [IBody2::SetTexture Method](#)
- [IBody2::RemoveTextureByDisplayState Method](#)
- [IBody2::SetTextureByDisplayState Method](#)
- [IModelDocExtension::CreateTexture Method](#)

 Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrackingIDs Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetTrackingIDs Method (IBody2)

Gets the [tracking IDs assigned to this body](#).

 .NET Syntax

Visual Basic (Declaration)

```
Function GetTrackingIDs( _  
    ByVal TrackingCookie As System.Integer, _  
    ByRef TrackingIDs As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim TrackingCookie As System.Integer  
Dim TrackingIDs As System.Object  
Dim value As System.Integer  
  
value = instance.GetTrackingIDs(TrackingCookie, TrackingIDs)
```

C#

```
System.int GetTrackingIDs(
    System.int TrackingCookie,
    out System.object TrackingIDs
)
```

C++/CLI

```
System.int GetTrackingIDs(
    & System.int TrackingCookie,
    [Out] System.Object^ TrackingIDs
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)
TrackingIDs
Array of tracking IDs on this body

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::GetTrackingIDs](#).

Example

[Get, Set, and Remove Tracking IDs on Body \(VBA\)](#)

Remarks

See [Tracking IDs](#) for more information.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::IGetTrackingIDs Method](#)
[IBody2::RemoveTrackingID Method](#)
[IBody2::SetTrackingID Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SolidWorks 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTrackingIDsCount Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetTrackingIDsCount Method (IBody2)

Gets the number of tracking IDs on this body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTrackingIDsCount( _
    ByVal TrackingCookie As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim TrackingCookie As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTrackingIDsCount(TrackingCookie)
```

C#

```
System.int GetTrackingIDsCount(  
    System.int TrackingCookie  
)
```

C++/CLI

```
System.int GetTrackingIDsCount(  
    & System.int TrackingCookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Return Value

Number of tracking IDs on this body

Visual Basic for Applications (VBA) Syntax

See [Body2::GetTrackingIDsCount](#).

Example

[Get, Set, and Remove Tracking IDs on Body \(VBA\)](#)

Remarks

Call this method before calling [IBody2::IGetTrackingIDs](#) to determine the size of the array for that method.

See [Tracking IDs](#) for more information.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::RemoveTrackingID Method](#)
[IBody2::SetTrackingID Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetType Method (IBody2)

Gets the type of the body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetType() As System.Integer
```

```
Dim instance As IBody2
Dim value As System.Integer

value = instance.GetType()
```

C#

```
System.int GetType()
```

C++/CLI

```
System.int GetType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Body type as defined in [swBodyType](#) [e](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::GetType](#).

Example

[Combine Assembly Components into Part \(VBA\)](#)
[Get Differences Between Parts \(VBA\)](#)
[Get Mirror Solid Data \(VBA\)](#)
[Get Names of Bodies in MultiBody Part \(VBA\)](#)
[Select Bodies \(VBA\)](#)
[Tessellate a Body \(C#\)](#)
[Tessellate a Body \(VB.NET\)](#)
[Tessellate a Body \(VBA\)](#)
[Fill Holes in Part \(C#\)](#)
[Fill Holes in Part \(VB.NET\)](#)
[Fill Holes in Part \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetUpdateStamp Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetUpdateStamp Method (IBody2)

Gets the update stamp for the body as of the last rebuild.

.NET Syntax

Visual Basic (Declaration)

```
Function GetUpdateStamp() As System.Integer
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IBody2
Dim value As System.Integer

value = instance.GetUpdateStamp()
```

C#

```
System.int GetUpdateStamp()
```

C++/CLI

```
System.int GetUpdateStamp();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Update stamp

Visual Basic for Applications (VBA) Syntax

See [Body2::GetUpdateStamp](#).

Remarks

The update stamp is not changed if the features contributing to the body geometry have not been rebuilt.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertexCount Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetVertexCount Method (IBody2)

Gets the number of vertices in this body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Integer  
  
value = instance.GetVertexCount()
```

C#

```
System.int GetVertexCount()
```

C++/CLI

```
System.int GetVertexCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of vertices in this body

Visual Basic for Applications (VBA) Syntax

See [Body2::GetVertexCount](#).

Remarks

Call this method before calling [IBody2::!GetVertices](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetVertices Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : GetVertices Method (IBody2)

Gets the vertices in this body.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertices() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Object  
  
value = instance.GetVertices()
```

C#

```
System.object GetVertices()
```

C++/CLI

```
System.Object^ GetVertices();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [vertices](#) in this body

Visual Basic for Applications (VBA) Syntax

See [Body2::GetVertices](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IGetVertices Method](#)
[GetVertexCount Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasMaterialPropertyValues Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : HasMaterialPropertyValues Method (IBody2)

Gets whether this body has an appearance.

.NET Syntax

Visual Basic (Declaration)

Function HasMaterialPropertyValues() As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Boolean  
  
value = instance.HasMaterialPropertyValues()
```

C#

```
System.bool HasMaterialPropertyValues()
```

C++/CLI

```
System.bool HasMaterialPropertyValues();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this body has an appearance, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::HasMaterialPropertyValues](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::MaterialPropertyValues2 Property \(\)](#)
[IBody2::RemoveMaterialProperty Method \(\)](#)
[IBody2::SetMaterialProperty Method \(\)](#)
[IBody2::GetMaterialPropertyName Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Hide Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Hide Method (IBody2)

Hides this temporary body in the context of the specified part.

.NET Syntax

Visual Basic (Declaration)

```
Sub Hide( _  
    ByVal Part As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Part As System.Object  
  
instance.Hide(Part)
```

C#

```
void Hide(  
    System.object Part  
)
```

C++/CLI

```
void Hide(  
& System.Object^ Part  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Part
[IModelDoc2](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::Hide](#).

Example

[Cut Body in Half Using Macro Feature \(VBA\)](#)
[Create and Convert Non-manifold Bodies \(C#\)](#)
[Create and Convert Non-manifold Bodies \(VB.NET\)](#)
[Create and Convert Non-manifold Bodies \(VBA\)](#)

Remarks

While SOLIDWORKS is displaying your IBody2 object using [IBody2::Display3](#), you cannot release it explicitly or implicitly. Before releasing or allowing your IBody2 object to be released, you must call this method to prevent it from being displayed.

COM applications should avoid explicitly releasing the IBody2 object by calling IBody2->Release() while it is being displayed by SOLIDWORKS. Dispatch applications should avoid allowing the IBody2 object to go out of scope while it is being displayed by SOLIDWORKS, and be destroyed when the ReleaseDispatch method is called automatically. Dispatch applications should also avoid explicitly releasing the IBody2 object by calling ReleaseDispatch while it is being displayed by SOLIDWORKS.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::IHide Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

HideBody Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : HideBody Method (IBody2)

Hides or shows this body.

.NET Syntax

Visual Basic (Declaration)

```
Sub HideBody( _  
    ByVal BHide As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim BHide As System.Boolean  
  
instance.HideBody(BHide)
```

C#

```
void HideBody(  
    System.bool BHide
```



)

C++/CLI

```
void HideBody(  
& System.bool BHide  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BHide

True to hide the body, false to show the body

Visual Basic for Applications (VBA) Syntax

See [Body2::HideBody](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IFeatureManager::ShowBodies Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddProfileArc Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileArc Method (IBody2)

Creates an arc profile curve and returns a pointer to that curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileArc( _  
    ByVal Center As System.Object, _  
    ByVal Axis As System.Object, _  
    ByVal Radius As System.Double, _  
    ByVal StartPoint As System.Object, _  
    ByVal EndPoint As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Center As System.Object  
Dim Axis As System.Object  
Dim Radius As System.Double  
Dim StartPoint As System.Object  
Dim EndPoint As System.Object  
Dim value As Curve
```

```
value = instance.IAddProfileArc(Center, Axis, Radius, StartPoint, EndPoint)
```

C#

```
Curve IAddProfileArc(
    System.object Center,
    System.object Axis,
    System.double Radius,
    System.object StartPoint,
    System.object EndPoint
)
```

C++/CLI

```
Curve^ IAddProfileArc(
    & System.Object^ Center,
    & System.Object^ Axis,
    & System.double Radius,
    & System.Object^ StartPoint,
    & System.Object^ EndPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Center
Array of 3 doubles (x,y,z)

Axis
Array of 3 doubles (x,y,z)

Radius
Arc radius

StartPoint
Array of 3 doubles (x,y,z)

EndPoint
Array of 3 doubles (x,y,z)

Return Value

[ICurve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddProfileArc](#).

Example

[Create Imported Surface Body from Sketch \(C#\)](#)

Remarks

This method always creates a full circle.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::AddProfileArc Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddProfileArcDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileArcDLL Method (IBody2)

Adds a profile arc.

Visual Basic (Declaration)

```
Function IAddProfileArcDLL( _
    ByRef Center As System.Double, _
    ByRef Axis As System.Double, _
    ByVal Radius As System.Double, _
    ByRef StartPoint As System.Double, _
    ByRef EndPoint As System.Double _
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Center As System.Double
Dim Axis As System.Double
Dim Radius As System.Double
Dim StartPoint As System.Double
Dim EndPoint As System.Double
Dim value As Curve

value = instance.IAddProfileArcDLL(Center, Axis, Radius, StartPoint, EndPoint)
```

C#

```
Curve IAddProfileArcDLL(
    ref System.double Center,
    ref System.double Axis,
    System.double Radius,
    ref System.double StartPoint,
    ref System.double EndPoint
)
```

C++/CLI

```
Curve^ IAddProfileArcDLL(
    & System.double% Center,
    & System.double% Axis,
    & System.double Radius,
    & System.double% StartPoint,
    & System.double% EndPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Center
Pointer to an array of 3 doubles (x,y,z)

Axis
Pointer to an array of 3 doubles (x,y,z)

Radius
Radius of the arc

StartPoint
Pointer to an array of 3 doubles (x,y,z)

EndPoint
Pointer to an array of 3 doubles (x,y,z)

Return Value

Pointer to the arc profile [curve](#)

See [Body2::IAddProfileArcDLL](#).

Availability

SOLIDWORKS 2001Plus FCS, Revision 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileBspline Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileBspline Method (IBody2)

Creates an B-spline profile curve and returns a pointer to that curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileBspline( _  
    ByVal Props As System.Object, _  
    ByVal Knots As System.Object, _  
    ByVal CtrlPtCoords As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Props As System.Object  
Dim Knots As System.Object  
Dim CtrlPtCoords As System.Object  
Dim value As Curve  
  
value = instance.IAddProfileBspline(Props, Knots, CtrlPtCoords)
```

C#

```
Curve IAddProfileBspline(  
    System.object Props,  
    System.object Knots,  
    System.object CtrlPtCoords  
)
```

C++/CLI

```
Curve^ IAddProfileBspline(  
& System.Object^ Props,  
& System.Object^ Knots,  
& System.Object^ CtrlPtCoords  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Props
Contains four integers packed into two double elements (see **Remarks**)
Knots
Array of numKnots (see **Remarks**)
CtrlPtCoords
Array of numCtrlPtCoord (see **Remarks**)

Return Value

[ICurve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddProfileBspline](#).

Remarks

You can use this method with [IBody2::ICreateRevolutionSurface](#) to generate any surface of revolution or with [IBody2::ICreateExtrusionSurface](#) to generate a tabulated cylinder.

The Props argument contains the following values:

- DimensionControlPoints
- Order
- NumCtrlPoints
- Periodicity

The length of the knots array is given by:

numKnots = NumCtrlPoints + Order

The length of the CtrlPtCoords is given by:

numCtrlPtCoord = NumCtrlPoints + DimensionControlPoints

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::AddProfileBspline Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddProfileBsplineByPts Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileBsplineByPts Method (IBody2)

Adds a profile B-spline.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileBsplineByPts( _  
    ByVal NumPoints As System.Integer, _  
    ByRef PointArray As System.Double _  
    ) As Curve
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim NumPoints As System.Integer  
Dim PointArray As System.Double  
Dim value As Curve  
  
value = instance.IAddProfileBsplineByPts(NumPoints, PointArray)
```

C#

```
Curve IAddProfileBsplineByPts(  
    System.int NumPoints,  
    ref System.double PointArray  
)
```

C++/CLI

```
Curve^ IAddProfileBsplineByPts(  
& System.int NumPoints,  
& System.double% PointArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumPoints

Number of B-spline points

PointArray

0-based array of 3 * NumPoints doubles

Return Value

Pointer to the profile B-spline, [ICurve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddProfileBsplineByPts](#).

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

[IBody2::AddProfileBsplineByPts Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddProfileBsplineDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileBsplineDLL Method (IBody2)

Adds a profile B-spline.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileBsplineDLL( _  
    ByRef Properties As System.Integer, _  
    ByRef KnotArray As System.Double, _  
    ByRef ControlPointCoordArray As System.Double _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Properties As System.Integer  
Dim KnotArray As System.Double  
Dim ControlPointCoordArray As System.Double  
Dim value As Curve  
  
value = instance.IAddProfileBsplineDLL(Properties, KnotArray, ControlPointCoordArray)
```

C#

```
Curve IAddProfileBsplineDLL(  
    ref System.int Properties,  
    ref System.double KnotArray,  
    ref System.double ControlPointCoordArray  
)
```

C++/CLI

```
Curve^ IAddProfileBsplineDLL(  
& System.int% Properties,  
& System.double% KnotArray,  
& System.double% ControlPointCoordArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Properties

Contains 4 longs (see **Remarks**)

KnotArray

Pointer to an array of numKnots doubles (see **Remarks**)

ControlPointCoordArray

Pointer to an array of numCtrlPtCoord doubles (see **Remarks**)

Return Value

Pointer to the profile B-spline [curve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddProfileBsplineDLL](#).

Remarks

You can use this method with [IBody2::ICreateRevolutionSurface](#) to generate any surface of revolution or with [IBody2::ICreateExtrusionSurface](#) to generate a tabulated cylinder.

The Properties argument contains the following values:

- DimensionControlPoints
- Order
- NumCtrlPoints
- Periodicity

The length of the KnotArray argument is:

$$\text{numKnots} = \text{NumCtrlPoints} + \text{Order}$$

The length of the ControlPointCoordArray is:

$$\text{numCtrlPtCoord} = \text{NumCtrlPoints} * \text{DimensionControlPoints}$$

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddProfileLine Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileLine Method (IBody2)

Creates a line profile curve and returns a pointer to that curve.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileLine( _  
    ByVal RootPoint As System.Object, _  
    ByVal Direction As System.Object _  
) As Curve
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim RootPoint As System.Object  
Dim Direction As System.Object  
Dim value As Curve
```

```
value = instance.IAddProfileLine(RootPoint, Direction)
```

C#

```
Curve IAddProfileLine(  
    System.Object RootPoint,  
    System.Object Direction  
)
```

C++/CLI

```
Curve^ IAddProfileLine(  
& System.Object^ RootPoint,  
& System.Object^ Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint

Array of 3 doubles (x,y,z)

Direction

Array of 3 doubles (x,y,z)

Return Value

Line profile, [ICurve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddProfileLine](#).

Example

[Create Imported Surface Body from Sketch \(C#\)](#)

Remarks

You can use this method with [IBody2::ICreateRevolutionSurface](#) to generate a cylindrical surface of revolution or with [IBody2::ICreateExtrusionSurface](#) to generate a tabulated cylinder.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::AddProfileLine Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAddProfileLineDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddProfileLineDLL Method (IBody2)

Adds a profile line.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddProfileLineDLL(  
    ByRef RootPoint As System.Double, _  
    ByRef Direction As System.Double _  
) As Curve
```

Visual Basic (Usage)



```

Dim instance As IBody2
Dim RootPoint As System.Double
Dim Direction As System.Double
Dim value As Curve

value = instance.IAddProfileLineDLL(RootPoint, Direction)

```

C#

```

Curve IAddProfileLineDLL(
    ref System.double RootPoint,
    ref System.double Direction
)

```

C++/CLI

```

Curve^ IAddProfileLineDLL(
    & System.double% RootPoint,
    & System.double% Direction
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint

Pointer to an array of 3 doubles (x,y,z)

Direction

Pointer to an array of 3 doubles (x,y,z)

Return Value

Pointer to the profile line [curve](#)

Visual Basic for Applications (VBA) Syntax

See [Body2.IAddProfileLineDLL](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAddVertexPoint Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IAddVertexPoint Method (IBody2)

Adds a vertex.

.NET Syntax

Visual Basic (Declaration)

```

Function IAddVertexPoint( _
    ByRef Point As System.Double _
) As Vertex

```

Visual Basic (Usage)

```

Dim instance As IBody2
Dim Point As System.Double
Dim value As Vertex

```



```
value = instance.IAddVertexPoint(Point)
```

C#

```
Vertex IAddVertexPoint(  
    ref System.double Point  
)
```

C++/CLI

```
Vertex^ IAddVertexPoint(  
& System.double% Point  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Point
Vertex to add

Return Value

[IVertex](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::IAddVertexPoint](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::AddVertexPoint Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICombineVolumes Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICombineVolumes Method (IBody2)

Combines the volumes of two bodies.

.NET Syntax

Visual Basic (Declaration)

```
Sub ICombineVolumes( _  
    ByVal ToolBody As Body2 _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim ToolBody As Body2  
  
instance.ICombineVolumes(ToolBody)
```

C#

```
void ICombineVolumes(  
    Body2 ToolBody  
)
```

C++/CLI

```
void ICombineVolumes(  
& Body2^ ToolBody  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ToolBody

Pointer to the [body](#) to be used as the tool

Visual Basic for Applications (VBA) Syntax

See [Body2::ICombineVolumes](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICopy Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICopy Method (IBody2)

Gets a copy of this body.

.NET Syntax

Visual Basic (Declaration)

```
Function ICopy() As Body2
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim value As Body2  
  
value = instance.ICopy()
```

C#

```
Body2 ICopy()
```

C++/CLI

```
Body2^ ICopy();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Copied [IBody2](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICopy](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::Copy Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBaseFeature Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBaseFeature Method (IBody2)

Creates a base feature for the imported body.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICreateBaseFeature( _  
    ByVal BodyIn As Body2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim BodyIn As Body2  
Dim value As System.Boolean  
  
value = instance.ICreateBaseFeature(BodyIn)
```

C#

```
System.bool ICreateBaseFeature(  
    Body2 BodyIn  
)
```

C++/CLI

```
System.bool ICreateBaseFeature(  
& Body2^ BodyIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

BodyIn
[Body](#), on which to create base feature

Return Value

True if the base feature was created, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateBaseFeature](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateBaseFeature Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBlendSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBlendSurface Method (IBody2)

Creates a constant radius rolling-ball blend surface (also known as a pipe surface) between two side surfaces.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBlendSurface( _  
    ByVal Surface1 As Surface, _  
    ByVal Range1 As System.Double, _  
    ByVal Surface2 As Surface, _  
    ByVal Range2 As System.Double, _  
    ByRef StartVec As System.Double, _  
    ByRef EndVec As System.Double, _  
    ByVal HaveHelpVec As System.Integer, _  
    ByRef HelpVec As System.Double, _  
    ByVal HaveHelpBox As System.Integer, _  
    ByRef HelpBox As System.Double _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Surface1 As Surface  
Dim Range1 As System.Double  
Dim Surface2 As Surface  
Dim Range2 As System.Double  
Dim StartVec As System.Double  
Dim EndVec As System.Double  
Dim HaveHelpVec As System.Integer  
Dim HelpVec As System.Double  
Dim HaveHelpBox As System.Integer  
Dim HelpBox As System.Double  
Dim value As Surface
```

```
value = instance.ICreateBlendSurface(Surface1, Range1, Surface2, Range2, StartVec, EndVec,  
HaveHelpVec, HelpVec, HaveHelpBox, HelpBox)
```

C#

```
Surface ICreateBlendSurface(  
    Surface Surface1,  
    System.double Range1,  
    Surface Surface2,  
    System.double Range2,  
    ref System.double StartVec,  
    ref System.double EndVec,  
    System.int HaveHelpVec,  
    ref System.double HelpVec,  
    System.int HaveHelpBox,  
    ref System.double HelpBox  
)
```

C++/CLI

```
Surface^ ICreateBlendSurface(  
& Surface^ Surface1,  
& System.double Range1,  
& Surface^ Surface2,  
& System.double Range2,  
& System.double% StartVec,  
& System.double% EndVec,  
& System.int HaveHelpVec,  
& System.double% HelpVec,  
& System.int HaveHelpBox,  
& System.double% HelpBox  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Surface1
First side [surface](#)
Range1
Signed offset of Surface1

Surface2
Second side [surface](#)
Range2
Signed offset of Surface2

StartVec
Array of 3 doubles representing a point close to the start of the blend spine

EndVec
Array of 3 doubles representing a point close to the end of the blend spine

HaveHelpVec
Optional; True if help vector is provided

HelpVec
Array of 3 doubles representing the direction of the help vector

HaveHelpBox
Optional; True if box is provided

HelpBox
Array of 6 doubles bounding the area of interest

Return Value

Newly created [surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateBlendSurface](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateBlendSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBodyFromFaces Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBodyFromFaces Method (IBody2)

Creates a temporary body from the faces.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateBodyFromFaces( _  
    ByVal NumOfFaces As System.Integer, _  
    ByVal FaceList As System.Object _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim NumOfFaces As System.Integer  
Dim FaceList As System.Object  
Dim value As Body2
```

```
value = instance.ICreateBodyFromFaces(NumOfFaces, FaceList)
```

C#

```
Body2 ICreateBodyFromFaces(  
    System.int NumOfFaces,
```

```
System.Object FaceList
)
```

C++/CLI

```
Body2^ ICreateBodyFromFaces(
& System.int NumOfFaces,
& System.Object^ FaceList
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

Number of faces to use to create the body

FaceList

Array containing the faces to use to create the body

Return Value

[IBody2](#) object

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateBodyFromFaces](#).

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

[IBody2::CreateBodyFromFaces Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateBoundedSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBoundedSurface Method (IBody2)

Creates a bounded surface from an independent base surface.

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreateBoundedSurface( _
    ByVal UOpt As System.Boolean, _
    ByVal VOpt As System.Boolean, _
    ByRef UvParams As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As IBody2
Dim UOpt As System.Boolean
Dim VOpt As System.Boolean
Dim UvParams As System.Double
```

```
instance.ICreateBoundedSurface(UOpt, VOpt, UvParams)
```

C#

```
void ICreateBoundedSurface(
    System.bool UOpt,
    System.bool VOpt,
    ref System.double UvParams
)
```



```
void ICreateBoundedSurface(
& System.bool UOpt,
& System.bool VOpt,
& System.double% UvParams
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UOpt

True if U parameter range is given in uvData, false for the entire U parameter range

VOpt

True if V parameter range is given in uvData, false for the entire V parameter range

UvParams

Array of 4 doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateBoundedSurface](#).

Remarks

Before you use this method, you must call one of the base surface creation methods, such as [IBody2::ICreateBsplineSurface](#).

The UOpt and VOpt arguments allow the application to supply parameter range information so that a bounded surface can be made up from part of the base surface. If UOpt and VOpt are both set to false, then SOLIDWORKS uses the entire parameter ranges. This method fails for surface with infinite parameter ranges.

UvParams contains 4 doubles describing the UV parameter ranges.

U parameter range	<i>uvData[0]</i> and <i>uvData[1]</i> ; <i>UvData[0]</i> must be less than <i>uvData[1]</i>
V parameter range	<i>uvData[2]</i> and <i>uvData[3]</i> ; <i>UvData[2]</i> must be less than <i>uvData[3]</i>

To construct a solid body from bounded surfaces, call [IPartDoc::ICreateNewBody2](#) first, which arranges for a placeholder for this bounded surface.

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

[IBody2::CreateBoundedSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBsplineSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBsplineSurface Method (IBody2)

Creates a new B-spline surface.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICreateBsplineSurface( _
    ByVal Props As System.Object, _
    ByVal UKnots As System.Object, _
    ByVal VKnots As System.Object, _
    ByVal CtrlPtCoords As System.Object _
) As Surface
```

Visual Basic (Usage)



```

Dim instance As IBody2
Dim Props As System.Object
Dim UKnots As System.Object
Dim VKnots As System.Object
Dim CtrlPtCoords As System.Object
Dim value As Surface

value = instance.ICreateBsplineSurface(Props, UKnots, VKnots, CtrlPtCoords)

```

C#

```

Surface ICreateBsplineSurface(
    System.object Props,
    System.object UKnots,
    System.object VKnots,
    System.object CtrlPtCoords
)

```

C++/CLI

```

Surface^ ICreateBsplineSurface(
    & System.Object^ Props,
    & System.Object^ UKnots,
    & System.Object^ VKnots,
    & System.Object^ CtrlPtCoords
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Props
 Array containing 8 integers (see **Remarks**)
UKnots
 Array of numUKnots (see **Remarks**)
VKnots
 Array of numVKnots (see **Remarks**)
CtrlPtCoords
 Array of numCtrlPtCoord (see **Remarks**)

Return Value

[ISurface](#) object

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateBsplineSurface](#).

Remarks

You can use this method with trimming curve creation routines (for example, [ISurface::IAddTrimmingLoop2](#)) to construct a trimmed surface.

The Props array contains the following elements. These are integers packed into a double array in the Dispatch version.

- Uorder, Vorder
- numV_CtrlPoints, numU_CtrlPoints
- Uperiodicity, Vperiodicity
- DimensionControlPoints, UNUSED (set =0)

The number of elements in the UKnots array is given by:

$$\text{numUKnots} = \text{numU_CtrlPoints} + \text{Uorder}$$

The number of elements in the VKnots array is given by:

$$\text{numVKnots} = \text{numV_CtrlPoints} + \text{Vorder}$$

The number of elements in the ctrlPtCoords array is given by:

$$\text{numCtrlPtCoord} = (\text{NumV_CtrlPoints} * \text{NumU_CtrlPoints} * \text{DimensionControlPoints})$$

NOTE: The order of the UV control points are reversed if you used [ISurface::GetBSurfParams3](#) or [ISurface::IGetBSurfParams](#) to get the data. You do not need to reverse the UV control points; instead, you can switch the UV knots and related parameters.

For periodics, the first knot must have multiplicity = 1 and all excess multiplicity must be imposed on the last knot. Therefore, a valid periodic knv vector would be { 0, 1, 2, 3, 3, 3 } for a cubic curve. The control point on the seam of the closed curve cannot be replicated at both ends; it should occur only at the beginning.

To convert from a clamped periodic curve (numKnots = numCtrlPts + Order, ctrlPts replicated, knot multiplicity = order at each end) to a SOLIDWORKS periodic curve, remove all but one of the knots at the beginning of the vector and remove one at the end. Also remove the last control point to avoid the point replication.

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateBsplineSurface Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateBsplineSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateBsplineSurfaceDLL Method (IBody2)

Creates a B-spline surface in this body.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ICreateBsplineSurfaceDLL( _  
    ByRef Properties As System.Integer, _  
    ByRef UKnotArray As System.Double, _  
    ByRef VKnotArray As System.Double, _  
    ByRef ControlPointCoordArray As System.Double _  
    ) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Properties As System.Integer  
Dim UKnotArray As System.Double  
Dim VKnotArray As System.Double  
Dim ControlPointCoordArray As System.Double  
Dim value As Surface  
  
value = instance.ICreateBsplineSurfaceDLL(Properties, UKnotArray, VKnotArray,  
ControlPointCoordArray)
```

C#

```
Surface ICreateBsplineSurfaceDLL(  
    ref System.int Properties,  
    ref System.double UKnotArray,  
    ref System.double VKnotArray,  
    ref System.double ControlPointCoordArray  
)
```

C++/CLI

```
Surface^ ICreateBsplineSurfaceDLL(  
& System.int% Properties,  
& System.double% UKnotArray,  
& System.double% VKnotArray,  
& System.double% ControlPointCoordArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Properties

Contains 8 longs (see **Remarks**)

UKnotArray

Array of numUKnots doubles (see **Remarks**)

VKnotArray

Array of numVKnots doubles (see **Remarks**)

ControlPointCoordArray

Array of numCtrlPtCoord doubles (see **Remarks**)

Return Value

New B-spline [surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateB splineSurfaceDLL](#).

Remarks

You can use this method with trimming curve creation routines (for example, [ISurface::AddTrimmingLoop2](#)) to construct a trimmed surface.

The Properties argument contains the following elements. These are integers packed into a double array in the Dispatch version.

- Uorder, Vorder
- numV_CtrlPoints, numU_CtrlPoints
- Uperiodicity, Vperiodicity
- DimensionControlPoints, UNUSED (set = 0)

The number of elements in UKnotArray is:

$\text{numUKnots} = \text{numU_CtrlPoints} + \text{Uorder}$

The number of elements in VKnotArray is:

$\text{numVKnots} = \text{numV_CtrlPoints} + \text{Vorder}$

The number of elements in ControlPointCoordArray is :

$\text{numCtrlPtCoord} = (\text{NumV_CtrlPoints} * \text{NumU_CtrlPoints} * \text{DimensionControlPoints})$

NOTE: The order of the UV control points are reversed if you used [ISurface::GetBSurfParams3](#) or [ISurface::IGetBSurfParams](#) to get the data. You do not need to reverse the UV control points; instead, you can switch the UV knots and related parameters.

For periodics, the first knot must have multiplicity = 1 and all excess multiplicity must be imposed on the last knot. Therefore, a valid periodic knv vector would be { 0, 1, 2, 3, 3, 3 } for a cubic curve. The control point on the seam of the closed curve cannot be replicated at both ends; it should occur only at the beginning.

To convert a clamped periodic curve (numKnots = numCtrlPts + Order, ctrlPts replicated, knot multiplicity = order at each end) to a SOLIDWORKS periodic curve, remove all but one of the knots at the beginning of the vector and remove one at the end. Also, remove the last control point to avoid the point replication.

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateExtrusionSurface Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateExtrusionSurface Method (IBody2)

Creates a new surface of extrusion (infinitely long tabulated cylinder).

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateExtrusionSurface( _  
    ByVal ProfileCurve As Curve, _  
    ByVal AxisDirection As System.Object _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim ProfileCurve As Curve  
Dim AxisDirection As System.Object  
Dim value As Surface  
  
value = instance.ICreateExtrusionSurface(ProfileCurve, AxisDirection)
```

C#

```
Surface ICreateExtrusionSurface(  
    Curve ProfileCurve,  
    System.object AxisDirection  
)
```

C++/CLI

```
Surface^ ICreateExtrusionSurface(  
& Curve^ ProfileCurve,  
& System.Object^ AxisDirection  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve

[ICurve](#) object

AxisDirection

Array of 3 doubles (x,y,z)

Return Value

[ISurface](#) object

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateExtrusionSurface](#).

Example

[Create Imported Surface Body from Sketch \(C#\)](#)

Remarks

You can use this method with:

- A set of related functions that construct a body from trimmed surfaces. The profile curve is extruded along the direction vector of axis direction, the new surface being the envelope of the curve. The profile curve must be of type line, circle, or B-spline curve.
- Trimming curve creation routines (for example [ISurface::!AddTrimmingLoop2](#)) to construct a trimmed tabulated cylinder.

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateExtrusionSurface Method](#)

Availability

ICreateExtrusionSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateExtrusionSurfaceDLL Method (IBody2)

Creates an extruded surface.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateExtrusionSurfaceDLL( _  
    ByVal ProfileCurve As Curve, _  
    ByRef AxisDirection As System.Double _  
    ) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim ProfileCurve As Curve  
Dim AxisDirection As System.Double  
Dim value As Surface  
  
value = instance.ICreateExtrusionSurfaceDLL(ProfileCurve, AxisDirection)
```

C#

```
Surface ICreateExtrusionSurfaceDLL(  
    Curve ProfileCurve,  
    ref System.double AxisDirection  
)
```

C++/CLI

```
Surface^ ICreateExtrusionSurfaceDLL(  
& Curve^ ProfileCurve,  
& System.double% AxisDirection  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve
Pointer to the profile [curve](#)
AxisDirection
Array of 3 doubles (x,y,z)

Return Value

Pointer to the new [surface](#) of extrusion (tabulated cylinder)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateExtrusionSurfaceDLL](#).

Remarks

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

ICreateNewSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateNewSurface Method (IBody2)

Creates a handle for a new surface to serve as geometry for a face to be added to the body.

.NET Syntax

Visual Basic (Declaration)

Function ICreateNewSurface() As Surface

Visual Basic (Usage)



```
Dim instance As IBody2
Dim value As Surface

value = instance.ICreateNewSurface()
```

C#

Surface ICreateNewSurface()

C++/CLI

Surface^ ICreateNewSurface();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISurface](#) object

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateNewSurface](#).

Remarks

This method is the first in a set of related functions that construct a body from trimmed surfaces. Internally, this function also creates a list that SOLIDWORKS uses as a place-holder for trimming curves used to trim the surface to the desired shape.

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateNewSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreateOffsetSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateOffsetSurface Method (IBody2)

Creates a new surface offset from an existing surface.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateOffsetSurface( _
    ByVal SurfaceIn As Surface, _
```

```
ByVal Distance As System.Double _  
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim SurfaceIn As Surface  
Dim Distance As System.Double  
Dim value As Surface  
  
value = instance.ICreateOffsetSurface(SurfaceIn, Distance)
```

C#

```
Surface ICreateOffsetSurface(  
    Surface SurfaceIn,  
    System.double Distance  
)
```

C++/CLI

```
Surface^ ICreateOffsetSurface(  
& Surface^ SurfaceIn,  
& System.double Distance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SurfaceIn
[Surface](#) from which to offset the new surface
Distance
Offset distance

Return Value

Newly created offset [surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateOffsetSurface](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateOffsetSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreatePlanarSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreatePlanarSurface Method (IBody2)

Creates a new infinite planar surface.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreatePlanarSurface(  
    ByVal VRootPoint As System.Object, _  
    ByVal VNormal As System.Object _  
) As Surface
```

Visual Basic (Usage)



```

Dim instance As IBody2
Dim VRootPoint As System.Object
Dim VNormal As System.Object
Dim value As Surface

value = instance.ICreatePlanarSurface(VRootPoint, VNormal)

```

C#

```

Surface ICreatePlanarSurface(
    System.Object VRootPoint,
    System.Object VNormal
)

```

C++/CLI

```

Surface^ ICreatePlanarSurface(
    & System.Object^ VRootPoint,
    & System.Object^ VNormal
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VRootPoint
Array of 3 doubles (x,y,z)

VNormal
Array of 3 doubles (x,y,z)

Return Value

New planar [surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreatePlanarSurface](#).

Remarks

You can use this method with:

- A set of related functions that construct a body from trimmed surfaces.
- Trimming curve creation routines (for example, [ISurface::IAddTrimmingLoop2](#)) to construct a trimmed surface.

To create a planar trimmed surface directly from the vertex points, see [IBody2::ICreatePlanarTrimSurfaceDLL](#).

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreatePlanarSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreatePlanarSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreatePlanarSurfaceDLL Method (IBody2)

Creates a planar surface.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreatePlanarSurfaceDLL( _  
    ByRef RootPoint As System.Double, _  
    ByRef Normal As System.Double _  
    ) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim RootPoint As System.Double  
Dim Normal As System.Double  
Dim value As Surface  
  
value = instance.ICreatePlanarSurfaceDLL(RootPoint, Normal)
```

C#

```
Surface ICreatePlanarSurfaceDLL(  
    ref System.double RootPoint,  
    ref System.double Normal  
)
```

C++/CLI

```
Surface^ ICreatePlanarSurfaceDLL(  
& System.double% RootPoint,  
& System.double% Normal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RootPoint
Pointer to an array of 3 doubles (x,y,z)
Normal
Pointer to an array of 3 doubles (x,y,z)

Return Value

Pointer to the new planar surface

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreatePlanarSurfaceDLL](#).

Remarks

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICreatePlanarTrimSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreatePlanarTrimSurfaceDLL Method (IBody2)

Creates a planar trim surface for this body.

.NET Syntax

Visual Basic (Declaration)

```
Sub ICreatePlanarTrimSurfaceDLL( _
    ByVal VertexCount As System.Integer, _
    ByRef Points As System.Double, _
    ByRef Normal As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim VertexCount As System.Integer
Dim Points As System.Double
Dim Normal As System.Double

instance.ICreatePlanarTrimSurfaceDLL(VertexCount, Points, Normal)
```

C#

```
void ICreatePlanarTrimSurfaceDLL(
    System.int VertexCount,
    ref System.double Points,
    ref System.double Normal
)
```

C++/CLI

```
void ICreatePlanarTrimSurfaceDLL(
    & System.int VertexCount,
    & System.double% Points,
    & System.double% Normal
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

VertexCount

Number of vertices

Points

Pointer to an array of doubles describing the points for the surface; trim curves are automatically created between each sequential vertex

Normal

Pointer to an array of normal vectors for the surface

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreatePlanarTrimSurfaceDLL](#).

Remarks

You can use this method instead of [IBody2::CreateTrimmedSurface](#), [IBody2::ICreatePlanarSurface](#), and [ISurface::IAddTrimmingLoop2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreatePlanarTrimSurfaceDLL Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreatePsplineSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreatePsplineSurfaceDLL Method (IBody2)

Creates a B-surface from a piecewise surface.

Visual Basic (Declaration)

```
Function ICreatePsplineSurfaceDLL( _
    ByVal Dim As System.Integer, _
    ByVal UOrder As System.Integer, _
    ByVal VOrder As System.Integer, _
    ByVal Ncol As System.Integer, _
    ByVal Nrow As System.Integer, _
    ByRef Coeffs As System.Double, _
    ByVal Basis As System.Integer, _
    ByRef Xform As System.Double, _
    ByVal ScaleFactor As System.Double _
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Dim As System.Integer
Dim UOrder As System.Integer
Dim VOrder As System.Integer
Dim Ncol As System.Integer
Dim Nrow As System.Integer
Dim Coeffs As System.Double
Dim Basis As System.Integer
Dim Xform As System.Double
Dim ScaleFactor As System.Double
Dim value As Surface

value = instance.ICreatePsplineSurfaceDLL(Dim, UOrder, VOrder, Ncol, Nrow, Coeffs, Basis, Xform, ScaleFactor)
```

C#

```
Surface ICreatePsplineSurfaceDLL(
    System.int Dim,
    System.int UOrder,
    System.int VOrder,
    System.int Ncol,
    System.int Nrow,
    ref System.double Coeffs,
    System.int Basis,
    ref System.double Xform,
    System.double ScaleFactor
)
```

C++/CLI

```
Surface^ ICreatePsplineSurfaceDLL(
    & System.int Dim,
    & System.int UOrder,
    & System.int VOrder,
    & System.int Ncol,
    & System.int Nrow,
    & System.double% Coeffs,
    & System.int Basis,
    & System.double% Xform,
    & System.double ScaleFactor
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Dim

Dimension of the surface:

- 3 = nonrational
- 4 = rational

UOrder

Order in U

VOrder

Order in V
Ncol
 Number of patches in U
Nrow
 Number of patches in V
Coeffs
 Coefficient array in the order that the Parasolid Kernel Interface routine CRPWPS needs them
Basis
 Representation method; current default is polynomial
Xform
 Transform to apply to the new surface
ScaleFactor
 Units-of-measure scaling

Return Value

Newly created B-[surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreatePspineSurfaceDLL](#).

Remarks

This method creates a B-surface from piecewise data.

As per Parasolid, The following ways to represent the data are available:

- Hermite (cubic only) (basis = 13651)
- Bezier (basis = 13652)
- Polynomial (basis = 13653)
- Taylor series (basis = 13654)

Dimension of coefficient vectors dim:

- For rational surfaces Dim = 4
- For non-rational surfaces Dim = 3

Order of each patch of the surface in u, Uorder, and in v, Vorder:

The order of the surface = degree + 1.

- The minimum order is 2.
- If the Hermite basis is used (basis = 13651) then the surface has to be bicubic (Uorder = Vorder = 4).

Number of columns Ncol: There must be at least one column.

Number of rows Nrow: There must be at least one row.

Coefficient data Coeffs:

- Contains (Uorder * Vorder * Ncol * Nrow) vectors of dimension Dim. If Dim = 3, then the vectors are 3-D vectors giving the x, y and z components. If Dim = 4, then each vector has a weight (w) associated with it, and x, y, z and w components are supplied for each vector. The weights supplied must be greater than 0.
- The data is supplied patch by patch, row by row.
- The interpretation of the patch data depends on the representation method chosen; this is determined by the value of the argument basis.
- Adjacent patches (in the u and v directions) must meet all along the corresponding boundary; that is, the surface must be continuous.

Representation method basis:

The expressions for each patch of the B-surface P(u,v) in the various representations are shown next. For generality, the rational form is given. The simplification to the non-rational form can be obtained by setting both the weights and the denominator equal to 1.0.

- Bezier vertices 13652:

The equation of a rational Bezier surface patch is:

$$P(u,v) = \frac{\sum_{i=0}^{nu} \sum_{j=0}^{nv} b_i(u) b_j(v) w_{ij}}{\sum_{i=0}^{nu} \sum_{j=0}^{nv} b_i(u) b_j(v)}$$

where nu = uorder-1, nv = vorder-1

V_{ij} = Bezier vertex

ij

w_{ij} = weight for V_{ij}

ij ij

b_i(u), b_j(v) = Bezier coefficients.

i j

For the rational form the Bezier vertices and weights are supplied:

V₀₀, w₀₀, V₀₁, w₀₁, ..., V_{0n}, w_{0n}, V₁₀, w₁₀, ..., V_{1n}, w_{1n}, ..., V_{m0}, w_{m0}, ..., V_{mn}, w_{mn}.

00 00 10 10 m0 m0 01 01 m1 m1 0n 0n mn mn

For the non-rational form the w's are missed out.

- Polynomial coefficients 13653:

The surface equation is given by a rational bipolynomial of orders Uorder, Vorder:

$$P(u,v) = \frac{\sum_{i=0}^{nu} \sum_{j=0}^{nv} w_{ij} A_{ij} u^i v^j}{\sum_{i=0}^{nu} \sum_{j=0}^{nv} w_{ij} u^i v^j}$$

where nu = Uorder-1, nv = Vorder-1

For the rational form the polynomial coefficients Aij are supplied:

A ,w ,A ,w ,...,A ,w ,A ,w ,...,A ,w ,...,A ,w ,...,A ,w
00 00 10 10 m0 m0 01 01 m1 m1 0n 0n mn mn

starting with the constant term and ending with the term of highest degree.

For the non-rational form the w's are missed out.

- Hermite coefficients 13651

This method can only be used for bicubics.

The Hermite equation for the patch in matrix form is:

$$P(u,v) = \frac{\begin{pmatrix} 1 & u & u^2 & u^3 \end{pmatrix} M A M^T \begin{pmatrix} 1 & v & v^2 & v^3 \end{pmatrix}}{\begin{pmatrix} 1 & u & u^2 & u^3 \end{pmatrix} M W M^T \begin{pmatrix} 1 & v & v^2 & v^3 \end{pmatrix}}$$

where M =

$$\begin{pmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ -3 & 3 & -2 & -1 \\ 2 & -2 & 1 & 1 \end{pmatrix}$$

$$A = \begin{pmatrix} w_{00}*P_{00} & w_{01}*P_{01} & w_{v00}*P_{v00} & w_{v01}*P_{v01} \\ w_{10}*P_{10} & w_{11}*P_{11} & w_{v10}*P_{v10} & w_{v11}*P_{v11} \\ w_{u00}*P_{u00} & w_{u01}*P_{u01} & w_{uv00}*P_{uv00} & w_{uv01}*P_{uv01} \\ w_{u10}*P_{u10} & w_{u11}*P_{u11} & w_{uv10}*P_{uv10} & w_{uv11}*P_{uv11} \end{pmatrix}$$

$$W = \begin{pmatrix} w_{00} & w_{01} & w_{v00} & w_{v01} \\ w_{10} & w_{11} & w_{v10} & w_{v11} \\ w_{u00} & w_{u01} & w_{uv00} & w_{uv01} \\ w_{u10} & w_{u11} & w_{uv10} & w_{uv11} \end{pmatrix}$$

and the superscript T denotes the transpose.

In the matrices A and W, the coefficients P, Pu, Pv and Puv are the points at the corners and their derivatives. The w's are the corresponding weights and their derivatives. P00 denotes P(0,0), and so on.

For the rational form the coefficients are supplied:

P00, w00, P10, w10, P01, w01, P11, w11

Pu00, wu00, Pu10, wu10, Pu01, wu01, Pu11, wu11

Pv00, wv00, Pv10, wv10, Pv01, wv01, Pv11, wv11

Puv00, wuv00, Puv10, wuv10, Puv01, wuv01, Puv11, wuv11

For the non-rational form, the w's are missed out.

- Taylor series 13654:

This method stores the derivatives evaluated u=0, v=0 corner of each patch, allowing the surface to be reconstructed as a Taylor series

$$P(u,v) = \frac{\sum_{i=0}^{nu} \sum_{j=0}^{nv} w_{ij} P_{ij} u^i v^j / i! j!}{\sum_{i=0}^{nu} \sum_{j=0}^{nv} w_{ij} u^i v^j}$$

```

-- -- (i)(j) i j /
> > w u v / i! j!
-- --

i=0 j=0

where nu = Uorder-1, nv = Vorder-1

i+j
(i)(j) d P
P = ----- (0,0)
i j
du dv

i+j
(i)(j) d w
w = ----- (0,0)
i j
du dv

```

The point is supplied first, followed by the U derivatives in order and ending with the derivative of order Uorder-1 in U, Vorder-1 in V.
Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateRevolutionSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateRevolutionSurface Method (IBody2)

Creates a new surface of revolution.

.NET Syntax

Visual Basic (Declaration)

```

Function ICreateRevolutionSurface( _
    ByVal ProfileCurve As Curve, _
    ByVal AxisPoint As System.Object, _
    ByVal AxisDirection As System.Object, _
    ByVal ProfileEndPtParams As System.Object _
) As Surface

```

Visual Basic (Usage)



```

Dim instance As IBody2
Dim ProfileCurve As Curve
Dim AxisPoint As System.Object
Dim AxisDirection As System.Object
Dim ProfileEndPtParams As System.Object
Dim value As Surface

```

```

value = instance.ICreateRevolutionSurface(ProfileCurve, AxisPoint, AxisDirection,
ProfileEndPtParams)

```

C#

```

Surface ICreateRevolutionSurface(
    Curve ProfileCurve,

```

```
System.Object AxisPoint,  
System.Object AxisDirection,  
System.Object ProfileEndPtParams  
)
```

C++/CLI

```
Surface^ ICreateRevolutionSurface(  
& Curve^ ProfileCurve,  
& System.Object^ AxisPoint,  
& System.Object^ AxisDirection,  
& System.Object^ ProfileEndPtParams  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve
Profile curve (generatrix)
AxisPoint
Array of 3 doubles (x,y,z)
AxisDirection
Array of 3 doubles (x,y,z)
ProfileEndPtParams
Array of 2 doubles (uStart,uEnd) (see **Remarks**)

Return Value

Pointer to a new [surface](#) of revolution

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateRevolutionSurface](#).

Remarks

You can use this method with:

- A set of related functions that construct a body from trimmed surfaces.
- Trimming curve creation routines (for example, [ISurface::AddTrimmingLoop2](#)) to construct a trimmed surface of revolution.

If you pass ProfileEndPtParams to this method, the surface is trimmed in the axial direction; otherwise, it is infinite. SOLIDWORKS closes the surface periodic (period [0,2PI]) in the direction of revolution. The ProfileEndPtParams parameters indicate to SOLIDWORKS which part of the curve to spin. These parameters are used only when the profile curve intersects the revolve axis. You must pass the parameters in ascending order. SOLIDWORKS extends the curve from the given parameter range to meet the revolve axis and spins this portion of curve.

You can also pass an empty VARIANT object to ProfileEndPtParams; it cannot be NULL. You must define a variable of type VARIANT.

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateRevolutionSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICreateRevolutionSurfaceDLL Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateRevolutionSurfaceDLL Method (IBody2)

Creates a surface of revolution for this body.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateRevolutionSurfaceDLL( _  
    ByVal ProfileCurve As Curve, _  
    ByRef AxisPoint As System.Double, _
```

```
ByRef AxisDirection As System.Double, _
ByRef ProfileEndPtParams As System.Double _
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim ProfileCurve As Curve
Dim AxisPoint As System.Double
Dim AxisDirection As System.Double
Dim ProfileEndPtParams As System.Double
Dim value As Surface

value = instance.ICreateRevolutionSurfaceDLL(ProfileCurve, AxisPoint, AxisDirection,
ProfileEndPtParams)
```

C#

```
Surface ICreateRevolutionSurfaceDLL(
    Curve ProfileCurve,
    ref System.double AxisPoint,
    ref System.double AxisDirection,
    ref System.double ProfileEndPtParams
)
```

C++/CLI

```
Surface^ ICreateRevolutionSurfaceDLL(
    & Curve^ ProfileCurve,
    & System.double% AxisPoint,
    & System.double% AxisDirection,
    & System.double% ProfileEndPtParams
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ProfileCurve
Pointer to a profile [curve](#) object
AxisPoint
Array of 3 doubles (x,y,z)
AxisDirection
Array of 3 doubles (x,y,z)
ProfileEndPtParams
Array of 2 doubles (uStart,uEnd)

Return Value

Pointer to a new [surface](#) of revolution

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateRevolutionSurfaceDLL](#).

Remarks

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Creates a ruled surface from the specified curves and apex point.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateRuledSurface( _
    ByVal Curve1 As Curve, _
    ByVal Curve2 As Curve, _
    ByRef ApexPoint As System.Double _
) As Surface
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Curve1 As Curve
Dim Curve2 As Curve
Dim ApexPoint As System.Double
Dim value As Surface

value = instance.ICreateRuledSurface(Curve1, Curve2, ApexPoint)
```

C#

```
Surface ICreateRuledSurface(
    Curve Curve1,
    Curve Curve2,
    ref System.double ApexPoint
)
```

C++/CLI

```
Surface^ ICreateRuledSurface(
    & Curve^ Curve1,
    & Curve^ Curve2,
    & System.double% ApexPoint
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Curve1

Pointer to first [curve](#)

Curve2

Pointer to second [curve](#)

ApexPoint

Array of 3 doubles (x, y, z) being the apex point

Return Value

Pointer to ruled [surface](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateRuledSurface](#).

Remarks

Any existing object created by this method is destroyed if you call this method again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::ICreateRuledSurface Method](#)

Availability

ICreateTempBodyFromSurfaces Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ICreateTempBodyFromSurfaces Method (IBody2)

Creates a temporary body from a list of existing trimmed surfaces.

.NET Syntax

Visual Basic (Declaration)

```
Function ICreateTempBodyFromSurfaces() As Body2
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim value As Body2
```

```
value = instance.ICreateTempBodyFromSurfaces()
```

C#

```
Body2 ICreateTempBodyFromSurfaces()
```

C++/CLI

```
Body2^ ICreateTempBodyFromSurfaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Temporary [body](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::ICreateTempBodyFromSurfaces](#).

Remarks

This method is the final call to a set of related functions (same as [IBody2::CreateBodyFromSurfaces](#)) that are designed to construct a temporary body from trimmed surfaces.

The first call in this process should be to [IPartDoc::CreateNewBody2](#), so as to arrange for a placeholder for all the trimmed surfaces.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::CreateTempBodyFromSurfaces Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

IDeleteBlends Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteBlends Method (IBody2)

Obsolete. Superseded by [IBody2::IDeleteBlends2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteBlends( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face2  
Dim value As System.Boolean  
  
value = instance.IDeleteBlends(NumOfFaces, FaceList)
```

C#

```
System.bool IDeleteBlends(  
    System.int NumOfFaces,  
    ref Face2 FaceList  
)
```

C++/CLI

```
System.bool IDeleteBlends(  
    & System.int NumOfFaces,  
    & Face2^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Visual Basic for Applications (VBA) Syntax

See [Body2::IDeleteBlends](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IDeleteBlends2 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteBlends2 Method (IBody2)

Obsolete. Superseded by [IBody2::DeleteBlends3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteBlends2( _  
    ByVal NumOfFaces As System.Integer, _  
    ByRef FaceList As Face2, _  
    ByVal DoLocalCheck As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face2
```

```
Dim DoLocalCheck As System.Boolean
Dim value As System.Boolean

value = instance.IDeleteBlends2(NumOfFaces, FaceList, DoLocalCheck)
```

C#

```
System.bool IDeleteBlends2(
    System.int NumOfFaces,
    ref Face2 FaceList,
    System.bool DoLocalCheck
)
```

C++/CLI

```
System.bool IDeleteBlends2(
    & System.int NumOfFaces,
    & Face2^% FaceList,
    & System.bool DoLocalCheck
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

Number of faces to delete

FaceList

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size NumOfFaces to delete
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

DoLocalCheck

True to perform a local check, false if not

Return Value

True if a set of fillet faces are removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::IDeleteBlends2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::DeleteBlends2 Method](#)
[IBody2::DeleteFaces5 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteBlends3 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteBlends3 Method (IBody2)

Removes a set of fillet faces from a temporary body and heals the body.

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteBlends3( _
    ByVal NumOfFaces As System.Integer, _
    ByRef FaceList As Face2, _
    ByVal DoLocalCheck As System.Boolean, _
    ByVal UsePlanarCap As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As IBody2
Dim NumOfFaces As System.Integer
Dim FaceList As Face2
Dim DoLocalCheck As System.Boolean
Dim UsePlanarCap As System.Boolean
Dim value As System.Boolean

value = instance.IDeleteBlends3(NumOfFaces, FaceList, DoLocalCheck, UsePlanarCap)

```

C#

```

System.bool IDeleteBlends3(
    System.int NumOfFaces,
    ref Face2 FaceList,
    System.bool DoLocalCheck,
    System.bool UsePlanarCap
)

```

C++/CLI

```

System.bool IDeleteBlends3(
    & System.int NumOfFaces,
    & Face2^% FaceList,
    & System.bool DoLocalCheck,
    & System.bool UsePlanarCap
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

Number of faces to delete

FaceList

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size NumOfFaces to delete
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

DoLocalCheck

True to perform a local check, false to not

UsePlanarCap

True to use planar caps, false to not (see **Remarks**)

Return Value

True if the set of fillet faces are removed, false if not

Remarks

Typically when deleting blends, an entire chain of blends are deleted. However, if only a few blends are deleted from a chain of blends and the UsePlanarCap parameter is not set to true, then the resultant body might be invalid.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::DeleteBlends3 Method](#)
[IBody2::DeleteFaces5 Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteFaces2 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteFaces2 Method (IBody2)

Obsolete. Superseded by [IBody2::IDeleteFaces3](#).

.NET Syntax

```
Function IDeleteFaces2( _
    ByVal NumOfFaces As System.Integer, _
    ByRef FaceList As Face2, _
    ByVal Option As System.Integer _
) As System.Integer
```



```
Dim instance As IBody2
Dim NumOfFaces As System.Integer
Dim FaceList As Face2
Dim Option As System.Integer
Dim value As System.Integer

value = instance.IDeleteFaces2(NumOfFaces, FaceList, Option)
```

```
System.int IDeleteFaces2(
    System.int NumOfFaces,
    ref Face2 FaceList,
    System.int Option
)
```

```
System.int IDeleteFaces2(
    & System.int NumOfFaces,
    & Face2^% FaceList,
    & System.int Option
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

FaceList

Option

Visual Basic for Applications (VBA) Syntax

See [Body2::IDeleteFaces2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

IDeleteFaces3 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteFaces3 Method (IBody2)

Obsolete. Superseded by [IBody2::IDeleteFaces4](#).

.NET Syntax

```
Sub IDeleteFaces3( _
    ByVal NumOfFaces As System.Integer, _
    ByRef FaceList As Face2, _
    ByVal Option As System.Integer, _
    ByVal DoLocalCheck As System.Boolean, _
```

```
ByRef LocalCheckResult As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim NumOfFaces As System.Integer  
Dim FaceList As Face2  
Dim Option As System.Integer  
Dim DoLocalCheck As System.Boolean  
Dim LocalCheckResult As System.Boolean  
  
instance.IDeleteFaces3(NumOfFaces, FaceList, Option, DoLocalCheck, LocalCheckResult)
```

C#

```
void IDeleteFaces3(  
    System.int NumOfFaces,  
    ref Face2 FaceList,  
    System.int Option,  
    System.bool DoLocalCheck,  
    ref System.bool LocalCheckResult  
)
```

C++/CLI

```
void IDeleteFaces3(  
& System.int NumOfFaces,  
& Face2^% FaceList,  
& System.int Option,  
& System.bool DoLocalCheck,  
& System.bool% LocalCheckResult  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

Number of faces to delete

FaceList

Array containing the [faces](#) to delete

Option

Additional control (see **Remarks**)

DoLocalCheck

True checks the bodies during the operation and sets retval to indicate whether or not the resultant body is valid, false does not

LocalCheckResult

True if body is valid, false if not; to obtain this value, you must pass True for the DoLocalCheck argument

Visual Basic for Applications (VBA) Syntax

See [Body2::IDeleteFaces3](#).

Remarks

All of the specified faces, which must belong to this temporary body, are deleted from IBody2. If the resulting body does not have a complete boundary, then SOLIDWORKS treats any holes as wounds and heals them as specified by the option argument. The option argument takes the following values:

Value	Loops on the faces to delete are...
0	Dependent on each other and should be healed at the same time. If extending faces does not yield a solution, then SOLIDWORKS tries to shrink the faces.
1	Independent and should be healed separately. This option also grows the parent faces around the hole to cover it.
2	Independent and should be healed separately. This option also finds a surface in which all edges of a hole lie and attaches this to a face covering the hole (SOLIDWORKS creates a new face to cover the hole).

For example, consider a cube with a through hole made up of four faces (a square hole). To delete these four faces, specify option 0 because the loop on the first face to be deleted is dependent on the loop of the second face to be deleted. Likewise, the loop on the second face to be delete is dependent on the third face to be deleted, and so on.

Now consider the same cube with a through hole, except this through hole is a simple cylinder (one face). To delete the cylindrical face, specify option 1 to heal the loops independently. This is necessary because the cylindrical face actually has two loops (one at either end of the cylinder) that need to be healed separately.

It is possible to generate invalid geometry when you use this method because checking is disabled. Call [IBody2::Check3](#) to verify that the body is a valid solid after using this method.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteFacesMakeSheetBodies Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteFacesMakeSheetBodies Method (IBody2)

Creates sheet bodies from deleted faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteFacesMakeSheetBodies( _  
    ByVal FaceCount As System.Integer, _  
    ByRef FaceList As Face2, _  
    ByVal SheetCount As System.Integer _  
    ) As Body2
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim FaceCount As System.Integer  
Dim FaceList As Face2  
Dim SheetCount As System.Integer  
Dim value As Body2  
  
value = instance.IDeleteFacesMakeSheetBodies(FaceCount, FaceList, SheetCount)
```

C#

```
Body2 IDeleteFacesMakeSheetBodies(  
    System.int FaceCount,  
    ref Face2 FaceList,  
    System.int SheetCount  
)
```

C++/CLI

```
Body2^ IDeleteFacesMakeSheetBodies(  
& System.int FaceCount,  
& Face2^% FaceList,  
& System.int SheetCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces to delete

FaceList

- in-process, unmanaged C++: Pointer to an array of the [faces](#)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

SheetCount

Number of sheet bodies to create

Return Value

- in-process, unmanaged C++: Pointer to an array of sheet [bodies](#) created from the deleted faces
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBody2.DeleteFacesMakeSheetBodiesCount](#) to get the number of sheet bodies to create from the deleted faces.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2.DeleteFacesMakeSheetBodies Method](#)
[IFace2.CreateSheetBody Method](#)
[IFace2.CreateSheetBodyByFaceExtension Method](#)
[IModeler.CreateSheetFromFaces Method](#)
[IModeler.CreateSheetFromSurface2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

IDeleteFacesMakeSheetBodiesCount Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : IDeleteFacesMakeSheetBodiesCount Method (IBody2)

Gets the number of sheet bodies to create from the deleted faces.

.NET Syntax

Visual Basic (Declaration)

```
Function IDeleteFacesMakeSheetBodiesCount( _  
    ByVal FaceCount As System.Integer, _  
    ByRef FaceList As Face2 _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim FaceCount As System.Integer  
Dim FaceList As Face2  
Dim value As System.Integer  
  
value = instance.IDeleteFacesMakeSheetBodiesCount(FaceCount, FaceList)
```

C#

```
System.int IDeleteFacesMakeSheetBodiesCount(  
    System.int FaceCount,  
    ref Face2 FaceList  
)
```

C++/CLI

```
System.int IDeleteFacesMakeSheetBodiesCount(  
& System.int FaceCount,  
& Face2^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces to delete from the body

FaceList

- in-process, unmanaged C++: Pointer to an array of the [faces](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

Number of sheet bodies to create from the deleted faces

Remarks

To create sheet bodies from deleted faces, call [IBody2::IDeleteFacesMakeSheetBodies](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12