

SOLIDWORKS API (.NET, VBA, C#) — Reference

(30/337): IBody2 (part 5 of 5)

SOLIDWORKS API Documentation (converted from CHM)

IBody2 (part 5 of 5) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialPropertyValues Property (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : MaterialPropertyValues Property (IBody2)

Obsolete. Superseded by [IBody2::MaterialPropertyValues2](#).

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialPropertyValues As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Object  
  
instance.MaterialPropertyValues = value  
value = instance.MaterialPropertyValues
```

C#

```
System.object MaterialPropertyValues {get; set;}
```

C++/CLI

```
property System.Object^ MaterialPropertyValues {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body2::MaterialPropertyValues](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

MaterialPropertyValues2 Property (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : MaterialPropertyValues2 Property (IBody2)

Gets or sets the material properties for a body other than the base body in the active configuration.

.NET Syntax

Visual Basic (Declaration)

```
Property MaterialPropertyValues2 As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Object  
  
instance.MaterialPropertyValues2 = value
```

```
value = instance.MaterialPropertyValues2
```

C#

```
System.Object MaterialPropertyValues2 {get; set;}
```

C++/CLI

```
property System.Object^ MaterialPropertyValues2 {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Body2::MaterialPropertyValues2](#).

Example

[Get Material Property Values \(VBA\)](#).

Remarks

The material values include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid settings are from 0 to 1 for all values.

This property is intended to be used on bodies other than the base body and should follow a call to [IPartDoc::EnumRelatedBodies2](#). The format of the parameters or return values is an array of 9 doubles as follows:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*]

To see a color change, you must:

1. Specify *R*, *G*, and *B*, each with a value between 0.0 and 1.0, inclusive. (These values are internally multiplied by 255.0 to determine the RGB color.)
2. Specify the reflectivity properties (*Diffuse*, *Specular*, *Shininess* (1.0 - Specular spread/Blurriness)), each with a value greater than 0.0 and less than or equal to 1.0.
3. Specify *Ambient*, *Transparency* and *Emission*, each with a value between 0.0 and 1.0, inclusive.
4. Refresh the graphics area after setting this property.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IComponent2::MaterialPropertyValues Property](#)
[IFace2::MaterialPropertyValues Property](#)
[IModelDoc2::MaterialPropertyValues Property](#)
[IPartDoc::MaterialPropertyValues Property](#)
[IBody2::IMaterialPropertyValues2 Property](#)
[IBody2::GetMaterialIdName2 Method](#)
[IBody2::GetMaterialPropertyName Method](#)
[IBody2::GetMaterialUserName2 Method](#)
[IBody2::IGetMaterialPropertyValuesForFace Method](#)
[IBody2::IRemoveMaterialProperty Method](#)
[IBody2::RemoveMaterialProperty Method](#)
[IBody2::SetMaterialIdName2 Method](#)
[IBody2::SetMaterialProperty Method](#)
[IBody2::SetMaterialUserName2 Method](#)
[IBody2::HasMaterialPropertyValues Method](#)
[IBody2::Display3 Method \(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MinimumRadius Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : MinimumRadius Method (IBody2)

Gets the minimum radius of this body.

.NET Syntax

Visual Basic (Declaration)

```
Function MinimumRadius() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Double  
  
value = instance.MinimumRadius()
```

C#

```
System.double MinimumRadius()
```

C++/CLI

```
System.double MinimumRadius();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Minimum radius on this body

Visual Basic for Applications (VBA) Syntax

See [Body2::MinimumRadius](#).

Example

[Get Minimum Radius of Bodies \(C#\)](#)
[Get Minimum Radius of Bodies \(VB.NET\)](#)
[Get Minimum Radius of Bodies \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name Property (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Name Property (IBody2)

Gets or sets the name of the selected body.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.String  
  
instance.Name = value  
  
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of selected body

Visual Basic for Applications (VBA) Syntax

See [Body2::Name](#).

Example

[Traverse Bodies \(C++\)](#)
[Get Bodies in Components \(C#\)](#)
[Get Bodies in Components \(VB.NET\)](#)
[Get Bodies in Components \(VBA\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

Remarks

If changing the name of the body, then the name must be unique and cannot contain the at-sign character (@). Before changing the name of the body, call [IFeatureManager::IsNameUsed](#) to find out if the name is unique and valid. To see the new name of the body in the FeatureManager design tree, call [IFeatureManager::UpdateFeatureTree](#) to update it.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

Negate Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Negate Method (IBody2)

Reverses the direction (i.e., orientation) of the body.

.NET Syntax

Visual Basic (Declaration)

```
Function Negate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Boolean
```

```
value = instance.Negate()
```

C#

```
System.bool Negate()
```

C++/CLI

```
System.bool Negate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the direction of the body is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::Negate](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic](#).

OffsetPlanarWireBody Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : OffsetPlanarWireBody Method (IBody2)

Offsets a planar wire body in the normal plane by the specified distance.

.NET Syntax

Visual Basic (Declaration)

```
Function OffsetPlanarWireBody( _  
    ByVal Distance As System.Double, _  
    ByVal Normal As MathVector, _  
    ByVal Option As System.Integer _  
) As Body2
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Distance As System.Double  
Dim Normal As MathVector  
Dim Option As System.Integer  
Dim value As Body2
```

```
value = instance.OffsetPlanarWireBody(Distance, Normal, Option)
```

C#

```
Body2 OffsetPlanarWireBody(  
    System.double Distance,  
    MathVector Normal,  
    System.int Option  
)
```

C++/CLI

```
Body2^ OffsetPlanarWireBody(  
& System.double Distance,  
& MathVector^ Normal,  
& System.int Option  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Distance

Distance by which to offset the planar wire body

Normal

Plane normal

Option

How to fill the gap between edges as defined in [swOffsetPlanarWireBodyOptions_e](#)

Return Value

Pointer to the [IBody2](#) object

Visual Basic for Applications (VBA) Syntax

See [Body2::OffsetPlanarWireBody](#).

Remarks

The offset direction is determined by the direction of the first edge and the normal. For example, imagine that you are standing on the plane with normal pointing upwards and you are looking along the first edge, then the offset is to your right.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Operations Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Operations Method (IBody2)

Obsolete. Superseded by [IBody2::Operations2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Operations( _  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As System.Object, _  
    ByVal NumMaxSections As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim OperationType As System.Integer  
Dim ToolBody As System.Object  
Dim NumMaxSections As System.Integer  
Dim value As System.Object  
  
value = instance.Operations(OperationType, ToolBody, NumMaxSections)
```

C#

```
System.object Operations(  
    System.int OperationType,  
    System.object ToolBody,  
    System.int NumMaxSections  
)
```

C++/CLI

```
System.Object^ Operations(  
& System.int OperationType,  
& System.Object^ ToolBody,  
& System.int NumMaxSections  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType

ToolBody

NumMaxSections

Visual Basic for Applications (VBA) Syntax

See [Body2::Operations](#).

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Operations2 Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Operations2 Method (IBody2)

Performs add, cut, and intersect (unite, subtract, and interfere) operations between two temporary bodies.

.NET Syntax

Visual Basic (Declaration)

```
Function Operations2( _  
    ByVal OperationType As System.Integer, _  
    ByVal ToolBody As System.Object, _  
    ByRef ErrorCode As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim OperationType As System.Integer  
Dim ToolBody As System.Object  
Dim ErrorCode As System.Integer  
Dim value As System.Object  
  
value = instance.Operations2(OperationType, ToolBody, ErrorCode)
```

C#

```
System.object Operations2(  
    System.int OperationType,  
    System.object ToolBody,  
    out System.int ErrorCode  
)
```

C++/CLI

```
System.Object^ Operations2(  
& System.int OperationType,  
& System.Object^ ToolBody,  
& [Out] System.int ErrorCode  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OperationType

Operation type as defined in [swBodyOperationType_e](#)

ToolBody

Tool body

ErrorCode

Error indicator as defined in [swBodyOperationError_e](#); returns swBodyOperationNoError if SOLIDWORKS does not generate an error

Return Value

Array of pointers to the resulting [bodies](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::Operations2](#).

Example

[Combine Assembly Components into Part \(VBA\)](#)
[Create Solid Bodies Using Geometry and Topology \(VBA\)](#)
[Cut Body in Half Using Macro Feature \(VBA\)](#)
[Get Differences Between Parts \(VBA\)](#)
[Create and Convert Non-manifold Bodies \(C#\)](#)
[Create and Convert Non-manifold Bodies \(VB.NET\)](#)
[Create and Convert Non-manifold Bodies \(VBA\)](#)

Remarks

If the target and tool bodies are the same in geometry, the result body of this method is NULL, and the return value is S_false.

This method works with two temporary bodies; one is the target and one is the tool. The output is a list of bodies resulting from the operation.

The two temporary bodies used in this function (the Body2 and ToolBody pointers) are invalid once the operation is complete. COM applications should release these two pointers after using this method. If your application needs to maintain these bodies, then you should make a copy of them using [IBody2::Copy](#) before passing them to this routine.

To perform a [swBodyOperationType_e](#).SWBODYINTERSECT between a sheet (surface) and a solid body, the sheet body must be the target body.

Use [IBody2::Check3](#) for both bodies before using this method to ensure that both bodies are valid solids. Using this method with invalid bodies can cause unexpected results.

If a non-manifold error is returned, use [IBody2::ResetEdgeTolerances](#) to visit all of the edges in the body to reset their tolerances. Then use [IBody2::Operations2](#) again.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::IOperations2 Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveFacesFromSheet Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveFacesFromSheet Method (IBody2)

Removes the specified faces from a sheet (surface) body.

.NET Syntax

Visual Basic (Declaration)

```
Sub RemoveFacesFromSheet ( _  
    ByVal NumOfFaces As System.Integer, _  
    ByVal FacesToRemove As System.Object _  
)
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim NumOfFaces As System.Integer  
Dim FacesToRemove As System.Object
```

```
instance.RemoveFacesFromSheet(NumOfFaces, FacesToRemove)
```

C#



```
void RemoveFacesFromSheet(
    System.int NumOfFaces,
    System.object FacesToRemove
)
```

C++/CLI

```
void RemoveFacesFromSheet(
    & System.int NumOfFaces,
    & System.Object^ FacesToRemove
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumOfFaces

Number of faces generated when these two bodies intersect

FacesToRemove

Array of faces to remove

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveFacesFromSheet](#).

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

[IBody2::!RemoveFacesFromSheet Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveMaterialProperty Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveMaterialProperty Method (IBody2)

Removes the material property values (e.g., color) from the body in the specified configurations in parts and assemblies.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMaterialProperty( _
    ByVal Config\_opt As System.Integer, _
    ByVal Config\_names As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Config_opt As System.Integer
Dim Config_names As System.Object
Dim value As System.Boolean
```

```
value = instance.RemoveMaterialProperty(Config_opt, Config_names)
```

C#

```
System.bool RemoveMaterialProperty(
    System.int Config\_opt,
    System.object Config\_names
)
```

C++/CLI

```
System.bool RemoveMaterialProperty(  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_names

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveMaterialProperty](#).

Example

[Remove Material Properties from Body \(C#\)](#)
[Remove Material Properties from Body \(VB.NET\)](#)
[Remove Material Properties from Body \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::!RemoveMaterialProperty Method](#)
[IBody2::!GetMaterialPropertyValuesForFace Method](#)
[IBody2::!MaterialPropertyValues2 Property](#)
[IBody2::MaterialPropertyValues2 Property](#)
[IBody2::GetMaterialIdName2 Method](#)
[IBody2::GetMaterialPropertyName Method](#)
[IBody2::GetMaterialUserName2 Method](#)
[IBody2::SetMaterialIdName2 Method](#)
[IBody2::SetMaterialProperty Method](#)
[IBody2::SetMaterialUserName2 Method](#)
[IBody2::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveRedundantTopology Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveRedundantTopology Method (IBody2)

Removes redundant topology from the body.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveRedundantTopology() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Boolean
```

```
value = instance.RemoveRedundantTopology()
```

C#

```
System.bool RemoveRedundantTopology()
```

C++/CLI

```
System.bool RemoveRedundantTopology();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the redundant topology is removed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveRedundantTopology](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IEdge::RemoveRedundantTopology Method](#)
[IFace2::RemoveRedundantTopology Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveTexture Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveTexture Method (IBody2)

Removes the texture applied to this body in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTexture( _  
    ByVal Config\_name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Config_name As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveTexture(Config_name)
```

C#

```
System.bool RemoveTexture(  
    System.string Config\_name  
)
```

C++/CLI

```
System.bool RemoveTexture(  
& System.String^ Config\_name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of the configuration

Return Value

True if texture is removed, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveTexture](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::SetTexture Method](#)
[IBody2::GetTexture Method](#)
[IBody2::SetTextureByDisplayState Method](#)
[IBody2::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTextureByDisplayState Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveTextureByDisplayState Method (IBody2)

Removes the texture applied to this body in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTextureByDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim DisplayStateName As System.String  
Dim value As System.Boolean  
  
value = instance.RemoveTextureByDisplayState(DisplayStateName)
```

C#

```
System.bool RemoveTextureByDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.bool RemoveTextureByDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name

Return Value

True if the texture is removed from the body, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveTextureByDisplayState](#).

Example

[Apply and Remove Texture By Body Display State \(C#\)](#)
[Apply and Remove Texture By Body Display State \(VB.NET\)](#)
[Apply and Remove Texture By Body Display State \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::SetTextureByDisplayState Method](#)
[IBody2::RemoveTexture Method](#)
[IBody2::SetTexture Method](#)
[IBody2::GetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveTrackingID Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : RemoveTrackingID Method (IBody2)

Removes a [tracking ID assigned to this body](#).

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveTrackingID(  
    ByVal TrackingCookie As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim TrackingCookie As System.Integer  
Dim value As System.Integer  
  
value = instance.RemoveTrackingID(TrackingCookie)
```

C#

```
System.int RemoveTrackingID(  
    System.int TrackingCookie  
)
```

C++/CLI

```
System.int RemoveTrackingID(  
& System.int TrackingCookie  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::RemoveTrackingID](#).

Example

[Get, Set, and Remove Tracking IDs on Body \(VBA\)](#)

Remarks

See [Tracking IDs](#) for more information.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::SetTrackingID Method](#)
[IBody2::GetTrackingIDCount Method](#)
[IBody2::IGetTrackingIDs Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetEdgeTolerances Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ResetEdgeTolerances Method (IBody2)

Resets the tolerance on all edges of this body.

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetEdgeTolerances()
```

Visual Basic (Usage)



```
Dim instance As IBody2  
instance.ResetEdgeTolerances()
```

C#

```
void ResetEdgeTolerances()
```

C++/CLI

```
void ResetEdgeTolerances();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body2::ResetEdgeTolerances](#).

Remarks

Use this method if [IBody2::Operations2](#) or [IBody2::!Operations2](#) returns a non-manifold error. Then use IBody2::Operations2 or IBody2::!Operations2 again after using this method.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

ResetPropertyExtension Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ResetPropertyExtension Method (IBody2)

Obsolete. Superseded by [IBody2::ResetPropertyExtension2](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension()
```

Visual Basic (Usage)



```
Dim instance As IBody2  
instance.ResetPropertyExtension()
```

C#

```
void ResetPropertyExtension()
```

C++/CLI

```
void ResetPropertyExtension();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body2::ResetPropertyExtension](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ResetPropertyExtension2 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : ResetPropertyExtension2 Method (IBody2)

Clears all values stored in the property extension.

.NET Syntax

Visual Basic (Declaration)

```
Sub ResetPropertyExtension2()
```

Visual Basic (Usage)



```
Dim instance As IBody2  
instance.ResetPropertyExtension2()
```

C#

```
void ResetPropertyExtension2()
```

C++/CLI

```
void ResetPropertyExtension2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Body2::ResetPropertyExtension2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::AddPropertyExtension2 Method](#)
[IBody2::GetPropertyExtension2 Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Save Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Save Method (IBody2)

Saves this body.

.NET Syntax

Visual Basic (Declaration)

```
Sub Save( _  
    ByVal StreamIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim StreamIn As System.Object  
  
instance.Save(StreamIn)
```

C#

```
void Save(  
    System.object StreamIn  
)
```

C++/CLI

```
void Save(  
& System.Object^ StreamIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

StreamIn

Stream to use for the save

Visual Basic for Applications (VBA) Syntax

See [Body2::Save](#).

Remarks

If you want to save the solid body associated with the document, then save the document.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::ISave Method](#)
[IModeler::IRestore2 Method \(\)](#)
[IModeler::Restore Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

Select Method (IBody2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Select Method (IBody2)

Obsolete. Superseded by [IBody2::Select2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.Select(Append, Mark)
```

C#

```
System.bool Select(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

Mark

Visual Basic for Applications (VBA) Syntax

See [Body2::Select](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Select2 Method (IBody2)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Select2 Method (IBody2)

Selects this body and marks it.

.NET Syntax

Visual Basic (Declaration)

```
Function Select2( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select2(Append, Data)
```

C#

```
System.bool Select2(  
    System.bool Append,  
    SelectData Data  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool Append,  
& SelectData^ Data  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the selection list, false replaces the selection list

Data

Pointer to the [ISelectData](#) object

Return Value

True if the body was selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::Select2](#).

Example

[Move Bodies \(C#\)](#)
[Move Bodies \(VB.NET\)](#)
[Move Bodies \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetCurrentSurface Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetCurrentSurface Method (IBody2)

Places an existing surface into a temporary body that is under construction.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetCurrentSurface( _  
    ByVal SurfaceIn As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim SurfaceIn As System.Object  
  
instance.SetCurrentSurface(SurfaceIn)
```

C#

```
void SetCurrentSurface(  
    System.object SurfaceIn  
)
```

C++/CLI

```
void SetCurrentSurface(  
    & System.Object^ SurfaceIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SurfaceIn

Surface, which might have been created using other surface creation routines, such as [IModeler::CreateCylindricalSurface2](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::SetCurrentSurface](#).

Remarks

This method is used with a set of related methods that construct a body from trimmed surfaces. This method takes an ISurface object created elsewhere and adds it to the temporary body object, which acts as a placeholder for the trimmed surfaces.

Follow calls to this method with one or more calls to the trimming-curve creation methods, such as [ISurface::AddTrimmingLoop2](#). Then, trim the surface using [IBody2::CreateTrimmedSurface](#). After you add all the surfaces to the body and trim appropriately, you can sew the body to create an imported SOLIDWORKS body feature using [IBody2::CreateBodyFromSurfaces](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::ISetCurrentSurface Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetIgesInfo Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetIgesInfo Method (IBody2)

Sends IGES-specific data to the geometric modeler.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetIgesInfo( _  
    ByVal SystemName As System.String, _  
    ByVal Granularity As System.Double, _
```

```
ByVal AttemptKnitting As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim SystemName As System.String  
Dim Granularity As System.Double  
Dim AttemptKnitting As System.Boolean  
  
instance.SetIgesInfo(SystemName, Granularity, AttemptKnitting)
```

C#

```
void SetIgesInfo(  
    System.string SystemName,  
    System.double Granularity,  
    System.bool AttemptKnitting  
)
```

C++/CLI

```
void SetIgesInfo(  
& System.String^ SystemName,  
& System.double Granularity,  
& System.bool AttemptKnitting  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SystemName

Name of the system as defined in [swIGESPreferredSystem_e](#)

Granularity

Level of granularity

AttemptKnitting

True knits the objects, false does not

Visual Basic for Applications (VBA) Syntax

See [Body2::SetIgesInfo](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialIdName Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetMaterialIdName Method (IBody2)

Obsolete. Superseded by [IBody2::SetMaterialIdName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialIdName( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Name As System.String
Dim value As System.Boolean

value = instance.SetMaterialIdName(Name)
```

C#

```
System.bool SetMaterialIdName(
    System.string Name
)
```

C++/CLI

```
System.bool SetMaterialIdName(
    & System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Visual Basic for Applications (VBA) Syntax

See [Body2::SetMaterialIdName](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialIdName2 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetMaterialIdName2 Method (IBody2)

Sets the material name for this body.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialIdName2( _
    ByVal Name As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2
Dim Name As System.String
Dim value As System.Boolean

value = instance.SetMaterialIdName2(Name)
```

C#

```
System.bool SetMaterialIdName2(
    System.string Name
)
```

C++/CLI

```
System.bool SetMaterialIdName2(
    & System.String^ Name
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Material name

Return Value

True if the material name is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::SetMaterialIdName2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetMaterialIdName2 Method](#)
[IBody2::GetMaterialUserName2 Method](#)
[IBody2::SetMaterialProperty Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialProperty Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetMaterialProperty Method (IBody2)

Sets the material for this body.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialProperty(  
    ByVal ConfigName As System.String, _  
    ByVal Database As System.String, _  
    ByVal MaterialName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim ConfigName As System.String  
Dim Database As System.String  
Dim MaterialName As System.String  
Dim value As System.Integer  
  
value = instance.SetMaterialProperty(ConfigName, Database, MaterialName)
```

C#

```
System.int SetMaterialProperty(  
    System.string ConfigName,  
    System.string Database,  
    System.string MaterialName  
)
```

C++/CLI

```
System.int SetMaterialProperty(  
& System.String^ ConfigName,  
& System.String^ Database,  
& System.String^ MaterialName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName

Name of configuration

Database

"solidworks material.sldmat" or "" or "custom materials.sldmat" (see **Remarks**)

MaterialName

Name of the SOLIDWORKS material to apply to the body (see **Remarks**)

Return Value

Return status as defined by [swBodyMaterialApplicationError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::SetMaterialProperty](#).

Example

[Set Material \(C#\)](#)

[Set Material \(VB.NET\)](#)

[Set Material \(VBA\)](#)

Remarks

Click **Tools > Options > System Options > File Locations > Material Databases** to verify that a folder for Database is specified.

You can only use materials from a valid SOLIDWORKS materials database. You can specify either "solidworks materials.sldmat" or "" for the SOLIDWORKS Materials database or "custom materials.sldmat" for the Custom Materials database.

You can also find out the names of the materials in the materials database by opening the database as an XML stream and work with the XML API to get the data.

See Also

[IBody2 Interface](#)

[IBody2 Members](#)

[IBody2::GetMaterialIdName2 Method](#)

[IBody2::GetMaterialPropertyName Method](#)

[IBody2::GetMaterialUserName2 Method](#)

[IBody2::IGetMaterialPropertyValuesForFace Method](#)

[IBody2::IRemoveMaterialProperty Method](#)

[IBody2::RemoveMaterialProperty Method](#)

[IBody2::SetMaterialIdName2 Method](#)

[IBody2::SetMaterialUserName2 Method](#)

[IBody2::IMaterialPropertyValues2 Property](#)

[IBody2::MaterialPropertyValues2 Property](#)

[IBody2::HasMaterialPropertyValues Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetMaterialUserName Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetMaterialUserName Method (IBody2)

Obsolete. Superseded by [IBody2::SetMaterialUserName2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialUserName( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim Name As System.String  
Dim value As System.Boolean
```



```
value = instance.SetMaterialUserName(Name)
```

C#

```
System.bool SetMaterialUserName(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetMaterialUserName(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Visual Basic for Applications (VBA) Syntax

See [Body2::SetMaterialUserName](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMaterialUserName2 Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetMaterialUserName2 Method (IBody2)

Sets the material name for this body. This material name is visible to the user.

.NET Syntax

Visual Basic (Declaration)

```
Function SetMaterialUserName2( _  
    ByVal Name As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Name As System.String  
Dim value As System.Boolean
```

```
value = instance.SetMaterialUserName2(Name)
```

C#

```
System.bool SetMaterialUserName2(  
    System.string Name  
)
```

C++/CLI

```
System.bool SetMaterialUserName2(  
& System.String^ Name  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Material name

Return Value

True if the material name is set successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::SetMaterialUserName2](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetMaterialUserName2 Method](#)
[IBody2::GetMaterialIdName2 Method](#)
[IBody2::GetMaterialPropertyName Method](#)
[IBody2::RemoveMaterialProperty Method](#)
[IBody2::GetMaterialPropertyValuesForFace Method](#)
[IBody2::RemoveMaterialProperty Method](#)
[IBody2::SetMaterialIdName2 Method](#)
[IBody2::SetMaterialProperty Method](#)
[IBody2::IMaterialPropertyValues2 Property](#)
[IBody2::MaterialPropertyValues2 Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTexture Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetTexture Method (IBody2)

Applies texture to this body in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTexture( _  
    ByVal Config\_name As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim Config_name As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean  
  
value = instance.SetTexture(Config_name, TextureIn)
```

C#

```
System.bool SetTexture(  
    System.string Config\_name,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTexture(  
& System.String^ Config\_name,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of the configuration

TextureIn

Pointer to the [Texture](#) object

Return Value

True if texture is applied, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::SetTexture](#).

Example

[RemoveTexture Method](#)
[RemoveTextureByDisplayState Method](#)
[IBody2::SetTextureByDisplayState Method](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetTexture Method](#)
[IBody2::RemoveTexture Method](#)
[IBody2::SetTextureByDisplayState Method](#)
[IBody2::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextureByDisplayState Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetTextureByDisplayState Method (IBody2)

Sets the texture applied to this body in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim DisplayStateName As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean  
  
value = instance.SetTextureByDisplayState(DisplayStateName, TextureIn)
```

C#

```
System.bool SetTextureByDisplayState(  
    System.string DisplayStateName,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTextureByDisplayState(  
& System.String^ DisplayStateName,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name
TextureIn
[Texture](#)

Return Value

True if texture applied to body, false if not

Visual Basic for Applications (VBA) Syntax

See [Body2::SetTextureByDisplayState](#).

Example

[Apply and Remove Texture By Body Display State \(C#\)](#)
[Apply and Remove Texture By Body Display State \(VB.NET\)](#)
[Apply and Remove Texture By Body Display State \(VBA\)](#)

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::RemoveTextureByDisplayState Method](#)
[IBody2::RemoveTexture Method](#)
[IBody2::SetTexture Method](#)
[IBody2::GetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTrackingID Method (IBody2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetTrackingID Method (IBody2)

Assigns a tracking ID to this body.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTrackingID( _  
    ByVal TrackingCookie As System.Integer, _  
    ByVal TrackingID As System.Integer _  
    ) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IBody2  
Dim TrackingCookie As System.Integer  
Dim TrackingID As System.Integer  
Dim value As System.Integer  
  
value = instance.SetTrackingID(TrackingCookie, TrackingID)
```

C#

```
System.int SetTrackingID(  
    System.int TrackingCookie,  
    System.int TrackingID  
)
```

C++/CLI

```
System.int SetTrackingID(  
& System.int TrackingCookie,
```

```
& System.int TrackingID  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TrackingCookie
Cookie obtained from [ISldWorks::RegisterTrackingDefinition](#)
TrackingID
Application-defined value for the tracking ID

Value	Action
>0	Body is tracked
0	Tracking of body is stopped

Return Value

Status as defined by [swTrackingIDError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Body2::SetTrackingID](#).

Example

[Get, Set, and Remove Tracking IDs on Body \(VBA\)](#)

Remarks

You can assign tracking IDs to bodies, [faces](#), [edges](#), [loops](#), and [vertices](#) in parts and assemblies only; you cannot assign tracking IDs to these entities in drawings. See [Tracking IDs](#) for more information.

See Also

[IBody2 Interface](#)
[IBody2 Members](#)
[IBody2::GetTrackingIDs Method](#)
[IBody2::RemoveTrackingID Method](#)
[IBody2::GetTrackingIDsCount Method](#)
[IBody2::IGetTrackingIDs Method](#)
[IModelDocExtension::FindTrackedObjects Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetXform Method (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : SetXform Method (IBody2)

Obsolete. Superseded by [IBody2::ApplyTransform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetXform( _  
    ByVal XformIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim XformIn As System.Object  
Dim value As System.Boolean  
  
value = instance.SetXform(XformIn)
```

C#

```
System.bool SetXform(  
    System.object XformIn  
)
```

C++/CLI

```
System.bool SetXform(  
& System.Object^ XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Visual Basic for Applications (VBA) Syntax

See [Body2::SetXform](#).

See Also

[IBody2 Interface](#)
[IBody2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (IBody2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBody2 Interface](#) : Visible Property (IBody2)

Gets whether this body is visible or hidden.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Visible As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBody2  
Dim value As System.Boolean  
  
value = instance.Visible
```

C#

```
System.bool Visible {get;}
```

C++/CLI

```
property System.bool Visible {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the body is visible, false if it is hidden

Visual Basic for Applications (VBA) Syntax

See [Body2::Visible](#).

See Also

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0