

SOLIDWORKS API (.NET VBA C#) — Reference

(31/337): IBodyFolder-IBomFeature

SOLIDWORKS API Documentation (converted from CHM)

IBodyFolder (Type)

IBodyFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBodyFolder Interface

Allows access to the bodies in solid, surface, and various weldment folders.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBodyFolder
```

Visual Basic (Usage)

```
Dim instance As IBodyFolder
```

C#

```
public interface IBodyFolder
```

C++/CLI

```
public interface class IBodyFolder
```

Visual Basic for Applications (VBA) Syntax

See [BodyFolder](#).

Example

[Get Features of Multibody Sheet Metal Part \(C#\)](#)
[Get Features of Multibody Sheet Metal Part \(VB.NET\)](#)
[Get Features of Multibody Sheet Metal Part \(VBA\)](#)

Remarks

For details on how to get this object, see [Accessing Bodies in Body Folders](#).

Accessors

[IFeature::GetSpecificFeature2 Method](#)

Access Diagram

[BodyFolder](#)

See Also

[IBodyFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBodyFolder Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBodyFolder Interface

The following tables list the members exposed by [IBodyFolder](#).

Public Properties

Name	Description
 Type	Gets the type of body folder.

[Top](#)

Public Methods

Name	Description
 GetAutomaticCutList	Gets whether to automatically generate a cut list when the first weldment feature is inserted in a part.
 GetAutomaticUpdate	Gets whether to automatically update cut lists.
 GetBodies	Gets the bodies in the folder.
 GetBodyCount	Gets the number of bodies in the folder.
 GetCutListSortOptions	Gets the cut list sort options.
 GetCutListType	Gets the type of cut list.
 GetFeature	Gets the feature for this body folder.
 GetTopLevelFeatureCount	Gets the number of top-level features in this body folder.
 GetTopLevelFeatures	Gets the top-level features in this body folder.
 IGetBodies	Gets the bodies in the folder.
 SetAutomaticCutList	Sets whether to automatically generate a cut list when the first weldment feature is inserted in a part.
 SetAutomaticUpdate	Sets whether to automatically update cut lists.
 SortCutList	Sorts the cut list.
 UpdateCutList	Updates an automatically generated cut list.

[Top](#)

See Also

[IBodyFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBodyFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBodyFolder Interface

For a list of all members of this type, see [IBodyFolder members](#).

Public Methods

Name	Description
 GetAutomaticCutList	Gets whether to automatically generate a cut list when the first weldment feature is inserted in a part.
 GetAutomaticUpdate	Gets whether to automatically update cut lists.
 GetBodies	Gets the bodies in the folder.
 GetBodyCount	Gets the number of bodies in the folder.
 GetCutListSortOptions	Gets the cut list sort options.
 GetCutListType	Gets the type of cut list.
 GetFeature	Gets the feature for this body folder.
 GetTopLevelFeatureCount	Gets the number of top-level features in this body folder.
 GetTopLevelFeatures	Gets the top-level features in this body folder.
 IGetBodies	Gets the bodies in the folder.
 SetAutomaticCutList	Sets whether to automatically generate a cut list when the first weldment feature is inserted in a part.
 SetAutomaticUpdate	Sets whether to automatically update cut lists.
 SortCutList	Sorts the cut list.



[UpdateCutList](#)

Updates an automatically generated cut list.

[Top](#)

See Also

[IBodyFolder Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBodyFolder Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBodyFolder Interface

For a list of all members of this type, see [IBodyFolder members](#).

Public Properties

Name

Description



[Type](#)

Gets the type of body folder.

[Top](#)

See Also

[IBodyFolder Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAutomaticCutList Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetAutomaticCutList Method (IBodyFolder)

Gets whether to automatically generate a cut list when the first weldment feature is inserted in a part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAutomaticCutList() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder
```

```
Dim value As System.Boolean
```

```
value = instance.GetAutomaticCutList()
```

C#

```
System.bool GetAutomaticCutList()
```

C++/CLI

```
System.bool GetAutomaticCutList();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to automatically generate a cut list, false to not

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetAutomaticCutList](#).

Example

See the [IBodyFolder](#) examples.

Remarks

By default, a cut list is automatically generated in new weldment parts. Use [IBodyFolder::SetAutomaticCutList](#) to change the default. Use [IPartDoc::IsWeldment](#) to get whether the part contains weldment feature.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::UpdateCutList Method](#)
[IBodyFolder::GetCutListType Method \(\)](#)
[IBodyFolder::GetCutListSortOptions Method \(\)](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAutomaticUpdate Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetAutomaticUpdate Method (IBodyFolder)

Gets whether to automatically update cut lists.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAutomaticUpdate() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Boolean  
  
value = instance.GetAutomaticUpdate()
```

C#

```
System.bool GetAutomaticUpdate()
```

C++/CLI

```
System.bool GetAutomaticUpdate();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to automatically update cut lists, false to update them manually

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetAutomaticUpdate](#).

Example

See the [IBodyFolder](#) examples.

Remarks

To update cut lists...

Manually

Automatically

Call...

[IBodyFolder::UpdateCutList](#)

[IBodyFolder::SetAutomaticUpdate](#)

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodies Method (IBodyFolder)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetBodies Method (IBodyFolder)

Gets the bodies in the folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodies() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Object  
  
value = instance.GetBodies()
```

C#

```
System.object GetBodies()
```

C++/CLI

```
System.Object^ GetBodies();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IBody2](#) objects

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetBodies](#).

Example

Example

[Get Bodies in Body Folders \(VBA\)](#)
[Get Features of Multibody Sheet Metal Part \(C#\)](#)
[Get Features of Multibody Sheet Metal Part \(VB.NET\)](#)
[Get Features of Multibody Sheet Metal Part \(VBA\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

Remarks

This method gets the bodies in the folder in the order in which they appear in the FeatureManager design tree; it does not get the bodies in any subfolders. See [Accessing Bodies in Body Folders](#) for details about the IBodyFolder interface.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::IGetBodies Method](#)
[IBodyFolder::GetBodyCount Method](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodyCount Method (IBodyFolder)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetBodyCount Method (IBodyFolder)

Gets the number of bodies in the folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodyCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Integer  
  
value = instance.GetBodyCount()
```

C#

```
System.int GetBodyCount()
```

C++/CLI

```
System.int GetBodyCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bodies in the folder

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetBodyCount](#).

Example

[Get Bodies in Body Folders \(VBA\)](#)
[Get Custom Properties for Configuration \(VBA\)](#)
[Get Features of Multibody Sheet Metal Part \(C#\)](#)
[Get Features of Multibody Sheet Metal Part \(VB.NET\)](#)
[Get Features of Multibody Sheet Metal Part \(VBA\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

Remarks

Use this method before using [IBodyFolder::IGetBodies](#).

See [Accessing Bodies in Body Folders](#) for details about the BodyFolder interface.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::GetBodies Method](#)

Availability

GetCutListSortOptions Method (IBodyFolder)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetCutListSortOptions Method (IBodyFolder)

Gets the cut list sort options.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCutListSortOptions() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder
Dim value As System.Object

value = instance.GetCutListSortOptions()
```

C#

```
System.object GetCutListSortOptions()
```

C++/CLI

```
System.Object^ GetCutListSortOptions();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICutListSortOptions](#); Null if [IBodyFolder::GetAutomaticCutList](#) returns false

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetCutListSortOptions](#).

Example

See the [IBodyFolder](#) examples.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::SortCutList Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

GetCutListType Method (IBodyFolder)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetCutListType Method (IBodyFolder)

Gets the type of cut list.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCutListType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder
Dim value As System.Integer

value = instance.GetCutListType()
```

C#

```
System.int GetCutListType()
```

C++/CLI

```
System.int GetCutListType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of cut list as defined in [swCutListType](#) [e](#)

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetCutListType](#).

Example

[Get Features of Multibody Sheet Metal Part \(VBA\)](#)
[Get Features of Multibody Sheet Metal Part \(VB.NET\)](#)
[Get Features of Multibody Sheet Metal Part \(C#\)](#)

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::GetAutomaticCutList Method \(\)](#)
[IBodyFolder::SetAutomaticCutList Method \(\)](#)
[IBodyFolder::UpdateCutList Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetFeature Method (IBodyFolder)

Gets the feature for this body folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder
Dim value As Feature

value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetFeature](#).

Remarks

See [Accessing Bodies in Body Folders](#) for details about the BodyFolder interface.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTopLevelFeatureCount Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetTopLevelFeatureCount Method (IBodyFolder)

Gets the number of top-level features in this body folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTopLevelFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Integer  
  
value = instance.GetTopLevelFeatureCount()
```

C#

```
System.int GetTopLevelFeatureCount()
```

C++/CLI

```
System.int GetTopLevelFeatureCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of top-level features

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetTopLevelFeatureCount](#).

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)

Availability

GetTopLevelFeatures Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : GetTopLevelFeatures Method (IBodyFolder)

Gets the top-level features in this body folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTopLevelFeatures() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Object  
  
value = instance.GetTopLevelFeatures()
```

C#

```
System.object GetTopLevelFeatures()
```

C++/CLI

```
System.Object^ GetTopLevelFeatures();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of top-level [IFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::GetTopLevelFeatures](#).

Remarks

Use [IBodyFolder::GetTopLevelFeatureCount](#) to determine the size of this method's returned array.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)

Availability

SOLIDWORKS 2026 FCS, Revision Number 34

IGetBodies Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : IGetBodies Method (IBodyFolder)

Gets the bodies in the folder.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetBodies( _  
    ByVal Count As System.Integer _  
) As Body2
```

```
Dim instance As IBodyFolder
Dim Count As System.Integer
Dim value As Body2

value = instance.IGetBodies(Count)
```

C#

```
Body2 IGetBodies(
    System.int Count
)
```

C++/CLI

```
Body2^ IGetBodies(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of bodies in the folder

Return Value

- in-process, unmanaged C++: Pointer to an array of [IBody2](#) objects
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

This method gets the bodies in the folder; it does not get the bodies in any subfolders. See [Accessing Bodies in Body Folders](#) for details about the BodyFolder interface.

To get the number of bodies in the folder, use [IBodyFolder::GetBodyCount](#) before using this method.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::GetBodies Method](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAutomaticCutList Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : SetAutomaticCutList Method (IBodyFolder)

Sets whether to automatically generate a cut list when the first weldment feature is inserted in a part.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAutomaticCutList( _
    ByVal CutList As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)

Copy Code

```
Dim instance As IBodyFolder
Dim CutList As System.Boolean
Dim value As System.Boolean
```

```
value = instance.SetAutomaticCutList(CutList)
```

C#

```
System.bool SetAutomaticCutList(  
    System.bool CutList  
)
```

C++/CLI

```
System.bool SetAutomaticCutList(  
& System.bool CutList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CutList

True to automatically generate a cut list, false to not

Return Value

True if enabled, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::SetAutomaticCutList](#).

Example

See the [IBodyFolder](#) examples.

Remarks

Use [IBodyFolder::GetAutomaticCutList](#) to find out if automatic generation of a cut list is enabled.

This method returns false if:

- the part does not contain a weldment feature. Use [IPartDoc::IsWeldment](#) to find out if the part contains this feature.
- a cut list folder already exists in the part. You must delete the cut list before you can enable automatic generation.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::UpdateCutList Method](#)
[IBodyFolder::GetCutListType Method \(\)](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAutomaticUpdate Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : SetAutomaticUpdate Method (IBodyFolder)

Sets whether to automatically update cut lists.

.NET Syntax

Visual Basic (Declaration)

```
Function SetAutomaticUpdate( _  
    ByVal Update As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBodyFolder
Dim Update As System.Boolean
Dim value As System.Boolean

value = instance.SetAutomaticUpdate(Update)
```

C#

```
System.bool SetAutomaticUpdate(
    System.bool Update
)
```

C++/CLI

```
System.bool SetAutomaticUpdate(
    & System.bool Update
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Update

True to automatically update cut lists, false to update them manually

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::SetAutomaticUpdate](#).

Example

See the [IBodyFolder](#) examples.

Remarks

To update cut lists...	Call...
Manually	IBodyFolder::UpdateCutList
Automatically	IBodyFolder::SetAutomaticUpdate

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::GetAutomaticUpdate Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SortCutList Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : SortCutList Method (IBodyFolder)

Sorts the cut list.

.NET Syntax

Visual Basic (Declaration)

```
Function SortCutList( _
    ByVal CutListSortOptions As System.Object, _
```

```
ByVal IgnoreInvalidFacesOrFeatures As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim CutListSortOptions As System.Object  
Dim IgnoreInvalidFacesOrFeatures As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SortCutList(CutListSortOptions, IgnoreInvalidFacesOrFeatures)
```

C#

```
System.bool SortCutList(  
    System.object CutListSortOptions,  
    System.bool IgnoreInvalidFacesOrFeatures  
)
```

C++/CLI

```
System.bool SortCutList(  
& System.Object^ CutListSortOptions,  
& System.bool IgnoreInvalidFacesOrFeatures  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[CutListSortOptions](#)
[ICutListSortOptions](#)

[IgnoreInvalidFacesOrFeatures](#)

True to sort bodies ignoring any invalid excluded faces/features, false to not sort the bodies if there are invalid excluded faces/features (see **Remarks**)

Return Value

True if sorting is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::SortCutList](#).

Example

See the [IBodyFolder](#) examples.

Remarks

Use [IBodyFolder::GetCutListSortOptions](#) to populate CutListSortOptions.

This method applies the CutListSortOptions settings, sorts the cut list, and refreshes the cut list in the FeatureManager design tree.

In the Cut List Sorting Options PropertyManager you select faces/features to exclude from sorting. If some of those selected faces/features to exclude are invalid, i.e., they are not of selection type BODYFEATURE or FACE or they cannot be excluded (see the end of this **Remark**), a dialog box pops up during the sort operation with:

Failed to exclude some of the selected faces in cut list sorting. Try selecting the corresponding features instead.

Would you like to continue:

Yes (Bodies will be sorted ignoring some of the excluded faces.)

No (Bodies will not be sorted.)

IgnoreInvalidFacesOrFeatures handles the situation when some of the body faces/features selected for exclusion ([ICutListSortOptions::SetFacesOrFeaturesToExclude](#)) can not be excluded.

Set IgnoreInvalidFacesOrFeatures to:

- True, to sort bodies ignoring any invalid excluded faces/features.
- False, to not sort the bodies if there are invalid excluded faces/features.

If you set IgnoreInvalidFacesOrFeatures to false and there are invalid faces/features in the exclusion list, then this method will not sort the cut list.

Other examples of faces and features that are invalid for exclusion:

- Chamfers that remove an entire face.
- Suppressed features.
- Features that create new bodies from sketches, such as boss-extrude, revolve, and sweep.
- Certain sheet metal features.

For more information, see the **Sorting Cut Lists** topics in the SOLIDWORKS Design user-interface help.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (IBodyFolder)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : Type Property (IBodyFolder)

Gets the type of body folder.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Type As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder
Dim value As System.Integer

value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of body folder as defined in [swBodyFolderFeatureType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BodyFolder::Type](#).

Example

[Get Bodies in Body Folders \(VBA\)](#)
[Get SolidBodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)
[Get Bodies in Body Folders \(VB.NET\)](#)
[Get Bodies in Body Folders \(C#\)](#)

Remarks

See [Accessing Bodies in Body Folders](#) for details about the BodyFolder interface.

See Also

Availability

SOLIDWORKS 2005 SP2, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateCutList Method (IBodyFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBodyFolder Interface](#) : UpdateCutList Method (IBodyFolder)

Updates an automatically generated cut list.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateCutList() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBodyFolder  
Dim value As System.Boolean  
  
value = instance.UpdateCutList()
```

C#

```
System.bool UpdateCutList()
```

C++/CLI

```
System.bool UpdateCutList();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the automatically generated cut list is successfully updated, false if not or because the document does not contain an automatically generated cut list

Visual Basic for Applications (VBA) Syntax

See [BodyFolder.UpdateCutList](#).

Remarks

You must specify when to update an automatically generated cut list in a part document. However, an automatically generated cut list in a drawing is automatically updated when you open a drawing that references the cut list.

To find out if the part contains a weldment feature, use [IPartDoc::IsWeldment](#). If it does, then use [IBodyFolder::GetAutomaticCutList](#) to find out if automatic generation of a cut list is enabled.

See Also

[IBodyFolder Interface](#)
[IBodyFolder Members](#)
[IBodyFolder::SetAutomaticCutList Method](#)
[IBodyFolder::GetCutListType Method \(\)](#)

Availability

SOLIDWORKS 2006 SP2, Revision Number 14

IBomFeature (Type)

IBomFeature Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomFeature Interface

Allows access to the BOM table feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBomFeature
```

Visual Basic (Usage)

```
Dim instance As IBomFeature
```

C#

```
public interface IBomFeature
```

C++/CLI

```
public interface class IBomFeature
```

Visual Basic for Applications (VBA) Syntax

See [BomFeature](#).

Example

[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)

Accessors

[IFeature::GetSpecificFeature2 Method](#)

[IBomTableAnnotation::BomFeature Property](#)

Access Diagram

[BomFeature](#)

See Also

[IBomFeature Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBomFeature Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomFeature Interface

The following tables list the members exposed by [IBomFeature](#).

Public Properties

Name	Description
Configuration	Gets or sets the name of configuration for this BOM table.
DetailedCutList	Gets or sets whether to show the detailed cut list in this BOM table.

		
	DisplayAsOneItem	Gets or sets whether all of the configurations appear with the same item number if the BOM table contains components that have multiple configurations.
	DissolvePartLevelRows	Gets or sets whether to dissolve weldment part level rows.
	FollowAssemblyOrder2	Gets or sets whether the order of the item numbers in the BOM follows the order in which the assembly appears in the FeatureManager design tree.
	KeepCurrentItemNumbers	Gets or sets whether item numbers are kept with their components when reordering rows of a BOM table.
	KeepMissingItems	Gets and sets the Keep Missing Items option for this BOM feature.
	KeepReplacedCompOption	Gets or sets how to replace components when keeping missing items.
	Name	Gets the name of this BOM table feature.
	NumberingTypeOnIndentedBOM	Gets and sets the type of numbering for this indented BOM table.
	PartConfigurationGrouping	Gets and sets the part configuration grouping for this BOM table.
	RoutingComponentGrouping	Gets or sets the routing component grouping options for this BOM table in a drawing of an assembly containing routing components.
	SequenceStartNumber	Gets or sets the number with which to start the numbering for this BOM table.
	StrikeoutMissingItems	Inserts a horizontal line through missing items in this BOM table (also called strike outs).
	TableType	Gets and sets the type of table for the Bill of Materials.
	ZeroQuantityDisplay	Gets or sets the character or value to display when a value is 0 in this BOM table.

[Top](#)

Public Methods

Name	Description
 FollowAssemblyOrder	Obsolete. Superseded by IBomFeature.FollowAssemblyOrder2.
 GetConfigurationCount	Gets the number of configurations available to this BOM table or used in this BOM table.
 GetConfigurations	Gets the configurations available to this BOM table or used in this BOM table.
 GetFeature	Gets the BOM table feature.
 GetLinkToDisplayState	Gets the name of the Display State linked to this BOM feature.
 GetReferencedModelName	Gets the name of the model referenced by this BOM feature.
 GetTableAnnotationCount	Gets the number of BOM table annotations for this BOM table feature.
 GetTableAnnotations	Gets the BOM table annotations for this BOM table feature.
 IGetConfigurations	Gets the configurations available to this BOM table or used in this BOM table.
 IGetTableAnnotations	Gets the BOM table annotations for this BOM table feature.
 ISetConfigurations	Sets the configurations used in this BOM table.
 SetConfigurations	Sets the configurations used in this BOM table.
 SetLinkToDisplayState	Sets the name of the Display State to which to link this BOM feature.

[Top](#)

See Also

[IBomFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBomFeature Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomFeature Interface

For a list of all members of this type, see [IBomFeature members](#).

Public Methods

Name	Description
------	-------------

 FollowAssemblyOrder	Obsolete. Superseded by IBomFeature:FollowAssemblyOrder2 .
 GetConfigurationCount	Gets the number of configurations available to this BOM table or used in this BOM table.
 GetConfigurations	Gets the configurations available to this BOM table or used in this BOM table.
 GetFeature	Gets the BOM table feature.
 GetLinkToDisplayState	Gets the name of the Display State linked to this BOM feature.
 GetReferencedModelName	Gets the name of the model referenced by this BOM feature.
 GetTableAnnotationCount	Gets the number of BOM table annotations for this BOM table feature.
 GetTableAnnotations	Gets the BOM table annotations for this BOM table feature.
 IGetConfigurations	Gets the configurations available to this BOM table or used in this BOM table.
 IGetTableAnnotations	Gets the BOM table annotations for this BOM table feature.
 ISetConfigurations	Sets the configurations used in this BOM table.
 SetConfigurations	Sets the configurations used in this BOM table.
 SetLinkToDisplayState	Sets the name of the Display State to which to link this BOM feature.

[Top](#)

See Also

[IBomFeature Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBomFeature Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomFeature Interface

For a list of all members of this type, see [IBomFeature members](#).

Public Properties

Name	Description
 Configuration	Gets or sets the name of configuration for this BOM table.
 DetailedCutList	Gets or sets whether to show the detailed cut list in this BOM table.
 DisplayAsOneItem	Gets or sets whether all of the configurations appear with the same item number if the BOM table contains components that have multiple configurations.
 DissolvePartLevelRows	Gets or sets whether to dissolve weldment part level rows.
 FollowAssemblyOrder2	Gets or sets whether the order of the item numbers in the BOM follows the order in which the assembly appears in the FeatureManager design tree.
 KeepCurrentItemNumbers	Gets or sets whether item numbers are kept with their components when reordering rows of a BOM table.
 KeepMissingItems	Gets and sets the Keep Missing Items option for this BOM feature.
 KeepReplacedCompOption	Gets or sets how to replace components when keeping missing items.
 Name	Gets the name of this BOM table feature.
 NumberingTypeOnIndentedBOM	Gets and sets the type of numbering for this indented BOM table.
 PartConfigurationGrouping	Gets and sets the part configuration grouping for this BOM table.
 RoutingComponentGrouping	Gets or sets the routing component grouping options for this BOM table in a drawing of an assembly containing routing components.
 SequenceStartNumber	Gets or sets the number with which to start the numbering for this BOM table.
 StrikeoutMissingItems	Inserts a horizontal line through missing items in this BOM table (also called strike outs).
 TableType	Gets and sets the type of table for the Bill of Materials.
 ZeroQuantityDisplay	Gets or sets the character or value to display when a value is 0 in this BOM table.

[Top](#)

See Also

Configuration Property (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : Configuration Property (IBomFeature)

Gets or sets the name of configuration for this BOM table.

.NET Syntax

Visual Basic (Declaration)

Property Configuration As System.String

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.String

instance.Configuration = value
value = instance.Configuration
```

C#

```
System.string Configuration {get; set;}
```

C++/CLI

```
property System.String^ Configuration {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the configuration shown in the BOM table

Visual Basic for Applications (VBA) Syntax

See [BomFeature::Configuration](#).

Example

See [IBomFeature](#) examples.

Example

[Insert BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert BOM Table and BOM Balloon \(VBA\)](#)

Remarks

You can only use this property for BOM tables that show one configuration at a time, such as for parts and indented subassembly style BOM tables.

You cannot use this property for top-level only BOM tables because information on multiple configurations can be shown at once in that style table. In that scenario, getting this property returns an empty string and setting the property has no effect. Use the [IBomFeature::GetConfigurationCount](#), [IBomFeature::GetConfigurations](#), [IBomFeature::IGetConfigurations](#), [IBomFeature::SetConfigurations](#), or [IBomFeature::ISetConfigurations](#) for that type of table.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

DetailedCutList Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : DetailedCutList Property (IBomFeature)

Gets or sets whether to show the detailed cut list in this BOM table.

.NET Syntax

Visual Basic (Declaration)

Property DetailedCutList As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Boolean

instance.DetailedCutList = value
value = instance.DetailedCutList
```

C#

```
System.bool DetailedCutList {get; set;}
```

C++/CLI

```
property System.bool DetailedCutList {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to show the detailed cut list in the BOM table, false to not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::DetailedCutList](#).

Remarks

This property applies to all types of BOM tables.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::DissolvePartLevelRows Property\(\)](#)

Availability

SOLIDWORKS 2012 SP02, Revision Number 20.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

DisplayAsOneItem Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : DisplayAsOneItem Property (IBomFeature)

Gets or sets whether all of the configurations appear with the same item number if the BOM table contains components that have multiple configurations.

Visual Basic (Declaration)

```
Property DisplayAsOneItem As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Boolean

instance.DisplayAsOneItem = value

value = instance.DisplayAsOneItem
```

C#

```
System.bool DisplayAsOneItem {get; set;}
```

C++/CLI

```
property System.bool DisplayAsOneItem {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if different configurations are displayed as the same item number, false if not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::DisplayAsOneItem](#).

Example

See [IBomFeature](#) examples.

Remarks

This property corresponds to the **Part Configuration Grouping > Display as one item number** check box in the **Bill of Materials** PropertyManager, which displays when you create or edit a BOM table in an assembly drawing.

This property applies to top-level only BOM tables. Use [IBomFeature::TableType](#) to determine the BOM table type.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::PartConfigurationGrouping Property](#)

Availability

SOLIDWORKS 2004 SP2, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

DissolvePartLevelRows Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : DissolvePartLevelRows Property (IBomFeature)

Gets or sets whether to dissolve weldment part level rows.

Visual Basic (Declaration)

Visual Basic (Usage)

Property DissolvePartLevelRows As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Boolean

instance.DissolvePartLevelRows = value

value = instance.DissolvePartLevelRows
```

C#

```
System.bool DissolvePartLevelRows {get; set;}
```

C++/CLI

```
property System.bool DissolvePartLevelRows {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to dissolve component rows, false to not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::DissolvePartLevelRows](#).

Remarks

This getter of this property is valid only when [IBomFeature::DetailedCutList](#) is set to true.

The setter of this property is valid only for:

- BOM tables of type [swBomType_e](#).swBomType_Indented (call [IBomFeature::TableType](#) to get the BOM table type)
- and -
- when IBomFeature::DetailedCutList is set to true.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

SOLIDWORKS API Help

[Send comments on this topic.](#)

FollowAssemblyOrder Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : FollowAssemblyOrder Method (IBomFeature)

Obsolete. Superseded by [IBomFeature::FollowAssemblyOrder2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function FollowAssemblyOrder() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Boolean
```

```
value = instance.FollowAssemblyOrder()
```

C#

```
System.bool FollowAssemblyOrder()
```

C++/CLI

```
System.bool FollowAssemblyOrder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True for the items numbers in the BOM to follow the order in which the assembly appears in the FeatureManager design tree, false to not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::FollowAssemblyOrder](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

FollowAssemblyOrder2 Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : FollowAssemblyOrder2 Property (IBomFeature)

Gets or sets whether the order of the item numbers in the BOM follows the order in which the assembly appears in the FeatureManager design tree.

.NET Syntax

Visual Basic (Declaration)

```
Property FollowAssemblyOrder2 As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.Boolean  
  
instance.FollowAssemblyOrder2 = value  
  
value = instance.FollowAssemblyOrder2
```

C#

```
System.bool FollowAssemblyOrder2 {get; set;}
```

C++/CLI

```
property System.bool FollowAssemblyOrder2 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for the item numbers in the BOM to follow the order in which the assembly appears in the FeatureManager design tree, false to not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::FollowAssemblyOrder2](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::KeepCurrentItemNumbers Property](#)

Availability

SOLIDWORKS 2005 SP2, Revision Number 13

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationCount Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetConfigurationCount Method (IBomFeature)

Gets the number of configurations available to this BOM table or used in this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationCount( _  
    ByVal OnlyVisible As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim OnlyVisible As System.Boolean  
Dim value As System.Integer  
  
value = instance.GetConfigurationCount(OnlyVisible)
```

C#

```
System.int GetConfigurationCount(  
    System.bool OnlyVisible  
)
```

C++/CLI

```
System.int GetConfigurationCount(  
& System.bool OnlyVisible  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OnlyVisible

True to get the number of configurations currently displayed in this table, false to get the total number of configurations available in this table

Return Value

Number of configurations in this BOM table or available to this BOM table

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetConfigurationCount](#).

Remarks

The view associated with this BOM can contain a model with multiple configurations.

For a top-level only style BOM table, there can be several Quantity columns, each showing the results for a different configuration. For the other styles of BOM tables, only a particular configuration can be shown in the table, and that configuration can be changed. To determine the style of the BOM table, use [IBomFeature::TableType](#).

If *OnlyVisible* is...

Then the value returned is...

True	Number of configurations currently shown in the BOM table. For a top-level only style BOM table, this could be any number from 0 to the total number of configurations available. For the other styles of BOM tables, this value is always 1.
false	Total number of configurations available.

To get the configuration names, call [IBomFeature::GetConfigurations](#) or [IBomFeature::!GetConfigurations](#).

Call this method before calling IBomFeature::!GetConfigurations to get the number of configurations.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurations Method (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetConfigurations Method (IBomFeature)

Gets the configurations available to this BOM table or used in this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurations( _
    ByVal OnlyVisible As System.Boolean, _
    ByRef Visible As System.Object _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IBomFeature
Dim OnlyVisible As System.Boolean
Dim Visible As System.Object
Dim value As System.Object

value = instance.GetConfigurations(OnlyVisible, Visible)
```

C#

```
System.object GetConfigurations(
    System.bool OnlyVisible,
    out System.object Visible
)
```

C++/CLI

```
System.Object^ GetConfigurations(
    & System.bool OnlyVisible,
    & [Out] System.Object^ Visible
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OnlyVisible

True to get the names of configurations currently displayed in this table, false to get the names of configurations available to this table

Visible

Array of BOOLEANS indicating the visibility of the configurations

Return Value

Array of strings of the names of the configurations

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetConfigurations](#).

Example

[Insert BOM Table \(C#\)](#)
[Insert BOM Table \(VB.NET\)](#)
[Insert BOM Table \(VBA\)](#)

Remarks

Although this method works on all styles of BOM tables (top-level only, parts-only, indented subassemblies), it is only necessary for top-level only style tables. For the other style tables, where only a single configuration is shown at a time, using [IBomFeature::Configuration](#) is simpler and more efficient.

The view associated with this BOM can contain a model with multiple configurations. For a top-level only style BOM table, there can be several Quantity columns, each showing the results for a different configuration. For the other styles of BOM tables, only a particular configuration can be shown in the table, and that configuration can be changed. To determine the BOM table style, use the [IBomFeature::TableType](#) property.

If OnlyVisible is...	Then Names contains the names of...	And Visible...
True	Only the configurations currently shown in the BOM table. For a top-level only style BOM table, this could be any number of configurations. For the other styles of BOM tables, it is one configuration name.	Can be passed in as NULL. If it is passed in as non-NULL, the array contains True for all items.
False	All configurations available.	Contains BOOLEANs that correspond to each item in Names indicating if that particular configuration is shown in the BOM table or not.

To get the number of configurations, use [IBomFeature::GetConfigurationCount](#).

To set the configurations, use [IBomFeature::SetConfigurations](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::GetConfigurations Method](#)
[IBomFeature::SetConfigurations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetFeature Method (IBomFeature)

Gets the BOM table feature.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IFeature](#) object for this BOM table

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetFeature](#).

Example

[Export BOMs to XML \(C#\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(VBA\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLinkToDisplayState Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetLinkToDisplayState Method (IBomFeature)

Gets the name of the Display State linked to this BOM feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLinkToDisplayState() As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.String  
  
value = instance.GetLinkToDisplayState()
```

C#

```
System.string GetLinkToDisplayState()
```

C++/CLI

```
System.String^ GetLinkToDisplayState();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the Display State linked to the BOM

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetLinkToDisplayState](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::SetLinkToDisplayState Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetReferencedModelName Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetReferencedModelName Method (IBomFeature)

Gets the name of the model referenced by this BOM feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferencedModelName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.String  
  
value = instance.GetReferencedModelName()
```

C#

```
System.string GetReferencedModelName()
```

C++/CLI

```
System.String^ GetReferencedModelName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the model referenced by this BOM feature

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetReferencedModelName](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

GetTableAnnotationCount Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetTableAnnotationCount Method (IBomFeature)

Gets the number of BOM table annotations for this BOM table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotationCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.Integer
```

```
value = instance.GetTableAnnotationCount()
```

C#

```
System.int GetTableAnnotationCount()
```

C++/CLI

```
System.int GetTableAnnotationCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of BOM table annotations for this BOM table feature

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetTableAnnotationCount](#).

Remarks

Call this method before calling [IBomFeature::IGetTableAnnotations](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

GetTableAnnotations Method (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : GetTableAnnotations Method (IBomFeature)

Gets the BOM table annotations for this BOM table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTableAnnotations() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Object

value = instance.GetTableAnnotations()
```

C#

```
System.Object GetTableAnnotations()
```

C++/CLI

```
System.Object^ GetTableAnnotations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IBOMTableAnnotation](#) objects

Visual Basic for Applications (VBA) Syntax

See [BomFeature::GetTableAnnotations](#).

Example

[Export BOMs to XML \(C#\)](#)
[Export BOMs to XML \(VB.NET\)](#)
[Export BOMs to XML \(VBA\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::GetTableAnnotationCount Method](#)
[IBomFeature::IGetTableAnnotations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConfigurations Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : IGetConfigurations Method (IBomFeature)

Gets the configurations available to this BOM table or used in this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConfigurations( _
    ByVal OnlyVisible As System.Boolean, _
    ByVal Count As System.Integer, _
    ByRef Visible As System.Boolean _
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim OnlyVisible As System.Boolean
Dim Count As System.Integer
Dim Visible As System.Boolean
Dim value As System.String

value = instance.IGetConfigurations(OnlyVisible, Count, Visible)
```

C#

```
System.string IGetConfigurations(  
    System.bool OnlyVisible,  
    System.int Count,  
    out System.bool Visible  
)
```

C++/CLI

```
System.String^ IGetConfigurations(  
& System.bool OnlyVisible,  
& System.int Count,  
& [Out] System.bool Visible  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OnlyVisible

True to get the names of configurations currently displayed in this table, false to get the names of configurations available to this table

Count

Number of items in the Visible and Names arguments

Visible

Array of BOOLEANS indicating the visibility of the configurations

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of the names of the configurations
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Although this method works on all styles of BOM tables (top-level only, parts-only, indented subassemblies), it is only necessary for top-level only style tables. For the other style tables, where only a single configuration is shown at a time, using [IBomFeature::Configuration](#) is simpler and more efficient.

The view associated with this BOM can contain a model with multiple configurations. For a top-level only style BOM table, there can be several Quantity columns, each showing the results for a different configuration. For the other styles of BOM tables, only a particular configuration can be shown in the table, and that configuration can be changed. To determine the BOM table style, use the [IBomFeature::TableType](#) property.

If OnlyVisible is...	Then Names contains the names of...	And Visible...
True	Only the configurations currently shown in the BOM table. For a top-level only style BOM table, this could be any number of configurations. For the other styles of BOM tables, it is one configuration name.	Can be passed in as NULL. If it is passed in as non-NULL, the array contains True for all items.
False	All configurations available.	Contains BOOLEANS that correspond to each item in Names indicating if that particular configuration is shown in the BOM table or not.

To get the number of configurations, use [IBomFeature::GetConfigurationCount](#).

To set the configurations, use [IBomFeature::!SetConfigurations](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::!SetConfigurations Method](#)
[IBomFeature::GetConfigurations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetTableAnnotations Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : IGetTableAnnotations Method (IBomFeature)

Gets the BOM table annotations for this BOM table feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTableAnnotations( _  
    ByVal Count As System.Integer _  
) As BomTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim Count As System.Integer  
Dim value As BomTableAnnotation  
  
value = instance.IGetTableAnnotations(Count)
```

C#

```
BomTableAnnotation IGetTableAnnotations(  
    System.int Count  
)
```

C++/CLI

```
BomTableAnnotation^ IGetTableAnnotations(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of BOM table annotations for this BOM feature

Return Value

- in-process, unmanaged C++: Pointer to an array of [IBOMTableAnnotation](#) objects
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBomFeature::GetTableAnnotationCount](#) to determine the size of the array.

See Also

[IBomFeature Interface](#)

[IBomFeature Members](#)

[IBomFeature::GetTableAnnotations Method](#)

Availability

SOLIDWORKS 204 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetConfigurations Method (IBomFeature)

[See Also](#)



Sets the configurations used in this BOM table.

VB.NET Syntax

Visual Basic (Declaration)

```
Function ISetConfigurations( _
    ByVal OnlyVisible As System.Boolean, _
    ByVal Count As System.Integer, _
    ByRef Visible As System.Boolean, _
    ByRef Names As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim OnlyVisible As System.Boolean
Dim Count As System.Integer
Dim Visible As System.Boolean
Dim Names As System.String
Dim value As System.Boolean

value = instance.ISetConfigurations(OnlyVisible, Count, Visible, Names)
```

C#

```
System.bool ISetConfigurations(
    System.bool OnlyVisible,
    System.int Count,
    ref System.bool Visible,
    ref System.string Names
)
```

C++/CLI

```
System.bool ISetConfigurations(
    & System.bool OnlyVisible,
    & System.int Count,
    & System.bool% Visible,
    & System.String^% Names
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OnlyVisible

Indicator of the contents of the arrays (see **Remarks**)

Count

Number of items in Visible and Names

Visible

- in-process, unmanaged C++: Pointer to an array of Booleans indicating the visibility of the configurations

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Names

- in-process, unmanaged C++: Pointer to an array of strings of the names of the configurations

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if configurations are set, false if not

Remarks

Although this method works on all styles of BOM tables (top-level only, parts-only, indented subassemblies), it is only necessary for top-level only style tables. For the other style tables, where only a single configuration is shown at a time, using [IBomFeature::Configuration](#) is simpler and more efficient.

NOTE: If the **Restrict top-level only BOMs to one configuration** option on the **Document Properties > Tables > Bill of Materials** dialog or [IModelDocExtension::GetUserPreferenceToggle\(swUserPreferenceToggle_e.swOneConfigOnlyTopLevelBom\)](#) returns true, then only the active or default configuration of the drawing view is inserted in the BOM.

The view associated with this BOM can contain a model with multiple configurations. For a top-level only style BOM table, there can be several Quantity columns, each showing the results for a different configuration. For the other styles of BOM tables, only a particular configuration can be shown in the table, and that configuration can be changed. To determine the BOM table style, use the [IBomFeature::TableType](#) property.

If OnlyVisible is...	Then Names contains the names of...	And Visible...
True	Only the configurations currently shown in the BOM table. For a top-level only style BOM table, this could be any number of configurations. For the other styles of BOM tables, it is one configuration name.	Can be passed in as null. If it is passed in as non-null, the array contains true for all items.
False	All configurations available.	Contains Booleans that correspond to each item in Names indicating if that particular configuration is shown in the BOM table or not.

To get the number of configurations, use [IBomFeature::GetConfigurationCount](#).

 See Also

- [IBomFeature Interface](#)
- [IBomFeature Members](#)
- [IBomFeature::SetConfigurations Method](#)
- [IBomFeature::IGetConfigurations Method](#)

 Availability

SOLIDWORKS 2004 FCS, revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepCurrentItemNumbers Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : KeepCurrentItemNumbers Property (IBomFeature)

Gets or sets whether item numbers are kept with their components when reordering rows of a BOM table.

 .NET Syntax

Visual Basic (Declaration)

Property KeepCurrentItemNumbers As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.Boolean  
  
instance.KeepCurrentItemNumbers = value  
  
value = instance.KeepCurrentItemNumbers
```

C#

```
System.bool KeepCurrentItemNumbers {get; set;}
```

C++/CLI

```
property System.bool KeepCurrentItemNumbers {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if item numbers are kept with their components when reordering rows, false if not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::KeepCurrentItemNumbers](#).

Example

See [IBomFeature](#) examples.

Remarks

Rows in a BOM table can be reordered in several different ways. For example, you can interactively reorder the rows manually in the **Bill of Materials Properties** dialog box and you can programmatically reorder rows using [IBomFeature::FollowAssemblyOrder2](#).

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 SP2, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepMissingItems Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : KeepMissingItems Property (IBomFeature)

Gets and sets the **Keep Missing Items** option for this BOM feature.

.NET Syntax

Visual Basic (Declaration)

Property KeepMissingItems As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.Boolean  
  
instance.KeepMissingItems = value  
  
value = instance.KeepMissingItems
```

C#

```
System.bool KeepMissingItems {get; set;}
```

C++/CLI

```
property System.bool KeepMissingItems {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep suppressed components, false to not

Visual Basic for Applications (VBA) Syntax

See [BomFeature::KeepMissingItems](#).

Example

See [IBomFeature](#) examples.

Remarks

Missing items are suppressed components.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::StrikeoutMissingItems Property](#)
[IBomFeature::KeepReplacedCompOption Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepReplacedCompOption Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : KeepReplacedCompOption Property (IBomFeature)

Gets or sets how to replace components when keeping missing items.

.NET Syntax

Visual Basic (Declaration)

Property KeepReplacedCompOption As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.KeepReplacedCompOption = value
value = instance.KeepReplacedCompOption
```

C#

```
System.int KeepReplacedCompOption {get; set;}
```

C++/CLI

```
property System.int KeepReplacedCompOption {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Option for replacing components as defined in [swKeepReplacedCompOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::KeepReplacedCompOption](#).

Example

See the [IBomFeature](#) examples.

Remarks

This property is valid only if [IBomFeature::KeepMissingItems](#) is set to true.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::StrikeoutMissingItems Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Name Property (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : Name Property (IBomFeature)

Gets the name of this BOM table feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Name As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this BOM table feature

Visual Basic for Applications (VBA) Syntax

See [BomFeature::Name](#).

Example

[Export BOM's Second Column to BOM Table Area \(C#\)](#)
[Export BOM's Second Column to BOM Table Area \(VB.NET\)](#)
[Export BOM's Second Column to BOM Table Area \(VBA\)](#)

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberingTypeOnIndentedBOM Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : NumberingTypeOnIndentedBOM Property (IBomFeature)

Gets and sets the type of numbering for this indented BOM table.

.NET Syntax

Visual Basic (Declaration)

Property NumberingTypeOnIndentedBOM As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.NumberingTypeOnIndentedBOM = value
value = instance.NumberingTypeOnIndentedBOM
```

C#

```
System.int NumberingTypeOnIndentedBOM {get; set;}
```

C++/CLI

```
property System.int NumberingTypeOnIndentedBOM {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of numbering as defined in [swNumberingType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::NumberingTypeOnIndentedBOM](#).

Example

See [IBomFeature](#) examples.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IView::InsertBomTable4 Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PartConfigurationGrouping Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : PartConfigurationGrouping Property (IBomFeature)

Gets and sets the part configuration grouping for this BOM table.

Visual Basic Syntax

Visual Basic (Declaration)

Property PartConfigurationGrouping As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.PartConfigurationGrouping = value
value = instance.PartConfigurationGrouping
```

C#

```
System.int PartConfigurationGrouping {get; set;}
```

C++/CLI

```
property System.int PartConfigurationGrouping {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Grouping as defined in [swPartConfigurationGroupingOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::PartConfigurationGrouping](#).

Remarks

This property corresponds to the **Part Configuration Grouping** section in the **Bill of Materials** PropertyManager, which displays when you create or edit a BOM table in an assembly drawing.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomTableAnnotation::GetComponents2 Method](#)
[IBomTableAnnotation::IGetComponents2 Method](#)
[IBomTableAnnotation::GetComponentsCount2 Method](#)
[IBomFeature::DisplayAsOneItem Property](#)

Availability

SOLIDWORKS 2011 SP03 , Revision Number 19.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

RoutingComponentGrouping Property (IBomFeature)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : RoutingComponentGrouping Property (IBomFeature)

Gets or sets the routing component grouping options for this BOM table in a drawing of an assembly containing routing components.

Visual Basic Syntax

Visual Basic (Declaration)

Property RoutingComponentGrouping As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.RoutingComponentGrouping = value

value = instance.RoutingComponentGrouping
```

C#

```
System.int RoutingComponentGrouping {get; set;}
```

C++/CLI

```
property System.int RoutingComponentGrouping {
    System.int get();
    void set ( &    System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Routing component grouping options as defined in [swRoutingComponentGroupOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::RoutingComponentGrouping](#).

Example

[Get and Set Routing Component Grouping Options for BOM Table \(C#\)](#)
[Get and Set Routing Component Grouping Options for BOM Table \(VB.NET\)](#)
[Get and Set Routing Component Grouping Options for BOM Table \(VBA\)](#)

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SequenceStartNumber Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : SequenceStartNumber Property (IBomFeature)

Gets or sets the number with which to start the numbering for this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Property SequenceStartNumber As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.SequenceStartNumber = value

value = instance.SequenceStartNumber
```

C#

```
System.int SequenceStartNumber {get; set;}
```

C++/CLI

```
property System.int SequenceStartNumber {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number with which to start the numbering

Visual Basic for Applications (VBA) Syntax

See [BomFeature::SequenceStartNumber](#).

Example

See [IBomFeature](#) examples.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConfigurations Method (IBomFeature)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : SetConfigurations Method (IBomFeature)

Sets the configurations used in this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function SetConfigurations( _
    ByVal OnlyVisible As System.Boolean, _
    ByVal Visible As System.Object, _
    ByVal Names As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim OnlyVisible As System.Boolean
Dim Visible As System.Object
Dim Names As System.Object
Dim value As System.Boolean

value = instance.SetConfigurations(OnlyVisible, Visible, Names)
```

C#

```
System.bool SetConfigurations(
    System.bool OnlyVisible,
    System.object Visible,
    System.object Names
)
```

C++/CLI

```
System.bool SetConfigurations(
    & System.bool OnlyVisible,
```

```
& System.Object^ Visible,  
& System.Object^ Names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OnlyVisible
Indicator of the contents of the arrays (see **Remarks**)
Visible
Array of Booleans indicating the visibility of the configurations
Names
Array of strings of the names of the configurations

Return Value

True if configurations are set, false if not

 Visual Basic for Applications (VBA) Syntax

See [BomFeature::SetConfigurations](#).

 Example

[Insert BOM Table \(C#\)](#)
[Insert BOM Table \(VB.NET\)](#)
[Insert BOM Table \(VBA\)](#)

 Remarks

Although this method works on all styles of BOM tables (top-level only, parts-only, indented subassemblies), it is only necessary for top-level only style tables. For the other style tables, where only a single configuration is shown at a time, using [IBomFeature::Configuration](#) is simpler and more efficient.

NOTE: If the **Restrict top-level only BOMs to one configuration** option on the **Document Properties > Tables > Bill of Materials** dialog or [IModelDocExtension::GetUserPreferenceToggle\(swUserPreferenceToggle_e.swOneConfigOnlyTopLevelBom\)](#) returns true, then only the active or default configuration of the drawing view is inserted in the BOM.

The view associated with this BOM can contain a model with multiple configurations. For a top-level only style BOM table, there can be several Quantity columns, each showing the results for a different configuration. For the other styles of BOM tables, only a particular configuration can be shown in the table, and that configuration can be changed. To determine the BOM table style, use the [IBomFeature::TableType](#) property.

If OnlyVisible is...	Then Names contains the names of...	And Visible...
True	Only the configurations currently shown in the BOM table. For a top-level only style BOM table, this could be any number of configurations. For the other styles of BOM tables, it is one configuration name.	Can be passed in as null or nothing. If it is passed in as non-null or non-nothing, then the array contains true for all items.
False	All configurations available.	Contains Booleans that correspond to each item in Names indicating if that particular configuration is shown in the BOM table or not.

To get the number of configurations, use [IBomFeature::GetConfigurationCount](#).

 See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::GetConfigurations Method](#)
[IBomFeature::ISetConfigurations Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetLinkToDisplayState Method (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : SetLinkToDisplayState Method (IBomFeature)

Sets the name of the Display State to which to link this BOM feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLinkToDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomFeature  
Dim DisplayStateName As System.String  
Dim value As System.Integer  
  
value = instance.SetLinkToDisplayState(DisplayStateName)
```

C#

```
System.int SetLinkToDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.int SetLinkToDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName

Name of the Display State to link to the BOM

Return Value

Return code as defined by [swLinkBomToDisplayStateError_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::SetLinkToDisplayState](#).

See Also

[IBomFeature Interface](#)

[IBomFeature Members](#)

[IBomFeature::GetLinkToDisplayState Method \(\)](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

StrikeoutMissingItems Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : StrikeoutMissingItems Property (IBomFeature)

Inserts a horizontal line through missing items in this BOM table (also called strike outs).

 .NET Syntax

Visual Basic (Declaration)

Property StrikeoutMissingItems As System.Boolean

Visual Basic (Usage) 

```
Dim instance As IBomFeature
Dim value As System.Boolean

instance.StrikeoutMissingItems = value

value = instance.StrikeoutMissingItems
```

C#

System.bool StrikeoutMissingItems {get; set;}

C++/CLI

```
property System.bool StrikeoutMissingItems {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to strike out suppressed components, false to not

 Visual Basic for Applications (VBA) Syntax

See [BomFeature::StrikeoutMissingItems](#).

 Example

See [IBomFeature](#) examples.

 Remarks

Missing items are suppressed components.
This property is valid only if [IBomFeature::KeepMissingItems](#) is set to true.

 See Also

- [IBomFeature Interface](#)
- [IBomFeature Members](#)
- [IBomFeature::KeepReplacedCompOption Property \(\)](#)

 Availability

SOLIDWORKS 2004 FCS, Revision Number 12

TableType Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : TableType Property (IBomFeature)

Gets and sets the type of table for the Bill of Materials.

 .NET Syntax

Visual Basic (Declaration)

Property TableType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer

instance.TableType = value

value = instance.TableType
```

C#

```
System.int TableType {get; set;}
```

C++/CLI

```
property System.int TableType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of table for the Bill of Materials as defined in [swBomType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::TableType](#).

Example

See [IBomFeature](#) examples.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)
[IBomFeature::Configuration Property](#)
[IBomFeature::GetConfigurationCount Method](#)
[IBomFeature::GetConfigurations Method](#)
[IBomFeature::IGetConfigurations Method](#)
[IBomFeature::SetConfigurations Method](#)
[IBomFeature::ISetConfigurations Method](#)
[IBomFeature::DetailedCutList Property](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

ZeroQuantityDisplay Property (IBomFeature)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomFeature Interface](#) : ZeroQuantityDisplay Property (IBomFeature)

Gets or sets the character or value to display when a value is 0 in this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Property ZeroQuantityDisplay As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomFeature
Dim value As System.Integer
```

```
instance.ZeroQuantityDisplay = value  
value = instance.ZeroQuantityDisplay
```

C#

```
System.int ZeroQuantityDisplay {get; set;}
```

C++/CLI

```
property System.int ZeroQuantityDisplay {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Character or value to display when value is 0 as defined by [swZeroQuantityDisplay_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomFeature::ZeroQuantityDisplay](#).

Example

See [IBomFeature](#) examples.

See Also

[IBomFeature Interface](#)
[IBomFeature Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12