

SOLIDWORKS API (.NET VBA C#) — Reference

(32/337): IBomTable-IBomTableAnnotation

SOLIDWORKS API Documentation (converted from CHM)

IBomTable (Type)

IBomTable Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTable Interface

Allows access to BOM table information and values.

IMPORTANT: You can no longer insert IBomTable objects; you can now only insert [IBomTableAnnotation](#) objects. IBomTable objects are not and cannot be converted to IBomTableAnnotation objects. Use the IBomTable APIs for legacy BOM tables only.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface IBomTable

Visual Basic (Usage)

Dim instance As [IBomTable](#)

C#

public interface IBomTable

C++/CLI

public interface class IBomTable

Visual Basic for Applications (VBA) Syntax

See [BomTable](#).

Accessors

[IView::GetBomTable](#) and [IView::IGetBomTable Method](#)
[IView::InsertBomTable](#) and [IView::IInsertBomTable Method](#)

Access Diagram

[BomTable](#)

See Also

[IBomTable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBomTable Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTable Interface

For a list of all members of this type, see [IBomTable members](#).

Public Methods

Name	Description
Attach	Obsolete. Superseded by IBomTable::Attach3 .
Attach2	Obsolete. Superseded by IBomTable::Attach3 .

 Attach3	Activates the BOM.
 DeSelect	Deselects this BOM table.
 Detach	Deactivates the BOM.
 GetColumnCount	Obsolete. Superseded by IBomTable.GetTotalColumnCount .
 GetColumnWidth	Gets the specified column width in meters.
 GetDisplayData	Returns the IDisplayData object for this BOM table.
 GetEntryText	Retrieves the contents of the specified cell as a string regardless of the cell's data type.
 GetEntryValue	Gets the contents of the specified cell.
 GetExtent	Gets the lower-left and upper-right extents of the BOM on the drawing sheet.
 GetHeaderText	Gets the header text for the specified column.
 GetRowCount	Obsolete. Superseded by IBomTable.GetTotalRowCount .
 GetRowHeight	Gets the specified row height in meters.
 GetTotalColumnCount	Gets the total number of columns in the BOM table.
 GetTotalRowCount	Gets the total number of rows in the BOM table.
 IGetDisplayData	Returns the IDisplayData object for this BOM table.
 IGetExtent	Gets the lower-left and upper-right extents of the BOM on the drawing sheet.
 IsVisible	Gets whether this BOM is visible.
 Select	Selects this BOM table and marks it.

[Top](#)

See Also

[IBomTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBomTable Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTable Interface

The following tables list the members exposed by [IBomTable](#).

Public Methods

Name	Description
 Attach	Obsolete. Superseded by IBomTable.Attach3 .
 Attach2	Obsolete. Superseded by IBomTable.Attach3 .
 Attach3	Activates the BOM.
 DeSelect	Deselects this BOM table.
 Detach	Deactivates the BOM.
 GetColumnCount	Obsolete. Superseded by IBomTable.GetTotalColumnCount .
 GetColumnWidth	Gets the specified column width in meters.
 GetDisplayData	Returns the IDisplayData object for this BOM table.
 GetEntryText	Retrieves the contents of the specified cell as a string regardless of the cell's data type.
 GetEntryValue	Gets the contents of the specified cell.
 GetExtent	Gets the lower-left and upper-right extents of the BOM on the drawing sheet.
 GetHeaderText	Gets the header text for the specified column.
 GetRowCount	Obsolete. Superseded by IBomTable.GetTotalRowCount .
 GetRowHeight	Gets the specified row height in meters.

		
	GetTotalColumnCount	Gets the total number of columns in the BOM table.
	GetTotalRowCount	Gets the total number of rows in the BOM table.
	IGetDisplayData	Returns the IDisplayData object for this BOM table.
	IGetExtent	Gets the lower-left and upper-right extents of the BOM on the drawing sheet.
	IsVisible	Gets whether this BOM is visible.
	Select	Selects this BOM table and marks it.

[Top](#)

See Also

[IBomTable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Attach Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : Attach Method (IBomTable)

Obsolete. Superseded by [IBomTable::Attach3](#).

.NET Syntax

Visual Basic (Declaration)

Sub Attach()

Visual Basic (Usage)



```
Dim instance As IBomTable
instance.Attach()
```

C#

```
void Attach()
```

C++/CLI

```
void Attach();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BomTable::Attach](#).

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Attach2 Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : Attach2 Method (IBomTable)

Obsolete. Superseded by [IBomTable::Attach3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Attach2() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Boolean
```

```
value = instance.Attach2()
```

C#

```
System.bool Attach2()
```

C++/CLI

```
System.bool Attach2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BomTable::Attach2](#).

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Attach3 Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : Attach3 Method (IBomTable)

Activates the BOM.

.NET Syntax

Visual Basic (Declaration)

```
Function Attach3() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Boolean
```

```
value = instance.Attach3()
```

C#

```
System.bool Attach3()
```

C++/CLI

```
System.bool Attach3();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if successfully attached, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTable::Attach3](#).

Remarks

If you want SOLIDWORKS to run in the background, then do not use this method. Using this method will cause SOLIDWORKS to become visible.

You must call this method before using any of the [IBomTable](#) methods.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::Detach](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeSelect Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : DeSelect Method (IBomTable)

Deselects this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function DeSelect() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Boolean  
  
value = instance.DeSelect()
```

C#

```
System.bool DeSelect()
```

C++/CLI

```
System.bool DeSelect();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the BOM table is successfully deselected, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTable::DeSelect](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::Select Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Detach Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : Detach Method (IBomTable)

Deactivates the BOM.

.NET Syntax

Visual Basic (Declaration)

Sub Detach()

Visual Basic (Usage)



```
Dim instance As IBomTable  
  
instance.Detach()
```

C#

void Detach()

C++/CLI

void Detach();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Use this method after you finish using the other [IBomTable](#) methods.

Visual Basic for Applications (VBA) Syntax

See [BomTable::Detach](#).

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnCount Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetColumnCount Method (IBomTable)

Obsolete. Superseded by [IBomTable::GetTotalColumnCount](#).

.NET Syntax

Visual Basic (Declaration)

Function GetColumnCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Integer  
  
value = instance.GetColumnCount()
```

C#

System.int GetColumnCount()

C++/CLI

```
System.int GetColumnCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetColumnCount](#).

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetColumnWidth Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetColumnWidth Method (IBomTable)

Gets the specified column width in meters.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnWidth(  
    ByVal Col As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim Col As System.Integer  
Dim value As System.Double
```

```
value = instance.GetColumnWidth(Col)
```

C#

```
System.double GetColumnWidth(  
    System.int Col  
)
```

C++/CLI

```
System.double GetColumnWidth(  
& System.int Col  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Col
Column number; this is a 0-based index

Return Value

Width of the specified column in meters

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetColumnWidth](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetTotalColumnCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayData Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetDisplayData Method (IBomTable)

Returns the [IDisplayData](#) object for this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Object  
  
value = instance.GetDisplayData()
```

C#

```
System.Object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Display data for this BOM table

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetDisplayData](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::IGetDisplayData](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEntryText Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetEntryText Method (IBomTable)

Retrieves the contents of the specified cell as a string regardless of the cell's data type.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntryText( _  
    ByVal Row As System.Integer, _
```

```
ByVal Col As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim Row As System.Integer  
Dim Col As System.Integer  
Dim value As System.String  
  
value = instance.GetEntryText(Row, Col)
```

C#

```
System.string GetEntryText(  
    System.int Row,  
    System.int Col  
)
```

C++/CLI

```
System.String^ GetEntryText(  
& System.int Row,  
& System.int Col  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Row number of the desired cell; this is a 0-based index

Col

Column number of the desired cell; this is a 0-based index

Return Value

Text string from the specified cell

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetEntryText](#).

Remarks

Use [IBomTable::GetEntryValue](#) for typed return values.

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)

[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntryValue Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetEntryValue Method (IBomTable)

Gets the contents of the specified cell.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntryValue( _  
    ByVal Row As System.Integer, _  
    ByVal Col As System.Integer _  
) As System.Object
```

```
Dim instance As IBomTable
Dim Row As System.Integer
Dim Col As System.Integer
Dim value As System.Object

value = instance.GetEntryValue(Row, Col)
```

C#

```
System.Object GetEntryValue(
    System.int Row,
    System.int Col
)
```

C++/CLI

```
System.Object^ GetEntryValue(
    & System.int Row,
    & System.int Col
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Row number of the desired cell; this is a 0-based index

Col

Column number of the desired cell; this is a 0-based index

Return Value

Object containing the information from the specified cell

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetEntryValue](#).

Remarks

After you receive a valid return value, you can evaluate the for the object's data type.

To return the cell contents as a string, use [IBomTable::GetEntryText](#).

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)

[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtent Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetExtent Method (IBomTable)

Gets the lower-left and upper-right extents of the BOM on the drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtent() As System.Object
```

Visual Basic (Usage)

```
Dim instance As IBomTable  
Dim value As System.Object  
  
value = instance.GetExtent()
```

C#

```
System.Object GetExtent()
```

C++/CLI

```
System.Object^ GetExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetExtent](#).

Remarks

SOLIDWORKS returns the values in meters with respect to drawing sheet space.

The return value is the following array of doubles:

[*lowerLeftPt*[3], *upperRightPt*[3]]

where:

- *lowerLeftPt*[3] is an array of 3 doubles describing the X,Y,Z location for the lower-left corner of the BOM
- *upperRightPt*[3] is an array of 3 doubles describing the X,Y,Z location for the upper-right corner of the BOM

Before you use any of the [IBomTable](#) methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetExtent Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetHeaderText Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetHeaderText Method (IBomTable)

Gets the header text for the specified column.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetHeaderText( _  
    ByVal Col As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim Col As System.Integer  
Dim value As System.String  
  
value = instance.GetHeaderText(Col)
```

C#

```
System.string GetHeaderText(  
    System.int Col  
)
```

C++/CLI

```
System.String^ GetHeaderText(  
& System.int Col  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Col
Column number with the desired header text; this is a 0-based index

Return Value

Text string from the column header

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetHeaderText](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRowCount Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetRowCount Method (IBomTable)

Obsolete. Superseded by [IBomTable::GetTotalRowCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Integer  
  
value = instance.GetRowCount()
```

C#

```
System.int GetRowCount()
```

C++/CLI

```
System.int GetRowCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetRowCount](#).

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRowHeight Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetRowHeight Method (IBomTable)

Gets the specified row height in meters.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRowHeight( _  
    ByVal Row As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim Row As System.Integer  
Dim value As System.Double  
  
value = instance.GetRowHeight(Row)
```

C#

```
System.double GetRowHeight(  
    System.int Row  
)
```

C++/CLI

```
System.double GetRowHeight(  
& System.int Row  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row

Row number; this is a 0-based index

Return Value

Height of the specified row in meters

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetRowHeight](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetTotalRowCount Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTotalColumnCount Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetTotalColumnCount Method (IBomTable)

Gets the total number of columns in the BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTotalColumnCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Integer  
  
value = instance.GetTotalColumnCount()
```

C#

```
System.int GetTotalColumnCount()
```

C++/CLI

```
System.int GetTotalColumnCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of columns in the BOM table

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetTotalColumnCount](#).

Remarks

This method returns 0 if the BOM is obscured, which may occur when debugging a macro. This is a quirk in Microsoft Excel, which is used by SOLIDWORKS for the BOM functionality.

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetTotalRowCount Method](#)
[IBomTable::GetColumnWidth Method](#)

Availability

SOLIDWORKS 2001Plus SP5, Revision Number 10.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTotalRowCount Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : GetTotalRowCount Method (IBomTable)

Gets the total number of rows in the BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTotalRowCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Integer
```

```
value = instance.GetTotalRowCount()
```

C#

```
System.int GetTotalRowCount()
```

C++/CLI

```
System.int GetTotalRowCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Total number of rows in the BOM table

Visual Basic for Applications (VBA) Syntax

See [BomTable::GetTotalRowCount](#).

Remarks

This method returns 0 if the BOM is obscured, which may occur when debugging a macro. This is a quirk in Microsoft Excel, which is used by SOLIDWORKS for the BOM functionality.

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetRowCount Method](#)
[IBomTable::GetTotalColumnCount Method](#)

Availability

SOLIDWORKS 2001Plus SP5, Revision Number 10.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDisplayData Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : IGetDisplayData Method (IBomTable)

Returns the [IDisplayData](#) object for this BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDisplayData() As DisplayData
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As DisplayData
```

```
value = instance.IGetDisplayData()
```

C#

```
DisplayData IGetDisplayData()
```

C++/CLI

```
DisplayData^ IGetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer for the [IDisplayData](#) for this BOM table

Visual Basic for Applications (VBA) Syntax

See [BomTable::IGetDisplayData](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetDisplayData Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetExtent Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : IGetExtent Method (IBomTable)

Gets the lower-left and upper-right extents of the BOM on the drawing sheet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExtent() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim value As System.Double  
  
value = instance.IGetExtent()
```

C#

```
System.double IGetExtent()
```

C++/CLI

```
System.double IGetExtent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array doubles (see **Remarks**)
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

SOLIDWORKS returns the values in meters with respect to drawing sheet space.

The return value is the following array of doubles:

[*lowerLeftPt*[3], *upperRightPt*[3]]

where:

- lowerLeftPt[3] is an array of 3 doubles describing the X,Y,Z location for the lower-left corner of the BOM
- upperRightPt[3] is an array of 3 doubles describing the X,Y,Z location for the upper-right corner of the BOM

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)
[IBomTable::GetExtent Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsVisible Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : IsVisible Method (IBomTable)

Gets whether this BOM is visible.

.NET Syntax

Visual Basic (Declaration)

```
Function IsVisible() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTable
Dim value As System.Boolean

value = instance.IsVisible()
```

C#

```
System.bool IsVisible()
```

C++/CLI

```
System.bool IsVisible();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the BOM is visible, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTable::IsVisible](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)
[IBomTable Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IBomTable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTable Interface](#) : Select Method (IBomTable)

Selects this BOM table and marks it.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Mark As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTable  
Dim Append As System.Boolean  
Dim Mark As System.Integer  
Dim value As System.Boolean  
  
value = instance.Select(Append, Mark)
```

C#

```
System.bool Select(  
    System.bool Append,  
    System.int Mark  
)
```

C++/CLI

```
System.bool Select(  
& System.bool Append,  
& System.int Mark  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the selection list, false replaces the selection list

Mark

Value you want to use as a mark

Return Value

True if the BOM table is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTable::Select](#).

Remarks

Before you use any of the IBomTable methods, activate the BOM table using [IBomTable::Attach3](#). After you finish getting BOM data, use [IBomTable::Detach](#) to deactivate the table.

See Also

[IBomTable Interface](#)

[IBomTable Members](#)

[IBomTable::DeSelect Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IBomTableAnnotation (Type)

IBomTableAnnotation Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableAnnotation Interface

Allows access to the [IBomFeature](#) object for this table annotation.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBomTableAnnotation
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation
```

C#

```
public interface IBomTableAnnotation
```

C++/CLI

```
public interface class IBomTableAnnotation
```

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation](#).

Example

[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)
[Get Components in Each BOM Table Row \(VBA\)](#)
[Sort Table \(VBA\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(C#\)](#)

Accessors

[IBomFeature::GetTableAnnotations](#) and [IBomFeature::!GetTableAnnotations](#)

[IModelDocExtension::InsertBOMTable](#)

[IView::InsertBomTable2](#)

Access Diagram

[BomTableAnnotation](#)

See Also

[IBomTableAnnotation Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBomTableSortData Interface](#)

IBomTableAnnotation Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableAnnotation Interface

The following tables list the members exposed by [IBomTableAnnotation](#).

Public Properties

Name	Description
 BomFeature	Gets the BOM for this table annotation.

[Top](#)

Public Methods

Name	Description
 ApplySavedSortScheme	Sorts this BOM table using the sort data that was previously saved in the table.
 Collapse	Collapses the specified item.
 Dissolve	Dissolves into individual components the subassembly or weldment at the specified row index of this BOM table annotation.
 Expand	Expands the specified item.
 GetAllCustomProperties	Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
 GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
 GetBomTableSortData	Gets an instance of IBomTableSortData .
 GetColumnCustomProperty	Gets the custom property used to fill the values in a specified user-defined column.
 GetColumnUseTitleAsPartNumber	Gets whether the document title is being used for the specified part-number column.
 GetComponents	Obsolete. Superseded by IBomTableAnnotation.GetComponents2.
 GetComponents2	Gets the components in the specified row for the specified configuration in this BOM table annotation.
 GetComponentsCount	Obsolete. Superseded by IBomTableAnnotation.GetComponentsCount2.
 GetComponentsCount2	Gets the number of components, the item number, and the part number in the specified row for the specified configuration in this BOM table annotation.
 GetModelPathNames	Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.
 GetModelPathNamesCount	Gets the number of model pathnames in the specified row of this BOM table annotation.
 IGetAllCustomProperties	Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
 IGetComponents	Obsolete. Superseded by IBomTableAnnotation.IGetComponents2.
 IGetComponents2	Gets the components in the specified row for the specified configuration in this BOM table annotation.
 IGetModelPathNames	Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.
 RestoreRestructuredComponents	Restores the previously dissolved subassembly or weldment at the specified row index of this BOM table annotation.
 SaveAsExcel	Saves this BOM table annotation as a Microsoft Excel document with the specified properties.
 SetColumnCustomProperty	Sets the custom property used to fill the values in a specified user-defined column.
 SetColumnUseTitleAsPartNumber	Sets whether to use the document title for the specified part-number column.
 Sort	Sorts this BOM table using the specified sorting data.

[Top](#)

See Also

[IBomTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks.Namespace](#)
[IBomTableSortData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBomTableAnnotation Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks.Namespace](#) : IBomTableAnnotation Interface

For a list of all members of this type, see [IBomTableAnnotation members](#).

Public Methods

Name	Description
------	-------------

	ApplySavedSortScheme	Sorts this BOM table using the sort data that was previously saved in the table.
	Collapse	Collapses the specified item.
	Dissolve	Dissolves into individual components the subassembly or weldment at the specified row index of this BOM table annotation.
	Expand	Expands the specified item.
	GetAllCustomProperties	Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
	GetAllCustomPropertiesCount	Gets the number of items in the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
	GetBomTableSortData	Gets an instance of IBomTableSortData .
	GetColumnCustomProperty	Gets the custom property used to fill the values in a specified user-defined column.
	GetColumnUseTitleAsPartNumber	Gets whether the document title is being used for the specified part-number column.
	GetComponents	Obsolete. Superseded by IBomTableAnnotation.GetComponents2 .
	GetComponents2	Gets the components in the specified row for the specified configuration in this BOM table annotation.
	GetComponentsCount	Obsolete. Superseded by IBomTableAnnotation.GetComponentsCount2 .
	GetComponentsCount2	Gets the number of components, the item number, and the part number in the specified row for the specified configuration in this BOM table annotation.
	GetModelPathNames	Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.
	GetModelPathNamesCount	Gets the number of model pathnames in the specified row of this BOM table annotation.
	IGetAllCustomProperties	Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.
	IGetComponents	Obsolete. Superseded by IBomTableAnnotation.IGetComponents2 .
	IGetComponents2	Gets the components in the specified row for the specified configuration in this BOM table annotation.
	IGetModelPathNames	Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.
	RestoreRestructuredComponents	Restores the previously dissolved subassembly or weldment at the specified row index of this BOM table annotation.
	SaveAsExcel	Saves this BOM table annotation as a Microsoft Excel document with the specified properties.
	SetColumnCustomProperty	Sets the custom property used to fill the values in a specified user-defined column.
	SetColumnUseTitleAsPartNumber	Sets whether to use the document title for the specified part-number column.
	Sort	Sorts this BOM table using the specified sorting data.

[Top](#)

 See Also

[IBomTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBomTableSortData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBomTableAnnotation Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableAnnotation Interface

For a list of all members of this type, see [IBomTableAnnotation members](#).

 Public Properties

Name	Description
 BomFeature	Gets the BOM for this table annotation.

[Top](#)

 See Also

[IBomTableAnnotation Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBomTableSortData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplySavedSortScheme Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : ApplySavedSortScheme Method (IBomTableAnnotation)

Sorts this BOM table using the sort data that was previously saved in the table.

.NET Syntax

Visual Basic (Declaration)

```
Function ApplySavedSortScheme( _  
    ByVal SortData As BomTableSortData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim SortData As BomTableSortData  
Dim value As System.Boolean
```

```
value = instance.ApplySavedSortScheme(SortData)
```

C#

```
System.bool ApplySavedSortScheme(  
    BomTableSortData SortData  
)
```

C++/CLI

```
System.bool ApplySavedSortScheme(  
& BomTableSortData^ SortData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SortData
[IBomTableSortData](#)

Return Value

True if BOM table is successfully sorted, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::ApplySavedSortScheme](#).

Example

[Sort Table \(VBA\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(C#\)](#)

Remarks

Before calling this method, you must:

1. Set [IBomTableSortData::SaveCurrentSortParameters](#) to true to indicate that the sort settings should be saved in the BOM table in the drawing.
2. [IBomTableAnnotation::Sort](#) to actually save the sort settings in the BOM table in the drawing.
3. [IBomTableAnnotation::GetBomTableSortData](#) to populate SortData.

See [Sorting Tables](#) for more information.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)

Availability

BomFeature Property (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : BomFeature Property (IBomTableAnnotation)

Gets the BOM for this table annotation.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property BomFeature As BomFeature
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim value As BomFeature
```

```
value = instance.BomFeature
```

C#

```
BomFeature BomFeature {get;}
```

C++/CLI

```
property BomFeature^ BomFeature {  
    BomFeature^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IBomFeature](#) object for this table annotation

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::BomFeature](#).

Example

[Insert and Show BOM Table and BOM Balloon \(C#\)](#)
[Insert and Show BOM Table and BOM Balloon \(VB.NET\)](#)
[Insert and Show BOM Table and BOM Balloon \(VBA\)](#)

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

Collapse Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : Collapse Method (IBomTableAnnotation)

Collapses the specified item.

.NET Syntax

Visual Basic (Declaration)

```
Sub Collapse( _
    ByVal CollapseType As System.Integer, _
    ByVal Index As System.Integer _
)
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation
Dim CollapseType As System.Integer
Dim Index As System.Integer

instance.Collapse(CollapseType, Index)
```

C#

```
void Collapse(
    System.int CollapseType,
    System.int Index
)
```

C++/CLI

```
void Collapse(
    & System.int CollapseType,
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CollapseType

Type of item to collapse as defined in [swBOMTableObjectType_e](#) (see **Remarks**)

Index

Row index; valid only if CollapseType is swBOMTableObjectType_e.swBOMTableObjectType_RowIndex

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::Collapse](#).

Example

[Expand, Collapse, and Dissolve a Subassembly in a BOM Table \(VBA\)](#)
[Expand, Collapse, and Dissolve a Subassembly in a BOM Table \(VB.NET\)](#)
[Expand, Collapse, and Dissolve a Subassembly in a BOM Table \(C#\)](#)

Remarks

If CollapseType is swBOMTableObjectType_e.swBOMTableObjectType_CutList, then all cut lists in the table collapse.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::Expand Method \(\)](#)
[IBomTableAnnotation::Dissolve Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Dissolve Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : Dissolve Method (IBomTableAnnotation)

Dissolves into individual components the subassembly or weldment at the specified row index of this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function Dissolve( _  
    ByVal RowIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Boolean  
  
value = instance.Dissolve(RowIndex)
```

C#

```
System.bool Dissolve(  
    System.int RowIndex  
)
```

C++/CLI

```
System.bool Dissolve(  
&    System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

1-based row index of the subassembly or weldment to dissolve

Return Value

True if the subassembly or weldment is dissolved, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::Dissolve](#).

Example

[Dissolve Subassembly in a BOM Table \(VBA\)](#)
[Dissolve Subassembly in a BOM Table \(VB.NET\)](#)
[Dissolve Subassembly in a BOM Table \(C#\)](#)

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::RestoreRestructuredComponents Method](#)
[IBomTableAnnotation::Collapse Method \(\)](#)
[IBomTableAnnotation::Expand Method \(\)](#)

Availability

SOLIDWORKS 2012 SP5, Revision Number 20.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

Expand Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : Expand Method (IBomTableAnnotation)

Expands the specified item.

.NET Syntax

Visual Basic (Declaration)

```
Sub Expand( _  
    ByVal ExpandType As System.Integer, _  
    ByVal Index As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim ExpandType As System.Integer  
Dim Index As System.Integer  
  
instance.Expand(ExpandType, Index)
```

C#

```
void Expand(  
    System.int ExpandType,  
    System.int Index  
)
```

C++/CLI

```
void Expand(  
& System.int ExpandType,  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExpandType

Type of item to expand as defined in [swBOMTableObjectType_e](#)

Index

Row index; valid only if ExpandType is swBOMTableObjectType_e.swBOMTableObjectType_RowIndex

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::Expand](#).

Example

[Expand, Collapse, and Dissolve Subassembly in a BOM Table Example \(VBA\)](#)
[Expand, Collapse, and Dissolve Subassembly in a BOM Table Example \(VB.NET\)](#)
[Expand, Collapse, and Dissolve Subassembly in a BOM Table Example \(C#\)](#)

Remarks

If ExpandType is swBOMTableObjectType_e.swBOMTableObjectType_CutList, then all cut lists in the table expand.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::Collapse Method \(\)](#)
[IBomTableAnnotation::Dissolve Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomProperties Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetAllCustomProperties Method (IBomTableAnnotation)

Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomProperties() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim value As System.Object  
  
value = instance.GetAllCustomProperties()
```

C#

```
System.Object GetAllCustomProperties()
```

C++/CLI

```
System.Object^ GetAllCustomProperties();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of strings of available custom properties

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetAllCustomProperties](#).

Example

[Get Available Custom Properties for BOM Table \(VBA\)](#)

Remarks

To get the number of custom properties, use [IBomTableAnnotation::GetAllCustomPropertiesCount](#).

The list of available custom properties includes all of the items in the BOM table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::IGetAllCustomProperties Method](#)
[IBomTableAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAllCustomPropertiesCount Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetAllCustomPropertiesCount Method (IBomTableAnnotation)

Gets the number of items in the list of available custom properties that can be used for a custom properties column in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAllCustomPropertiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim value As System.Integer  
  
value = instance.GetAllCustomPropertiesCount()
```

C#

```
System.int GetAllCustomPropertiesCount()
```

C++/CLI

```
System.int GetAllCustomPropertiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of available custom properties

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetAllCustomPropertiesCount](#).

Remarks

Call this method before calling [IBomTableAnnotation::IGetAllCustomProperties](#).

The list of possible custom properties includes all of the items in the BOM table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetAllCustomProperties Method](#)
[IBomTableAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetBomTableSortData Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetBomTableSortData Method (IBomTableAnnotation)

Gets an instance of [IBomTableSortData](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetBomTableSortData() As BomTableSortData
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim value As BomTableSortData  
  
value = instance.GetBomTableSortData()
```

C#

```
BomTableSortData GetBomTableSortData()
```

C++/CLI

```
BomTableSortData^ GetBomTableSortData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBomTableSortData](#)

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetBomTableSortData](#).

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColumnCustomProperty Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetColumnCustomProperty Method (IBomTableAnnotation)

Gets the custom property used to fill the values in a specified user-defined column.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnCustomProperty( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim Index As System.Integer  
Dim value As System.String
```

```
value = instance.GetColumnCustomProperty(Index)
```

C#

```
System.string GetColumnCustomProperty(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetColumnCustomProperty(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Column from which to get the custom property

Return Value

Custom property used to fill the values in this user-defined column

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetColumnCustomProperty](#).

Example

[Get Custom Properties for BOM Table Columns \(VBA\)](#)

Remarks

This method will return an empty string if the column is not a user-defined column.

To get the list of custom properties, use [IBomTableAnnotation::GetAllCustomProperties](#) or [IBomTableAnnotation::!GetAllCustomProperties](#). The list of possible custom properties includes all of the items in the BOM table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetAllCustomPropertiesCount Method](#)
[IBomTableAnnotation::SetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetColumnUseTitleAsPartNumber Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetColumnUseTitleAsPartNumber Method (IBomTableAnnotation)

Gets whether the document title is being used for the specified part-number column.

.NET Syntax

Visual Basic (Declaration)

```
Function GetColumnUseTitleAsPartNumber( _  
    ByVal Index As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim Index As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetColumnUseTitleAsPartNumber(Index)
```

C#

```
System.bool GetColumnUseTitleAsPartNumber(  
    System.int Index  
)
```

C++/CLI

```
System.bool GetColumnUseTitleAsPartNumber(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
0-based number indicating the part-number column

Return Value

True if document title is being used for the specified part-number column, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetColumnUseTitleAsPartNumber](#).

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::SetColumnUseTitleAsPartNumber Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponents Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetComponents Method (IBomTableAnnotation)

Obsolete. Superseded by [IBomTableAnnotation::GetComponents2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponents( _  
    ByVal RowIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetComponents(RowIndex)
```

C#

```
System.object GetComponents(  
    System.int RowIndex  
)
```

C++/CLI

```
System.Object^ GetComponents(  
& System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
Row in the BOM table where to get the components; 0-based index

Return Value

Array of [components](#) in the specified row

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetComponents](#).

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponents2 Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetComponents2 Method (IBomTableAnnotation)

Gets the components in the specified row for the specified configuration in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponents2( _  
    ByVal RowIndex As System.Integer, _  
    ByVal Configuration As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim Configuration As System.String  
Dim value As System.Object  
  
value = instance.GetComponents2(RowIndex, Configuration)
```

C#

```
System.object GetComponents2(  
    System.int RowIndex,  
    System.string Configuration  
)
```

C++/CLI

```
System.Object^ GetComponents2(  
    & System.int RowIndex,  
    & System.String^ Configuration  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

Row in the BOM table where to get the components; 0-based index

Configuration

Configuration for which to get components in top-level only BOMs; specify an empty string for parts only and indented BOMs

Return Value

Array of [components](#) in the specified row for the specified configuration

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetComponents2](#).

Example

[Get Components in Each BOM Table Row \(VBA\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetComponentsCount2 Method](#)
[IBomTableAnnotation::!GetComponents2 Method](#)

Availability

SOLIDWORKS 2011 SP03 , Revision Number 19.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponentsCount Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetComponentsCount Method (IBomTableAnnotation)

Obsolete. Superseded by [IBomTableAnnotation::GetComponentsCount2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentsCount( _  
    ByVal RowIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.GetComponentsCount(RowIndex)
```

C#

```
System.int GetComponentsCount(  
    System.int RowIndex  
)
```

C++/CLI

```
System.int GetComponentsCount(  
& System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

Row in the BOM table where to get the number of components; 0-based index

Return Value

Number of components in the specified row

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetComponentsCount](#).

Remarks

Call this method before calling [IBomTableAnnotation::!GetComponents](#) to determine the size of the array for that method.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetComponents Method](#)

Availability

GetComponentsCount2 Method (IBomTableAnnotation)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetComponentsCount2 Method (IBomTableAnnotation)

Gets the number of components, the item number, and the part number in the specified row for the specified configuration in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentsCount2( _
    ByVal RowIndex As System.Integer, _
    ByVal Configuration As System.String, _
    ByRef ItemNumber As System.String, _
    ByRef PartNumber As System.String _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation
Dim RowIndex As System.Integer
Dim Configuration As System.String
Dim ItemNumber As System.String
Dim PartNumber As System.String
Dim value As System.Integer

value = instance.GetComponentsCount2(RowIndex, Configuration, ItemNumber, PartNumber)
```

C#

```
System.int GetComponentsCount2(
    System.int RowIndex,
    System.string Configuration,
    out System.string ItemNumber,
    out System.string PartNumber
)
```

C++/CLI

```
System.int GetComponentsCount2(
    & System.int RowIndex,
    & System.String^ Configuration,
    & [Out] System.String^ ItemNumber,
    & [Out] System.String^ PartNumber
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

Row in the BOM table where to get the number of components; 0-based index

Configuration

Configuration for which to count components in top-level only BOMs; specify an empty string for parts only and indented BOMs

ItemNumber

Item number of the specified row

PartNumber

Part number of the specified row

Return Value

Number of components in the specified row for the specified configuration

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetComponentsCount2](#).

Example

[Get Components in Each BOM Table Row \(VBA\)](#)
[Get Components in Each BOM Table Row \(VB.NET\)](#)
[Get Components in Each BOM Table Row \(C#\)](#)

Remarks

Call this method before calling [IBomTableAnnotation::IGetComponents2](#) to determine the size of the array for that method.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetComponents2 Method](#)

Availability

SOLIDWORKS 2011 SP03 , Revision Number 19.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetModelPathNames Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetModelPathNames Method (IBomTableAnnotation)

Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelPathNames( _  
    ByVal RowIndex As System.Integer, _  
    ByRef ItemNumber As System.String, _  
    ByRef PartNumber As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim ItemNumber As System.String  
Dim PartNumber As System.String  
Dim value As System.Object
```

```
value = instance.GetModelPathNames(RowIndex, ItemNumber, PartNumber)
```

C#

```
System.object GetModelPathNames(  
    System.int RowIndex,  
    out System.string ItemNumber,  
    out System.string PartNumber  
)
```

C++/CLI

```
System.Object^ GetModelPathNames(  
& System.int RowIndex,  
& [Out] System.String^ ItemNumber,  
& [Out] System.String^ PartNumber  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
Row in the BOM table; 0-based index
ItemNumber
Item number for the specified BOM table row
PartNumber
Part number for the specified BOM table row

Return Value

Array of full pathnames of the models in the specified BOM table row

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetModelPathNames](#).

Example

[Get Model Pathnames in BOM Table \(C#\)](#)
[Get Model Pathnames in BOM Table \(VB.NET\)](#)
[Get Model Pathnames in BOM Table \(VBA\)](#)

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetModelPathNames Method](#)
[IBomTableAnnotation::GetModelPathNamesCount Method](#)

Availability

SOLIDWORKS 2011 SP01, Revision Number 19.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetModelPathNamesCount Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : GetModelPathNamesCount Method (IBomTableAnnotation)

Gets the number of model pathnames in the specified row of this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function GetModelPathNamesCount( _  
    ByVal RowIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.GetModelPathNamesCount(RowIndex)
```

C#

```
System.int GetModelPathNamesCount(  
    System.int RowIndex  
)
```

C++/CLI

```
System.int GetModelPathNamesCount(  
&    System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
Row in the BOM table; 0-based index

Return Value

Number of model pathnames in the specified row

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::GetModelPathNamesCount](#).

Example

[Get Model Pathnames in BOM Table \(C#\)](#)
[Get Model Pathnames in BOM Table \(VB.NET\)](#)
[Get Model Pathnames in BOM Table \(VBA\)](#)

Remarks

Call this method before calling [IBomTableAnnotation::IGetModelPathNames](#) to determine the size of the array for that method.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetModelPathNames Method](#)

Availability

SOLIDWORKS 2011 SP01, Revision Number 19.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAllCustomProperties Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : IGetAllCustomProperties Method (IBomTableAnnotation)

Gets the list of available custom properties that can be used for a custom properties column in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAllCustomProperties( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetAllCustomProperties(Count)
```

C#

```
System.string IGetAllCustomProperties(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetAllCustomProperties(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of available custom properties

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of available custom properties
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

To get the number of custom properties, use [IBomTableAnnotation::GetAllCustomPropertiesCount](#).

The list of available custom properties includes all of the items in the BOM table, which includes items from the file summary items and file custom properties that have been set.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetAllCustomProperties Method](#)
[IBomTableAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetComponents Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : IGetComponents Method (IBomTableAnnotation)

Obsolete. Superseded by [IBomTableAnnotation::IGetComponents2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponents( _  
    ByVal RowIndex As System.Integer, _  
    ByVal Count As System.Integer _  
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim Count As System.Integer  
Dim value As Component2  
  
value = instance.IGetComponents(RowIndex, Count)
```

C#

```
Component2 IGetComponents(  
    System.int RowIndex,  
    System.int Count  
)
```

C++/CLI

```
Component2^ IGetComponents(  
& System.int RowIndex,  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex
Row in the BOM table where to get the components; 0-based index
Count
Number of components in the specified row

Return Value

- in-process, unmanaged C++: Pointer to an array of [components](#) in the specified row
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBomTableAnnotation::GetComponentsCount](#) to get the value of Count.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetComponents Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetComponents2 Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : IGetComponents2 Method (IBomTableAnnotation)

Gets the components in the specified row for the specified configuration in this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetComponents2( _  
    ByVal RowIndex As System.Integer, _  
    ByVal Configuration As System.String, _  
    ByVal Count As System.Integer _  
    ) As Component2
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim Configuration As System.String  
Dim Count As System.Integer  
Dim value As Component2  
  
value = instance.IGetComponents2(RowIndex, Configuration, Count)
```

C#

```
Component2 IGetComponents2(  
    System.int RowIndex,  
    System.string Configuration,  
    System.int Count  
)
```

C++/CLI

```
Component2^ IGetComponents2(  
& System.int RowIndex,  
& System.String^ Configuration,  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

Row in the BOM table where to get the components; 0-based index

Configuration

Configuration for which to count components in top-level only BOMs; specify an empty string for parts only and indented BOMs

Count

Number of components in the specified row

Return Value

- in-process, unmanaged C++: Pointer to an array of [components](#) in the specified row for the specified configuration
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBomTableAnnotation::GetComponentsCount2](#) to get the value of Count.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::GetComponents2 Method](#)

Availability

SOLIDWORKS 2011 SP03 , Revision Number 19.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetModelPathNames Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : IGetModelPathNames Method (IBomTableAnnotation)

Gets the full pathnames of all documents in the specified row of this BOM table annotation. Also gets the item and part numbers associated with the specified row.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetModelPathNames( _  
    ByVal RowIndex As System.Integer, _  
    ByVal Count As System.Integer, _  
    ByRef ItemNumber As System.String, _  
    ByRef PartNumber As System.String _  
    ) As System.String
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim Count As System.Integer  
Dim ItemNumber As System.String  
Dim PartNumber As System.String  
Dim value As System.String  
  
value = instance.IGetModelPathNames(RowIndex, Count, ItemNumber, PartNumber)
```

C#

```
System.string IGetModelPathNames(  
    System.int RowIndex,  
    System.int Count,  
    out System.string ItemNumber,  
    out System.string PartNumber  
)
```

C++/CLI

```
System.String^ IGetModelPathNames(  
& System.int RowIndex,  
& System.int Count,  
& [Out] System.String^ ItemNumber,  
& [Out] System.String^ PartNumber  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

Row in the BOM table; 0-based index

Count

Number of model pathnames

ItemNumber

Item number for the specified BOM table row

PartNumber

Part number for the specified BOM table row

Return Value

- in-process, unmanaged C++: Pointer to an array of model pathnames in the specified row
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IBomTableAnnotation::GetModelPathNamesCount](#) to get the value of Count.

See Also

[IBomTableAnnotation Interface](#)

[IBomTableAnnotation Members](#)

[IBomTableAnnotation::GetModelPathNames Method](#)

Availability

SOLIDWORKS 2011 SP01, Revision Number 19.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

RestoreRestructuredComponents Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : RestoreRestructuredComponents Method (IBomTableAnnotation)

Restores the previously dissolved subassembly or weldment at the specified row index of this BOM table annotation.

.NET Syntax

Visual Basic (Declaration)

```
Function RestoreRestructuredComponents( _  
    ByVal RowIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim RowIndex As System.Integer  
Dim value As System.Boolean
```

```
value = instance.RestoreRestructuredComponents(RowIndex)
```

C#

```
System.bool RestoreRestructuredComponents(  
    System.int RowIndex  
)
```

C++/CLI

```
System.bool RestoreRestructuredComponents(  
& System.int RowIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowIndex

1-based row index, if more than one subassembly or weldment are dissolved; 0, if only one subassembly or weldment is dissolved

Return Value

True if the subassembly or weldment is restored, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::RestoreRestructuredComponents](#).

Example

[Dissolve Subassembly in a BOM Table \(VBA\)](#)
[Dissolve Subassembly in a BOM Table \(VB.NET\)](#)
[Dissolve Subassembly in a BOM Table \(C#\)](#)

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::Dissolve Method](#)

Availability

SOLIDWORKS 2012 SP5, Revision Number 20.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveAsExcel Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : SaveAsExcel Method (IBomTableAnnotation)

Saves this BOM table annotation as a Microsoft Excel document with the specified properties.

.NET Syntax

Visual Basic (Declaration)

```
Function SaveAsExcel( _  
    ByVal FileName As System.String, _  
    ByVal IncludeHidden As System.Boolean, _  
    ByVal IncludeFileImages As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim FileName As System.String  
Dim IncludeHidden As System.Boolean  
Dim IncludeFileImages As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SaveAsExcel(FileName, IncludeHidden, IncludeFileImages)
```

C#

```
System.bool SaveAsExcel(  
    System.string FileName,  
    System.bool IncludeHidden,  
    System.bool IncludeFileImages  
)
```

C++/CLI

```
System.bool SaveAsExcel(  
& System.String^ FileName,  
& System.bool IncludeHidden,  
& System.bool IncludeFileImages  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FileName

Full path and file name of the Microsoft Excel file to save to (*.xls)

IncludeHidden

True to include text in hidden cells, false to not

IncludeFileImages

True to include file images, false to not

Return Value

True if the table is saved as a Microsoft Excel file, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::SaveAsExcel](#).

Example

[Save Table to Microsoft Excel \(VBA\)](#)

See Also

[IBomTableAnnotation Interface](#)

[IBomTableAnnotation Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnCustomProperty Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : SetColumnCustomProperty Method (IBomTableAnnotation)

Sets the custom property used to fill the values in a specified user-defined column.

.NET Syntax

Visual Basic (Declaration)

```
Function SetColumnCustomProperty( _  
    ByVal Index As System.Integer, _  
    ByVal CustomProp As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim Index As System.Integer  
Dim CustomProp As System.String  
Dim value As System.Boolean
```

```
value = instance.SetColumnCustomProperty(Index, CustomProp)
```

C#

```
System.bool SetColumnCustomProperty(  
    System.int Index,  
    System.string CustomProp  
)
```

C++/CLI

```
System.bool SetColumnCustomProperty(  
& System.int Index,  
& System.String^ CustomProp  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Column for which to get the custom property

CustomProp

Custom property used to fill the values in this user-defined column

Return Value

True if the custom property is successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::SetColumnCustomProperty](#).

Remarks

Use this method to create a user-defined column where each row in the column is automatically filled in with the custom property value for that particular configuration for that component. The default title for the column is the name of the custom property. If the specified custom property is not a valid custom property, then each row in the column remains empty.

To create a user-defined column that is not attached to a custom property; for example, you want to fill in each row of the column yourself, use this method with the CustomProp value specified as the title of the column.

To get the list of available custom properties, use [IBomTableAnnotation::GetAllCustomProperties](#) or [IBomTableAnnotation::!GetAllCustomProperties](#). The list of available custom properties includes all of the items in the BOM table, which includes items from the file summary items and file custom properties that have been set.

This method returns false if the column is not a user-defined column, and no action is taken.

See Also

[IBomTableAnnotation Interface](#)

[IBomTableAnnotation Members](#)

[IBomTableAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 SP1, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetColumnUseTitleAsPartNumber Method (IBomTableAnnotation)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : SetColumnUseTitleAsPartNumber Method (IBomTableAnnotation)

Sets whether to use the document title for the specified part-number column.

.NET Syntax

Visual Basic (Declaration)

```
Function SetColumnUseTitleAsPartNumber( _  
    ByVal Index As System.Integer, _  
    ByVal UseTitle As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBomTableAnnotation  
Dim Index As System.Integer  
Dim UseTitle As System.Boolean  
Dim value As System.Boolean
```

```
value = instance.SetColumnUseTitleAsPartNumber(Index, UseTitle)
```

C#



```
System.bool SetColumnUseTitleAsPartNumber(  
    System.int Index,  
    System.bool UseTitle  
)
```

C++/CLI

```
System.bool SetColumnUseTitleAsPartNumber(  
& System.int Index,  
& System.bool UseTitle  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

0-based index indicating the part-number column

UseTitle

True to use the document title for the specified part-number column, false to not

Return Value

True to use the document title for the specified part-number column, false if you specify an invalid column number or the specified column is not the part-number column

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::SetColumnUseTitleAsPartNumber](#).

See Also

[IBomTableAnnotation Interface](#)

[IBomTableAnnotation Members](#)

[IBomTableAnnotation::GetColumnCustomProperty Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12

SOLIDWORKS API Help

[Send comments on this topic.](#)

Sort Method (IBomTableAnnotation)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableAnnotation Interface](#) : Sort Method (IBomTableAnnotation)

Sorts this BOM table using the specified sorting data.

.NET Syntax

Visual Basic (Declaration)

```
Function Sort(  
    ByVal SortData As BomTableSortData  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableAnnotation  
Dim SortData As BomTableSortData  
Dim value As System.Boolean
```

```
value = instance.Sort(SortData)
```

C#

```
System.bool Sort(  
    BomTableSortData SortData  
)
```

C++/CLI

```
System.bool Sort(  
& BomTableSortData^ SortData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[SortData](#)
[IBomTableSortData](#)

Return Value

True if sorted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [BomTableAnnotation::Sort](#).

Example

[Sort Table \(C#\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(VBA\)](#)

Remarks

Before calling this method, call [IBomTableAnnotation::GetBomTableSortData](#) to populate SortData.

See [Sorting Tables](#) for more information.

See Also

[IBomTableAnnotation Interface](#)
[IBomTableAnnotation Members](#)
[IBomTableAnnotation::ApplySavedSortScheme Method \(\)](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0