

SOLIDWORKS API (.NET VBA C#) — Reference

(33/337): IBomTableSortData- IBoundaryBossFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IBomTableSortData (Type)

IBomTableSortData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableSortData Interface

Allows access to the sort data of an [IBomTableAnnotation](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBomTableSortData
```

Visual Basic (Usage)

```
Dim instance As IBomTableSortData
```

C#

```
public interface IBomTableSortData
```

C++/CLI

```
public interface class IBomTableSortData
```

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData](#).

Example

[Sort Table \(VBA\)](#)
[Sort Table \(VB.NET\)](#)
[Sort Table \(C#\)](#)

Remarks

See [Sorting Tables](#) for more information.

Accessors

[IBomTableAnnotation::GetBomTableSortData](#)

Access Diagram

[BomTableSortData](#)

See Also

[IBomTableSortData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBomTableSortData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableSortData Interface

The following tables list the members exposed by [IBomTableSortData](#).

Public Properties

Name	Description
 Ascending	Gets and sets whether this is an ascending sort for the specified sort order index.
 ColumnIndex	Gets and sets the column index for the specified sort order index.
 DoNotChangeItemNumber	Gets and sets whether to change BOM item numbers after sorting.
 ItemGroups	Gets and sets the categories into which the BOM table rows are grouped.
 SaveCurrentSortParameters	Gets and sets whether to save the current sort settings in the BOM table in the drawing.
 SortMethod	Gets and sets the method for sorting the BOM table.

[Top](#)

 See Also

[IBomTableSortData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBomTableSortData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBomTableSortData Interface

For a list of all members of this type, see [IBomTableSortData members](#).

 Public Properties

Name	Description
 Ascending	Gets and sets whether this is an ascending sort for the specified sort order index.
 ColumnIndex	Gets and sets the column index for the specified sort order index.
 DoNotChangeItemNumber	Gets and sets whether to change BOM item numbers after sorting.
 ItemGroups	Gets and sets the categories into which the BOM table rows are grouped.
 SaveCurrentSortParameters	Gets and sets whether to save the current sort settings in the BOM table in the drawing.
 SortMethod	Gets and sets the method for sorting the BOM table.

[Top](#)

 See Also

[IBomTableSortData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Ascending Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : Ascending Property (IBomTableSortData)

Gets and sets whether this is an ascending sort for the specified sort order index.

 .NET Syntax

Visual Basic (Declaration)

```
Property Ascending( _  
    ByVal SortOrderIndex As System.Integer _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableSortData  
Dim SortOrderIndex As System.Integer  
Dim value As System.Boolean  
  
instance.Ascending(SortOrderIndex) = value
```

```
value = instance.Ascending(SortOrderIndex)
```

C#

```
System.bool Ascending(  
    System.int SortOrderIndex  
) {get; set;}
```

C++/CLI

```
property System.bool Ascending {  
    System.bool get(System.int SortOrderIndex);  
    void set (System.int SortOrderIndex, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SortOrderIndex
0 for primary sort, 1 for secondary sort, 2 for tertiary sort (see **Remarks**)

Property Value

True if sort is ascending, false if descending

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData.Ascending](#).

Example

See the [IBomTableSortData](#) examples.

Remarks

BOM tables may be sorted by up to three columns. This property maps the sort order index with a sorting direction (ascending or descending). Call this property three times to set the sorting directions of all three sort order indexes.

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ColumnIndex Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : ColumnIndex Property (IBomTableSortData)

Gets and sets the column index for the specified sort order index.

.NET Syntax

Visual Basic (Declaration)

```
Property ColumnIndex( _  
    ByVal SortOrderIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableSortData  
Dim SortOrderIndex As System.Integer  
Dim value As System.Integer
```

```
instance.ColumnIndex(SortOrderIndex) = value  
value = instance.ColumnIndex(SortOrderIndex)
```

C#

```
System.int ColumnIndex(  
    System.int SortOrderIndex  
) {get; set;}
```

C++/CLI

```
property System.int ColumnIndex {  
    System.int get(System.int SortOrderIndex);  
    void set (System.int SortOrderIndex, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SortOrderIndex
0 for primary sort, 1 for secondary sort, 2 for tertiary sort (see **Remarks**)

Property Value

0-based column index mapped to the specified SortOrderIndex; specify -1 if the specified SortOrderIndex is not used

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData::ColumnIndex](#).

Example

See the [IBomTableSortData](#) examples.

Remarks

BOM tables may be sorted by up to three columns. This property maps one column to a sort order index. Call this property three times to set the sort order indexes of all three columns.

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DoNotChangeItemNumber Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : DoNotChangeItemNumber Property (IBomTableSortData)

Gets and sets whether to change BOM item numbers after sorting.

.NET Syntax

Visual Basic (Declaration)

```
Property DoNotChangeItemNumber As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBomTableSortData  
Dim value As System.Boolean  
  
instance.DoNotChangeItemNumber = value
```

```
value = instance.DoNotChangeItemNumber
```

C#

```
System.bool DoNotChangeItemNumber {get; set;}
```

C++/CLI

```
property System.bool DoNotChangeItemNumber {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to preserve BOM item numbers, false to re-number them

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData::DoNotChangeItemNumber](#).

Example

See the [IBomTableSortData](#) examples.

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ItemGroups Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : ItemGroups Property (IBomTableSortData)

Gets and sets the categories into which the BOM table rows are grouped.

.NET Syntax

Visual Basic (Declaration)

```
Property ItemGroups As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBomTableSortData  
Dim value As System.Object
```

```
instance.ItemGroups = value
```

```
value = instance.ItemGroups
```

C#

```
System.object ItemGroups {get; set;}
```

C++/CLI

```
property System.Object^ ItemGroups {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of categories as defined in [swBomTableSortItemGroup_e](#) or null (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData::ItemGroups](#).

Example

See the [IBomTableSortData](#) examples.

Remarks

You can set this property in one of two ways:

- Specify null to indicate that the BOM table rows are not to be grouped into categories.
- Specify an array of [swBomTableSortItemGroup_e](#) enumerators to indicate that the BOM table rows are to be grouped into categories (assemblies, parts, user defined).

For example, when you set this property to an array of three enumerators in the following order, assemblies are grouped first, parts are grouped next, and user-defined categories are grouped last:

- [swBomTableSortItemGroup_e](#).swBomTableSortItemGroup_Assemblies
- [swBomTableSortItemGroup_e](#).swBomTableSortItemGroup_Parts
- [swBomTableSortItemGroup_e](#).swBomTableSortItemGroup_Other

To eliminate grouping into a category, do not include it in the array.

For example, when you set this property to the following array, no assemblies are grouped, parts are grouped first, and user-defined categories are grouped last:

- [swBomTableSortItemGroup_e](#).swBomTableSortItemGroup_Parts
- [swBomTableSortItemGroup_e](#).swBomTableSortItemGroup_Other

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SaveCurrentSortParameters Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : SaveCurrentSortParameters Property (IBomTableSortData)

Gets and sets whether to save the current sort settings in the BOM table in the drawing.

.NET Syntax

Visual Basic (Declaration)

Property SaveCurrentSortParameters As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBomTableSortData
Dim value As System.Boolean
```

```
instance.SaveCurrentSortParameters = value
```

```
value = instance.SaveCurrentSortParameters
```

C#

```
System.bool SaveCurrentSortParameters {get; set;}
```

C++/CLI

```
property System.bool SaveCurrentSortParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to save the current sort settings in the BOM table, false to not

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData::SaveCurrentSortParameters](#).

Example

See the [IBomTableSortData](#) examples.

Remarks

After setting this property to true, you must call [IBomTableAnnotation::Sort](#) to actually save the sort settings in the BOM table in the drawing. Thereafter, instead of setting all of the sorting parameters every time you instantiate a new IBomTableAnnotation for this table, you can simply call [IBomTableAnnotation::ApplySavedSortScheme](#) to re-sort the table using the sort settings saved in the BOM table.

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SortMethod Property (IBomTableSortData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBomTableSortData Interface](#) : SortMethod Property (IBomTableSortData)

Gets and sets the method for sorting the BOM table.

.NET Syntax

Visual Basic (Declaration)

```
Property SortMethod As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBomTableSortData  
Dim value As System.Integer
```

```
instance.SortMethod = value
```

```
value = instance.SortMethod
```

C#

```
System.int SortMethod {get; set;}
```

C++/CLI

```
property System.int SortMethod {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sort method as defined by [swBomTableSortMethod_e](#)

Visual Basic for Applications (VBA) Syntax

See [BomTableSortData::SortMethod](#).

Example

See the [IBomTableSortData](#) examples.

See Also

[IBomTableSortData Interface](#)
[IBomTableSortData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

IBoundaryBossFeatureData (Type)

IBoundaryBossFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBoundaryBossFeatureData Interface

Allows access to a boundary feature that is a boss or base.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBoundaryBossFeatureData
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
```

C#

```
public interface IBoundaryBossFeatureData
```

C++/CLI

```
public interface class IBoundaryBossFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#)

Access Diagram

[BoundaryBossFeatureData](#)

See Also

[IBoundaryBossFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertNetBlend Method \(\)](#)
[IFeatureManager::SetNetBlendCurveData Method \(\)](#)
[IFeatureManager::SetNetBlendDirectionData Method \(\)](#)

IBoundaryBossFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBoundaryBossFeatureData Interface

The following tables list the members exposed by [IBoundaryBossFeatureData](#).

Public Properties

Name	Description
AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the boundary feature to affect in the multibody part.

 D1CurveInfluence	Gets or sets the type of curve influence for Direction 1 for this boundary feature.
 D1Curves	Gets or sets the curves for Direction 1 for this boundary feature.
 D2CurveInfluence	Gets or sets the type of curve influence for Direction 2 for this boundary feature.
 D2Curves	Gets or sets the curves for Direction 2 for this boundary feature.
 FeatureScope	Gets or sets whether to use scope for the boundary feature in a multibody part.
 FeatureScopeBodies	Gets or sets the bodies that this boundary feature affects in a multibody part.
 FeatureScopeBodiesCount	Gets the number of bodies that this boundary feature affects in a multibody part.
 MergeResult	Gets or sets whether to merge all boundary feature elements.
 MergeTangentFaces	Gets or sets whether to make the surfaces in the resulting boundary feature tangent if the corresponding boundary segments are tangent.
 ThinFeatureReversed	Gets whether this thin feature boundary feature is reversed.
 ThinFeatureThickness	Gets or sets the thickness of this thin feature boundary feature.
 ThinFeatureType	Gets or sets the type of thin feature for this boundary feature.
 TrimByD1	Gets whether to trim surfaces in Direction 1 when curves do not form a closed boundary feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this boundary feature.
 GetAlignmentType	Gets the type of alignment for the specified curve in the specified direction for this boundary feature.
 GetCurvesCount	Gets the number of curves in the specified direction in this boundary feature.
 GetDirectionVector	Gets the entity used as the direction vector for the specified curve in the specified direction in this boundary feature.
 GetDraftAngle	Gets the draft angle for the specified curve in the specified direction in this boundary feature.
 GetDraftAngleReverseDirection	Gets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.
 GetGuideTangencyType	Gets the type of tangency for the specified curve in the specified direction in this boundary feature.
 GetTangentApplyToAll	Gets whether one handle that controls all constraints for the entire profile is displayed for the specified curve in the specified direction in this boundary feature.
 GetTangentDirectionReversed	Gets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.
 GetTangentInfluence	Gets the curve influence for the specified curve in the specified direction in this boundary feature.
 GetTangentLength	Gets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.
 IsThinFeature	Gets whether the boundary feature is a thin feature.
 ReleaseSelectionAccess	Releases access to the selections for this boundary feature.
 SetAlignmentType	Sets the type of alignment for the specified curve in the specified direction for this boundary feature.
 SetDirectionVector	Sets the entity to use as the direction vector for the specified curve in the specified direction in this boundary feature.
 SetDraftAngle	Sets the draft angle for the specified curve in the specified direction in this boundary feature.
 SetDraftAngleReverseDirection	Sets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.
 SetGuideTangencyType	Sets the type of tangency for the specified curve in the specified direction in this boundary feature.
 SetTangentApplyToAll	Sets whether to display one handle that controls all constraints for the entire profile for the specified curve in the specified direction in this boundary feature.
 SetTangentDirectionReversed	Sets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.
 SetTangentInfluence	Sets the curve influence toward the next curve for the specified curve in the specified direction in this boundary feature.
 SetTangentLength	Sets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.

[Top](#)

See Also

[IBoundaryBossFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IBoundaryBossFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBoundaryBossFeatureData Interface

For a list of all members of this type, see [IBoundaryBossFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that define this boundary feature.
GetAlignmentType	Gets the type of alignment for the specified curve in the specified direction for this boundary feature.
GetCurvesCount	Gets the number of curves in the specified direction in this boundary feature.
GetDirectionVector	Gets the entity used as the direction vector for the specified curve in the specified direction in this boundary feature.
GetDraftAngle	Gets the draft angle for the specified curve in the specified direction in this boundary feature.
GetDraftAngleReverseDirection	Gets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.
GetGuideTangencyType	Gets the type of tangency for the specified curve in the specified direction in this boundary feature.
GetTangentApplyToAll	Gets whether one handle that controls all constraints for the entire profile is displayed for the specified curve in the specified direction in this boundary feature.
GetTangentDirectionReversed	Gets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.
GetTangentInfluence	Gets the curve influence for the specified curve in the specified direction in this boundary feature.
GetTangentLength	Gets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.
IsThinFeature	Gets whether the boundary feature is a thin feature.
ReleaseSelectionAccess	Releases access to the selections for this boundary feature.
SetAlignmentType	Sets the type of alignment for the specified curve in the specified direction for this boundary feature.
SetDirectionVector	Sets the entity to use as the direction vector for the specified curve in the specified direction in this boundary feature.
SetDraftAngle	Sets the draft angle for the specified curve in the specified direction in this boundary feature.
SetDraftAngleReverseDirection	Sets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.
SetGuideTangencyType	Sets the type of tangency for the specified curve in the specified direction in this boundary feature.
SetTangentApplyToAll	Sets whether to display one handle that controls all constraints for the entire profile for the specified curve in the specified direction in this boundary feature.
SetTangentDirectionReversed	Sets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.
SetTangentInfluence	Sets the curve influence toward the next curve for the specified curve in the specified direction in this boundary feature.
SetTangentLength	Sets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.

[Top](#)

See Also

[IBoundaryBossFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertNetBlend Method \(\)](#)
[IFeatureManager::SetNetBlendCurveData Method \(\)](#)
[IFeatureManager::SetNetBlendDirectionData Method \(\)](#)

IBoundaryBossFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBoundaryBossFeatureData Interface

For a list of all members of this type, see [IBoundaryBossFeatureData members](#).

Public Properties

Name	Description
------	-------------

 AutoSelect	Gets or sets whether to automatically select all or only specific bodies for the boundary feature to affect in the multibody part.
 D1CurveInfluence	Gets or sets the type of curve influence for Direction 1 for this boundary feature.
 D1Curves	Gets or sets the curves for Direction 1 for this boundary feature.
 D2CurveInfluence	Gets or sets the type of curve influence for Direction 2 for this boundary feature.
 D2Curves	Gets or sets the curves for Direction 2 for this boundary feature.
 FeatureScope	Gets or sets whether to use scope for the boundary feature in a multibody part.
 FeatureScopeBodies	Gets or sets the bodies that this boundary feature affects in a multibody part.
 FeatureScopeBodiesCount	Gets the number of bodies that this boundary feature affects in a multibody part.
 MergeResult	Gets or sets whether to merge all boundary feature elements.
 MergeTangentFaces	Gets or sets whether to make the surfaces in the resulting boundary feature tangent if the corresponding boundary segments are tangent.
 ThinFeatureReversed	Gets whether this thin feature boundary feature is reversed.
 ThinFeatureThickness	Gets or sets the thickness of this thin feature boundary feature.
 ThinFeatureType	Gets or sets the type of thin feature for this boundary feature.
 TrimByD1	Gets whether to trim surfaces in Direction 1 when curves do not form a closed boundary feature.

[Top](#)

 See Also

[IBoundaryBossFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertNetBlend Method \(\)](#)
[IFeatureManager::SetNetBlendCurveData Method \(\)](#)
[IFeatureManager::SetNetBlendDirectionData Method \(\)](#)

AccessSelections Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : AccessSelections Method (IBoundaryBossFeatureData)

Gains access to the selections that define this boundary feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBoundaryBossFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
```



Copy Code

& System.Object^ [Component](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which to modify the feature (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::AccessSelections](#).

Example

[Insert Boundary Feature \(C#\)](#)

[Insert Boundary Feature \(VB.NET\)](#)

[Insert Boundary Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the ModelDoc2 object for the part - Component argument is Nothing or null
Assembly	- TopDoc is the ModelDoc2 object for the assembly - Component argument is the Component2 object in which to modify the feature

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [BoundaryBossFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBoundaryBossFeatureData Interface](#)

[IBoundaryBossFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AutoSelect Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : AutoSelect Property (IBoundaryBossFeatureData)

Gets or sets whether to automatically select all or only specific bodies for the boundary feature to affect in the multibody part.

.NET Syntax

Visual Basic (Declaration)

Property AutoSelect As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
```

```
Dim value As System.Boolean
```

```
instance.AutoSelect = value
```

```
value = instance.AutoSelect
```

C#

```
System.bool AutoSelect {get; set;}
```

C++/CLI

```
property System.bool AutoSelect {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to automatically select all bodies, false to select [specific bodies](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::AutoSelect](#).

Remarks

This property is only available when:

- [IBoundaryBossFeatureData::FeatureScope](#) property is true.
- curves are [faces](#) or [edges](#).

The boundary feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)

[IBoundaryBossFeatureData.Members](#)

[IBoundaryBossFeatureData::FeatureScopeBodiesCount Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1CurveInfluence Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : D1CurveInfluence Property (IBoundaryBossFeatureData)

Gets or sets the type of curve influence for Direction 1 for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D1CurveInfluence As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Integer
```

```
instance.D1CurveInfluence = value
```

```
value = instance.D1CurveInfluence
```

C#

```
System.int D1CurveInfluence {get; set;}
```

C++/CLI

```
property System.int D1CurveInfluence {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of curve influence for Direction 1 as defined in [swBoundaryBossCurveInfluenceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::D1CurveInfluence](#).

Remarks

The type of curve influence direction that you specify for Direction 1 is applied to all selections in that direction. The availability of the types of curve influences depends on the geometry of the curves that you select for Direction 1.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1Curves Property \(\)](#)
[IBoundaryBossFeatureData::D2CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::D2Curves Property \(\)](#)
[IBoundaryBossFeatureData::TrimByD1 Property \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D1Curves Property (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : D1Curves Property (IBoundaryBossFeatureData)

Gets or sets the curves for Direction 1 for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

Property D1Curves As System.Object

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Object
```

```
instance.D1Curves = value
```

```
value = instance.D1Curves
```

C#

```
System.object D1Curves {get; set;}
```

C++/CLI

```
property System.Object^ D1Curves {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of curves for Direction 1 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::D1Curves](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

[Sketch curves](#), [faces](#), or [edges](#) can be used to create the boundary feature. Boundary features are created based on the order of the curve selection.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::D2CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::D2Curves Property \(\)](#)
[IBoundaryBossFeatureData::TrimByD1 Property \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2CurveInfluence Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : D2CurveInfluence Property (IBoundaryBossFeatureData)

Gets or sets the type of curve influence for Direction 2 for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Property D2CurveInfluence As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Integer
```

```
instance.D2CurveInfluence = value
```

```
value = instance.D2CurveInfluence
```

C#

```
System.int D2CurveInfluence {get; set;}
```

C++/CLI

```
property System.int D2CurveInfluence {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of curve influence for Direction 2 as defined in [swBoundaryBossCurveInfluenceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::D2CurveInfluence](#).

Remarks

The type of curve influence direction that you specify for Direction 2 is applied to all selections in that direction. The availability of the types of curve influences depends on the geometry of the curves that you select for Direction 2.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::D1Curves Property \(\)](#)
[IBoundaryBossFeatureData::D2Curves Property \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

D2Curves Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : D2Curves Property (IBoundaryBossFeatureData)

Gets or sets the curves for Direction 2 for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

Property D2Curves As System.Object

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Object  
  
instance.D2Curves = value  
  
value = instance.D2Curves
```

C#

```
System.object D2Curves {get; set;}
```

C++/CLI

```
property System.Object^ D2Curves {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of curves for Direction 2 (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::D2Curves](#).

Remarks

[Sketch curves](#), [faces](#), or [edges](#) can be used to create the boundary feature. Boundary features are created based on the order of the curve selection.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::D1Curves Property \(\)](#)
[IBoundaryBossFeatureData::D2CurveInfluence Property \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::TrimByD1 Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScope Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : FeatureScope Property (IBoundaryBossFeatureData)

Gets or sets whether to use scope for the boundary feature in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScope As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Boolean
```

```
instance.FeatureScope = value
```

```
value = instance.FeatureScope
```

C#

```
System.bool FeatureScope {get; set;}
```

C++/CLI

```
property System.bool FeatureScope {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if only the [specified bodies](#) in the multibody part are affected by the boundary feature, false if all of the bodies in the multibody part are affected by the boundary feature

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::FeatureScope](#).

Remarks

This property is only available when the curves are [faces](#) or [edges](#).

The boundary feature is expanded along the plane on which the feature is created and selects all or only the specified bodies it intersects.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::AutoSelect Property \(\)](#)
[IBoundaryBossFeatureData::FeatureScopeBodiesCount Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FeatureScopeBodies Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : FeatureScopeBodies Property (IBoundaryBossFeatureData)

Gets or sets the bodies that this boundary feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

Property FeatureScopeBodies As System.Object

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Object
```

```
instance.FeatureScopeBodies = value
```

```
value = instance.FeatureScopeBodies
```

C#

```
System.Object FeatureScopeBodies {get; set;}
```

C++/CLI

```
property System.Object^ FeatureScopeBodies {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [bodies](#) that this boundary feature affects

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::FeatureScopeBodies](#).

Remarks

This property is only available when:

- [IBoundaryBossFeatureData::FeatureScope](#) is true.
- curves are [faces](#) or [edges](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::AutoSelect Property \(\)](#)
[IBoundaryBossFeatureData::FeatureScopeBodiesCount Property \(\)](#)

Availability

FeatureScopeBodiesCount Property (IBoundaryBossFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : FeatureScopeBodiesCount Property (IBoundaryBossFeatureData)

Gets the number of bodies that this boundary feature affects in a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property FeatureScopeBodiesCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
Dim value As System.Integer

value = instance.FeatureScopeBodiesCount
```

C#

```
System.int FeatureScopeBodiesCount {get;}
```

C++/CLI

```
property System.int FeatureScopeBodiesCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

Number of bodies

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::FeatureScopeBodiesCount](#).

Remarks

This property is only available when [IBoundaryBossFeatureData::FeatureScope](#) is true.See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::FeatureScopeBodies Property \(\)](#)
[IBoundaryBossFeatureData::AutoSelect Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

GetAlignmentType Method (IBoundaryBossFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetAlignmentType Method (IBoundaryBossFeatureData)

Gets the type of alignment for the specified curve in the specified direction for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAlignmentType( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Integer  
  
value = instance.GetAlignmentType(Direction, GuideIndex)
```

C#

```
System.int GetAlignmentType(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.int GetAlignmentType(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see [Remarks](#))

Return Value

Type of alignment as defined in [swBoundaryBossAlignment_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetAlignmentType](#).

Remarks

This method is only available for a single-direction boundary feature.

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)

[IBoundaryBossFeatureData Members](#)

[IBoundaryBossFeatureData::SetAlignmentType Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurvesCount Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetCurvesCount Method (IBoundaryBossFeatureData)

Gets the number of curves in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurvesCount( _  
    ByVal Direction As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim value As System.Integer  
  
value = instance.GetCurvesCount(Direction)
```

C#

```
System.int GetCurvesCount(  
    System.int Direction  
)
```

C++/CLI

```
System.int GetCurvesCount(  
    & System.int Direction  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

Return Value

Number of curves

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetCurvesCount](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1Curves Property \(\)](#)
[IBoundaryBossFeatureData::D2Curves Property \(\)](#)
[IBoundaryBossFeatureData::GetAlignmentType Method \(\)](#)
[IBoundaryBossFeatureData::GetDirectionVector Method \(\)](#)
[IBoundaryBossFeatureData::GetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::GetDraftAngleReverseDirection Method \(\)](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetAlignmentType Method \(\)](#)
[IBoundaryBossFeatureData::SetDirectionVector Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngleReverseDirection Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetDirectionVector Method (IBoundaryBossFeatureData)

Gets the entity used as the direction vector for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDirectionVector( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetDirectionVector(Direction, GuideIndex)
```

C#

```
System.object GetDirectionVector(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.Object^ GetDirectionVector(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Return Value

Entity used as the direction vector:

- linear [edge](#)
- [axis](#)
- [face](#)
- [plane](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetDirectionVector](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

This method is only available if the type of tangency of the direction vector is [swBoundaryBossTangencyType_e](#).swBoundaryBossTangency_DirectionVector. Use [IBoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

NOTE: Using two vertices for the direction vector is not currently supported by the SOLIDWORKS API.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::SetDirectionVector Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftAngle Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetDraftAngle Method (IBoundaryBossFeatureData)

Gets the draft angle for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftAngle( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Double  
  
value = instance.GetDraftAngle(Direction, GuideIndex)
```

C#

```
System.double GetDraftAngle(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.double GetDraftAngle(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
Direction as defined in [swBoundaryBossDirection](#) e
GuideIndex
Index of the curve (see **Remarks**)

Return Value

Draft angle

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetDraftAngle](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetDraftAngleReverseDirection Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngleReverseDirection Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDraftAngleReverseDirection Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetDraftAngleReverseDirection Method (IBoundaryBossFeatureData)

Gets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDraftAngleReverseDirection( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetDraftAngleReverseDirection(Direction, GuideIndex)
```

C#

```
System.bool GetDraftAngleReverseDirection(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.bool GetDraftAngleReverseDirection(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Return Value

True if the draft angle is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetDraftAngleReverseDirection](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngleReverseDirection Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetGuideTangencyType Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetGuideTangencyType Method (IBoundaryBossFeatureData)

Gets the type of tangency for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetGuideTangencyType( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Integer
```

```
value = instance.GetGuideTangencyType(Direction, GuideIndex)
```

C#

```
System.int GetGuideTangencyType(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.int GetGuideTangencyType(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Return Value

Type of tangency as defined in [swBoundaryBossTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetGuideTangencyType](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTangentApplyToAll Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetTangentApplyToAll Method (IBoundaryBossFeatureData)

Gets whether one handle that controls all constraints for the entire profile is displayed for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTangentApplyToAll( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Boolean
```

```
value = instance.GetTangentApplyToAll(Direction, GuideIndex)
```

C#

```
System.bool GetTangentApplyToAll(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.bool GetTangentApplyToAll(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Return Value

True if one handle that controls all constraints for the entire profile is displayed, false if multiple handles that permit individual segment control are displayed

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetTangentApplyToAll](#).

Remarks

This method is only available for a single-direction boundary feature.

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTangentDirectionReversed Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetTangentDirectionReversed Method (IBoundaryBossFeatureData)

Gets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTangentDirectionReversed( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Boolean
```

```
value = instance.GetTangentDirectionReversed(Direction, GuideIndex)
```

C#

```
System.bool GetTangentDirectionReversed(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.bool GetTangentDirectionReversed(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection](#) e

GuideIndex

Index of the curve (see **Remarks**)

Return Value

True if the direction of adjacent tangent faces is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetTangentDirectionReversed](#).

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTangentInfluence Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetTangentInfluence Method (IBoundaryBossFeatureData)

Gets the curve influence for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTangentInfluence(  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



Copy Code

```

Dim instance As IBoundaryBossFeatureData
Dim Direction As System.Integer
Dim GuideIndex As System.Integer
Dim value As System.Double

value = instance.GetTangentInfluence(Direction, GuideIndex)

```

C#

```

System.double GetTangentInfluence(
    System.int Direction,
    System.int GuideIndex
)

```

C++/CLI

```

System.double GetTangentInfluence(
    & System.int Direction,
    & System.int GuideIndex
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
Direction as defined in [swBoundaryBossDirection_e](#)
GuideIndex
Index of the curve (see **Remarks**)

Return Value

Percentage of curve influence; 0.0 <= value for curve influence <= 1.0

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetTangentInfluence](#).

Remarks

This method is only available if curves in both directions exist and the type of curve influence is:

- [swBoundaryBossCurveInfluenceType_e.swBoundaryBossCurve_GlobalInfluence](#)
- or -
- [swBoundaryBossCurveInfluenceType_e.swBoundaryBossCurve_ToNextSharpInfluence](#)

Call [IBoundaryBossFeatureData::D1CurveInfluence](#) and [IBoundaryBossFeatureData::D2CurveInfluence](#) to determine the type of curve influences in both directions.

This method is not available if the type of tangency is:

- [swBoundaryBossTangencyType_e.swBoundaryBossTangency_None](#)
- or -
- [swBoundaryBossTangencyType_e.swBoundaryBossTangency_Default](#)

Call [IBoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

To get a valid range of values for GuideIndex, call [IBoundaryBossFeatureData::GetCurvesCount](#).

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

GetTangentLength Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : GetTangentLength Method (IBoundaryBossFeatureData)

Gets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTangentLength( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim value As System.Double
```

```
value = instance.GetTangentLength(Direction, GuideIndex)
```

C#

```
System.double GetTangentLength(  
    System.int Direction,  
    System.int GuideIndex  
)
```

C++/CLI

```
System.double GetTangentLength(  
& System.int Direction,  
& System.int GuideIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Return Value

Tangent length

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::GetTangentLength](#).

Remarks

This method is not available when the type of tangency is [swBoundaryBossTangencyType_e](#).swBoundaryBossTangency_None. Call [IBoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

To get a valid range of values for GuideIndex, call [IBoundaryBossFeatureData::GetCurvesCount](#).

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)

[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsThinFeature Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : IsThinFeature Method (IBoundaryBossFeatureData)

Gets whether the boundary feature is a thin feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IsThinFeature() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Boolean
```

```
value = instance.IsThinFeature()
```

C#

```
System.bool IsThinFeature()
```

C++/CLI

```
System.bool IsThinFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the boundary feature is a thin feature, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::IsThinFeature](#).

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::ThinFeatureReversed Property \(\)](#)
[IBoundaryBossFeatureData::ThinFeatureThickness Property \(\)](#)
[IBoundaryBossFeatureData::ThinFeatureType Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeResult Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : MergeResult Property (IBoundaryBossFeatureData)

Gets or sets whether to merge all boundary feature elements.

.NET Syntax

Visual Basic (Declaration)

Property MergeResult As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
Dim value As System.Boolean

instance.MergeResult = value

value = instance.MergeResult
```

C#

```
System.bool MergeResult {get; set;}
```

C++/CLI

```
property System.bool MergeResult {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to merge all boundary feature elements, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::MergeResult](#).

Remarks

This property is only available when the curves are [faces](#) or [edges](#).

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MergeTangentFaces Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : MergeTangentFaces Property (IBoundaryBossFeatureData)

Gets or sets whether to make the surfaces in the resulting boundary feature tangent if the corresponding boundary segments are tangent.

.NET Syntax

Visual Basic (Declaration)

```
Property MergeTangentFaces As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
Dim value As System.Boolean

instance.MergeTangentFaces = value
```

```
value = instance.MergeTangentFaces
```

C#

```
System.bool MergeTangentFaces {get; set;}
```

C++/CLI

```
property System.bool MergeTangentFaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to make the surfaces in the resulting boundary feature tangent if the corresponding boundary segments are tangent, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::MergeTangentFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::MergeResult Property \(\)](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : ReleaseSelectionAccess Method (IBoundaryBossFeatureData)

Releases access to the selections for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::ReleaseSelectionAccess](#).

Remarks

[IBoundaryBossFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetAlignmentType Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetAlignmentType Method (IBoundaryBossFeatureData)

Sets the type of alignment for the specified curve in the specified direction for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetAlignmentType( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal AlignmentType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim AlignmentType As System.Integer  
  
instance.SetAlignmentType(Direction, GuideIndex, AlignmentType)
```

C#

```
void SetAlignmentType(  
    System.int Direction,  
    System.int GuideIndex,  
    System.int AlignmentType  
)
```

C++/CLI

```
void SetAlignmentType(  
& System.int Direction,  
& System.int GuideIndex,  
& System.int AlignmentType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
Direction as defined in [swBoundaryBossDirection_e](#)
GuideIndex
Index of the curve (see **Remarks**)
AlignmentType
Type of alignment as defined in [swBoundaryBossAlignment_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetAlignmentType](#).

Remarks

This method is only available for a single-direction boundary feature.
You must use the appropriate combination of tangents and alignments.

Type of tangency as defined in swBoundaryBossTangencyType_e	Type of alignment as defined in swBoundaryBossAlignment_e
swBoundaryBossTangency_DirectionVector - or - swBoundaryBossTangency_NormalToProfile	• swAlignWithNextSection • swAlignWithSectionNormal
swBoundaryBossTangency_TangencyToFace -or - swBoundaryBossTangency_CurvatureToFace	• swAlignWithNextSection • swAlignWithSectionNormal • swAlignWithIsoParameter • swAlignWithOtherGeometry

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetAlignmentType Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SetDirectionVector Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetDirectionVector Method (IBoundaryBossFeatureData)

Sets the entity to use as the direction vector for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDirectionVector( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal DirectionVector As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim DirectionVector As System.Object  
  
instance.SetDirectionVector(Direction, GuideIndex, DirectionVector)
```

C#

```
void SetDirectionVector(
    System.int Direction,
    System.int GuideIndex,
    System.object DirectionVector
)
```

C++/CLI

```
void SetDirectionVector(
    & System.int Direction,
    & System.int GuideIndex,
    & System.Object^ DirectionVector
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

DirectionVector

Entity to use as the direction vector:

- linear [edge](#)
- [axis](#)
- [face](#)
- [plane](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetDirectionVector](#).

Remarks

This method is only available if the type of tangency of the direction vector is [swBoundaryBossTangencyType_e](#).swBoundaryBossTangency_DirectionVector. Use [BoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

Call [BoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

NOTE: Using two vertices for the direction vector is not currently supported by the SOLIDWORKS API.

See Also

[IBoundaryBossFeatureData Interface](#)

[IBoundaryBossFeatureData Members](#)

[IBoundaryBossFeatureData::GetDirectionVector Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDraftAngle Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetDraftAngle Method (IBoundaryBossFeatureData)

Sets the draft angle for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetDraftAngle( _
    ByVal Direction As System.Integer, _
    ByVal GuideIndex As System.Integer, _
    ByVal DraftAngle As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
Dim Direction As System.Integer
Dim GuideIndex As System.Integer
Dim DraftAngle As System.Double

instance.SetDraftAngle(Direction, GuideIndex, DraftAngle)
```

C#

```
void SetDraftAngle(
    System.int Direction,
    System.int GuideIndex,
    System.double DraftAngle
)
```

C++/CLI

```
void SetDraftAngle(
    & System.int Direction,
    & System.int GuideIndex,
    & System.double DraftAngle
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
Direction as defined in [swBoundaryBossDirection_e](#)
GuideIndex
Index of the curve (see **Remarks**)
DraftAngle
Draft angle

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetDraftAngle](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::GetDraftAngleReverseDirection Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngleReverseDirection Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetDraftAngleReverseDirection Method (IBoundaryBossFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetDraftAngleReverseDirection Method (IBoundaryBossFeatureData)

Sets whether the draft angle is flipped for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```

Sub SetDraftAngleReverseDirection( _
    ByVal Direction As System.Integer, _
    ByVal GuideIndex As System.Integer, _
    ByVal IsFlipped As System.Boolean _
)

```

Visual Basic (Usage)



```

Dim instance As IBoundaryBossFeatureData
Dim Direction As System.Integer
Dim GuideIndex As System.Integer
Dim IsFlipped As System.Boolean

instance.SetDraftAngleReverseDirection(Direction, GuideIndex, IsFlipped)

```

C#

```

void SetDraftAngleReverseDirection(
    System.int Direction,
    System.int GuideIndex,
    System.bool IsFlipped
)

```

C++/CLI

```

void SetDraftAngleReverseDirection(
    & System.int Direction,
    & System.int GuideIndex,
    & System.bool IsFlipped
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
 Direction as defined in [swBoundaryBossDirection_e](#)
GuideIndex
 Index of the curve (see **Remarks**)
IsFlipped
 True if the draft angle is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetDraftAngleReverseDirection](#).

Example

[Insert Boundary Feature \(C#\)](#)
[Insert Boundary Feature \(VB.NET\)](#)
[Insert Boundary Feature \(VBA\)](#)

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetDraftAngle Method \(\)](#)
[IBoundaryBossFeatureData::GetDraftAngleReverseDirection Method \(\)](#)
[IBoundaryBossFeatureData::SetDraftAngle Method \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetGuideTangencyType Method (IBoundaryBossFeatureData)

Sets the type of tangency for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetGuideTangencyType( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal TangType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim TangType As System.Integer  
  
instance.SetGuideTangencyType(Direction, GuideIndex, TangType)
```

C#

```
void SetGuideTangencyType(  
    System.int Direction,  
    System.int GuideIndex,  
    System.int TangType  
)
```

C++/CLI

```
void SetGuideTangencyType(  
& System.int Direction,  
& System.int GuideIndex,  
& System.int TangType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

TangType

Type of tangency as defined in [swBoundaryBossTangencyType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetGuideTangencyType](#).

Remarks

This method is only available when a minimum of three curves in the specified direction exist.

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

If specified curve is...	Then the valid types of tangency as defined in swBoundaryBossTangencyType_e are...
Sketch curve	- swBoundaryBossTangency_None - swBoundaryBossTangency_DirectionVector - swBoundaryBossTangency_NormalToProfile
Face	- swBoundaryBossTangency_None - swBoundaryBossTangency_DirectionVector - swBoundaryBossTangency_NormalToProfile - swBoundaryBossTangency_TangencyToFace - swBoundaryBossTangency_CurvatureToFace
Edge	- swBoundaryBossTangency_Default - swBoundaryBossTangency_None - swBoundaryBossTangency_DirectionVector - swBoundaryBossTangency_TangencyToFace - swBoundaryBossTangency_CurvatureToFace

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTangentApplyToAll Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetTangentApplyToAll Method (IBoundaryBossFeatureData)

Sets whether to display one handle that controls all constraints for the entire profile for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTangentApplyToAll( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal Apply As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim Apply As System.Boolean
```

```
instance.SetTangentApplyToAll(Direction, GuideIndex, Apply)
```

C#

```
void SetTangentApplyToAll(  
    System.int Direction,  
    System.int GuideIndex,  
    System.bool Apply  
)
```

C++/CLI

```
void SetTangentApplyToAll(  
& System.int Direction,  
& System.int GuideIndex,  
& System.bool Apply  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Apply

True to display one handle that controls all constraints for the entire profile, false to display multiple handles that permit individual segment control

Visual Basic for Applications (VBA) Syntax

See [IBoundaryBossFeatureData::SetTangentApplyToAll](#).

Remarks

This method is only available for a single-direction boundary feature.

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTangentDirectionReversed Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetTangentDirectionReversed Method (IBoundaryBossFeatureData)

Sets whether the direction of adjacent tangent faces is flipped for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTangentDirectionReversed( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal Flip As System.Boolean _  
)
```

Visual Basic (Usage)

```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim Flip As System.Boolean  
  
instance.SetTangentDirectionReversed(Direction, GuideIndex, Flip)
```

C#

```
void SetTangentDirectionReversed(  
    System.int Direction,  
    System.int GuideIndex,  
    System.bool Flip  
)
```

C++/CLI

```
void SetTangentDirectionReversed(  
& System.int Direction,  
& System.int GuideIndex,  
& System.bool Flip  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction
Direction as defined in [swBoundaryBossDirection](#) e
GuideIndex
Index of the curve (see **Remarks**)
Flip
True to flip the direction of adjacent tangent faces, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetTangentDirectionReversed](#).

Remarks

Call [IBoundaryBossFeatureData::GetCurvesCount](#) to get a valid range of values for GuideIndex.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTangentInfluence Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetTangentInfluence Method (IBoundaryBossFeatureData)

Sets the curve influence toward the next curve for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTangentInfluence( _  
    ByVal Direction As System.Integer, _  
    ByVal GuideIndex As System.Integer, _  
    ByVal Influence As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim Direction As System.Integer  
Dim GuideIndex As System.Integer  
Dim Influence As System.Double  
  
instance.SetTangentInfluence(Direction, GuideIndex, Influence)
```

C#

```
void SetTangentInfluence(  
    System.int Direction,  
    System.int GuideIndex,  
    System.double Influence  
)
```

C++/CLI

```

void SetTangentInfluence(
& System.int Direction,
& System.int GuideIndex,
& System.double Influence
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Influence

Percentage of curve influence; 0.0 <= value for curve influence <= 1.0

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetTangentInfluence](#).

Remarks

This method is only available if curves in both directions exist and the type of curve influence is:

- [swBoundaryBossCurveInfluenceType_e](#).swBoundaryBossCurve_GlobalInfluence
- or -
- swBoundaryBossCurveInfluenceType_e.swBoundaryBossCurve_ToNextSharpInfluence

Call [IBoundaryBossFeatureData::D1CurveInfluence](#) and [IBoundaryBossFeatureData::D2CurveInfluence](#) to determine the type of curve influences in both directions.

This method is not available if the type of tangency is:

- [swBoundaryBossTangencyType_e](#).swBoundaryBossTangency_None
- or -
- swBoundaryBossTangencyType_e.swBoundaryBossTangency_Default

Call [IBoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

To get a valid range of values for GuideIndex, call [IBoundaryBossFeatureData::GetCurvesCount](#).

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::MergeTangentFaces Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTangentLength Method (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : SetTangentLength Method (IBoundaryBossFeatureData)

Sets the tangent length, which controls the amount of influence for the specified curve in the specified direction in this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```

Sub SetTangentLength(
    ByVal Direction As System.Integer, _
    ByVal GuideIndex As System.Integer, _
    ByVal Length As System.Double _
)

```

```
Dim instance As IBoundaryBossFeatureData
Dim Direction As System.Integer
Dim GuideIndex As System.Integer
Dim Length As System.Double

instance.SetTangentLength(Direction, GuideIndex, Length)
```

C#

```
void SetTangentLength(
    System.int Direction,
    System.int GuideIndex,
    System.double Length
)
```

C++/CLI

```
void SetTangentLength(
    & System.int Direction,
    & System.int GuideIndex,
    & System.double Length
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Direction

Direction as defined in [swBoundaryBossDirection_e](#)

GuideIndex

Index of the curve (see **Remarks**)

Length

Tangent length

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::SetTangentLength](#).

Remarks

This method is not available when the type of tangency is [swBoundaryBossTangencyType_e.swBoundaryBossTangency_None](#). Call [IBoundaryBossFeatureData::GetGuideTangencyType](#) to determine the type of tangency.

To get a valid range of values for GuideIndex, call [IBoundaryBossFeatureData::GetCurvesCount](#).

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::GetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::GetTangentLength Method \(\)](#)
[IBoundaryBossFeatureData::SetGuideTangencyType Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentApplyToAll Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentDirectionReversed Method \(\)](#)
[IBoundaryBossFeatureData::SetTangentInfluence Method \(\)](#)
[IBoundaryBossFeatureData::MergeResult Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

ThinFeatureReversed Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : ThinFeatureReversed Property (IBoundaryBossFeatureData)

Gets whether this thin feature boundary feature is reversed.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ThinFeatureReversed As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Boolean  
  
value = instance.ThinFeatureReversed
```

C#

```
System.bool ThinFeatureReversed {get;}
```

C++/CLI

```
property System.bool ThinFeatureReversed {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this thin feature boundary feature is reversed, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::ThinFeatureReversed](#).

Remarks

Before calling this property, call [IBoundaryBossFeatureData::IsThinFeature](#) to determine if the boundary feature is a thin feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::ThinFeatureThickness Property \(\)](#)
[IBoundaryBossFeatureData::ThinFeatureType Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinFeatureThickness Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : ThinFeatureThickness Property (IBoundaryBossFeatureData)

Gets or sets the thickness of this thin feature boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinFeatureThickness(  
    ByVal ThicknessDirection As System.Boolean _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData
Dim ThicknessDirection As System.Boolean
Dim value As System.Double

instance.ThinFeatureThickness(ThicknessDirection) = value

value = instance.ThinFeatureThickness(ThicknessDirection)
```

C#

```
System.double ThinFeatureThickness(
    System.bool ThicknessDirection
) {get; set;}
```

C++/CLI

```
property System.double ThinFeatureThickness {
    System.double get(System.bool ThicknessDirection);
    void set (System.bool ThicknessDirection, System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ThicknessDirection
Direction of thickness as defined in [swBoundaryBossDirection_e](#)

Property Value

Thickness of this thin feature boundary feature

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::ThinFeatureThickness](#).

Remarks

Before calling this property, call [IBoundaryBossFeatureData::IsThinFeature](#) to determine if the boundary feature is a thin feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::ThinFeatureReversed Property\(\)](#)
[IBoundaryBossFeatureData::ThinFeatureType Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ThinFeatureType Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : ThinFeatureType Property (IBoundaryBossFeatureData)

Gets or sets the type of thin feature for this boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ThinFeatureType As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IBoundaryBossFeatureData
Dim value As System.Integer
```



```
instance.ThinFeatureType = value
```

```
value = instance.ThinFeatureType
```

C#

```
System.int ThinFeatureType {get; set;}
```

C++/CLI

```
property System.int ThinFeatureType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of thin feature as defined in [swThinWallType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::ThinFeatureType](#).

Remarks

Before calling this property, call [IBoundaryBossFeatureData::IsThinFeature](#) to determine if the boundary feature is a thin feature.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::ThinFeatureReversed Property\(\)](#)
[IBoundaryBossFeatureData::ThinFeatureThickness Property\(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TrimByD1 Property (IBoundaryBossFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundaryBossFeatureData Interface](#) : TrimByD1 Property (IBoundaryBossFeatureData)

Gets whether to trim surfaces in Direction 1 when curves do not form a closed boundary feature.

.NET Syntax

Visual Basic (Declaration)

```
Property TrimByD1 As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundaryBossFeatureData  
Dim value As System.Boolean
```

```
instance.TrimByD1 = value
```

```
value = instance.TrimByD1
```

C#

```
System.bool TrimByD1 {get; set;}
```

C++/CLI

```
property System.bool TrimByD1 {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to trim surfaces in Direction 1 when curves do not form a closed boundary feature, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundaryBossFeatureData::TrimByD1](#).

Remarks

This property is only available when curves exist in both Direction 1 and Direction 2.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[IBoundaryBossFeatureData Interface](#)
[IBoundaryBossFeatureData Members](#)
[IBoundaryBossFeatureData::D1Curves Property \(\)](#)
[IBoundaryBossFeatureData::D2Curves Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0