

SOLIDWORKS API (.NET VBA C#) — Reference

(34/337): IBoundingBoxFeatureData- IBrokenOutSectionFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IBoundingBoxFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBoundingBoxFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBoundingBoxFeatureData Interface

Allows access to a bounding box feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBoundingBoxFeatureData
```

Visual Basic (Usage)

```
Dim instance As IBoundingBoxFeatureData
```

C#

```
public interface IBoundingBoxFeatureData
```

C++/CLI

```
public interface class IBoundingBoxFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData](#).

Example

[Create Bounding Box \(VBA\)](#)
[Create Bounding Box \(C#\)](#)

Remarks

Use [IModelDoc2::ClearSelection2](#) to clear the selection made when the bounding box feature is created.

To display or hide the bounding box sketch, call [IModelDoc2::SetUserPreferenceToggle](#) to set [swUserPreferenceToggle_e.swViewDispGlobalBBBox](#) to true or false, respectively.

For more information about the properties of this feature, see **SOLIDWORKS web help > Parts and Features > Reference Geometry > Bounding Boxes > Bounding Box PropertyManager**.

Accessors

[IFeature::GetDefinition](#)

[IFeatureManager::CreateDefinition](#)

Access Diagram

[BoundingBoxFeatureData](#)

See Also

[IBoundingBoxFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetSphericalBoxDiameter Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBoundingBoxFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



The following tables list the members exposed by [IBoundingBoxFeatureData](#).

 Public Properties

Name	Description
 CoordinateSystem	Gets or sets the coordinate system reference for this bounding box feature.
 IncludeEnvelopeComponents	Gets or sets whether to include envelope components in this bounding box feature.
 IncludeHiddenBodies	Gets or sets whether to include hidden bodies in this bounding box feature.
 IncludeHiddenComponents	Gets or sets whether to include hidden components in this bounding box feature.
 IncludeSurfaces	Gets or sets whether to include surfaces in this bounding box feature.
 IwaDirectionType	Gets or sets the length, width, or thickness direction with respect to a specified coordinate system of the rectangular bounding box feature. Gets or sets the axis direction with respect to a specified coordinate system of the cylindrical bounding box feature.
 PlanarEntity	Gets or sets the reference face or plane for this bounding box feature.
 ReferenceFaceOrPlane	Gets or sets how to create the bounding box.

[Top](#)

 Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this bounding box feature.
 ReleaseSelectionAccess	Releases access to the selections for this bounding box feature.

[Top](#)

 See Also

[IBoundingBoxFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetSphericalBoxDiameter Method \(\)](#)

IBoundingBoxFeatureData Interface Methods

[See Also](#)



For a list of all members of this type, see [IBoundingBoxFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this bounding box feature.
 ReleaseSelectionAccess	Releases access to the selections for this bounding box feature.

[Top](#)

 See Also

[IBoundingBoxFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetSphericalBoxDiameter Method \(\)](#)

IBoundingBoxFeatureData Interface Properties

[See Also](#)



For a list of all members of this type, see [IBoundingBoxFeatureData members](#).

 Public Properties

Name	Description
------	-------------

	CoordinateSystem	Gets or sets the coordinate system reference for this bounding box feature.
	IncludeEnvelopeComponents	Gets or sets whether to include envelope components in this bounding box feature.
	IncludeHiddenBodies	Gets or sets whether to include hidden bodies in this bounding box feature.
	IncludeHiddenComponents	Gets or sets whether to include hidden components in this bounding box feature.
	IncludeSurfaces	Gets or sets whether to include surfaces in this bounding box feature.
	IwaDirectionType	Gets or sets the length, width, or thickness direction with respect to a specified coordinate system of the rectangular bounding box feature. Gets or sets the axis direction with respect to a specified coordinate system of the cylindrical bounding box feature.
	PlanarEntity	Gets or sets the reference face or plane for this bounding box feature.
	ReferenceFaceOrPlane	Gets or sets how to create the bounding box.

[Top](#)

See Also

[IBoundingBoxFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::GetSphericalBoxDiameter Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : AccessSelections Method (IBoundingBoxFeatureData)

Gains access to the selections that define this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which to modify the feature (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::AccessSelections](#).

Example

See the [IBoundingBoxFeatureData](#) example.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the ModelDoc2 object for the part - Component argument is Nothing or null
Assembly	- TopDoc is the ModelDoc2 object for the assembly - Component argument is the Component2 object in which to modify the feature

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBoundingBoxFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CoordinateSystem Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : CoordinateSystem Property (IBoundingBoxFeatureData)

Gets or sets the coordinate system reference for this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CoordinateSystem As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Object
```

```
instance.CoordinateSystem = value
```

```
value = instance.CoordinateSystem
```

C#

```
System.object CoordinateSystem {get; set;}
```

C++/CLI

```
property System.Object^ CoordinateSystem {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Feature](#)

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::CoordinateSystem](#).

Remarks

This property is valid only if [IBoundingBoxFeatureData::ReferenceFaceOrPlane](#) is set to [swGlobalBoundingBoxFitOptions_e.swBoundingBoxType_CustomCoordSys](#).

Set this property and [IBoundingBoxFeatureData::IwtaDirectionType](#) to define a custom coordinate system for this rectangular or cylindrical bounding box feature.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)
[ICoordinateSystemFeatureData Interface](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeEnvelopeComponents Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : IncludeEnvelopeComponents Property (IBoundingBoxFeatureData)

Gets or sets whether to include envelope components in this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

```
Property IncludeEnvelopeComponents As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Boolean  
  
instance.IncludeEnvelopeComponents = value  
  
value = instance.IncludeEnvelopeComponents
```

C#

```
System.bool IncludeEnvelopeComponents {get; set;}
```

C++/CLI

```
property System.bool IncludeEnvelopeComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include envelope components, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::IncludeEnvelopeComponents](#).

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeHiddenBodies Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : IncludeHiddenBodies Property (IBoundingBoxFeatureData)

Gets or sets whether to include hidden bodies in this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

Property IncludeHiddenBodies As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Boolean
```

```
instance.IncludeHiddenBodies = value
```

```
value = instance.IncludeHiddenBodies
```

C#

```
System.bool IncludeHiddenBodies {get; set;}
```

C++/CLI

```
property System.bool IncludeHiddenBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include hidden bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::IncludeHiddenBodies](#).

Example

See the [IBoundingBoxFeatureData](#) example.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IncludeHiddenComponents Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : IncludeHiddenComponents Property (IBoundingBoxFeatureData)

Gets or sets whether to include hidden components in this bounding box feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property IncludeHiddenComponents As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Boolean  
  
instance.IncludeHiddenComponents = value  
value = instance.IncludeHiddenComponents
```

C#

```
System.bool IncludeHiddenComponents {get; set;}
```

C++/CLI

```
property System.bool IncludeHiddenComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include hidden components, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData.IncludeHiddenComponents](#).

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IncludeSurfaces Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : IncludeSurfaces Property (IBoundingBoxFeatureData)

Gets or sets whether to include surfaces in this bounding box feature.

Visual Basic Syntax

Visual Basic (Declaration)

Property IncludeSurfaces As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Boolean  
  
instance.IncludeSurfaces = value  
value = instance.IncludeSurfaces
```

C#

```
System.bool IncludeSurfaces {get; set;}
```

C++/CLI

```
property System.bool IncludeSurfaces {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to include surfaces, false to not

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::IncludeSurfaces](#).

Example

See the [IBoundingBoxFeatureData](#) example.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

lwtaDirectionType Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : lwtaDirectionType Property (IBoundingBoxFeatureData)

Gets or sets the length, width, or thickness direction with respect to a specified coordinate system of the rectangular bounding box feature. Gets or sets the axis direction with respect to a specified coordinate system of the cylindrical bounding box feature.

.NET Syntax

Visual Basic (Declaration)

```
Property lwtaDirectionType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Integer
```

```
instance.lwtaDirectionType = value
```

```
value = instance.lwtaDirectionType
```

C#

```
System.int lwtaDirectionType {get; set;}
```

C++/CLI

```
property System.int lwtaDirectionType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Direction mapping as defined by [swGlobalBBoxLWTADirectionType_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::IwtaDirectionType](#).

Remarks

This property is valid only if [IBoundingBoxFeatureData::ReferenceFaceOrPlane](#) is set to [swGlobalBoundingBoxFitOptions_e.swBoundingBoxType_CustomCoordSys](#).

Set this property and [IBoundingBoxFeatureData::CoordinateSystem](#) to define a custom coordinate system for this rectangular or cylindrical bounding box feature.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2026 SP01, Revision Number 34.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

PlanarEntity Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : PlanarEntity Property (IBoundingBoxFeatureData)

Gets or sets the reference face or plane for this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

Property PlanarEntity As System.Object

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Object
```

```
instance.PlanarEntity = value
```

```
value = instance.PlanarEntity
```

C#

```
System.Object PlanarEntity {get; set;}
```

C++/CLI

```
property System.Object^ PlanarEntity {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Planar [face](#) or [plane](#)

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::PlanarEntity](#).

Example

See the [IBoundingBoxFeatureData](#) example.

Remarks

This property is valid only if [IBoundingBoxFeatureData.ReferenceFaceOrPlane](#) is set to [swGlobalBoundingBoxFitOptions_e.swBoundingBoxType_CustomPlane](#).

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReferenceFaceOrPlane Property (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : ReferenceFaceOrPlane Property (IBoundingBoxFeatureData)

Gets or sets how to create the bounding box.

.NET Syntax

Visual Basic (Declaration)

Property ReferenceFaceOrPlane As System.Integer

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
Dim value As System.Integer
```

```
instance.ReferenceFaceOrPlane = value
```

```
value = instance.ReferenceFaceOrPlane
```

C#

```
System.int ReferenceFaceOrPlane {get; set;}
```

C++/CLI

```
property System.int ReferenceFaceOrPlane {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Fit type as defined in [swGlobalBoundingBoxFitOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData.ReferenceFaceOrPlane](#).

Example

See the [IBoundingBoxFeatureData](#) example.

Remarks

If this property is set to:

- swGlobalBoundingBoxFitOptions_e.swBoundingBoxType_CustomPlane, then select a face or plane using [IModelDocExtension::SelectByRay](#) with TypeWanted set to [swSelectType_e.swSelfFACES](#) before calling this method.

- swGlobalBoundingBoxFitOptions_e.swBoundingBoxType_CustomCoordSys, then use [IBoundingBoxFeatureData::CoordinateSystem](#) to specify the reference coordinate system and use [IBoundingBoxFeatureData::IwtaDirectionType](#) to specify the length, width, thickness, or axis direction mapping with respect to the reference coordinate system.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)
[IBoundingBoxFeatureData::PlanarEntity Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IBoundingBoxFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBoundingBoxFeatureData Interface](#) : ReleaseSelectionAccess Method (IBoundingBoxFeatureData)

Releases access to the selections for this bounding box feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBoundingBoxFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BoundingBoxFeatureData::ReleaseSelectionAccess](#).

Remarks

[IBoundingBoxFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[IBoundingBoxFeatureData Interface](#)
[IBoundingBoxFeatureData Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

IBreakCornerFeatureData (Type)

IBreakCornerFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakCornerFeatureData Interface

Allows access to a break corner feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBreakCornerFeatureData
```

Visual Basic (Usage)

```
Dim instance As IBreakCornerFeatureData
```

C#

```
public interface IBreakCornerFeatureData
```

C++/CLI

```
public interface class IBreakCornerFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData](#).

Example

[Modify Break Corner Feature \(C#\)](#)
[Modify Break Corner Feature \(VB.NET\)](#)
[Modify Break Corner Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[BreakCornerFeatureData](#)

See Also

[IBreakCornerFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalCornerTrim Method](#)
[IModelDoc2::InsertSheetMetalBreakCorner Method](#)

IBreakCornerFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakCornerFeatureData Interface

For a list of all members of this type, see [IBreakCornerFeatureData members](#).

Public Methods

Name	Description
AccessSelections	Gains access to the selections that describe this break corner feature.
GetEntitiesCount	Gets the number of faces or edges associated with this break corner feature.

		
	IAccessSelections	Gains access to the selections that describe this break corner feature.
	IGetEntities	Gets the faces or edges to which this break corner is applied.
	ISetEntities	Sets the faces or edges to which this break corner is applied.
	ReleaseSelectionAccess	Releases access to selections for this break corner feature.

[Top](#)

See Also

[IBreakCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalCornerTrim Method](#)
[IModelDoc2::InsertSheetMetalBreakCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBreakCornerFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IBreakCornerFeatureData Interface

The following tables list the members exposed by [IBreakCornerFeatureData](#).

Public Properties

Name	Description
 BreakType	Gets or sets the break corner type.
 CenteredOnBendLines	Gets or sets whether to center the corner cuts relative to the bend lines of this break corner feature.
 Distance	Gets or sets the chamfer length or fillet radius, depending on the break corner type.
 Entities	Gets or sets the faces or edges to which this break corner is applied.
 InternalCornersOnly	Gets or sets whether to add or subtract material from break corner/corner trim features.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this break corner feature.
 GetEntitiesCount	Gets the number of faces or edges associated with this break corner feature.
 IAccessSelections	Gains access to the selections that describe this break corner feature.
 IGetEntities	Gets the faces or edges to which this break corner is applied.
 ISetEntities	Sets the faces or edges to which this break corner is applied.
 ReleaseSelectionAccess	Releases access to selections for this break corner feature.

[Top](#)

See Also

[IBreakCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertSheetMetalCornerTrim Method](#)
[IModelDoc2::InsertSheetMetalBreakCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBreakCornerFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IBreakCornerFeatureData Interface

For a list of all members of this type, see [IBreakCornerFeatureData members](#).

Public Properties

Name	Description
 BreakType	Gets or sets the break corner type.
 CenteredOnBendLines	Gets or sets whether to center the corner cuts relative to the bend lines of this break corner feature.
 Distance	Gets or sets the chamfer length or fillet radius, depending on the break corner type.
 Entities	Gets or sets the faces or edges to which this break corner is applied.
 InternalCornersOnly	Gets or sets whether to add or subtract material from break corner/corner trim features.

[Top](#)

 See Also

[IBreakCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager.InsertSheetMetalCornerTrim Method](#)
[IModelDoc2.InsertSheetMetalBreakCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IBreakCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : AccessSelections Method (IBreakCornerFeatureData)

Gains access to the selections that describe this break corner feature.

 .NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::AccessSelections](#).

Example

[Modify Break Corner Feature \(C#\)](#)
[Modify Break Corner Feature \(VB.NET\)](#)
[Modify Break Corner Feature \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBreakCornerFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)
[IBreakCornerFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakType Property (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : BreakType Property (IBreakCornerFeatureData)

Gets or sets the break corner type.

.NET Syntax

Visual Basic (Declaration)

Property BreakType As System.Integer

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim value As System.Integer
```

```
instance.BreakType = value
```

```
value = instance.BreakType
```

C#

```
System.int BreakType {get; set;}
```

C++/CLI

```
property System.int BreakType {  
    System.int get();
```

```
void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Break corner type as defined in [swBreakCornerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::BreakType](#).

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

CenteredOnBendLines Property (IBreakCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : CenteredOnBendLines Property (IBreakCornerFeatureData)

Gets or sets whether to center the corner cuts relative to the bend lines of this break corner feature.

.NET Syntax

Visual Basic (Declaration)

Property CenteredOnBendLines As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim value As System.Boolean
```

```
instance.CenteredOnBendLines = value
```

```
value = instance.CenteredOnBendLines
```

C#

```
System.bool CenteredOnBendLines {get; set;}
```

C++/CLI

```
property System.bool CenteredOnBendLines {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to center the corner cuts on the bend lines, false to not

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::CenteredOnBendLines](#).

Example

[Modify Break Corner Feature \(C#\)](#)
[Modify Break Corner Feature \(VB.NET\)](#)
[Modify Break Corner Feature \(VBA\)](#)

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Distance Property (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : Distance Property (IBreakCornerFeatureData)

Gets or sets the chamfer length or fillet radius, depending on the break corner type.

.NET Syntax

Visual Basic (Declaration)

Property Distance As System.Double

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim value As System.Double
```

```
instance.Distance = value
```

```
value = instance.Distance
```

C#

```
System.double Distance {get; set;}
```

C++/CLI

```
property System.double Distance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Chamfer length or fillet radius

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::Distance](#).

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Entities Property (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : Entities Property (IBreakCornerFeatureData)

Gets or sets the faces or edges to which this break corner is applied.

.NET Syntax

Visual Basic (Declaration)

Property Entities As System.Object

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim value As System.Object  
  
instance.Entities = value  
  
value = instance.Entities
```

C#

```
System.object Entities {get; set;}
```

C++/CLI

```
property System.Object^ Entities {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) or [edges](#)

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::Entities](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)
[IBreakCornerFeatureData::IGetEntities Method](#)
[IBreakCornerFeatureData::ISetEntities Method](#)
[IBreakCornerFeatureData::GetEntitiesCount Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntitiesCount Method (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : GetEntitiesCount Method (IBreakCornerFeatureData)

Gets the number of faces or edges associated with this break corner feature.

.NET Syntax

Visual Basic (Declaration)

Function GetEntitiesCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData
Dim value As System.Integer

value = instance.GetEntitiesCount()
```

C#

```
System.int GetEntitiesCount()
```

C++/CLI

```
System.int GetEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces or edges

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::GetEntitiesCount](#).

Remarks

Call this method before calling [IBreakCornerFeatureData::!GetEntities](#).

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : IAccessSelections Method (IBreakCornerFeatureData)

Gains access to the selections that describe this break corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
```

```
        Component2 Component
    )
```

C++/CLI

```
System.bool IAccessSelections(
&    ModelDoc2^ TopDoc,
&    Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::IAccessSelections](#).

Remarks

Remark

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IBreakCornerFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBreakCornerFeatureData Interface](#)

[IBreakCornerFeatureData Members](#)

[IBreakCornerFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEntities Method (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : IGetEntities Method (IBreakCornerFeatureData)

Gets the faces or edges to which this break corner is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEntities( _
    ByVal Count As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData
Dim Count As System.Integer
Dim value As System.Object
```

```
value = instance.IGetEntities(Count)
```

C#

```
System.object IGetEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetEntities(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces or edges

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) or [edges](#) of size count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IBreakCornerFeatureData::GetEntitiesCount](#) before calling this method. See Access Selections that Define Features for additional details on using this method.

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)
[IBreakCornerFeatureData::ISetEntities Method](#)
[IBreakCornerFeatureData::Entities Property](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

InternalCornersOnly Property (IBreakCornerFeatureData)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : InternalCornersOnly Property (IBreakCornerFeatureData)

Gets or sets whether to add or subtract material from break corner/corner trim features.

.NET Syntax

Visual Basic (Declaration)

```
Property InternalCornersOnly As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
Dim value As System.Boolean
```

```
instance.InternalCornersOnly = value
```

```
value = instance.InternalCornersOnly
```

C#

```
System.bool InternalCornersOnly {get; set;}
```

C++/CLI

```
property System.bool InternalCornersOnly {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to add or subtract material from break corner/corner trim features, false to not

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::InternalCornersOnly](#).

Example

[Modify Break Corner Feature \(C#\)](#)
[Modify Break Corner Feature \(VB.NET\)](#)
[Modify Break Corner Feature \(VBA\)](#)

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEntities Method (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : ISetEntities Method (IBreakCornerFeatureData)

Sets the faces or edges to which this break corner is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEntities( _
    ByVal EntCount As System.Integer, _
    ByRef EntArray As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData
Dim EntCount As System.Integer
Dim EntArray As System.Object

instance.ISetEntities(EntCount, EntArray)
```

C#

```
void ISetEntities(
    System.int EntCount,
    ref System.object EntArray
)
```

C++/CLI

```
void ISetEntities(
    & System.int EntCount,
    & System.Object^% EntArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntCount
 Number of faces or edges

EntArray

- in-process, unmanaged C++: Pointer to an array of [faces](#) or [edges](#) of size entCount
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::!SetEntities](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)
[IBreakCornerFeatureData::!GetEntities Method](#)
[IBreakCornerFeatureData::Entities Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IBreakCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakCornerFeatureData Interface](#) : ReleaseSelectionAccess Method (IBreakCornerFeatureData)

Releases access to selections for this break corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBreakCornerFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BreakCornerFeatureData::ReleaseSelectionAccess](#).

Remarks

[IBreakCornerFeatureData::AccessSelections](#) or [IBreakCornerFeatureData::!AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IBreakCornerFeatureData Interface](#)
[IBreakCornerFeatureData Members](#)

Availability

IBreakLine (Type)

IBreakLine Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakLine Interface

Allows access to information about a break line in a [drawing view](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBreakLine
```

Visual Basic (Usage)

```
Dim instance As IBreakLine
```

C#

```
public interface IBreakLine
```

C++/CLI

```
public interface class IBreakLine
```

Visual Basic for Applications (VBA) Syntax

See [BreakLine](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(VBA\)](#)

Remarks

A break line is represented graphically in a SOLIDWORKS drawing by a pair of lines in the drawing view.

Accessors

[IView::GetBreakLines](#) and [IView::IGetBreakLines Method](#)

[IView::InsertBreak Method](#)

Access Diagram

[BreakLine](#)

See Also

[IBreakLine Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::BreakView Method](#)

IBreakLine Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakLine Interface

The following tables list the members exposed by [IBreakLine](#).

Public Properties

Name	Description
 BreakSketchBlocks	Gets or sets whether to break sketch blocks.
 Layer	Gets or sets the layer for this break line in the drawing view.
 Orientation	Gets the orientation of this break line in the drawing view.
 ShapeIntensity	Gets or sets the shape intensity of a jagged cut break line.
 Style	Gets or sets the style of the break line in the drawing view.

[Top](#)

Public Methods

Name	Description
 GetPosition	Gets the location of this break line in the drawing view.
 GetView	Gets the drawing view for this break line.
 Select	Selects the break line and marks it.
 SetPosition	Sets the locations of the break lines in the drawing view.

[Top](#)

See Also

[IBreakLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::BreakView Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBreakLine Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakLine Interface

For a list of all members of this type, see [IBreakLine members](#).

Public Methods

Name	Description
 GetPosition	Gets the location of this break line in the drawing view.
 GetView	Gets the drawing view for this break line.
 Select	Selects the break line and marks it.
 SetPosition	Sets the locations of the break lines in the drawing view.

[Top](#)

See Also

[IBreakLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::BreakView Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IBreakLine Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBreakLine Interface

For a list of all members of this type, see [IBreakLine members](#).

Public Properties

Name	Description
 BreakSketchBlocks	Gets or sets whether to break sketch blocks.

 Layer	Gets or sets the layer for this break line in the drawing view.
 Orientation	Gets the orientation of this break line in the drawing view.
 ShapeIntensity	Gets or sets the shape intensity of a jagged cut break line.
 Style	Gets or sets the style of the break line in the drawing view.

[Top](#)

See Also

[IBreakLine Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IDrawingDoc::BreakView Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BreakSketchBlocks Property (IBreakLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : BreakSketchBlocks Property (IBreakLine)

Gets or sets whether to break sketch blocks.

.NET Syntax

Visual Basic (Declaration)

Property BreakSketchBlocks As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBreakLine
Dim value As System.Boolean

instance.BreakSketchBlocks = value

value = instance.BreakSketchBlocks
```

C#

```
System.bool BreakSketchBlocks {get; set;}
```

C++/CLI

```
property System.bool BreakSketchBlocks {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to break sketch blocks, false to not

Visual Basic for Applications (VBA) Syntax

See [BreakLine::BreakSketchBlocks](#).

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPosition Method (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : GetPosition Method (IBreakLine)

Gets the location of this break line in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPosition( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetPosition(Index)
```

C#

```
System.double GetPosition(  
    System.int Index  
)
```

C++/CLI

```
System.double GetPosition(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Break line to work with (0 or 1)

Return Value

Location of the break line (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BreakLine::GetPosition](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(VBA\)](#)

Remarks

A drawing view break consists of a pair of lines. This method gets the break line at the location indicated by the Index argument.

If the orientation of the break is...	Then the return value is...
Horizontal	Y value relative to the drawing view origin (center) that indicates where the break is along the Y axis
Vertical	X value relative to the drawing view origin (center) that indicates where the break is along the X axis

To determine the orientation of the break line, use [IBreakLine::Orientation](#) .

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)
[IBreakLine::SetPosition Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetView Method (IBreakLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : GetView Method (IBreakLine)

Gets the drawing view for this break line.

.NET Syntax

Visual Basic (Declaration)

Function GetView() As View

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim value As View  
  
value = instance.GetView()
```

C#

```
View GetView()
```

C++/CLI

```
View^ GetView();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IView](#) object

Visual Basic for Applications (VBA) Syntax

See [BreakLine::GetView](#).

Remarks

A drawing view can have several breaks. To get all of the breaks in a drawing view, use [IView::GetBreakLines](#).

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Layer Property (IBreakLine)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : Layer Property (IBreakLine)

Gets or sets the layer for this break line in the drawing view.

.NET Syntax

Visual Basic (Declaration)

Property Layer As System.String

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim value As System.String
```

```
instance.Layer = value
```

```
value = instance.Layer
```

C#

```
System.string Layer {get; set;}
```

C++/CLI

```
property System.String^ Layer {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of the layer

Visual Basic for Applications (VBA) Syntax

See [BreakLine::Layer](#).

Remarks

An empty string indicates no layer. If you set the layer to a layer name that does not exist, nothing happens.

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Orientation Property (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : Orientation Property (IBreakLine)

Gets the orientation of this break line in the drawing view.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Orientation As System.Integer

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim value As System.Integer
```

```
value = instance.Orientation
```

C#

```
System.int Orientation {get;}
```

C++/CLI

```
property System.int Orientation {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Break orientation as defined in [swBreakLineOrientation_e](#)

Visual Basic for Applications (VBA) Syntax

See [BreakLine::Orientation](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(VBA\)](#)

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)
[IBreakline::GetPosition Method](#)
[IBreakline::SetPosition Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : Select Method (IBreakLine)

Selects the break line and marks it.

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _  
    ByVal Append As System.Boolean, _  
    ByVal Data As SelectData _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim Append As System.Boolean  
Dim Data As SelectData  
Dim value As System.Boolean  
  
value = instance.Select(Append, Data)
```

C#

```
System.bool Select(  
    System.bool Append,
```

```
        SelectData Data
    )
```

C++/CLI

```
System.bool Select(
& System.bool Append,
& SelectData^ Data
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Append

True appends the break line to the selection list, false replaces the selection list with this break line

Data

Pointer to the [ISelectData](#) object

Return Value

True if the selection is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [BreakLine::Select](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(V.NET\)](#)
[Create Break View \(VBA\)](#)

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetPosition Method (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : SetPosition Method (IBreakLine)

Sets the locations of the break lines in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Function SetPosition( _
    ByVal Position1 As System.Double, _
    ByVal Position2 As System.Double _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IBreakLine
Dim Position1 As System.Double
Dim Position2 As System.Double
Dim value As System.Boolean
```

```
value = instance.SetPosition(Position1, Position2)
```

C#



```
System.bool SetPosition(  
    System.double Position1,  
    System.double Position2  
)
```

C++/CLI

```
System.bool SetPosition(  
& System.double Position1,  
& System.double Position2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Position1

Location of the first break line

Position2

Location of the second break line

Return Value

True if the break lines are positioned, false if not

Visual Basic for Applications (VBA) Syntax

See [BreakLine::SetPosition](#).

Example

[Create Break View \(VBA\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(C#\)](#)

Remarks

Call [IModelDoc2::EditRebuild3](#) after calling this method.

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)
[IBreakLine::GetPosition Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShapeIntensity Property (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : ShapeIntensity Property (IBreakLine)

Gets or sets the shape intensity of a jagged cut break line.

.NET Syntax

Visual Basic (Declaration)

```
Property ShapeIntensity As System.Integer
```

Visual Basic (Usage)

```
Dim instance As IBreakLine  
Dim value As System.Integer
```



Copy Code

```
instance.ShapeIntensity = value  
value = instance.ShapeIntensity
```

C#

```
System.int ShapeIntensity {get; set;}
```

C++/CLI

```
property System.int ShapeIntensity {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Shape intensity of a jagged cut break line; valid range is 1 (most) to 5 (least) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BreakLine::ShapeIntensity](#).

Example

[Insert Jagged Cut Break \(C#\)](#)
[Insert Jagged Cut Break \(VB.NET\)](#)
[Insert Jagged Cut Break \(VBA\)](#)

Remarks

Call [IBreakLine::Style](#) to determine if this break line is a jagged cut break line.

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Style Property (IBreakLine)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBreakLine Interface](#) : Style Property (IBreakLine)

Gets or sets the style of the break line in the drawing view.

.NET Syntax

Visual Basic (Declaration)

```
Property Style As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBreakLine  
Dim value As System.Integer
```

```
instance.Style = value
```

```
value = instance.Style
```

C#

```
System.int Style {get; set;}
```

C++/CLI

```
property System.int Style {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Break line style as defined in [swBreakLineStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [BreakLine::Style](#).

Example

[Create Break View \(C#\)](#)
[Create Break View \(VB.NET\)](#)
[Create Break View \(VBA\)](#)

Remarks

This property might automatically load the model in the view.

To get or set the shape intensity of a jagged cut break line, call [IBreakLine::ShapeIntensity](#).

See Also

[IBreakLine Interface](#)
[IBreakLine Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

IBrokenOutSectionFeatureData (Type)

IBrokenOutSectionFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBrokenOutSectionFeatureData Interface

Allows access to the broken-out section feature data of a drawing view.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBrokenOutSectionFeatureData
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData
```

C#

```
public interface IBrokenOutSectionFeatureData
```

C++/CLI

```
public interface class IBrokenOutSectionFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[BrokenOutSectionFeatureData](#)

See Also

[IBrokenOutSectionFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IView::GetBreakOutSections Method](#)
[IView::IGetBreakOutSections Method](#)

IBrokenOutSectionFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBrokenOutSectionFeatureData Interface

For a list of all members of this type, see [IBrokenOutSectionFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this broken-out section feature.
GetSketchSegmentCount	Gets the number of sketch segments that form the border of this broken-out section feature.

		
	IAccessSelections	Gains access to the selections that define this broken-out section feature.
	IGetSketchSegment	Gets the sketch segments that form the border of this broken-out section feature.
	ReleaseSelectionAccess	Releases access to the selections in this broken-out section feature.

[Top](#)

See Also

[IBrokenOutSectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IView::GetBreakOutSections Method](#)
[IView::IGetBreakOutSections Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBrokenOutSectionFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBrokenOutSectionFeatureData Interface

The following tables list the members exposed by [IBrokenOutSectionFeatureData](#).

Public Properties

Name	Description
 Depth	Gets or sets the depth of exposure of inner details of the model in the broken-out section feature.
 DepthReference	Gets or sets the geometry reference that defines the depth of exposure of inner details of the model in the broken-out section feature.
 EditSketch	Gets or sets whether to place this broken-out section feature in edit sketch mode.
 SketchSegment	Gets the sketch segments that form the border of this broken-out section feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this broken-out section feature.
 GetSketchSegmentCount	Gets the number of sketch segments that form the border of this broken-out section feature.
 IAccessSelections	Gains access to the selections that define this broken-out section feature.
 IGetSketchSegment	Gets the sketch segments that form the border of this broken-out section feature.
 ReleaseSelectionAccess	Releases access to the selections in this broken-out section feature.

[Top](#)

See Also

[IBrokenOutSectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IView::GetBreakOutSections Method](#)
[IView::IGetBreakOutSections Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBrokenOutSectionFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBrokenOutSectionFeatureData Interface

For a list of all members of this type, see [IBrokenOutSectionFeatureData members](#).

Public Properties

Name	Description
 Depth	Gets or sets the depth of exposure of inner details of the model in the broken-out section feature.
 DepthReference	Gets or sets the geometry reference that defines the depth of exposure of inner details of the model in the broken-out section feature.

	EditSketch	Gets or sets whether to place this broken-out section feature in edit sketch mode.
	SketchSegment	Gets the sketch segments that form the border of this broken-out section feature.

[Top](#)

See Also

[IBrokenOutSectionFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IView::GetBreakOutSections Method](#)
[IView::!GetBreakOutSections Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : AccessSelections Method (IBrokenOutSectionFeatureData)

Gains access to the selections that define this broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::AccessSelections](#).

Example

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBrokenOutSectionFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Depth Property (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : Depth Property (IBrokenOutSectionFeatureData)

Gets or sets the depth of exposure of inner details of the model in the broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

Property Depth As System.Double

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim value As System.Double
```

```
instance.Depth = value
```

```
value = instance.Depth
```

C#

```
System.double Depth {get; set;}
```

C++/CLI

```
property System.double Depth {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Depth exposure of inner details (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::Depth](#).

Example

[Get Broken-Out Section Feature Data \(C#\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(VBA\)](#)

Remarks

Before setting this property, you must set [IBrokenOutSectionFeatureData::EditSketch](#) to false.

This property is valid only if [IBrokenOutSectionFeatureData::DepthReference](#) is null and the selection list is empty.

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DepthReference Property (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : DepthReference Property (IBrokenOutSectionFeatureData)

Gets or sets the geometry reference that defines the depth of exposure of inner details of the model in the broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

Property DepthReference As Entity

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim value As Entity
```

```
instance.DepthReference = value
```

```
value = instance.DepthReference
```

C#

```
Entity DepthReference {get; set;}
```

C++/CLI

```
property Entity^ DepthReference {  
    Entity^ get();  
    void set ( & Entity^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IEntity](#) (see [Remarks](#))

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::DepthReference](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Remarks

Before setting this property, you must set [IBrokenOutSectionFeatureData::EditSketch](#) to false.

To set the depth reference you can either:

- Set this property to an [IEntity](#) object.
- or-
- Set this property to null and select the depth geometry in the drawing view.

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::Depth Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EditSketch Property (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : EditSketch Property (IBrokenOutSectionFeatureData)

Gets or sets whether to place this broken-out section feature in edit sketch mode.

.NET Syntax

Visual Basic (Declaration)

```
Property EditSketch As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim value As System.Boolean  
  
instance.EditSketch = value  
value = instance.EditSketch
```

C#

```
System.bool EditSketch {get; set;}
```

C++/CLI

```
property System.bool EditSketch {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to place this feature in edit sketch mode, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::EditSketch](#).

Example

[Get Broken-Out Section Feature Data \(C#\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(VBA\)](#)

Remarks

To get the sketch segments that circumscribe this broken-out section feature:

1. Set this property to true.
2. Call [IBrokenOutSectionFeatureData::SketchSegment](#) or [IBrokenOutSectionFeatureData::IGetSketchSegment](#).

To set the depth or depth reference for this broken-out section feature:

1. Set this property to false.
2. Call [IBrokenOutSectionFeatureData::Depth](#) or [IBrokenOutSectionFeatureData::DepthReference](#).

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSketchSegmentCount Method (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : GetSketchSegmentCount Method (IBrokenOutSectionFeatureData)

Gets the number of sketch segments that form the border of this broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchSegmentCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim value As System.Integer  
  
value = instance.GetSketchSegmentCount()
```

C#

```
System.int GetSketchSegmentCount()
```

C++/CLI

```
System.int GetSketchSegmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of sketch segments

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::GetSketchSegmentCount](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Remarks

Before calling this method you must set [IBrokenOutSectionFeatureData::EditSketch](#) to true.

Call this method to set the Count parameter of [IBrokenOutSectionFeatureData::IGetSketchSegment](#).

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::SketchSegment Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IBrokenOutSectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : IAccessSelections Method (IBrokenOutSectionFeatureData)

Gains access to the selections that define this broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IBrokenOutSectionFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSketchSegment Method (IBrokenOutSectionFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : IGetSketchSegment Method (IBrokenOutSectionFeatureData)

Gets the sketch segments that form the border of this broken-out section feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetSketchSegment( _  
    ByVal Count As System.Integer _  
) As SketchSegment
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim Count As System.Integer  
Dim value As SketchSegment
```

```
value = instance.IGetSketchSegment(Count)
```

C#

```
SketchSegment IGetSketchSegment(  
    System.int Count  
)
```

C++/CLI

```
SketchSegment^ IGetSketchSegment(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of sketch segments

Return Value

- In-process, unmanaged C++: Pointer to an array of [ISketchSegments](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

To get the sketch segments that form the border of this broken-out section feature:

1. Set the property [IBrokenOutSectionFeatureData::EditSketch](#) to true.
2. Call [IBrokenOutSectionFeatureData::GetSketchSegmentCount](#) to set the value of this method's Count parameter.
3. Call this method.

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::SketchSegment Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : ReleaseSelectionAccess Method (IBrokenOutSectionFeatureData)

Releases access to the selections in this broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::ReleaseSelectionAccess](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Remarks

[IBrokenOutSectionFeatureData::AccessSelections](#) or [IBrokenOutSectionFeatureData::!AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SketchSegment Property (IBrokenOutSectionFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBrokenOutSectionFeatureData Interface](#) : SketchSegment Property (IBrokenOutSectionFeatureData)

Gets the sketch segments that form the border of this broken-out section feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SketchSegment As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBrokenOutSectionFeatureData  
Dim value As System.Object
```

```
value = instance.SketchSegment
```

C#

```
System.Object SketchSegment {get;}
```

C++/CLI

```
property System.Object^ SketchSegment {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [ISketchSegment](#)s

Visual Basic for Applications (VBA) Syntax

See [BrokenOutSectionFeatureData::SketchSegment](#).

Example

[Get Broken-Out Section Feature Data \(VBA\)](#)
[Get Broken-Out Section Feature Data \(VB.NET\)](#)
[Get Broken-Out Section Feature Data \(C#\)](#)

Remarks

To get the sketch segments that form the border of this broken-out section feature:

1. Set the property [IBrokenOutSectionFeatureData::EditSketch](#) to true.
2. Call this property.

See Also

[IBrokenOutSectionFeatureData Interface](#)
[IBrokenOutSectionFeatureData Members](#)
[IBrokenOutSectionFeatureData::GetSketchSegmentCount Method](#)

Availability

