

SOLIDWORKS API (.NET VBA C#) — Reference

(35/337): IBSurfParamData-ICalloutStringVariable

SOLIDWORKS API Documentation (converted from CHM)

IBSurfParamData (Type)

IBSurfParamData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBSurfParamData Interface

Allows access to the parameterization data of a B-spline surface.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IBSurfParamData
```

Visual Basic (Usage)

```
Dim instance As IBSurfParamData
```

C#

```
public interface IBSurfParamData
```

C++/CLI

```
public interface class IBSurfParamData
```

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

Accessors

[ISurface::GetBSurfParams3](#)

Access Diagram

[BSurfParamData](#)

See Also

[IBSurfParamData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISurfaceParameterizationData Interface](#)

IBSurfParamData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBSurfParamData Interface

For a list of all members of this type, see [IBSurfParamData members](#).

Public Methods

Name	Description
GetControlPoints	Gets the coordinates of a control point at a specific row and column of the control point matrix.
IGetControlPoints	Gets the coordinates of a control point at a specific row and column of the control point matrix.

[Top](#)

See Also

[IBSurfParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISurfaceParameterizationData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBSurfParamData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBSurfParamData Interface

The following tables list the members exposed by [IBSurfParamData](#).

Public Properties

Name	Description
 ControlPointColumnCount	Gets the number of control point columns.
 ControlPointDimension	Gets the dimension of the control points.
 ControlPointRowCount	Gets the number of control point rows.
 UKnots	Gets the knot vector in the U direction.
 UOrder	Gets the order of the surface in the U direction.
 UPeriodicity	Gets whether the surface is periodic in the U direction.
 VKnots	Gets the knot vector in the V direction.
 VOrder	Gets the order of the surface in the V direction.
 VPeriodicity	Gets whether the surface is periodic in the V direction.

[Top](#)

Public Methods

Name	Description
 GetControlPoints	Gets the coordinates of a control point at a specific row and column of the control point matrix.
 IGetControlPoints	Gets the coordinates of a control point at a specific row and column of the control point matrix.

[Top](#)

See Also

[IBSurfParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISurfaceParameterizationData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IBSurfParamData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IBSurfParamData Interface

For a list of all members of this type, see [IBSurfParamData members](#).

Public Properties

Name	Description
 ControlPointColumnCount	Gets the number of control point columns.
 ControlPointDimension	Gets the dimension of the control points.
 ControlPointRowCount	Gets the number of control point rows.
 UKnots	Gets the knot vector in the U direction.
 UOrder	Gets the order of the surface in the U direction.

 UPeriodicity	Gets whether the surface is periodic in the U direction.
 VKnots	Gets the knot vector in the V direction.
 VOrder	Gets the order of the surface in the V direction.
 VPeriodicity	Gets whether the surface is periodic in the V direction.

[Top](#)

See Also

[IBSurfParamData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ISurfaceParameterizationData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ControlPointColumnCount Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : ControlPointColumnCount Property (IBSurfParamData)

Gets the number of control point columns.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ControlPointColumnCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim value As System.Integer
```

```
value = instance.ControlPointColumnCount
```

C#

```
System.int ControlPointColumnCount {get;}
```

C++/CLI

```
property System.int ControlPointColumnCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of control point columns

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::ControlPointColumnCount](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::GetControlPoints Method](#)
[IBSurfParamData::IGetControlPoints Method](#)
[IBSurfParamData::ControlPointRowCount Property](#)
[IBSurfParamData::UKnots Property](#)

Availability

ControlPointDimension Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : ControlPointDimension Property (IBSurfParamData)

Gets the dimension of the control points.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ControlPointDimension As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IBSurfParamData
Dim value As System.Integer

value = instance.ControlPointDimension
```

C#

```
System.int ControlPointDimension {get;}
```

C++/CLI

```
property System.int ControlPointDimension {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

- 3 - non-rational surfaces
- 4 - rational surfaces

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::ControlPointDimension](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::GetControlPoints Method](#)
[IBSurfParamData::IGetControlPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

ControlPointRowCount Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : ControlPointRowCount Property (IBSurfParamData)

Gets the number of control point rows.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ControlPointRowCount As System.Integer

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim value As System.Integer  
  
value = instance.ControlPointRowCount
```

C#

```
System.int ControlPointRowCount {get;}
```

C++/CLI

```
property System.int ControlPointRowCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of control point rows

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::ControlPointRowCount](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::GetControlPoints Method](#)
[IBSurfParamData::!GetControlPoints Method](#)
[IBSurfParamData::ControlPointColumnCount Property](#)
[IBSurfParamData::VKnots Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetControlPoints Method (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : GetControlPoints Method (IBSurfParamData)

Gets the coordinates of a control point at a specific row and column of the control point matrix.

.NET Syntax

Visual Basic (Declaration)

```
Function GetControlPoints( _  
    ByVal Row As System.Integer, _  
    ByVal Column As System.Integer _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim Row As System.Integer
```

```
Dim Column As System.Integer
Dim value As System.Object

value = instance.GetControlPoints(Row, Column)
```

C#

```
System.object GetControlPoints(
    System.int Row,
    System.int Column
)
```

C++/CLI

```
System.Object^ GetControlPoints(
    & System.int Row,
    & System.int Column
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Row
1 <= index of row <= [ControlPointRowCount](#)
Column
1 <= index of column <= [ControlPointColumnCount](#)

Return Value

Array of control point coordinates

 Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::GetControlPoints](#).

 Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

 Remarks

Control points are stored in (ControlPointColumnCount*ControlPointRowCount) vectors of dimension [ControlPointDimension](#). The U direction of surface is in the row direction. The V direction of surface is in the column direction.

- For non-rational surfaces ControlPointDimension = 3, and control point coordinates are stored as [x0,y0,z0,x1,y1,z1,.....].
- For rational surfaces ControlPointDimension = 4, and control point coordinates and weights are stored as [x0,y0,z0,w0,x1,y1,z1,w1,.....].
- For example, 6 control points are stored in 6 vectors of dimension 3 in a 2X3 matrix as follows:

Row1, Column1	Row1, Column2	# Coordinates
x0, y0, z0	x1, y1, z1	= 6
Row2, Column1	Row2, Column2	
x2, y2, z2	x3, y3, z3	= 6
Row3, Column1	Row3, Column2	
x4, y4, z4	x5, y5, z5	= 6
	Total	= 18

 See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::IGetControlPoints Method](#)

 Availability

IGetControlPoints Method (IBSurfParamData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : IGetControlPoints Method (IBSurfParamData)

Gets the coordinates of a control point at a specific row and column of the control point matrix.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetControlPoints( _
    ByVal Row As System.Integer, _
    ByVal Column As System.Integer, _
    ByVal Count As System.Integer _
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As IBSurfParamData
Dim Row As System.Integer
Dim Column As System.Integer
Dim Count As System.Integer
Dim value As System.Double

value = instance.IGetControlPoints(Row, Column, Count)
```

C#

```
System.double IGetControlPoints(
    System.int Row,
    System.int Column,
    System.int Count
)
```

C++/CLI

```
System.double IGetControlPoints(
    & System.int Row,
    & System.int Column,
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*Row*1 <= index of row <= [ControlPointRowCount](#)*Column*1 <= index of column <= [ControlPointColumnCount](#)*Count*[ControlPointDimension](#)

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Control points are stored in (ControlPointColumnCount*ControlPointRowCount) vectors of dimension [ControlPointDimension](#). The U direction of surface is in the row direction. The V direction of surface is in the column direction.

- For non-rational surfaces ControlPointDimension = 3, and control point coordinates are stored as [x0,y0,z0,x1,y1,z1,.....].
- For rational surfaces ControlPointDimension = 4, and control point coordinates and weights are stored as [x0,y0,z0,w0,x1,y1,z1,w1,.....].
- For example, 6 control points are stored in 6 vectors of dimension 3 in a 2X3 matrix as follows:

Row1, Column1	Row1, Column2	# Coordinates
x0, y0, z0	x1, y1, z1	= 6
Row2, Column1	Row2, Column2	
x2, y2, z2	x3, y3, z3	= 6
Row3, Column1	Row3, Column2	
x4, y4, z4	x5, y5, z5	= 6
	Total	= 18

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData.GetControlPoints Method](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UKnots Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : UKnots Property (IBSurfParamData)

Gets the knot vector in the U direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UKnots As System.Object

Visual Basic (Usage)

```
Dim instance As IBSurfParamData
Dim value As System.Object

value = instance.UKnots
```

C#

```
System.object UKnots {get;}
```

C++/CLI

```
property System.Object^ UKnots {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of knot doubles

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::UKnots](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

Remarks

Returned array contains ([control-point column count](#) + [U order](#)) knot values. If the surface is periodic in the U direction, then data is converted and returned in a non-periodic form with additional knots added to the surface ends.

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::VKnots Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UOrder Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : UOrder Property (IBSurfParamData)

Gets the order of the surface in the U direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UOrder As System.Integer

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim value As System.Integer
```

```
value = instance.UOrder
```

C#

```
System.int UOrder {get;}
```

C++/CLI

```
property System.int UOrder {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Order in the U direction

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::Uorder](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::UKnots Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UPeriodicity Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : UPeriodicity Property (IBSurfParamData)

Gets whether the surface is periodic in the U direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UPeriodicity As System.Boolean

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim value As System.Boolean
```

```
value = instance.UPeriodicity
```

C#

```
System.bool UPeriodicity {get;}
```

C++/CLI

```
property System.bool UPeriodicity {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if surface is periodic in U direction, false if not

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::UPeriodicity](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

Remarks

If a surface is periodic in one direction (that is, cylinder, cone, torus (apple and lemon shapes), spheres), then U is the periodic direction.

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::VPeriodicity Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VKnots Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : VKnots Property (IBSurfParamData)

Gets the knot vector in the V direction.

.NET Syntax

ReadOnly Property VKnots As System.Object



```
Dim instance As IBSurfParamData
Dim value As System.Object

value = instance.VKnots
```

```
System.object VKnots {get;}
```

```
property System.Object^ VKnots {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of knot doubles

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::VKnots](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

Remarks

Returned array contains ([control-point row count](#) + [V order](#)) knot values. If the surface is periodic in the V direction, then data is converted and returned in a non-periodic form with additional knots added to the surface ends.

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::UKnots Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

VOrder Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : VOrder Property (IBSurfParamData)

Gets the order of the surface in the V direction.

.NET Syntax

ReadOnly Property VOrder As System.Integer



```
Dim instance As IBSurfParamData
Dim value As System.Integer
```

```
value = instance.VOrder
```

C#

```
System.int VOrder {get;}
```

C++/CLI

```
property System.int VOrder {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Order in the V direction

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::VOrder](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::UOrder Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

VPeriodicity Property (IBSurfParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IBSurfParamData Interface](#) : VPeriodicity Property (IBSurfParamData)

Gets whether the surface is periodic in the V direction.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property VPeriodicity As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IBSurfParamData  
Dim value As System.Boolean
```

```
value = instance.VPeriodicity
```

C#

```
System.bool VPeriodicity {get;}
```

C++/CLI

```
property System.bool VPeriodicity {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if surface is periodic in V direction, false if not

Visual Basic for Applications (VBA) Syntax

See [BSurfParamData::VPeriodicity](#).

Example

[Get B-Spline Surface Parameterization Data \(C#\)](#)
[Get B-Spline Surface Parameterization Data \(VB.NET\)](#)
[Get B-Spline Surface Parameterization Data \(VBA\)](#)

See Also

[IBSurfParamData Interface](#)
[IBSurfParamData Members](#)
[IBSurfParamData::UPeriodicity Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

ICallout (Type)

ICallout Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICallout Interface

Allows add-in applications to manipulate single and multi-row callouts.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICallout
```

Visual Basic (Usage)



```
Dim instance As ICallout
```

C#

```
public interface ICallout
```

C++/CLI

```
public interface class ICallout
```

Visual Basic for Applications (VBA) Syntax

See [Callout](#).

Example

[Create Multi-row Callouts \(VBA\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

Remarks

To create callouts, you must implement the [ISwCalloutHandler](#) interface.

Accessors

[IModelDocExtension::CreateCallout](#) (independent of a selection)
[IModelView::CreateCallout](#)
[IPropertyManagerPageSelectionbox::Callout Property](#)
[ISelectData::Callout Property](#)
[ISelectionMgr::CreateCallout2](#) (dependent on a selection)

Access Diagram

[Callout](#)

See Also

[ICallout Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICallout Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICallout Interface

The following tables list the members exposed by [ICallout](#).

Public Properties

Name	Description
 EnablePushPin	Gets or sets whether to enable the pushpin for this callout.
 FontSize	Gets or sets the font size for this callout.
 IgnoreValue	Gets or sets whether to ignore the callout value in the given row.
 Label2	Gets or sets the text for the label in the specified row of this callout.
 MultipleLeaders	Gets or sets the display of multiple leaders for this callout.
 OpaqueColor	Gets or sets the opaque (background) color for the labels for this callout.
 Position	Gets and sets the position of this callout.
 SkipColon	Gets and sets whether to add a colon at the end of the callout label.
 TargetStyle	Gets or sets the type of connection at the target point for this callout.
 TextBox	Gets or sets whether the callout text is enclosed within a box.
 TextColor	Gets or sets the color of the text in the specified row in this callout.
 TextFormat	Gets or sets the text format for this callout.
 Value	Gets or sets the value in for the specified row in this callout.
 ValueInactive	Gets or sets whether the user can edit the value in the specified row in this callout.

[Top](#)

Public Methods

Name	Description
 Display	Shows or hides the independent (i.e., not attached to a selection) callout.
 GetLeader	Gets the leader properties of the callout.
 GetTargetPoint	Gets the target point for the specified row in this callout.
 SetLeader	Sets the leader properties of the callout.
 SetTargetPoint	Sets the target point for the specified row in this callout.
 UpdatePosition	Obsolete. Superseded by ICallout.Position.

[Top](#)

See Also

[ICallout Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICallout Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICallout Interface

For a list of all members of this type, see [ICallout members](#).

Public Methods

Name	Description
 Display	Shows or hides the independent (i.e., not attached to a selection) callout.
 GetLeader	Gets the leader properties of the callout.
 GetTargetPoint	Gets the target point for the specified row in this callout.
 SetLeader	Sets the leader properties of the callout.

		
	SetTargetPoint	Sets the target point for the specified row in this callout.
	UpdatePosition	Obsolete: Superseded by Callout.Position

[Top](#)

See Also

[ICallout Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICallout Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICallout Interface

For a list of all members of this type, see [ICallout members](#).

Public Properties

Name	Description
 EnablePushPin	Gets or sets whether to enable the pushpin for this callout.
 FontSize	Gets or sets the font size for this callout.
 IgnoreValue	Gets or sets whether to ignore the callout value in the given row.
 Label2	Gets or sets the text for the label in the specified row of this callout.
 MultipleLeaders	Gets or sets the display of multiple leaders for this callout.
 OpaqueColor	Gets or sets the opaque (background) color for the labels for this callout.
 Position	Gets and sets the position of this callout.
 SkipColon	Gets and sets whether to add a colon at the end of the callout label.
 TargetStyle	Gets or sets the type of connection at the target point for this callout.
 TextBox	Gets or sets whether the callout text is enclosed within a box.
 TextColor	Gets or sets the color of the text in the specified row in this callout.
 TextFormat	Gets or sets the text format for this callout.
 Value	Gets or sets the value in for the specified row in this callout.
 ValueInactive	Gets or sets whether the user can edit the value in the specified row in this callout.

[Top](#)

See Also

[ICallout Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Display Method (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : Display Method (ICallout)

Shows or hides the independent (i.e., not attached to a selection) callout.

.NET Syntax

Visual Basic (Declaration)

```
Function Display(  
    ByVal Display As System.Boolean  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout
Dim Display As System.Boolean
Dim value As System.Boolean

value = instance.Display(Display)
```

C#

```
System.bool Display(
    System.bool Display
)
```

C++/CLI

```
System.bool Display(
    & System.bool Display
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Display

True to show the callout, false to hide it

Return Value

True if the operation is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Callout::Display](#).

Example

[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

EnablePushPin Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : EnablePushPin Property (ICallout)

Gets or sets whether to enable the pushpin for this callout.

Visual Basic Syntax

Visual Basic (Declaration)

```
Property EnablePushPin As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout
Dim value As System.Boolean

instance.EnablePushPin = value

value = instance.EnablePushPin
```

C#

```
System.bool EnablePushPin {get; set;}
```

C++/CLI

```
property System.bool EnablePushPin {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable the callout pushpin, false to disable it

Visual Basic for Applications (VBA) Syntax

See [Callout::EnablePushPin](#).

Example

[Create Multi-row Callouts \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FontSize Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : FontSize Property (ICallout)

Gets or sets the font size for this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property FontSize As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICallout
Dim value As System.Integer

instance.FontSize = value

value = instance.FontSize
```

C#

```
System.int FontSize {get; set;}
```

C++/CLI

```
property System.int FontSize {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Font size of the callout

Visual Basic for Applications (VBA) Syntax

See [Callout::FontSize](#).

Example

[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLeader Method (ICallout)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : GetLeader Method (ICallout)

Gets the leader properties of the callout.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeader( _
    ByRef Visible As System.Boolean, _
    ByRef Multiple As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout
Dim Visible As System.Boolean
Dim Multiple As System.Boolean
Dim value As System.Boolean

value = instance.GetLeader(Visible, Multiple)
```

C#

```
System.bool GetLeader(
    out System.bool Visible,
    out System.bool Multiple
)
```

C++/CLI

```
System.bool GetLeader(
    & [Out] System.bool Visible,
    & [Out] System.bool Multiple
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visible

True if leader is displayed, false if not (see **Remarks**)

Multiple

True if multiple leaders are displayed, false if not

Visual Basic for Applications (VBA) Syntax

See [Callout::GetLeader](#).

Remarks

If Visible is false, then [ICallout::TargetStyle](#) is swCalloutTargetStyle_None.

See Also

[ICallout Interface](#)

[ICallout Members](#)

[ICallout::SetLeader Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTargetPoint Method (ICallout)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : GetTargetPoint Method (ICallout)

Gets the target point for the specified row in this callout.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetTargetPoint( _  
    ByVal RowID As System.Integer, _  
    ByRef XPos As System.Double, _  
    ByRef YPos As System.Double, _  
    ByRef ZPos As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim XPos As System.Double  
Dim YPos As System.Double  
Dim ZPos As System.Double  
  
instance.GetTargetPoint(RowID, XPos, YPos, ZPos)
```

C#

```
void GetTargetPoint(  
    System.int RowID,  
    out System.double XPos,  
    out System.double YPos,  
    out System.double ZPos  
)
```

C++/CLI

```
void GetTargetPoint(  
& System.int RowID,  
& [Out] System.double XPos,
```

```
& [Out] System.double YPos,  
& [Out] System.double ZPos  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row in callout
XPos
x coordinate of target point
YPos
y coordinate of target point
ZPos
z coordinate of target point

Visual Basic for Applications (VBA) Syntax

See [Callout::GetTargetPoint](#).

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::SetTargetPoint Method](#)
[ICallout::UpdatePosition Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

IgnoreValue Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : IgnoreValue Property (ICallout)

Gets or sets whether to ignore the callout value in the given row.

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreValue( _  
    ByVal RowID As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim value As System.Boolean  
  
instance.IgnoreValue(RowID) = value  
  
value = instance.IgnoreValue(RowID)
```

C#

```
System.bool IgnoreValue(  
    System.int RowID  
) {get; set;}
```

C++/CLI

```
property System.bool IgnoreValue {  
    System.bool get(System.int RowID);  
    void set (System.int RowID, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Index of callout row

Property Value

True to ignore callout value, false to not

Visual Basic for Applications (VBA) Syntax

See [ICallout::IgnoreValue](#).

Example

[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

Remarks

Use this API to remove the white space that remains in the callout when [ICallout::Value](#) is set to an empty string.

This property applies only to a callout that is independent of a selection or created with [IModelDocExtension::CreateCallout](#).

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Label2 Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : Label2 Property (ICallout)

Gets or sets the text for the label in the specified row of this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property Label2( _  
    ByVal RowID As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim value As System.String  
  
instance.Label2(RowID) = value  
  
value = instance.Label2(RowID)
```

C#

```
System.string Label2(  
    System.int RowID  
) {get; set;}
```

C++/CLI

```
property System.String^ Label2 {  
    System.String^ get(System.int RowID);  
    void set (System.int RowID, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row for label

Property Value

Text for label

Visual Basic for Applications (VBA) Syntax

See [Callout::Label2](#).

Example

[Create Multi-row Callouts \(VBA\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::SkipColon Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

MultipleLeaders Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : MultipleLeaders Property (ICallout)

Gets or sets the display of multiple leaders for this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property MultipleLeaders As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout
Dim value As System.Boolean

instance.MultipleLeaders = value

value = instance.MultipleLeaders
```

C#

```
System.bool MultipleLeaders {get; set;}
```

C++/CLI

```
property System.bool MultipleLeaders {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display multiple leaders, false to not

Visual Basic for Applications (VBA) Syntax

See [Callout::MultipleLeaders](#).

Example

[Create Multi-row Callouts \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

OpaqueColor Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : OpaqueColor Property (ICallout)

Gets or sets the opaque (background) color for the labels for this callout.

.NET Syntax

Visual Basic (Declaration)

Property OpaqueColor As System.Integer

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim value As System.Integer  
  
instance.OpaqueColor = value  
value = instance.OpaqueColor
```

C#

```
System.int OpaqueColor {get; set;}
```

C++/CLI

```
property System.int OpaqueColor {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[System color](#)

Visual Basic for Applications (VBA) Syntax

See [Callout::OpaqueColor](#).

Example

[Create Multi-row Callouts \(VBA\)](#)

Remarks

You must use a system color; you cannot use any other RGB values. To see system colors, click **Tools > Options > Colors** in the SOLIDWORKS Design user interface.

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::TextColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

Position Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : Position Property (ICallout)

Gets and sets the position of this callout.

.NET Syntax

Visual Basic (Declaration)

Property Position As MathPoint

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim value As MathPoint
```

```
instance.Position = value
```

```
value = instance.Position
```

C#

```
MathPoint Position {get; set;}
```

C++/CLI

```
property MathPoint^ Position {  
    MathPoint^ get();  
    void set ( & MathPoint^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Position](#) of this callout

Visual Basic for Applications (VBA) Syntax

See [Callout::Position](#).

Example

[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::GetTargetPoint Method](#)
[ICallout::SetTargetPoint Method](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SetLeader Method (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : SetLeader Method (ICallout)

Sets the leader properties of the callout.

.NET Syntax

Visual Basic (Declaration)

```
Function SetLeader( _  
    ByVal Visible As System.Boolean, _  
    ByVal Multiple As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim Visible As System.Boolean  
Dim Multiple As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetLeader(Visible, Multiple)
```

C#

```
System.bool SetLeader(  
    System.bool Visible,  
    System.bool Multiple  
)
```

C++/CLI

```
System.bool SetLeader(  
& System.bool Visible,  
& System.bool Multiple  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Visible

True to display the leader, false to not (see **Remarks**)

Multiple

True to display multiple leaders, false to not

Return Value

True if the operation is successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Callout::SetLeader](#).

Example

[Create a Callout Independent of a Selection \(C#\)](#)

[Create a Callout Independent of a Selection \(VB.NET\)](#)

[Create a Callout Independent of a Selection \(VBA\)](#)

Remarks

You can only use this method before the callout is shown or while the callout is hidden.

If Visible is set to false, then [ICallout::TargetStyle](#) is automatically set to swCalloutTargetStyle_None.

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::GetLeader Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTargetPoint Method (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : SetTargetPoint Method (ICallout)

Sets the target point for the specified row in this callout.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTargetPoint( _  
    ByVal RowID As System.Integer, _  
    ByVal XPos As System.Double, _  
    ByVal YPos As System.Double, _  
    ByVal ZPos As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim XPos As System.Double  
Dim YPos As System.Double  
Dim ZPos As System.Double  
  
instance.SetTargetPoint(RowID, XPos, YPos, ZPos)
```

C#

```
void SetTargetPoint(  
    System.int RowID,  
    System.double XPos,  
    System.double YPos,  
    System.double ZPos  
)
```

C++/CLI

```
void SetTargetPoint(  
& System.int RowID,  
& System.double XPos,  
& System.double YPos,  
& System.double ZPos  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row in callout
XPos
x coordinate for this target point
YPos
y coordinate for this target point
ZPos
z coordinate for this target poi

Visual Basic for Applications (VBA) Syntax

See [Callout::SetTargetPoint](#).

Example

[Create Multi-row Callouts \(VBA\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::GetTargetPoint Method](#)
[ICallout::UpdatePosition Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

SkipColon Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : SkipColon Property (ICallout)

Gets and sets whether to add a colon at the end of the callout label.

.NET Syntax

Visual Basic (Declaration)

```
Property SkipColon As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim value As System.Boolean  
  
instance.SkipColon = value  
value = instance.SkipColon
```

C#

```
System.bool SkipColon {get; set;}
```

C++/CLI

```
property System.bool SkipColon {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

False to add a colon, true to not

Visual Basic for Applications (VBA) Syntax

See [Callout::SkipColon](#).

Example

[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

Remarks

This property applies only to a callout that is independent of a selection or created with [IModelDocExtension::CreateCallout](#).

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::Label2 Property](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TargetStyle Property (ICallout)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : TargetStyle Property (ICallout)

Gets or sets the type of connection at the target point for this callout.

.NET Syntax

Visual Basic (Declaration)

Property TargetStyle As System.Integer

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim value As System.Integer  
  
instance.TargetStyle = value  
value = instance.TargetStyle
```

C#

```
System.int TargetStyle {get; set;}
```

C++/CLI

```
property System.int TargetStyle {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Connection style as defined in [swCalloutTargetStyle_e](#)

Visual Basic for Applications (VBA) Syntax

See [Callout::TargetStyle](#).

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextBox Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : TextBox Property (ICallout)

Gets or sets whether the callout text is enclosed within a box.

.NET Syntax

Visual Basic (Declaration)

Property TextBox As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICallout
Dim value As System.Boolean

instance.TextBox = value

value = instance.TextBox
```

C#

```
System.bool TextBox {get; set;}
```

C++/CLI

```
property System.bool TextBox {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True encloses the callout text in a box, false does not

Visual Basic for Applications (VBA) Syntax

See [Callout::TextBox](#).

Example

[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

Remarks

You can only set this property before the callout is shown or while the callout is hidden.

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextColor Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : TextColor Property (ICallout)

Gets or sets the color of the text in the specified row in this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property TextColor( _  
    ByVal RowID As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim value As System.Integer  
  
instance.TextColor(RowID) = value  
  
value = instance.TextColor(RowID)
```

C#

```
System.int TextColor(  
    System.int RowID  
) {get; set;}
```

C++/CLI

```
property System.int TextColor {  
    System.int get(System.int RowID);  
    void set (System.int RowID, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row in callout

Property Value

[System color](#)

Visual Basic for Applications (VBA) Syntax

See [Callout::TextColor](#).

Example

[Create Multi-row Callouts \(VBA\)](#)

Remarks

You must use a system color; you cannot use any other RGB values. To see system colors, click **Tools > Options > Colors** in the SOLIDWORKS Design user interface.

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::OpaqueColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextFormat Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : TextFormat Property (ICallout)

Gets or sets the text format for this callout.

Visual Basic Syntax

Visual Basic (Declaration)

Property TextFormat As TextFormat

Visual Basic (Usage)



```
Dim instance As ICallout
Dim value As TextFormat

instance.TextFormat = value
value = instance.TextFormat
```

C#

```
TextFormat TextFormat {get; set;}
```

C++/CLI

```
property TextFormat^ TextFormat {
    TextFormat^ get();
    void set ( & TextFormat^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[ITextFormat](#)

Visual Basic for Applications (VBA) Syntax

See [Callout::TextFormat](#).

Example

[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdatePosition Method (ICallout)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : UpdatePosition Method (ICallout)

Obsolete. Superseded by [Callout::Position](#).

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub UpdatePosition( _
    ByVal XPos As System.Double, _
    ByVal YPos As System.Double, _
    ByVal ZPos As System.Double _
)
```

Visual Basic (Usage)

```
Dim instance As ICallout  
Dim XPos As System.Double  
Dim YPos As System.Double  
Dim ZPos As System.Double  
  
instance.UpdatePosition(XPos, YPos, ZPos)
```

C#

```
void UpdatePosition(  
    System.double XPos,  
    System.double YPos,  
    System.double ZPos  
)
```

C++/CLI

```
void UpdatePosition(  
& System.double XPos,  
& System.double YPos,  
& System.double ZPos  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XPos
x coordinate for callout
YPos
y coordinate for callout
ZPos
z coordinate for callout

Visual Basic for Applications (VBA) Syntax

See [Callout::UpdatePosition](#).

See Also

[ICallout Interface](#)
[ICallout Members](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

Value Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : Value Property (ICallout)

Gets or sets the value in for the specified row in this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property Value( _  
    ByVal RowID As System.Integer _  
) As System.String
```

Visual Basic (Usage)

```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim value As System.String
```

```
instance.Value(RowID) = value  
value = instance.Value(RowID)
```

C#

```
System.string Value(  
    System.int RowID  
) {get; set;}
```

C++/CLI

```
property System.String^ Value {  
    System.String^ get(System.int RowID);  
    void set (System.int RowID, System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row in callout

Property Value

Value

Visual Basic for Applications (VBA) Syntax

See [Callout::Value](#).

Example

[Create Multi-row Callouts \(VBA\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::ValueInactive Property](#)
[ICallout::TextColor Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

SOLIDWORKS API Help

[Send comments](#) on this topic.

ValueInactive Property (ICallout)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICallout Interface](#) : ValueInactive Property (ICallout)

Gets or sets whether the user can edit the value in the specified row in this callout.

.NET Syntax

Visual Basic (Declaration)

```
Property ValueInactive( _  
    ByVal RowID As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ICallout  
Dim RowID As System.Integer  
Dim value As System.Boolean
```



```
instance.ValueInactive(RowID) = value  
value = instance.ValueInactive(RowID)
```

C#

```
System.bool ValueInactive(  
    System.int RowID  
) {get; set;}
```

C++/CLI

```
property System.bool ValueInactive {  
    System.bool get(System.int RowID);  
    void set (System.int RowID, System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

RowID
Row in callout

Property Value

True if the value in this row cannot be modified, false if it can

Visual Basic for Applications (VBA) Syntax

See [Callout::ValueInactive](#).

Example

[Create Multi-row Callouts \(VBA\)](#)
[Create a Callout Independent of a Selection \(VBA\)](#)
[Create a Callout Independent of a Selection \(VB.NET\)](#)
[Create a Callout Independent of a Selection \(C#\)](#)

See Also

[ICallout Interface](#)
[ICallout Members](#)
[ICallout::Value Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15

ICalloutAngleVariable (Type)

ICalloutAngleVariable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutAngleVariable Interface

Allows access to an angle variable in a hole callout.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICalloutAngleVariable
```

Visual Basic (Usage)



```
Dim instance As ICalloutAngleVariable
```

C#

```
public interface ICalloutAngleVariable
```

C++/CLI

```
public interface class ICalloutAngleVariable
```

Visual Basic for Applications (VBA) Syntax

See [CalloutAngleVariable](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

Remarks

To access a CalloutAngleVariable object:

1. Call [IDisplayDimension::GetHoleCalloutVariables](#).
2. Iterate through the [CalloutVariable](#) objects returned by IDisplayDimension::GetHoleCalloutVariables and call [ICalloutVariable::Type](#).

If the type of hole callout equals [swCalloutVariableType_e.swCalloutVariable_Angle](#), then that object is a CalloutAngleVariable object.

Access Diagram

[CalloutAngleVariable](#)

See Also

[ICalloutAngleVariable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutLengthVariable Interface](#)
[ICalloutStringVariable Interface](#)

ICalloutAngleVariable Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutAngleVariable Interface

The following tables list the members exposed by [ICalloutAngleVariable](#).

Public Properties

Name	Description
------	-------------

 Angle	Gets the value of an angle variable in a hole callout.
 Precision	Gets or sets the number of digits to display after the decimal point of the angle value of this hole callout.

[Top](#)

 See Also

[ICalloutAngleVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutLengthVariable Interface](#)
[ICalloutStringVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICalloutAngleVariable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutAngleVariable Interface

For a list of all members of this type, see [ICalloutAngleVariable members](#).

 Public Properties

Name	Description
 Angle	Gets the value of an angle variable in a hole callout.
 Precision	Gets or sets the number of digits to display after the decimal point of the angle value of this hole callout.

[Top](#)

 See Also

[ICalloutAngleVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutLengthVariable Interface](#)
[ICalloutStringVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Angle Property (ICalloutAngleVariable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutAngleVariable Interface](#) : Angle Property (ICalloutAngleVariable)

Gets the value of an angle variable in a hole callout.

 .NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Angle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICalloutAngleVariable  
Dim value As System.Double
```

```
value = instance.Angle
```

C#

```
System.double Angle {get;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [CalloutAngleVariable::Angle](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

See Also

[ICalloutAngleVariable Interface](#)
[ICalloutAngleVariable Members](#)
[ICalloutAngleVariable::Precision Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Precision Property (ICalloutAngleVariable)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutAngleVariable Interface](#) : Precision Property (ICalloutAngleVariable)

Gets or sets the number of digits to display after the decimal point of the angle value of this hole callout.

.NET Syntax

Visual Basic (Declaration)

Property Precision As System.Integer

Visual Basic (Usage)



```
Dim instance As ICalloutAngleVariable  
Dim value As System.Integer
```

```
instance.Precision = value
```

```
value = instance.Precision
```

C#

```
System.int Precision {get; set;}
```

C++/CLI

```
property System.int Precision {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of digits displayed after the decimal point of the angle value

Visual Basic for Applications (VBA) Syntax

See [CalloutAngleVariable::Precision](#).

See Also

[ICalloutAngleVariable Interface](#)
[ICalloutAngleVariable Members](#)
[ICalloutAngleVariable::Angle Property \(\)](#)

ICalloutLengthVariable (Type)

ICalloutLengthVariable Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutLengthVariable Interface

Allows access to a length variable in a hole callout.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICalloutLengthVariable
```

Visual Basic (Usage)



```
Dim instance As ICalloutLengthVariable
```

C#

```
public interface ICalloutLengthVariable
```

C++/CLI

```
public interface class ICalloutLengthVariable
```

Visual Basic for Applications (VBA) Syntax

See [CalloutLengthVariable](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

Remarks

To access a CalloutLengthVariable object:

1. Call [IDisplayDimension::GetHoleCalloutVariables](#).
2. Iterate through the [CalloutVariable](#) objects returned by IDisplayDimension::GetHoleCalloutVariables and call [ICalloutVariable::Type](#).

If the type of hole callout equals [swCalloutVariableType_e.swCalloutVariable_Length](#), then that object is a CalloutLengthVariable object.

Access Diagram

[CalloutLengthVariable](#)

See Also

[ICalloutLengthVariable Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutStringVariable Interface](#)

ICalloutLengthVariable Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutLengthVariable Interface

The following tables list the members exposed by [ICalloutLengthVariable](#).

Public Properties

Name	Description
------	-------------

 Length	Gets or sets the length for this length variable in a hole callout.
 Precision	Gets or sets number of digits after the decimal point to display the primary precision value for a length variable in a hole callout.
 TolerancePrecision	Gets or sets number of digits after the decimal point to display the primary tolerance value for the length variable in a hole callout.

[Top](#)

See Also

[ICalloutLengthVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutStringVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICalloutLengthVariable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutLengthVariable Interface

For a list of all members of this type, see [ICalloutLengthVariable members](#).

Public Properties

Name	Description
 Length	Gets or sets the length for this length variable in a hole callout.
 Precision	Gets or sets number of digits after the decimal point to display the primary precision value for a length variable in a hole callout.
 TolerancePrecision	Gets or sets number of digits after the decimal point to display the primary tolerance value for the length variable in a hole callout.

[Top](#)

See Also

[ICalloutLengthVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutStringVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Length Property (ICalloutLengthVariable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutLengthVariable Interface](#) : Length Property (ICalloutLengthVariable)

Gets or sets the length for this length variable in a hole callout.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Length As System.Double

Visual Basic (Usage)



```
Dim instance As ICalloutLengthVariable  
Dim value As System.Double
```

```
value = instance.Length
```

C#

```
System.double Length {get;}
```

C++/CLI

```
property System.double Length {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length

Visual Basic for Applications (VBA) Syntax

See [ICalloutLengthVariable::Length](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

See Also

[ICalloutLengthVariable Interface](#)
[ICalloutLengthVariable Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Precision Property (ICalloutLengthVariable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutLengthVariable Interface](#) : Precision Property (ICalloutLengthVariable)

Gets or sets number of digits after the decimal point to display the primary precision value for a length variable in a hole callout.

.NET Syntax

Visual Basic (Declaration)

Property Precision As System.Integer

Visual Basic (Usage)



```
Dim instance As ICalloutLengthVariable
Dim value As System.Integer

instance.Precision = value
value = instance.Precision
```

C#

```
System.int Precision {get; set;}
```

C++/CLI

```
property System.int Precision {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of digits after the decimal point to display the primary precision value

Visual Basic for Applications (VBA) Syntax

See [ICalloutLengthVariable::Precision](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

Remarks

Call [IDisplayDimension::SetPrecision3](#) to set the dual precision value for a display dimension for a hole callout.

See Also

[ICalloutLengthVariable Interface](#)
[ICalloutLengthVariable Members](#)
[ICalloutLengthVariable::TolerancePrecision Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TolerancePrecision Property (ICalloutLengthVariable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutLengthVariable Interface](#) : TolerancePrecision Property (ICalloutLengthVariable)

Gets or sets number of digits after the decimal point to display the primary tolerance value for the length variable in a hole callout.

.NET Syntax

Visual Basic (Declaration)

Property TolerancePrecision As System.Integer

Visual Basic (Usage)



```
Dim instance As ICalloutLengthVariable  
Dim value As System.Integer
```

```
instance.TolerancePrecision = value
```

```
value = instance.TolerancePrecision
```

C#

```
System.int TolerancePrecision {get; set;}
```

C++/CLI

```
property System.int TolerancePrecision {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of digits after the decimal point to display the primary tolerance value

Visual Basic for Applications (VBA) Syntax

See [CalloutLengthVariable::TolerancePrecision](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

Remarks

Call [IDisplayDimension::SetPrecision3](#) to set the dual tolerance value for a display dimension for a hole callout.

See Also

[ICalloutLengthVariable Interface](#)
[ICalloutLengthVariable Members](#)
[ICalloutLengthVariable.Precision Property \(\)](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

ICalloutStringValue (Type)

ICalloutStringValue Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutStringValue Interface

Allows access to a string variable in a hole callout.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ICalloutStringValue
```

Visual Basic (Usage)



```
Dim instance As ICalloutStringValue
```

C#

```
public interface ICalloutStringValue
```

C++/CLI

```
public interface class ICalloutStringValue
```

Visual Basic for Applications (VBA) Syntax

See [CalloutStringValue](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

Remarks

To access a CalloutStringValue object:

1. Call [IDisplayDimension::GetHoleCalloutVariables](#).
2. Iterate through the [CalloutVariable](#) objects returned by [IDisplayDimension::GetHoleCalloutVariables](#) and call [ICalloutVariable::Type](#).

If the type of hole callout equals [swCalloutVariableType_e.swCalloutVariable_String](#), then that object is a CalloutStringValue object.

Access Diagram

[CalloutStringValue](#)

See Also

[ICalloutStringValue Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutLengthVariable Interface](#)

ICalloutStringValue Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutStringValue Interface

The following tables list the members exposed by [ICalloutStringValue](#).

Public Properties

Name	Description
------	-------------



[String](#)

Gets or sets the text for this string variable in a hole callout.

[Top](#)

See Also

[ICalloutStringVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutLengthVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICalloutStringVariable Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICalloutStringVariable Interface

For a list of all members of this type, see [ICalloutStringVariable members](#).

Public Properties

Name

Description



[String](#)

Gets or sets the text for this string variable in a hole callout.

[Top](#)

See Also

[ICalloutStringVariable Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICalloutAngleVariable Interface](#)
[ICalloutLengthVariable Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

String Property (ICalloutStringVariable)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICalloutStringVariable Interface](#) : String Property (ICalloutStringVariable)

Gets or sets the text for this string variable in a hole callout.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property String As System.String
```

Visual Basic (Usage)



```
Dim instance As ICalloutStringVariable  
Dim value As System.String  
  
value = instance.String
```

C#

```
System.string String {get;}
```

C++/CLI

```
property System.String^ String {  
    System.String^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Text

Visual Basic for Applications (VBA) Syntax

See [CalloutStringVariable::String](#).

Example

[Get and Set Hole Callout Variables \(C#\)](#)
[Get and Set Hole Callout Variables \(VB.NET\)](#)
[Get and Set Hole Callout Variables \(VBA\)](#)

See Also

[ICalloutStringVariable Interface](#)
[ICalloutStringVariable Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0