

SOLIDWORKS API (.NET VBA C#) — Reference

(40/337): IChamferFeatureData2

SOLIDWORKS API Documentation (converted from CHM)

IChamferFeatureData2 (Type)

IChamferFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData2 Interface

Allows access to a chamfer feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IChamferFeatureData2
```

Visual Basic (Usage)

```
Dim instance As IChamferFeatureData2
```

C#

```
public interface IChamferFeatureData2
```

C++/CLI

```
public interface class IChamferFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#)

Access Diagram

[ChamferFeatureData2](#)

See Also

[IChamferFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::FeatureChamfer Method](#)
[IVariableFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Interface](#)
[IFeatureManager::InsertFeatureChamfer Method](#)

IChamferFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData2 Interface

The following tables list the members exposed by [IChamferFeatureData2](#).

Public Properties

Name	Description
------	-------------

 EdgeChamferAngle	Gets or sets the angle on the edge of the chamfer feature.
 Edges	Gets or sets a list of the edges to which a chamfer is applied.
 EqualDistance	Gets or sets whether to specify a single value for distance or vertex.
 Faces	Gets and sets a list of the faces to which a chamfer is applied.
 IVertex	Gets or sets the vertex to which a chamfer is applied.
 KeepFeatures	Gets or sets whether to keep existing features on the entities selected for the chamfer.
 LoopCount	Gets the number of loops to which a chamfer is applied.
 Loops	Gets and sets the loops to which a chamfer is applied.
 PropagateFeatureToParts	Gets or sets whether to extend the chamfer feature to all affected parts in the assembly.
 TangentPropagation	Gets or sets whether to extend the chamfer to all faces that are tangent to the selected faces or edges.
 Type	Gets or sets the type of chamfer feature.
 Vertex	Gets or sets the vertex to which a chamfer is applied.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this chamfer feature.
 GetEdgeChamferDistance	Gets the edge chamfer distance on either side of the edge.
 GetEdgeCount	Gets the number of edges that are chamfered.
 GetFaceCount	Gets the number of faces that are chamfered.
 GetIsFlipped	Gets whether the chamfer feature is flipped.
 GetVertexChamferDistance	Gets the vertex chamfer distance.
 IAccessSelections	Accesses the selections that define this chamfer feature.
 IGetEdges	Gets the edges to which a chamfer is applied.
 IGetFaces	Gets the faces to which a chamfer is applied.
 IGetLoops	Gets the loops to which a chamfer is applied.
 ISetEdges	Sets the edges to which a chamfer is applied.
 ISetFaces	Gets the faces to which a chamfer is applied.
 ISetLoops	Sets the loops to which a chamfer is applied.
 ReleaseSelectionAccess	Releases access to the selections that created this chamfer feature.
 SetEdgeChamferDistance	Sets the edge chamfer distance on either side of the edge.
 SetIsFlipped	Gets whether the chamfer feature is flipped.
 SetVertexChamferDistance	Sets the vertex chamfer distance.

[Top](#)

See Also

[IChamferFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::FeatureChamfer Method](#)
[IVariableFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Interface](#)
[IFeatureManager::InsertFeatureChamfer Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IChamferFeatureData2 Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData2 Interface

For a list of all members of this type, see [IChamferFeatureData2 members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this chamfer feature.
 GetEdgeChamferDistance	Gets the edge chamfer distance on either side of the edge.
 GetEdgeCount	Gets the number of edges that are chamfered.
 GetFaceCount	Gets the number of faces that are chamfered.
 GetIsFlipped	Gets whether the chamfer feature is flipped.
 GetVertexChamferDistance	Gets the vertex chamfer distance.
 IAccessSelections	Accesses the selections that define this chamfer feature.
 IGetEdges	Gets the edges to which a chamfer is applied.
 IGetFaces	Gets the faces to which a chamfer is applied.
 IGetLoops	Gets the loops to which a chamfer is applied.
 ISetEdges	Sets the edges to which a chamfer is applied.
 ISetFaces	Sets the faces to which a chamfer is applied.
 ISetLoops	Sets the loops to which a chamfer is applied.
 ReleaseSelectionAccess	Releases access to the selections that created this chamfer feature.
 SetEdgeChamferDistance	Sets the edge chamfer distance on either side of the edge.
 SetIsFlipped	Gets whether the chamfer feature is flipped.
 SetVertexChamferDistance	Sets the vertex chamfer distance.

[Top](#)

See Also

[IChamferFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::FeatureChamfer Method](#)
[IVariableFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Interface](#)
[IFeatureManager::InsertFeatureChamfer Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IChamferFeatureData2 Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IChamferFeatureData2 Interface

For a list of all members of this type, see [IChamferFeatureData2 members](#).

Public Properties

Name	Description
 EdgeChamferAngle	Gets or sets the angle on the edge of the chamfer feature.
 Edges	Gets or sets a list of the edges to which a chamfer is applied.
 EqualDistance	Gets or sets whether to specify a single value for distance or vertex.
 Faces	Gets and sets a list of the faces to which a chamfer is applied.
 IVertex	Gets or sets the vertex to which a chamfer is applied.
 KeepFeatures	Gets or sets whether to keep existing features on the entities selected for the chamfer.
 LoopCount	Gets the number of loops to which a chamfer is applied.
 Loops	Gets and sets the loops to which a chamfer is applied.
 PropagateFeatureToParts	Gets or sets whether to extend the chamfer feature to all affected parts in the assembly.
 TangentPropagation	Gets or sets whether to extend the chamfer to all faces that are tangent to the selected faces or edges.

 Type	Gets or sets the type of chamfer feature.
 Vertex	Gets or sets the vertex to which a chamfer is applied.

[Top](#)

See Also

[IChamferFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::FeatureChamfer Method](#)
[IVariableFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Interface](#)
[IFeatureManager::InsertFeatureChamfer Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : AccessSelections Method (IChamferFeatureData2)

Gains access to the selections that define this chamfer feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::AccessSelections](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

		Remark
To modify a feature in a...	Then...	
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL	
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified	

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IChamferFeatureData2::ReleaseSelectionAccess](#) if not

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::IAccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EdgeChamferAngle Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : EdgeChamferAngle Property (IChamferFeatureData2)

Gets or sets the angle on the edge of the chamfer feature.

.NET Syntax

Visual Basic (Declaration)

Property EdgeChamferAngle As System.Double

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Double
```

```
instance.EdgeChamferAngle = value
```

```
value = instance.EdgeChamferAngle
```

C#

```
System.double EdgeChamferAngle {get; set;}
```

C++/CLI

```
property System.double EdgeChamferAngle {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Chamfer angle of the edge of the chamfer feature

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::EdgeChamferAngle](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

This method is relevant only for an angle-distance type of chamfer.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::Type Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edges Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : Edges Property (IChamferFeatureData2)

Gets or sets a list of the edges to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

Property Edges As System.Object

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim value As System.Object
```

```
instance.Edges = value
```

```
value = instance.Edges
```

C#

```
System.object Edges {get; set;}
```

C++/CLI

```
property System.Object^ Edges {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

List of chamfered edges

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::Edges](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::GetEdgeCount Method](#)
[IChamferFeatureData2::IGetEdges Method](#)
[IChamferFeatureData2::ISetEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EqualDistance Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : EqualDistance Property (IChamferFeatureData2)

Gets or sets whether to specify a single value for distance or vertex.

.NET Syntax

Visual Basic (Declaration)

Property EqualDistance As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Boolean
```

```
instance.EqualDistance = value
```

```
value = instance.EqualDistance
```

C#

```
System.bool EqualDistance {get; set;}
```

C++/CLI

```
property System.bool EqualDistance {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to specify a single value for distance or vertex, false to not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::EqualDistance](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Faces Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : Faces Property (IChamferFeatureData2)

Gets and sets a list of the faces to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of IFace2

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::Faces](#).

Example

[Get Chamfer Distances \(C#\)](#)
[Get Chamfer Distances \(VB.NET\)](#)
[Get Chamfer Distances \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::GetFaceCount Method](#)
[IChamferFeatureData2::GetFaces Method](#)
[IChamferFeatureData2::SetEdges Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgeChamferDistance Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : GetEdgeChamferDistance Method (IChamferFeatureData2)

Gets the edge chamfer distance on either side of the edge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeChamferDistance( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Side As System.Integer  
Dim value As System.Double  
  
value = instance.GetEdgeChamferDistance(Side)
```

C#

```
System.double GetEdgeChamferDistance(  
    System.int Side  
)
```

C++/CLI

```
System.double GetEdgeChamferDistance(  
    & System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side
Feature direction (see **Remarks**)

Return Value

Edge chamfer distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::GetEdgeChamferDistance](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

Set the Side parameter to 0 or 1. For angle-distance chamfers, set side to 0.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::SetEdgeChamferDistance Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgeCount Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : GetEdgeCount Method (IChamferFeatureData2)

Gets the number of edges that are chamfered.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::GetEdgeCount](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

Call this method before calling [IChamferFeatureData2::IGetEdges](#).

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : GetFaceCount Method (IChamferFeatureData2)

Gets the number of faces that are chamfered.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Integer  
  
value = instance.GetFaceCount()
```

C#

```
System.int GetFaceCount()
```

C++/CLI

```
System.int GetFaceCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::GetFaceCount](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

Call this method before calling [IChamferFeatureData2::IGetFaces](#).

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetIsFlipped Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : GetIsFlipped Method (IChamferFeatureData2)

Gets whether the chamfer feature is flipped.

.NET Syntax

Visual Basic (Declaration)

```
Function GetIsFlipped( _  
    ByVal Entity As System.Object _  
    ) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Entity As System.Object  
Dim value As System.Boolean  
  
value = instance.GetIsFlipped(Entity)
```

C#

```
System.bool GetIsFlipped(  
    System.object Entity  
)
```

C++/CLI

```
System.bool GetIsFlipped(  
& System.Object^ Entity  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity
Edge, face, or loop

Return Value

True if the chamfer feature is flipped, false if not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::GetIsFlipped](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::SetIsFlipped Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetVertexChamferDistance Method (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : GetVertexChamferDistance Method (IChamferFeatureData2)

Gets the vertex chamfer distance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetVertexChamferDistance( _  
    ByVal Side As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Side As System.Integer  
Dim value As System.Double  
  
value = instance.GetVertexChamferDistance(Side)
```

C#

```
System.double GetVertexChamferDistance(  
    System.int Side  
)
```

C++/CLI

```
System.double GetVertexChamferDistance(  
&    System.int Side  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Feature direction (see **Remarks**)

Return Value

Vertex chamfer distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::GetVertexChamferDistance](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

There are three edges of a vertex. Set the Side parameter to 0, 1, or 2. The Side parameter is relevant only for vertex-type of chamfers.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::SetVertexChamferDistance Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : IAccessSelections Method (IChamferFeatureData2)

Accesses the selections that define this chamfer feature.

.NET Syntax

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```



```
Dim instance As IChamferFeatureData2
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)
```

```
System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)
```

```
System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::IAccessSelections](#).

Remarks

Remark

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc argument is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IChamferFeatureData2::ReleaseSelectionAccess](#) if not

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : IGetEdges Method (IChamferFeatureData2)

Gets the edges to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetEdges( _  
    ByVal Count As System.Integer _  
) As Edge
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Count As System.Integer  
Dim value As Edge  
  
value = instance.IGetEdges(Count)
```

C#

```
Edge IGetEdges(  
    System.int Count  
)
```

C++/CLI

```
Edge^ IGetEdges(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IChamferFeatureData2::GetEdgeCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::ISetEdges Method](#)
[IChamferFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : IGetFaces Method (IChamferFeatureData2)

Gets the faces to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal FaceCount As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim FaceCount As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces(FaceCount)
```

C#

```
Face2 IGetFaces(  
    System.int FaceCount  
)
```

C++/CLI

```
Face2^ IGetFaces(  
& System.int FaceCount  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size FaceCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IChamferFeatureData2::GetFaceCount](#) before calling this method.

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::ISetFaces Method](#)
[IChamferFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLoops Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : IGetLoops Method (IChamferFeatureData2)

Gets the loops to which a chamfer is applied.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetLoops( _  
    ByVal Count As System.Integer _  
) As Loop
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Count As System.Integer  
Dim value As Loop  
  
value = instance.IGetLoops(Count)
```

C#

```
Loop IGetLoops(  
    System.int Count  
)
```

C++/CLI

```
Loop^ IGetLoops(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of loops

Return Value

- in-process, unmanaged C++: Pointer to an array of [loops](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [IChamferFeatureData2::LoopCount](#) before calling this method.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::ISetLoops Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetEdges Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : ISetEdges Method (IChamferFeatureData2)

Sets the edges to which a chamfer is applied.

Visual Basic Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _
    ByVal Count As System.Integer, _
    ByRef EdgeList As Edge _
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim Count As System.Integer
Dim EdgeList As Edge

instance.ISetEdges(Count, EdgeList)
```

C#

```
void ISetEdges(
    System.int Count,
    ref Edge EdgeList
)
```

C++/CLI

```
void ISetEdges(
    & System.int Count,
    & Edge^% EdgeList
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of edges
EdgeList

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::IGetEdges Method](#)
[IChamferFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFaces Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : ISetFaces Method (IChamferFeatureData2)

Gets the faces to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _
    ByVal Count As System.Integer, _
    ByRef FaceList As Face2 _
)
```

Visual Basic (Usage)

```
Dim instance As IChamferFeatureData2  
Dim Count As System.Integer  
Dim FaceList As Face2  
  
instance.ISetFaces(Count, FaceList)
```

C#

```
void ISetFaces(  
    System.int Count,  
    ref Face2 FaceList  
)
```

C++/CLI

```
void ISetFaces(  
& System.int Count,  
& Face2^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of faces

FaceList

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::IGetFaces Method](#)
[IChamferFeatureData2::Faces Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetLoops Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : ISetLoops Method (IChamferFeatureData2)

Sets the loops to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetLoops(  
    ByVal Count As System.Integer, _  
    ByRef LoopList As Loop _  
)
```

Visual Basic (Usage)

```
Dim instance As IChamferFeatureData2  
Dim Count As System.Integer  
Dim LoopList As Loop
```

```
instance.ISetLoops(Count, LoopList)
```

C#

```
void ISetLoops(  
    System.int Count,  
    ref Loop LoopList  
)
```

C++/CLI

```
void ISetLoops(  
& System.int Count,  
& Loop^% LoopList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of loops

LoopList

- in-process, unmanaged C++: Pointer to an array of [loops](#) of size Count

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IChamferFeatureData2 Interface](#)

[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::IGetLoops Method](#)

[IChamferFeatureData2::Loops Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IVertex Property (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : IVertex Property (IChamferFeatureData2)

Gets or sets the vertex to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

Property IVertex As Vertex

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As Vertex
```

```
instance.IVertex = value
```

```
value = instance.IVertex
```

C#

```
Vertex IVertex {get; set;}
```

C++/CLI

```
property Vertex^ IVertex {  
    Vertex^ get();  
    void set ( & Vertex^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Chamfered vertex](#)

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::IVertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::Vertex Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

KeepFeatures Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : KeepFeatures Property (IChamferFeatureData2)

Gets or sets whether to keep existing features on the entities selected for the chamfer.

.NET Syntax

Visual Basic (Declaration)

Property KeepFeatures As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Boolean
```

```
instance.KeepFeatures = value
```

```
value = instance.KeepFeatures
```

C#

```
System.bool KeepFeatures {get; set;}
```

C++/CLI

```
property System.bool KeepFeatures {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True keeps the existing features, false does not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::KeepFeatures](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LoopCount Property (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : LoopCount Property (IChamferFeatureData2)

Gets the number of loops to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property LoopCount As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Integer
```

```
value = instance.LoopCount
```

C#

```
System.int LoopCount {get;}
```

C++/CLI

```
property System.int LoopCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of loops

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::LoopCount](#).

Remarks

Call this property before calling [IChamferFeatureData2::GetLoops](#).

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::!SetLoops Method](#)
[IChamferFeatureData2::Loops Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Loops Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : Loops Property (IChamferFeatureData2)

Gets and sets the loops to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

Property Loops As System.Object

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Object
```

```
instance.Loops = value
```

```
value = instance.Loops
```

C#

```
System.object Loops {get; set;}
```

C++/CLI

```
property System.Object^ Loops {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of chamfered [loops](#)

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::Loops](#).

Example

[Get Chamfer Distances \(C#\)](#)
[Get Chamfer Distances \(VB.NET\)](#)
[Get Chamfer Distances \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)
[IChamferFeatureData2::!GetLoops Method](#)
[IChamferFeatureData2::!SetLoops Method](#)
[IChamferFeatureData2::LoopCount Property](#)

Availability

PropagateFeatureToParts Property (IChamferFeatureData2)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : PropagateFeatureToParts Property (IChamferFeatureData2)

Gets or sets whether to extend the chamfer feature to all affected parts in the assembly.

.NET Syntax

Visual Basic (Declaration)

Property PropagateFeatureToParts As System.Boolean

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim value As System.Boolean

instance.PropagateFeatureToParts = value

value = instance.PropagateFeatureToParts
```

C#

```
System.bool PropagateFeatureToParts {get; set;}
```

C++/CLI

```
property System.bool PropagateFeatureToParts {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend the chamfer feature to all affected parts in the assembly, false to not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::PropagateFeatureToParts](#).

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

ReleaseSelectionAccess Method (IChamferFeatureData2)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : ReleaseSelectionAccess Method (IChamferFeatureData2)

Releases access to the selections that created this chamfer feature.

.NET Syntax

Visual Basic (Declaration)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::ReleaseSelectionAccess](#).

Example

[Get Edge Chamfer Distances \(C#\)](#)
[Get Edge Chamfer Distances \(VB.NET\)](#)
[Get Edge Chamfer Distances \(VBA\)](#)

Remarks

[IChamferFeatureData2::AccessSelections](#) or [IChamferFeatureData2::IAccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEdgeChamferDistance Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : SetEdgeChamferDistance Method (IChamferFeatureData2)

Sets the edge chamfer distance on either side of the edge.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEdgeChamferDistance( _  
    ByVal Side As System.Integer, _  
    ByVal Distance As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Side As System.Integer  
Dim Distance As System.Double
```

```
instance.SetEdgeChamferDistance(Side, Distance)
```

C#

```
void SetEdgeChamferDistance(  
    System.int Side,  
    System.double Distance  
)
```

C++/CLI

```
void SetEdgeChamferDistance(  
& System.int Side,  
& System.double Distance  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Feature direction (see **Remarks**)

Distance

Edge chamfer distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::SetEdgeChamferDistance](#).

Remarks

Set the Side parameter to 0 or 1. For angle-distance chamfers, set side to 0.

See Also

[IChamferFeatureData2 Interface](#)

[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::GetEdgeChamferDistance Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetIsFlipped Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : SetIsFlipped Method (IChamferFeatureData2)

Gets whether the chamfer feature is flipped.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetIsFlipped( _  
    ByVal Entity As System.Object, _  
    ByVal Flip As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim Entity As System.Object  
Dim Flip As System.Boolean  
  
instance.SetIsFlipped(Entity, Flip)
```

C#

```
void SetIsFlipped(
    System.object Entity,
    System.bool Flip
)
```

C++/CLI

```
void SetIsFlipped(
    & System.Object^ Entity,
    & System.bool Flip
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entity

Chamfer feature

Flip

True flips the chamfer feature, false does not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::SetIsFlipped](#).

See Also

[IChamferFeatureData2 Interface](#)

[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::GetIsFlipped Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetVertexChamferDistance Method (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : SetVertexChamferDistance Method (IChamferFeatureData2)

Sets the vertex chamfer distance.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVertexChamferDistance( _
    ByVal Side As System.Integer, _
    ByVal Distance As System.Double _
)
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim Side As System.Integer
Dim Distance As System.Double
```

```
instance.SetVertexChamferDistance(Side, Distance)
```

C#

```
void SetVertexChamferDistance(
    System.int Side,
    System.double Distance
)
```

C++/CLI

```
void SetVertexChamferDistance(
& System.int Side,
& System.double Distance
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Side

Feature direction (see **Remarks**)

Distance

Vertex chamfer distance

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::SetVertexChamferDistance](#).

Remarks

There are three edges of a vertex. Set the Side parameter to 0, 1, or 2 to specify the edge. The Side parameter is relevant only for vertex-type chamfers.

See Also

[IChamferFeatureData2 Interface](#)

[IChamferFeatureData2 Members](#)

[IChamferFeatureData2::GetVertexChamferDistance Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TangentPropagation Property (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : TangentPropagation Property (IChamferFeatureData2)

Gets or sets whether to extend the chamfer to all faces that are tangent to the selected faces or edges.

.NET Syntax

Visual Basic (Declaration)

```
Property TangentPropagation As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2
Dim value As System.Boolean
```

```
instance.TangentPropagation = value
```

```
value = instance.TangentPropagation
```

C#

```
System.bool TangentPropagation {get; set;}
```

C++/CLI

```
property System.bool TangentPropagation {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to propagate chamfer to tangent faces, false to not

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::TangentPropagation](#).

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IChamferFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : Type Property (IChamferFeatureData2)

Gets or sets the type of chamfer feature.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Integer
```

```
instance.Type = value
```

```
value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of chamfer as defined in [swChamferType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::Type](#).

Example

[Get Chamfer Distances \(VB.NET\)](#)
[Get Chamfer Distances \(C#\)](#)
[Get Chamfer Distances \(VBA\)](#)

Remarks

Both `swChamferType_e.swChamferAngleDistance` and `swChamferType_e.swChamferDistanceDistance` are edge chamfers. This means that all measurements are from edges. An angle-distance chamfer requires an angle and a distance; a distance-distance chamfer requires two distances, one for each side of the chamfered edge.

A `swChamferType_e.swChamferVertex` chamfer only works on a vertex with three adjacent edges of the same convexity. A vertex chamfer requires three distances along three adjacent edges. For non-linear edges, this value is an arc length value; it is not a chordal value. See [Vertex::EnumEdgesOriented](#) to determine the edge order used by this method.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Vertex Property (IChamferFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IChamferFeatureData2 Interface](#) : Vertex Property (IChamferFeatureData2)

Gets or sets the vertex to which a chamfer is applied.

.NET Syntax

Visual Basic (Declaration)

Property Vertex As System.Object

Visual Basic (Usage)



```
Dim instance As IChamferFeatureData2  
Dim value As System.Object
```

```
instance.Vertex = value
```

```
value = instance.Vertex
```

C#

```
System.Object Vertex {get; set;}
```

C++/CLI

```
property System.Object^ Vertex {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Chamfered vertex

Visual Basic for Applications (VBA) Syntax

See [ChamferFeatureData2::Vertex](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IChamferFeatureData2 Interface](#)
[IChamferFeatureData2 Members](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0