

SOLIDWORKS API (.NET VBA C#) — Reference (42/337): IClearanceResult-ICoEdge

SOLIDWORKS API Documentation (converted from CHM)

IClearanceResult (Type)

IClearanceResult Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClearanceResult Interface

Allows you to access the results of [clearance verification](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IClearanceResult
```

Visual Basic (Usage)



```
Dim instance As IClearanceResult
```

C#

```
public interface IClearanceResult
```

C++/CLI

```
public interface class IClearanceResult
```

Visual Basic for Applications (VBA) Syntax

See [ClearanceResult](#).

Example

See the [IClearanceVerificationMgr](#) examples.

Remarks

For more information see **SOLIDWORKS online Help > Assemblies > Detecting Problems > Clearance Verification**.

Accessors

[IClearanceVerificationManager::CalculateClearances](#)

Access Diagram

[ClearanceResult](#)

See Also

[IClearanceResult Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IClearanceResult Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClearanceResult Interface

The following tables list the members exposed by [IClearanceResult](#).

Public Properties

Name	Description
ClearanceType	Gets the clearance type.



[ClearanceValue](#)

Gets the clearance value.



[ComponentsOrFaces](#)

Gets the assembly components, faces, or both involved in this clearance result.

[Top](#)

See Also

[IClearanceResult Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IClearanceResult Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClearanceResult Interface

For a list of all members of this type, see [IClearanceResult members](#).

Public Properties

Name	Description
ClearanceType	Gets the clearance type.
ClearanceValue	Gets the clearance value.
ComponentsOrFaces	Gets the assembly components, faces, or both involved in this clearance result.

[Top](#)

See Also

[IClearanceResult Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClearanceType Property (IClearanceResult)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceResult Interface](#) : ClearanceType Property (IClearanceResult)

Gets the clearance type.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ClearanceType As System.Integer

Visual Basic (Usage)



```
Dim instance As IClearanceResult  
Dim value As System.Integer
```

```
value = instance.ClearanceType
```

C#

```
System.int ClearanceType {get;}
```

C++/CLI

```
property System.int ClearanceType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Clearance type as defined by [swClearanceType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ClearanceResult::ClearanceType](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceResult Interface](#)
[IClearanceResult Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ClearanceValue Property (IClearanceResult)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceResult Interface](#) : ClearanceValue Property (IClearanceResult)

Gets the clearance value.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property ClearanceValue As System.Double
```

Visual Basic (Usage)



```
Dim instance As IClearanceResult  
Dim value As System.Double  
  
value = instance.ClearanceValue
```

C#

```
System.double ClearanceValue {get;}
```

C++/CLI

```
property System.double ClearanceValue {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Clearance value

Visual Basic for Applications (VBA) Syntax

See [ClearanceResult::ClearanceValue](#).

Example

See the [IClearanceVerificationMgr](#) examples.

Remarks

This property is valid only if [IClearanceResult::ClearanceType](#) is [swClearanceType_e.swClearanceType_Distance](#).

See Also

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ComponentsOrFaces Property (IClearanceResult)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceResult Interface](#) : ComponentsOrFaces Property (IClearanceResult)

Gets the assembly components, faces, or both involved in this clearance result.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ComponentsOrFaces As System.Object

Visual Basic (Usage)



```
Dim instance As IClearanceResult  
Dim value As System.Object  
  
value = instance.ComponentsOrFaces
```

C#

```
System.Object ComponentsOrFaces {get;}
```

C++/CLI

```
property System.Object^ ComponentsOrFaces {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of assembly [components](#), [faces](#), or both

Visual Basic for Applications (VBA) Syntax

See [ClearanceResult::Components](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceResult Interface](#)
[IClearanceResult Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

IClearanceVerificationMgr (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IClearanceVerificationMgr Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClearanceVerificationMgr Interface

Allows you to check the clearance between selected components and/or faces in assemblies.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IClearanceVerificationMgr
```

Visual Basic (Usage)

```
Dim instance As IClearanceVerificationMgr
```

C#

```
public interface IClearanceVerificationMgr
```

C++/CLI

```
public interface class IClearanceVerificationMgr
```

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr](#).

Example

'VBA

'=====

'Preconditions:

'1. Open *Public_documents\SOLIDWORKS\SOLIDWORKS 2024\samples\tutorial\advdrawings\98food processor.sldasm*.

'2. In the FeatureManager design tree, multi-select gear-caddy and shaft gear components.

'3. Open an Immediate window.

'Postconditions: Inspect the Immediate window.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim selMgr As SldWorks.SelectionMgr
Dim asmDoc As SldWorks.AssemblyDoc
Dim CVMgr As SldWorks.ClearanceVerificationMgr
Option Explicit
```

```
Sub main()
```

```
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    Set asmDoc = swModel
    Set CVMgr = asmDoc.ClearanceVerificationManager
    Set selMgr = swModel.SelectionManager
```

```
    Dim comp() As SldWorks.Component2
    Dim faces() As SldWorks.Face2
```

```
    ReDim comp(0)
    ReDim faces(0)
```

```
    Dim i As Long
    For i = 0 To selMgr.GetSelectedObjectCount() - 1
        If selMgr.GetSelectedObjectType3(i + 1, 0) = swSelectType_e.swSelCOMPONENTS Then
```

```

    If (Not comp(UBound(comp)) Is Nothing) Then
        ReDim Preserve comp(UBound(comp) + 1)
    End If
    Set comp(UBound(comp)) = selMgr.GetSelectedObject6(i + 1, -1)
Else
    If selMgr.GetSelectedObjectType3(i + 1, 0) = swSelectType_e.swSelfFACES Then
        If (Not faces(UBound(faces)) Is Nothing) Then
            ReDim Preserve faces(UBound(faces) + 1)
        End If
        Set faces(UBound(faces)) = selMgr.GetSelectedObject6(i + 1, -1)
    Else
        End
    End If
End If
Next

Dim facesVar As Variant
Dim compsVar As Variant
If (Not comp(0) Is Nothing) Then
    compsVar = comp
End If

If (Not faces(0) Is Nothing) Then
    facesVar = faces
End If

Dim err As Long
Debug.Print "Successfully set components or faces to check: " & CVMgr.SetComponentsOrFacesToCheck(compsVar, facesVar, err)

Dim var As Variant
var = CVMgr.GetComponentsOrFacesToCheck()
Debug.Print "Number of entities to check: " & (UBound(var) + 1)

Debug.Print "Successfully set minimum acceptable clearance of 0.05 m: " & CVMgr.SetMinimumAcceptableClearance(0.05)
CVMgr.CheckClearanceBetween = swCheckClearanceBetweenSelectedItems
CVMgr.TreatSubAssembliesAsComponents = False
CVMgr.IgnoreClearanceEqualToSpecifiedValue = True

Dim ClearanceVar As Variant
ClearanceVar = CVMgr.CalculateClearances()

Dim iter As Integer
Dim clearance As ClearanceResult

For iter = 0 To UBound(ClearanceVar)
    Set clearance = ClearanceVar(iter)

    Dim clrObjVar As Variant
    clrObjVar = clearance.ComponentsOrFaces
    Debug.Print "Number of clearance result entities: " & (UBound(clrObjVar) + 1)
    Dim clrObjs(2) As Object
    Set clrObjs(0) = clrObjVar(0)
    Set clrObjs(1) = clrObjVar(1)

    Debug.Print "Clearance type as defined by swClearanceType_e: " & clearance.ClearanceType
    Debug.Print "Clearance value (m): " & clearance.ClearanceValue
Next

End Sub

```

Remarks

For more information see **SOLIDWORKS online Help > Assemblies > Detecting Problems > Clearance Verification**.

Accessors

[IAssemblyDoc::ClearanceVerificationManager](#)

Access Diagram

[ClearanceVerificationMgr](#)

See Also

[IClearanceVerificationMgr Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IClearanceVerificationMgr Interface Members

[See Also](#) [Properties](#) [Methods](#)[SolidWorks.Interop.sldworks Namespace](#) : IClearanceVerificationMgr Interface

The following tables list the members exposed by [IClearanceVerificationMgr](#).

Public Properties

Name	Description
CheckClearanceBetween	Gets or sets the type of clearance check: between selected items or between selected items and the rest of the assembly.
IgnoreClearanceEqualToSpecifiedValue	Gets or sets whether to ignore clearances equal to or greater than IClearanceVerificationMgr::GetMinimumAcceptableClearance .
TreatSubAssembliesAsComponents	Gets or sets whether to treat subassemblies as single components for clearance verification.

[Top](#)

Public Methods

Name	Description
CalculateClearances	Runs a clearance check of selected assembly components and/or faces.
GetComponentsOrFacesToCheck	Gets the components and/or faces for which to check clearance.
GetMinimumAcceptableClearance	Gets the minimum acceptable clearance value.
SetComponentsOrFacesToCheck	Sets the components or faces for which to check clearances.
SetMinimumAcceptableClearance	Sets the minimum acceptable clearance value.

[Top](#)

See Also

[IClearanceVerificationMgr Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IClearanceResult Interface](#)

IClearanceVerificationMgr Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : IClearanceVerificationMgr Interface

For a list of all members of this type, see [IClearanceVerificationMgr members](#).

Public Methods

Name	Description
CalculateClearances	Runs a clearance check of selected assembly components and/or faces.
GetComponentsOrFacesToCheck	Gets the components and/or faces for which to check clearance.
GetMinimumAcceptableClearance	Gets the minimum acceptable clearance value.
SetComponentsOrFacesToCheck	Sets the components or faces for which to check clearances.
SetMinimumAcceptableClearance	Sets the minimum acceptable clearance value.

[Top](#)

See Also

[IClearanceVerificationMgr Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IClearanceResult Interface](#)

IClearanceVerificationMgr Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClearanceVerificationMgr Interface

For a list of all members of this type, see [IClearanceVerificationMgr members](#).

Public Properties

Name	Description
 CheckClearanceBetween	Gets or sets the type of clearance check: between selected items or between selected items and the rest of the assembly.
 IgnoreClearanceEqualToSpecifiedValue	Gets or sets whether to ignore clearances equal to or greater than IClearanceVerificationMgr::GetMinimumAcceptableClearance .
 TreatSubAssembliesAsComponents	Gets or sets whether to treat subassemblies as single components for clearance verification.

[Top](#)

See Also

[IClearanceVerificationMgr Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IClearanceResult Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CalculateClearances Method (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : CalculateClearances Method (IClearanceVerificationMgr)

Runs a clearance check of selected assembly components and/or faces.

.NET Syntax

Visual Basic (Declaration)

```
Function CalculateClearances() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Object  
  
value = instance.CalculateClearances()
```

C#

```
System.object CalculateClearances()
```

C++/CLI

```
System.Object^ CalculateClearances();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IClearanceResults](#)

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::CalculateClearances](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

CheckClearanceBetween Property (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : CheckClearanceBetween Property (IClearanceVerificationMgr)

Gets or sets the type of clearance check: between selected items or between selected items and the rest of the assembly.

.NET Syntax

Visual Basic (Declaration)

Property CheckClearanceBetween As System.Integer

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Integer
```

```
instance.CheckClearanceBetween = value  
value = instance.CheckClearanceBetween
```

C#

```
System.int CheckClearanceBetween {get; set;}
```

C++/CLI

```
property System.int CheckClearanceBetween {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of clearance check as defined by [swCheckClearanceBetween_e](#)

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::CheckClearanceBetween](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : GetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

Gets the components and/or faces for which to check clearance.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentsOrFacesToCheck() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Object  
  
value = instance.GetComponentsOrFacesToCheck()
```

C#

```
System.Object GetComponentsOrFacesToCheck()
```

C++/CLI

```
System.Object^ GetComponentsOrFacesToCheck();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [components](#) and/or [faces](#)

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::GetComponentsOrFacesToCheck](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : GetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

Gets the minimum acceptable clearance value.

.NET Syntax

Visual Basic (Declaration)

```
Function GetMinimumAcceptableClearance() As System.Double
```

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Double  
  
value = instance.GetMinimumAcceptableClearance()
```

C#

```
System.double GetMinimumAcceptableClearance()
```

C++/CLI

```
System.double GetMinimumAcceptableClearance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Minimum acceptable clearance value

Visual Basic for Applications (VBA) Syntax

See [IClearanceVerificationMgr::GetMinimumAcceptableClearance](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)
[IClearanceVerificationMgr::IgnoreClearanceEqualToSpecifiedValue Property \(\)](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreClearanceEqualToSpecifiedValue Property (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : IgnoreClearanceEqualToSpecifiedValue Property (IClearanceVerificationMgr)

Gets or sets whether to ignore clearances equal to or greater than [IClearanceVerificationMgr::GetMinimumAcceptableClearance](#).

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreClearanceEqualToSpecifiedValue As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Boolean
```

```
instance.IgnoreClearanceEqualToSpecifiedValue = value  
value = instance.IgnoreClearanceEqualToSpecifiedValue
```

C#

```
System.bool IgnoreClearanceEqualToSpecifiedValue {get; set;}
```

C++/CLI

```
property System.bool IgnoreClearanceEqualToSpecifiedValue {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to ignore clearances equal to or greater than the specified value, false to not

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::IgnoreClearanceEqualToSpecifiedValue](#).

Example

See the [IClearanceVerificationMgr](#) examples.

Remarks

If this property is true, use [IClearanceVerificationMgr::SetMinimumAcceptableClearance](#) to specify the minimum clearance value, at or above which clearances are ignored.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : SetComponentsOrFacesToCheck Method (IClearanceVerificationMgr)

Sets the components or faces for which to check clearances.

.NET Syntax

Visual Basic (Declaration)

```
Function SetComponentsOrFacesToCheck( _  
    ByVal Components As System.Object, _  
    ByVal Faces As System.Object, _  
    ByRef Errors As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim Components As System.Object  
Dim Faces As System.Object  
Dim Errors As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetComponentsOrFacesToCheck(Components, Faces, Errors)
```

C#

```
System.bool SetComponentsOrFacesToCheck(  
    System.object Components,  
    System.object Faces,  
    out System.int Errors  
)
```

C++/CLI

```
System.bool SetComponentsOrFacesToCheck(  
& System.Object^ Components,  
& System.Object^ Faces,  
& [Out] System.int Errors  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Components
Array of [components](#)
Faces
Array of [faces](#)
Errors
Error code as defined by [swClearanceVerificationSetEntityErrors_e](#)

Return Value

True if components and/or faces successfully set, false if not

 Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::SetComponentsOrFacesToCheck](#).

 Example

See the [IClearanceVerificationMgr](#) examples.

 See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

 Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : SetMinimumAcceptableClearance Method (IClearanceVerificationMgr)

Sets the minimum acceptable clearance value.

 .NET Syntax

Visual Basic (Declaration)

```
Function SetMinimumAcceptableClearance( _  
    ByVal Value As System.Double _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IClearanceVerificationMgr  
Dim Value As System.Double  
Dim value As System.Boolean  
  
value = instance.SetMinimumAcceptableClearance(Value)
```

C#

```
System.bool SetMinimumAcceptableClearance(  
    System.double Value  
)
```

C++/CLI

```
System.bool SetMinimumAcceptableClearance(  
    & System.double Value  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Value
Minimum acceptable clearance value

Return Value

True if minimum acceptable clearance value successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::SetMinimumAcceptableClearance](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)
[IClearanceVerificationMgr.IgnoreClearanceEqualToSpecifiedValue Property\(\)](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

TreatSubAssembliesAsComponents Property (IClearanceVerificationMgr)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClearanceVerificationMgr Interface](#) : TreatSubAssembliesAsComponents Property (IClearanceVerificationMgr)

Gets or sets whether to treat subassemblies as single components for clearance verification.

.NET Syntax

Visual Basic (Declaration)

Property TreatSubAssembliesAsComponents As System.Boolean

Visual Basic (Usage)



```
Dim instance As IClearanceVerificationMgr  
Dim value As System.Boolean  
  
instance.TreatSubAssembliesAsComponents = value  
  
value = instance.TreatSubAssembliesAsComponents
```

C#

```
System.bool TreatSubAssembliesAsComponents {get; set;}
```

C++/CLI

```
property System.bool TreatSubAssembliesAsComponents {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to not check clearances between components within subassemblies, false to check them

Visual Basic for Applications (VBA) Syntax

See [ClearanceVerificationMgr::TreatSubAssembliesAsComponents](#).

Example

See the [IClearanceVerificationMgr](#) examples.

See Also

[IClearanceVerificationMgr Interface](#)
[IClearanceVerificationMgr Members](#)

Availability

SOLIDWORKS 2024 SP01, Revision Number 32.1

IClosedCornerFeatureData (Type)

IClosedCornerFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClosedCornerFeatureData Interface

Allows access to a closed corner feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IClosedCornerFeatureData
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData
```

C#

```
public interface IClosedCornerFeatureData
```

C++/CLI

```
public interface class IClosedCornerFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[ClosedCornerFeatureData](#)

See Also

[IClosedCornerFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalClosedCorner Method](#)

IClosedCornerFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClosedCornerFeatureData Interface

The following tables list the members exposed by [IClosedCornerFeatureData](#).

Public Properties

Name	Description
 CornerType	Gets or sets the closed corner type.
 Faces	Gets or sets the faces for this closed corner feature.

	GapDistance	Gets or sets the distance for the gap in a closed corner in a sheet metal part.
	OpenBendRegion	Gets or sets whether this closed corner has an open bend region.
	OverlapUnderlapRatio	Gets or sets the overlap/underlap ratio for this closed corner.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this closed corner feature.
 IAccessSelections	Obsolete. Superseded by IClosedCornerFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections that describe this closed corner feature.
 IGetFaces	Gets the faces for this closed corner feature.
 IGetFacesCount	Gets the number of faces in this closed corner feature.
 ISetFaces	Sets the faces for this closed corner feature.
 ReleaseSelectionAccess	Releases access to selections that describe this closed corner feature.

[Top](#)

See Also

[IClosedCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalClosedCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IClosedCornerFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClosedCornerFeatureData Interface

For a list of all members of this type, see [IClosedCornerFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this closed corner feature.
 IAccessSelections	Obsolete. Superseded by IClosedCornerFeatureData.IAccessSelections2
 IAccessSelections2	Gains access to the selections that describe this closed corner feature.
 IGetFaces	Gets the faces for this closed corner feature.
 IGetFacesCount	Gets the number of faces in this closed corner feature.
 ISetFaces	Sets the faces for this closed corner feature.
 ReleaseSelectionAccess	Releases access to selections that describe this closed corner feature.

[Top](#)

See Also

[IClosedCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalClosedCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IClosedCornerFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IClosedCornerFeatureData Interface

For a list of all members of this type, see [IClosedCornerFeatureData members](#).

Public Properties

Name	Description
 CornerType	Gets or sets the closed corner type.
 Faces	Gets or sets the faces for this closed corner feature.
 GapDistance	Gets or sets the distance for the gap in a closed corner in a sheet metal part.
 OpenBendRegion	Gets or sets whether this closed corner has an open bend region.
 OverlapUnderlapRatio	Gets or sets the overlap/underlap ratio for this closed corner.

[Top](#)

See Also

[IClosedCornerFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDoc2::InsertSheetMetalClosedCorner Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : AccessSelections Method (IClosedCornerFeatureData)

Gains access to the selections that define this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IClosedCornerFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document

Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::AccessSelections](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

Remarks

Remark

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IClosedCornerFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[IAccessSelections2 Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerType Property (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : CornerType Property (IClosedCornerFeatureData)

Gets or sets the closed corner type.

.NET Syntax

Visual Basic (Declaration)

Property CornerType As System.Integer

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Integer  
  
instance.CornerType = value  
  
value = instance.CornerType
```

C#

```
System.int CornerType {get; set;}
```

C++/CLI

```
property System.int CornerType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner type as defined in [swClosedCornerTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::CornerType](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

Faces Property (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : Faces Property (IClosedCornerFeatureData)

Gets or sets the faces for this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

Property Faces As System.Object

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Object
```

```
instance.Faces = value
```

```
value = instance.Faces
```

C#

```
System.object Faces {get; set;}
```

C++/CLI

```
property System.Object^ Faces {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [faces](#) that describe the closed corner

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::Faces](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[IClosedCornerFeatureData::IGetFaces Method](#)
[IClosedCornerFeatureData::IGetFacesCount Method](#)
[IClosedCornerFeatureData::ISetFaces Method](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GapDistance Property (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : GapDistance Property (IClosedCornerFeatureData)

Gets or sets the distance for the gap in a closed corner in a sheet metal part.

.NET Syntax

Visual Basic (Declaration)

Property GapDistance As System.Double

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Double
```

```
instance.GapDistance = value
```

```
value = instance.GapDistance
```

C#

```
System.double GapDistance {get; set;}
```

C++/CLI

```
property System.double GapDistance {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap distance

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::GapDistance](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : IAccessSelections Method (IClosedCornerFeatureData)

Obsolete. Superseded by [IClosedCornerFeatureData::IAccessSelections2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc, _  
    ByVal Component As Component _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim TopDoc As ModelDoc  
Dim Component As Component  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc TopDoc,  
    Component Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc^ TopDoc,  
& Component^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Component

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::IAccessSelections](#).

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections2 Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : IAccessSelections2 Method (IClosedCornerFeatureData)

Gains access to the selections that describe this closed corner feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IAccessSelections2( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections2(TopDoc, Component)
```

C#

```
System.bool IAccessSelections2(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections2(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::IAccessSelections2](#).

Remarks

Remark

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [IClosedCornerFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[AccessSelections Method](#)

Availability

IGetFaces Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : IGetFaces Method (IClosedCornerFeatureData)

Gets the faces for this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Object  
  
value = instance.IGetFaces()
```

C#

```
System.object IGetFaces()
```

C++/CLI

```
System.Object^ IGetFaces();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of [faces](#) that describe the closed corner
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[IClosedCornerFeatureData.IGetFacesCount Method](#)
[IClosedCornerFeatureData.ISetFaces Method](#)
[IClosedCornerFeatureData.Faces Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

IGetFacesCount Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : IGetFacesCount Method (IClosedCornerFeatureData)

Gets the number of faces in this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFacesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Integer  
  
value = instance.IGetFacesCount()
```

C#

```
System.int IGetFacesCount()
```

C++/CLI

```
System.int IGetFacesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of faces in the closed corner

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::IGetFacesCount](#).

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[IClosedCornerFeatureData::IGetFaces Method](#)
[IClosedCornerFeatureData::ISetFaces Method](#)
[IClosedCornerFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFaces Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : ISetFaces Method (IClosedCornerFeatureData)

Sets the faces for this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal FaceCount As System.Integer, _  
    ByRef FaceArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim FaceCount As System.Integer  
Dim FaceArray As System.Object  
  
instance.ISetFaces(FaceCount, FaceArray)
```

C#

```
void ISetFaces(  
    System.int FaceCount,  
    ref System.object FaceArray  
)
```

C++/CLI

```
void ISetFaces(
& System.int FaceCount,
& System.Object^% FaceArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceCount

Number of faces used to describe the closed corner

FaceArray

- in-process, unmanaged C++: Pointer to an array of [faces](#) used to describe the closed corner of size FaceCount
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this method.

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)
[IClosedCornerFeatureData::IGetFaces Method](#)
[IClosedCornerFeatureData::IGetFacesCount Method](#)
[IClosedCornerFeatureData::Faces Property](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OpenBendRegion Property (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : OpenBendRegion Property (IClosedCornerFeatureData)

Gets or sets whether this closed corner has an open bend region.

.NET Syntax

Visual Basic (Declaration)

```
Property OpenBendRegion As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData
Dim value As System.Boolean
```

```
instance.OpenBendRegion = value
```

```
value = instance.OpenBendRegion
```

C#

```
System.bool OpenBendRegion {get; set;}
```

C++/CLI

```
property System.bool OpenBendRegion {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an open bend region, false if not

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::OpenBendRegion](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverlapUnderlapRatio Property (IClosedCornerFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : OverlapUnderlapRatio Property (IClosedCornerFeatureData)

Gets or sets the overlap/underlap ratio for this closed corner.

.NET Syntax

Visual Basic (Declaration)

Property OverlapUnderlapRatio As System.Double

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
Dim value As System.Double
```

```
instance.OverlapUnderlapRatio = value
```

```
value = instance.OverlapUnderlapRatio
```

C#

```
System.double OverlapUnderlapRatio {get; set;}
```

C++/CLI

```
property System.double OverlapUnderlapRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Ratio

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::OverlapUnderlapRatio](#).

Example

[Create and Modify Closed Corner Feature \(C#\)](#)
[Create and Modify Closed Corner Feature \(VB.NET\)](#)
[Create and Modify Closed Corner Feature \(VBA\)](#)

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

Availability

SOLIDWORKS 2008 FCS, Revision Number 16.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IClosedCornerFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IClosedCornerFeatureData Interface](#) : ReleaseSelectionAccess Method (IClosedCornerFeatureData)

Releases access to selections that describe this closed corner feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IClosedCornerFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ClosedCornerFeatureData::ReleaseSelectionAccess](#).

Remarks

[IClosedCornerFeatureData::AccessSelections](#) and [IClosedCornerFeatureData::!AccessSelections2](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IClosedCornerFeatureData Interface](#)
[IClosedCornerFeatureData Members](#)

Availability

SOLIDWORKS 2001 SP2, Revision Number 9.2

ICoEdge (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICoEdge Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoEdge Interface

Allows access to the underlying edge and loop as well as various coedge data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICoEdge
```

Visual Basic (Usage)



```
Dim instance As ICoEdge
```

C#

```
public interface ICoEdge
```

C++/CLI

```
public interface class ICoEdge
```

Visual Basic for Applications (VBA) Syntax

See [CoEdge](#).

Example

[Select Edges of All Holes on Face \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)

Accessors

[ICoEdge::GetNext](#) and [ICoEdge::!GetNext](#)
[ICoEdge::GetPartner](#) and [ICoEdge::!GetPartner](#)
[IDiagnoseResult::GetCoEdgesAtGap](#) and [IDiagnoseResult::!GetCoEdgesAtGap](#)
[IEnumCoEdges::Next](#)
[ILoop2::GetCoEdges](#) and [ILoop2::!GetCoEdges](#)
[ILoop2::GetFirstCoEdge](#) and [ILoop2::!GetFirstCoEdge](#)
[ISMGussetFeatureData::ReferenceLine](#)

Access Diagram

[CoEdge](#)

See Also

[ICoEdge Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumCoEdgeClass Interface](#)
[IEdge Interface](#)
[ILoop2 Interface](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICoEdge Interface Methods

[See Also](#)



For a list of all members of this type, see [ICoEdge members](#).

Public Methods

Name	Description
 Evaluate	Obsolete. Superseded by ICoEdge.Evaluate2
 Evaluate2	Gets the (X,Y,Z) location and the tangency vector on the coedge at the specified position.
 GetCurve	Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.
 GetCurveParams	Gets the curve parameters.
 GetEdge	Gets the edge that corresponds to this coedge.
 GetLoop	Gets the loop containing this coedge.
 GetNext	Gets the next coedge from the current coedge.
 GetPartner	Gets the partner for this coedge.
 GetSense	Gets the sense of the coedge.
 IEvaluate	Obsolete. Superseded by ICoEdge.IEvaluate2
 IEvaluate2	Gets the (x,y, z) location and the tangency vector on the coedge at the specified position.
 IGetCurve	Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.
 IGetCurveParams	Gets the curve parameters.
 IGetEdge	Gets the edge that corresponds to this coedge.
 IGetLoop	Obsolete. Superseded by ICoEdge.IGetLoop2
 IGetLoop2	Gets the loop containing this coedge.
 IGetNext	Gets the next coedge from the current coedge.
 IGetPartner	Gets the partner for this coedge.

[Top](#)

See Also

- [ICoEdge Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [IEnumCoEdgeClass Interface](#)
- [IEdge Interface](#)
- [ILoop2 Interface](#)

ICoEdge Interface Members

[See Also](#) [Methods](#)

The following tables list the members exposed by [ICoEdge](#).

Public Methods

Name	Description
 Evaluate	Obsolete. Superseded by ICoEdge.Evaluate2
 Evaluate2	Gets the (X,Y,Z) location and the tangency vector on the coedge at the specified position.
 GetCurve	Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.
 GetCurveParams	Gets the curve parameters.
 GetEdge	Gets the edge that corresponds to this coedge.
 GetLoop	Gets the loop containing this coedge.
 GetNext	Gets the next coedge from the current coedge.
 GetPartner	Gets the partner for this coedge.

	GetSense	Gets the sense of the coedge.
	IEvaluate	Obsolete. Superseded by ICoEdge::IEvaluate2 .
	IEvaluate2	Gets the (x,y, z) location and the tangency vector on the coedge at the specified position.
	IGetCurve	Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.
	IGetCurveParams	Gets the curve parameters.
	IGetEdge	Gets the edge that corresponds to this coedge.
	IGetLoop	Obsolete. Superseded by ICoEdge::IGetLoop2 .
	IGetLoop2	Gets the loop containing this coedge.
	IGetNext	Gets the next coedge from the current coedge.
	IGetPartner	Gets the partner for this coedge.

[Top](#)

See Also

[ICoEdge Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IEnumCoEdgeClass Interface](#)
[IEdge Interface](#)
[ILoop2 Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Evaluate Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : Evaluate Method (ICoEdge)

Obsolete. Superseded by [ICoEdge::Evaluate2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Evaluate( _
    ByVal Param As System.Double _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge
Dim Param As System.Double
Dim value As System.Object

value = instance.Evaluate(Param)
```

C#

```
System.object Evaluate(
    System.double Param
)
```

C++/CLI

```
System.Object^ Evaluate(
    & System.double Param
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Param

Curve parameter desired (U value desired for evaluation)

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::Evaluate](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

The tangency vector is defined to be in the direction of the coedge.

The format of the return value is an array of 6 doubles:

- retval[0] x location on the curve
- retval[1] y location on the curve
- retval[2] z location on the curve
- retval[3] x vector describing the tangency at the parameter location on the coedge
- retval[4] y vector describing the tangency at the parameter location on the coedge
- retval[5] z vector describing the tangency at the parameter location on the coedge

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IEvaluate Method](#)
[ICoEdge::GetCurveParams Method](#)
[ICoEdge::IGetCurveParams Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Evaluate2 Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : Evaluate2 Method (ICoEdge)

Gets the (X,Y,Z) location and the tangency vector on the coedge at the specified position.

.NET Syntax

Visual Basic (Declaration)

```
Function Evaluate2( _  
    ByVal Param As System.Double, _  
    ByVal NumberOfDerivatives As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim Param As System.Double  
Dim NumberOfDerivatives As System.Integer  
Dim value As System.Object  
  
value = instance.Evaluate2(Param, NumberOfDerivatives)
```

C#

```
System.object Evaluate2(  
    System.double Param,  
    System.int NumberOfDerivatives  
)
```

C++/CLI

```
System.Object^ Evaluate2(
& System.double Param,
& System.int NumberOfDerivatives
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Param

Curve parameter desired (U value desired for evaluation)

NumberOfDerivatives

Number of derivatives

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::Evaluate2](#).

Remarks

The tangency vector is defined to be in the direction of the coedge.

The format of the return value is an array of (NumberOfDerivatives + 1) * 3 doubles:

[evaluated point], [evaluated derivative 1],...[evaluated derivative NumberOfDerivatives]

In pseudo mathematical notation, this can be written as:

$P(t) \quad P(t)/dt \quad P(t)/dtdt \quad \dots\dots\dots$

In terms of the number of derivatives that can be returned for a curve type, you could write:

Curve type	Maximum number of derivatives
Line/circle/ellipse	2
Intersection curve	2
Constant parameter line	Determined by underlying surface
SP-curve	2
B-curve	Any number

where the curve type is from [ICurve::Identity](#).

For a curve of type swCurveTypes_e::TRIMMED_TYPE, the number of derivatives is determined by the base curve as obtained from [ICurve::GetBaseCurve](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IEvaluate2 Method](#)
[ICoEdge::GetCurveParams Method](#)
[ICoEdge::IGetCurveParams Method](#)

Availability

SOLIDWORKS 2007 SP5, Revision Number 15.5

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurve Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetCurve Method (ICoEdge)

Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurve() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge
Dim value As System.Object

value = instance.GetCurve()
```

C#

```
System.object GetCurve()
```

C++/CLI

```
System.Object^ GetCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Curve that is attached to this coedge (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetCurve](#).

Remarks

This method may return Nothing if no geometry is attached to the coedge. The edge may still be accurate, and you can obtain the geometry from the edge using:

- [ICoEdge::GetEdge](#)
- [IEdge::GetCurve](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetCurve Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurveParams Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetCurveParams Method (ICoEdge)

Gets the curve parameters.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurveParams() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge
Dim value As System.Object
```

```
value = instance.GetCurveParams()
```

C#

```
System.Object GetCurveParams()
```

C++/CLI

```
System.Object^ GetCurveParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetCurveParams](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

Remarks

The return value format is an array of 10 doubles:

- retval[0] X startpoint
- retval[1] Y startpoint
- retval[2] Z startpoint
- retval[3] X endpoint
- retval[4] Y endpoint
- retval[5] Z endpoint
- retval[6] startParam
- retval[7] endParam
- retval[8] sense (Not used)
- retval[9] curve type (Not used)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetCurveParams Method](#)
[IEdge::GetCurveParams2 Method](#)
[IEdge::IGetCurveParams2 Method](#)
[ICurve Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdge Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetEdge Method (ICoEdge)

Gets the edge that corresponds to this coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdge() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As System.Object  
  
value = instance.GetEdge()
```

C#

```
System.Object GetEdge()
```

C++/CLI

```
System.Object^ GetEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Edge that corresponds to this coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetEdge](#).

Example

[Select Tangent Edges via Iteration \(VBA\)](#)
[Get and Fill Gaps in Body \(C#\)](#)
[Get and Fill Gaps in Body \(VB.NET\)](#)
[Get and Fill Gaps in Body \(VBA\)](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetEdge Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLoop Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetLoop Method (ICoEdge)

Gets the loop containing this coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetLoop() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As System.Object  
  
value = instance.GetLoop()
```

C#

```
System.Object GetLoop()
```

C++/CLI

```
System.Object^ GetLoop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Loop containing this coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetLoop](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Loop of Edges \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetLoop2 Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetNext Method (ICoEdge)

Gets the next coedge from the current coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Coedge from the current coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetNext](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Tangent Edges via Iteration \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)

Remarks

This method is cyclical; it loops back on itself and does not return NULL.

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetNext Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)
[ILoop2::GetCoEdgeCount Method](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::IGetCoEdges Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPartner Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetPartner Method (ICoEdge)

Gets the partner for this coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartner() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As System.Object  
  
value = instance.GetPartner()
```

C#

```
System.object GetPartner()
```

C++/CLI

```
System.Object^ GetPartner();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Partner coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetPartner](#).

Example

[Determine Type of Face \(VBA\)](#)
[Select Tangent Edges via Iteration \(VBA\)](#)
[Select Tangent Faces \(VBA\)](#)
[Select Edges of All Holes on Face \(C#\)](#)
[Select Edges of All Holes on Face \(VB.NET\)](#)
[Select Edges of All Holes on Face \(VBA\)](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetPartner Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSense Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : GetSense Method (ICoEdge)

Gets the sense of the coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSense() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As System.Boolean  
  
value = instance.GetSense()
```

C#

```
System.bool GetSense()
```

C++/CLI

```
System.bool GetSense();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the coedge has the same direction as the underlying edge, false if not

Visual Basic for Applications (VBA) Syntax

See [CoEdge::GetSense](#).

Example

[Select Tangent Edges via Iteration \(VBA\)](#)
[Get Sense for Each Coedge in a Loop \(VBA\)](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IEvaluate Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IEvaluate Method (ICoEdge)

Obsolete. Superseded by [ICoEdge::IEvaluate2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IEvaluate( _  
    ByVal Param As System.Double _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim Param As System.Double  
Dim value As System.Double  
  
value = instance.IEvaluate(Param)
```

C#

```
System.double IEvaluate(  
    System.double Param
```

)

C++/CLI

```
System.double IEvaluate(  
& System.double Param  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Param

Curve parameter desired (U value desired for evaluation)

Return Value

Pointer to an array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IEvaluate](#).

Remarks

The tangency vector is defined to be in the direction of the coedge.

The format of the return value is an array of 6 doubles:

- retval[0] x location on the curve
- retval[1] y location on the curve
- retval[2] z location on the curve
- retval[3] x vector describing the tangency at the parameter location on the coedge
- retval[4] y vector describing the tangency at the parameter location on the coedge
- retval[5] z vector describing the tangency at the parameter location on the coedge

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::Evaluate Method](#)
[ICoEdge::GetCurveParams Method](#)
[ICoEdge::IGetCurveParams Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IEvaluate2 Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IEvaluate2 Method (ICoEdge)

Gets the (x,y, z) location and the tangency vector on the coedge at the specified position.

.NET Syntax

Visual Basic (Declaration)

```
Function IEvaluate2( _  
    ByVal Param As System.Double, _  
    ByVal NumberOfDerivatives As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim Param As System.Double  
Dim NumberOfDerivatives As System.Integer  
Dim value As System.Double  
  
value = instance.IEvaluate2(Param, NumberOfDerivatives)
```

C#

```
System.double IEvaluate2(  
    System.double Param,  
    System.int NumberOfDerivatives  
)
```

C++/CLI

```
System.double IEvaluate2(  
& System.double Param,  
& System.int NumberOfDerivatives  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Param

Curve parameter desired (U value desired for evaluation)

NumberOfDerivatives

Number of derivatives

Return Value

Array of doubles (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IEvaluate2](#).

Remarks

The tangency vector is defined to be in the direction of the coedge.

The format of the return value is an array of (NumberOfDerivatives + 1) * 3 doubles:

[*evaluated point*], [*evaluated derivative 1*],...[*evaluated derivative NumberOfDerivatives*]

In pseudo mathematical notation, this can be written as:

P(t) P(t)/dt P(t)/dtdt

In terms of the number of derivatives that can be returned for a curve type, you could write:

Curve type	Maximum number of derivatives
Line/circle/ellipse	2
Intersection curve	2
Constant parameter line	Determined by underlying surface
SP-curve	2
B-curve	Any number

where the curve type is from [ICurve::Identity](#).

For a curve of type swCurveTypes_e::TRIMMED_TYPE, the number of derivatives is determined by the base curve as obtained from [ICurve::GetBaseCurve](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::Evaluate2 Method](#)
[ICoEdge::GetCurveParams Method](#)
[ICoEdge::IGetCurveParams Method](#)

Availability

IGetCurve Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetCurve Method (ICoEdge)

Gets the underlying curve of this coedge if the coedge is a result of imprecisely sewing two surfaces together.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetCurve() As Curve
```

Visual Basic (Usage)



```
Dim instance As ICoEdge
Dim value As Curve

value = instance.IGetCurve()
```

C#

```
Curve IGetCurve()
```

C++/CLI

```
Curve^ IGetCurve();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the curve that is attached to this coedge (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetCurve](#).

Remarks

This method may return NULL if no geometry is attached to the coedge. The edge may still be accurate, and you can obtain the geometry from the edge using:

- [ICoEdge::IGetEdge](#)
- [IEdge::IGetCurve](#)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::GetCurve Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetCurveParams Method (ICoEdge)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetCurveParams Method (ICoEdge)

Gets the curve parameters.

.NET Syntax

Visual Basic (Declaration)

Function IGetCurveParams() As System.Double

Visual Basic (Usage)



```
Dim instance As ICoEdge
Dim value As System.Double
```

```
value = instance.IGetCurveParams()
```

C#

```
System.double IGetCurveParams()
```

C++/CLI

```
System.double IGetCurveParams();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of doubles (see **Remarks**)
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Example

[Get Edge Data By Name \(C++\)](#)

Remarks

The return value format is an array of 10 doubles:

- retval[0] X startpoint
- retval[1] Y startpoint
- retval[2] Z startpoint
- retval[3] X endpoint
- retval[4] Y endpoint
- retval[5] Z endpoint
- retval[6] startParam
- retval[7] endParam
- retval[8] sense (Not used)
- retval[9] curve type (Not used)

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICurve Interface](#)
[ICoEdge::GetCurveParams Method](#)
[IEdge::GetCurveParams2 Method](#)
[ICoEdge::IGetCurveParams Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdge Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetEdge Method (ICoEdge)

Gets the edge that corresponds to this coedge.

.NET Syntax

Visual Basic (Declaration)

Function IGetEdge() As Edge

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As Edge  
  
value = instance.IGetEdge()
```

C#

```
Edge IGetEdge()
```

C++/CLI

```
Edge^ IGetEdge();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [edge](#) that corresponds to this coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetEdge](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::GetEdge Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLoop Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetLoop Method (ICoEdge)

Obsolete. Superseded by [ICoEdge::IGetLoop2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLoop() As Loop
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As Loop  
  
value = instance.IGetLoop()
```

C#

```
Loop IGetLoop()
```

C++/CLI

```
Loop^ IGetLoop();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetLoop](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetLoop2 Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetLoop2 Method (ICoEdge)

Gets the loop containing this coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLoop2() As Loop2
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As Loop2  
  
value = instance.IGetLoop2()
```

C#

```
Loop2 IGetLoop2()
```

C++/CLI

```
Loop2^ IGetLoop2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [loop](#).

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetLoop2](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::GetLoop Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetNext Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetNext Method (ICoEdge)

Gets the next coedge from the current coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As CoEdge
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As CoEdge
```

```
value = instance.IGetNext()
```

C#

```
CoEdge IGetNext()
```

C++/CLI

```
CoEdge^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [coedge](#) from the current coedge

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetNext](#).

Remarks

This method is cyclical; it loops back on itself and does not return NULL.

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::IGetNext Method](#)
[ILoop2::GetFirstCoEdge Method](#)
[ILoop2::IGetFirstCoEdge Method](#)
[ILoop2::GetCoEdgeCount Method](#)
[ILoop2::GetCoEdges Method](#)
[ILoop2::IGetCoEdges Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetPartner Method (ICoEdge)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoEdge Interface](#) : IGetPartner Method (ICoEdge)

Gets the partner for this coedge.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPartner() As CoEdge
```

Visual Basic (Usage)



```
Dim instance As ICoEdge  
Dim value As CoEdge
```

```
value = instance.IGetPartner()
```

C#

```
CoEdge IGetPartner()
```

C++/CLI

```
CoEdge^ IGetPartner();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the partner [coedge](#)

Visual Basic for Applications (VBA) Syntax

See [CoEdge::IGetPartner](#).

See Also

[ICoEdge Interface](#)
[ICoEdge Members](#)
[ICoEdge::GetPartner Method](#)