

SOLIDWORKS API (.NET VBA C#) — Reference (51/337): IComponent2 (part 4 of 4)

SOLIDWORKS API Documentation (converted from CHM)

IComponent2 (part 4 of 4) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetReferencedDisplayStates Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetReferencedDisplayStates Method (IComponent2)

Sets the specified display state of this component to be referenced by the specified assembly display state(s).

.NET Syntax

Visual Basic (Declaration)

```
Function SetReferencedDisplayStates( _  
    ByVal ComponentDisplayStateName As System.String, _  
    ByVal Option As System.Integer, _  
    ByVal AssemblyDisplayStateNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim ComponentDisplayStateName As System.String  
Dim Option As System.Integer  
Dim AssemblyDisplayStateNames As System.Object  
Dim value As System.Boolean  
  
value = instance.SetReferencedDisplayStates(ComponentDisplayStateName, Option,  
AssemblyDisplayStateNames)
```

C#

```
System.bool SetReferencedDisplayStates(  
    System.string ComponentDisplayStateName,  
    System.int Option,  
    System.object AssemblyDisplayStateNames  
)
```

C++/CLI

```
System.bool SetReferencedDisplayStates(  
& System.String^ ComponentDisplayStateName,  
& System.int Option,  
& System.Object^ AssemblyDisplayStateNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ComponentDisplayStateName

Component display state name

Option

Display state option as defined in [swDisplayStateOpts_e](#)

AssemblyDisplayStateNames

Array of assembly display state names; valid only if Option is set to swDisplayStateOpts_e.swSpecifyDisplayState

Return Value

True if component display state referenced successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetReferencedDisplayStates](#).

See Also

[IComponent2 Interface](#)

[IComponent2 Members](#)

[IComponent2::GetReferencedDisplayStates Method \(\)](#)

[IComponent2::SetVisibilityInAsmDisplayStates Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSmartComponentData Method (IComponent2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetSmartComponentData Method (IComponent2)

Sets the features, components, and feature references of a Smart Component.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function SetSmartComponentData( _  
    ByVal FeaturesSelected As System.Object, _  
    ByVal ComponentsSelected As System.Object, _  
    ByVal References As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim FeaturesSelected As System.Object  
Dim ComponentsSelected As System.Object  
Dim References As System.Object  
Dim value As System.Boolean  
  
value = instance.SetSmartComponentData(FeaturesSelected, ComponentsSelected, References)
```

C#

```
System.bool SetSmartComponentData(  
    System.object FeaturesSelected,  
    System.object ComponentsSelected,  
    System.object References  
)
```

C++/CLI

```
System.bool SetSmartComponentData(  
& System.Object^ FeaturesSelected,  
& System.Object^ ComponentsSelected,  
& System.Object^ References  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FeaturesSelected

Array of boolean values indicating which features to enable in the Smart Component (see **Remarks**)

ComponentsSelected

Array of boolean values indicating which components to enable in the Smart Component (see **Remarks**)

References

Array of feature reference entities in the target assembly that are used to activate the features specified by FeaturesSelected (see **Remarks**)

Return Value

True if successful, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetSmartComponentData](#).

Example

[Activate Smart Features in an Assembly \(VBA\)](#)

[Activate Smart Features in an Assembly \(VB.NET\)](#)

[Activate Smart Features in an Assembly \(C#\)](#)

Remarks

A Smart Component is defined by its:

- Components
- Features
- Feature references

See the SOLIDWORKS Help for more information about Smart Components.

Use this method to:

- Change which features and components to enable in a Smart Component.
- Activate the Smart Features.

Before calling this method:

1. Open an assembly that contains a Smart Component whose Smart Features have not yet been activated.
2. Find the Smart Component in the assembly using [IComponent2::IsSmartComponent](#).
3. Call [IComponent2::GetSmartComponentData](#) to obtain the current feature and component arrays for the Smart Component.
4. Create two boolean arrays whose elements map one-to-one with the elements in the feature and component arrays.
5. For each element in each boolean array, specify true if the corresponding feature or component is enabled in the Smart Component. Specify false if it is not.
6. Set FeaturesSelected and ComponentsSelected with the corresponding boolean arrays.
7. Create an array of reference entities (e.g., faces, edges, points) selected from the target assembly that map to the feature reference entities that were defined for the Smart Component.
8. Set References to the array of reference entities.

Use [ISmartComponentFeatureData](#) to:

- Insert new features and components into a Smart Component.
- Delete features and components from a Smart Component.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IAssemblyDoc::AddSmartComponent Method](#)
[IAssemblyDoc::CreateSmartComponent Method](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetSuppression Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetSuppression Method (IComponent2)

Obsolete. Superseded by [IComponent2::SetSuppression2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetSuppression( _  
    ByVal State As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim State As System.Integer  
Dim value As System.Integer  
  
value = instance.SetSuppression(State)
```

C#

```
System.int SetSuppression(  
    System.int State  
)
```

C++/CLI

```
System.int SetSuppression(  
&    System.int State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

Visual Basic for Applications (VBA) Syntax

See [Component2::SetSuppression](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetSuppression2 Method (IComponent2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetSuppression2 Method (IComponent2)

Sets the suppression state of this component.

.NET Syntax

Visual Basic (Declaration)

```
Function SetSuppression2(  
    ByVal State As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim State As System.Integer  
Dim value As System.Integer  
  
value = instance.SetSuppression2(State)
```

C#

```
System.int SetSuppression2(  
    System.int State  
)
```

C++/CLI

```
System.int SetSuppression2(  
&    System.int State  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

Suppression state of this component as defined in [swComponentSuppressionState_e](#)

Return Value

Status as defined in [swSuppressionError_e](#)

Visual Basic for Applications (VBA) Syntax

See [Component2::SetSuppression2](#).

Example

[Access Assembly \(C++\)](#)
[Set All Assembly Components Lightweight or Resolved \(VBA\)](#)
[Set Fully Resolved Assembly to Lightweight \(C#\)](#)
[Set Fully Resolved Assembly to Lightweight \(VB.NET\)](#)
[Set Fully Resolved Assembly to Lightweight \(VBA\)](#)

Remarks

SOLIDWORKS does not allow suppressing components while a PropertyManager page is open.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IAssemblyDoc::LightweightAllResolved Method](#)
[IAssemblyDoc::SetComponentSuppression Method](#)
[IComponent2::GetSuppression Method](#)
[IComponent2::IsSuppressed Method](#)
[IComponent2::IsHidden Method](#)
[IAssemblyDoc::CompConfigProperties5 Method \(\)](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTexture Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetTexture Method (IComponent2)

Applies texture to this component in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTexture( _  
    ByVal Config\_name As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim Config_name As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean  
  
value = instance.SetTexture(Config_name, TextureIn)
```

C#

```
System.bool SetTexture(  
    System.string Config\_name,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTexture(  
& System.String^ Config\_name,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Config_name
Name of configuration
TextureIn
Pointer to the [ITexture](#) object

Return Value

True if texture is applied, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetTexture](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::GetTexture Method](#)
[IComponent2::RemoveTexture Method](#)
[IComponent2::SetTextureByDisplayState Method](#)
[IComponent2::RemoveTextureByDisplayState Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTextureByDisplayState Method (IComponent2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetTextureByDisplayState Method (IComponent2)

Sets the texture applied to this component in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTextureByDisplayState( _  
    ByVal DisplayStateName As System.String, _  
    ByVal TextureIn As Texture _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim DisplayStateName As System.String  
Dim TextureIn As Texture  
Dim value As System.Boolean  
  
value = instance.SetTextureByDisplayState(DisplayStateName, TextureIn)
```

C#

```
System.bool SetTextureByDisplayState(  
    System.string DisplayStateName,  
    Texture TextureIn  
)
```

C++/CLI

```
System.bool SetTextureByDisplayState(  
& System.String^ DisplayStateName,  
& Texture^ TextureIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Display state name
TextureIn
[Texture](#)

Return Value

True if texture is applied to the component, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetTextureByDisplayState](#).

Example

[Apply and Remove Texture To and From Component By Display State \(C#\)](#)
[Apply and Remove Texture To and From Component By Display State \(VB.NET\)](#)
[Apply and Remove Texture To and From Component By Display State \(VBA\)](#)

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::RemoveTextureByDisplayState Method](#)
[IComponent2::RemoveTexture Method](#)
[IComponent2::SetTexture Method](#)
[IComponent2::GetTexture Method](#)
[IModelDocExtension::CreateTexture Method](#)

Availability

SOLIDWORKS 2010 SP1, Revision Number 18.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTransformAndSolve Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetTransformAndSolve Method (IComponent2)

Obsolete. Superseded by [IComponent2::SetTransformAndSolve2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetTransformAndSolve( _  
    ByVal XformIn As MathTransform _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim XformIn As MathTransform  
Dim value As System.Boolean  
  
value = instance.SetTransformAndSolve(XformIn)
```

C#

```
System.bool SetTransformAndSolve(  
    MathTransform XformIn  
)
```

C++/CLI

```
System.bool SetTransformAndSolve(  
& MathTransform^ XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Visual Basic for Applications (VBA) Syntax

See [Component2::SetTransformAndSolve](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

SetTransformAndSolve2 Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetTransformAndSolve2 Method (IComponent2)

Obsolete. Superseded by [IComponent2::SetTransformAndSolve3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetTransformAndSolve2( _  
    ByVal XformIn As MathTransform _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim XformIn As MathTransform  
Dim value As System.Boolean
```

```
value = instance.SetTransformAndSolve2(XformIn)
```

C#

```
System.bool SetTransformAndSolve2(  
    MathTransform XformIn  
)
```

C++/CLI

```
System.bool SetTransformAndSolve2(  
& MathTransform^ XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Pointer to the [IMathTransform](#) object to use to set and solve

Return Value

True if the transform was set and solved, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetTransformAndSolve2](#).

Remarks

If making multiple calls to this method, consider using [IDragOperator::Drag](#), which is more efficient because it reuses the solver. However, [DragOperator::Drag](#) does not support clash detection or dynamic clearance.

The transform specified must be in relation to the root component. See [IConfiguration::GetRootComponent](#) or [IConfiguration::IGetRootComponent2](#).

SOLIDWORKS moves the destination component, or any component above it in the assembly tree, so that the destination component's transform is set to the desired one. Transforming an object using this method can cause SOLIDWORKS to transform other mated or constrained objects.

After you have changed a component's transform, you can call [IAssemblyDoc::UpdateBox](#) to avoid clipping in shaded display mode.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::GetTotalTransform Method](#)
[IComponent2::Transform2 Property](#)
[IComponent2::GetSpecificTransform Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetTransformAndSolve3 Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetTransformAndSolve3 Method (IComponent2)

Sets the transform and solves for the mates for this component.

.NET Syntax

Visual Basic (Declaration)

```
Function SetTransformAndSolve3( _  
    ByVal XformIn As MathTransform, _  
    ByVal ThisConfiguration As System.Boolean _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim XformIn As MathTransform  
Dim ThisConfiguration As System.Boolean  
Dim value As System.Boolean  
  
value = instance.SetTransformAndSolve3(XformIn, ThisConfiguration)
```

C#

```
System.bool SetTransformAndSolve3(  
    MathTransform XformIn,  
    System.bool ThisConfiguration  
)
```

C++/CLI

```
System.bool SetTransformAndSolve3(  
& MathTransform^ XformIn,  
& System.bool ThisConfiguration  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Pointer to the [IMathTransform](#) object to use to set and solve

ThisConfiguration

True to transform this configuration, false to transform all configurations

Return Value

True if the transform was set and solved, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetTransformAndSolve3](#).

Remarks

If making multiple calls to this method, consider using [IDragOperator::Drag](#), which is more efficient because it reuses the solver. However, [DragOperator::Drag](#) does not support clash detection or dynamic clearance.

The transform specified must be in relation to the root component. See [IConfiguration::GetRootComponent](#) or [IConfiguration::IGetRootComponent2](#).

SOLIDWORKS moves the destination component, or any component above it in the assembly tree, so that the destination component's transform is set to the desired one. Transforming an object using this method can cause SOLIDWORKS to transform other mated or constrained objects.

After you have changed a component's transform, you can call [IAssemblyDoc::UpdateBox](#) to avoid clipping in shaded display mode.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::GetTotalTransform Method \(\)](#)
[IComponent2::GetSpecificTransform Method \(\)](#)
[IComponent2::Transform2 Property \(\)](#)

Availability

SOLIDWORKS 2019 FCS, Revision Number 27.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVisibility Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetVisibility Method (IComponent2)

Sets the visibility state for this component.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetVisibility(_  
    ByVal State As System.Integer, _  
    ByVal Config\_opt As System.Integer, _  
    ByVal Config\_names As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim State As System.Integer  
Dim Config_opt As System.Integer  
Dim Config_names As System.Object  
  
instance.SetVisibility(State, Config_opt, Config_names)
```

C#

```
void SetVisibility(  
    System.int State,  
    System.int Config\_opt,  
    System.object Config\_names  
)
```

C++/CLI

```
void SetVisibility(  
& System.int State,  
& System.int Config\_opt,  
& System.Object^ Config\_names  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

State

Visibility state as defined in [swComponentVisibilityState_e](#)

Config_opt

Configuration option as defined in [swInConfigurationOpts_e](#)

Config_names

Array of configuration names; valid only if Config_opt is set to swInConfigurationOpts_e.swSpecifyConfiguration

Visual Basic for Applications (VBA) Syntax

See [Component2::SetVisibility](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::Visible Property](#)
[IComponent2::!SetVisibility Method](#)
[IComponent2::!GetVisibility Method](#)
[IComponent2::GetVisibility Method](#)
[IComponent2::IsHidden Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetVisibilityInAsmDisplayStates Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetVisibilityInAsmDisplayStates Method (IComponent2)

Sets the visibility of this component in the specified assembly display state(s).

.NET Syntax

Visual Basic (Declaration)

```
Function SetVisibilityInAsmDisplayStates( _  
    ByVal HideComponent As System.Integer, _  
    ByVal Option As System.Integer, _  
    ByVal AssemblyDisplayStateNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim HideComponent As System.Integer  
Dim Option As System.Integer  
Dim AssemblyDisplayStateNames As System.Object  
Dim value As System.Boolean  
  
value = instance.SetVisibilityInAsmDisplayStates(HideComponent, Option, AssemblyDisplayStateNames)
```

C#

```
System.bool SetVisibilityInAsmDisplayStates(  
    System.int HideComponent,  
    System.int Option,  
    System.object AssemblyDisplayStateNames  
)
```

C++/CLI

```
System.bool SetVisibilityInAsmDisplayStates(  
& System.int HideComponent,  
& System.int Option,  
& System.Object^ AssemblyDisplayStateNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

HideComponent

Visibility as defined in [swComponentVisibilityState_e](#)

Option

Display state option as defined in [swDisplayStateOpts_e](#)

AssemblyDisplayStateNames

Array of assembly display state names; valid only if Option is set to swDisplayStateOpts_e.swSpecifyDisplayState

Return Value

True if visibility successfully set, false if not

Visual Basic for Applications (VBA) Syntax

See [Component2::SetVisibilityInAsmDisplayStates](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::SetReferencedDisplayStates Method \(\)](#)
[IComponent2::GetVisibilityInAsmDisplayStates Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetXform Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : SetXform Method (IComponent2)

Obsolete. Superseded by [IComponent2::Transform2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetXform( _  
    ByVal XformIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim XformIn As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetXform(XformIn)
```

C#

```
System.bool SetXform(  
    System.object XformIn  
)
```

C++/CLI

```
System.bool SetXform(  
    & System.Object^ XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Visual Basic for Applications (VBA) Syntax

See [Component2::SetXform](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetXformAndSolve Method (IComponent2)

[See Also](#)



Obsolete. Superseded by [IComponent2::SetTransformAndSolve2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetXformAndSolve( _  
    ByVal XformIn As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim XformIn As System.Object  
Dim value As System.Boolean  
  
value = instance.SetXformAndSolve(XformIn)
```

C#

```
System.bool SetXformAndSolve(  
    System.object XformIn  
)
```

C++/CLI

```
System.bool SetXformAndSolve(  
& System.Object^ XformIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

XformIn

Visual Basic for Applications (VBA) Syntax

See [Component2::SetXformAndSolve](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Solving Property (IComponent2)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IComponent2 Interface : Solving Property (IComponent2)

Gets the **Solve as** option (rigid or flexible) of this component.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Solving As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim value As System.Integer  
  
value = instance.Solving
```

C#

```
System.int Solving {get;}
```

C++/CLI

```
property System.int Solving {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Solve as option as defined in [swComponentSolvingOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [Component2::Solving](#).

Example

[Get Component State \(C#\)](#)
[Get Component State \(VB.NET\)](#)
[Get Component State \(VBA\)](#)

Remarks

You can also use [IAssemblyDoc::CompConfigProperties4](#) to set the **Solve as** state of a component.

This property only applies to subassembly components, not part components. If you try to get the **Solve as** option of a part component, this property returns -1.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IAssemblyDoc::CompConfigProperties5 Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Transform Property (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : Transform Property (IComponent2)

Obsolete. Superseded by [IComponent2::Transform2](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Transform As MathTransform
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim value As MathTransform
```

```
instance.Transform = value
```

```
value = instance.Transform
```

C#

```
MathTransform Transform {get; set;}
```

C++/CLI

```
property MathTransform^ Transform {  
    MathTransform^ get();  
    void set ( & MathTransform^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Component2::Transform](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Transform2 Property (IComponent2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : Transform2 Property (IComponent2)

Gets or sets the component transform.

.NET Syntax

Visual Basic (Declaration)

Property Transform2 As MathTransform

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim value As MathTransform  
  
instance.Transform2 = value  
  
value = instance.Transform2
```

C#

```
MathTransform Transform2 {get; set;}
```

C++/CLI

```
property MathTransform^ Transform2 {  
    MathTransform^ get();  
    void set ( & MathTransform^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Component transform](#)

Visual Basic for Applications (VBA) Syntax

See [Component2::Transform2](#).

Example

[Align Assembly Component to Assembly Origin and Planes \(VBA\)](#)
[Combine Assembly Components into Part \(VBA\)](#)
[Get Transforms of Assembly Components \(VBA\)](#)
[Transform Point from Component Space to Assembly Space \(C#\)](#)
[Transform Point from Component Space to Assembly Space \(VB.NET\)](#)
[Transform Point from Component Space to Assembly Space \(VBA\)](#)

Remarks

This property affects the underlying model geometry and the display of the component.

You must specify the transform in relation to the root component. This also applies when there is an in-context edit in progress. The transform is still with respect to the root component of the active assembly document, not with respect to the root component of the edit target. See [IConfiguration::GetRootComponent](#) and [IConfiguration::IGetRootComponent2](#).

The destination component, or any component above it in the assembly tree, is moved so that the destination component's transform is set to the desired one.

You can call [IModelDoc2::Rebuild](#) with the `swUpdateMates` argument to rebuild the model after transforming a component. This is much faster than rebuilding all of the geometry for the model using the now obsolete `IAssemblyDoc::EditRebuild`.

This property lets you violate existing mate relationships. If you place a component at an invalid location based on the mate definitions, then `IModelDoc2::Rebuild` recalculates existing mate relationships and moves your components to the closest valid location.

After you change a component's transform, you can call [IAssemblyDoc::UpdateBox](#) to avoid clipping in shaded display mode.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IComponent2::GetTotalTransform Method](#)
[IComponent2::PresentationTransform Property](#)
[IComponent2::RemovePresentationTransform Method](#)
[IComponent2::SetTransformAndSolve2 Method](#)
[IComponent2::GetSpecificTransform Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateExternalFileReferences Method (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : UpdateExternalFileReferences Method (IComponent2)

Updates the external file references of this model.

.NET Syntax

Visual Basic (Declaration)

```
Sub UpdateExternalFileReferences( _  
    ByVal ConfigOption As System.Integer, _  
    ByVal ConfigName As System.String, _  
    ByVal UpdateStatus As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim ConfigOption As System.Integer  
Dim ConfigName As System.String  
Dim UpdateStatus As System.Integer  
  
instance.UpdateExternalFileReferences(ConfigOption, ConfigName, UpdateStatus)
```

C#

```
void UpdateExternalFileReferences(  
    System.int ConfigOption,  
    System.string ConfigName,  
    System.int UpdateStatus  
)
```

C++/CLI

```
void UpdateExternalFileReferences(  
& System.int ConfigOption,  
& System.String^ ConfigName,  
& System.int UpdateStatus  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigOption

Configuration option as defined [swExternalFileReferencesConfig_e](#)

ConfigName

Name of configuration; required when ConfigOption set to swExternalFileReferencesNamedConfig

UpdateStatus

Update status option as defined by [swExternalFileReferencesUpdate_e](#)

Visual Basic for Applications (VBA) Syntax

See [Component2::UpdateExternalFileReferences](#).

See Also

[IComponent2 Interface](#)

[IComponent2 Members](#)

[IComponent2::IListExternalFileReferences2 Method](#)

[IComponent2::ListExternalFileReferences2 Method](#)

[IFeature::IListExternalFileReferences2 Method](#)

[IFeature::ListExternalFileReferences2 Method](#)

[IFeature::UpdateExternalFileReferences Method](#)

[IModelDocExtension::IListExternalFileReferences Method](#)

[IModelDocExtension::ListExternalFileReferences Method](#)

[IModelDocExtension::UpdateExternalFileReferences Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

UseNamedConfiguration Property (IComponent2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : UseNamedConfiguration Property (IComponent2)

Gets whether a specified configuration or the in-use/last active configuration is used.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UseNamedConfiguration As System.Boolean

Visual Basic (Usage)



```
Dim instance As IComponent2
Dim value As System.Boolean
```

```
value = instance.UseNamedConfiguration
```

C#

```
System.bool UseNamedConfiguration {get;}
```

C++/CLI

```
property System.bool UseNamedConfiguration {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if a configuration is specified and used, false if the in-use/last active configuration is used

Visual Basic for Applications (VBA) Syntax

See [Component2::UseNamedConfiguration](#).

Remarks

Use [IAssemblyDoc::CompConfigProperties4](#) to set this property.

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Visible Property (IComponent2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IComponent2 Interface](#) : Visible Property (IComponent2)

Gets or sets the visibility state of this component.

.NET Syntax

Visual Basic (Declaration)

Property Visible As System.Integer

Visual Basic (Usage)



```
Dim instance As IComponent2  
Dim value As System.Integer
```

```
instance.Visible = value
```

```
value = instance.Visible
```

C#

```
System.int Visible {get; set;}
```

C++/CLI

```
property System.int Visible {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Visibility state as defined in [swComponentVisibilityState_e](#)

Visual Basic for Applications (VBA) Syntax

See [Component2::Visible](#).

Example

[Open Assembly in Large Design Review Mode \(C#\)](#)
[Open Assembly in Large Design Review Mode \(VB.NET\)](#)
[Open Assembly in Large Design Review Mode \(VBA\)](#)

Remarks

This functionality is also available using [IModelDoc2::HideComponent2](#) and [IModelDoc2::ShowComponent2](#).

See Also

[IComponent2 Interface](#)
[IComponent2 Members](#)
[IAssemblyDoc::SetComponentVisibility Method](#)
[IAssemblyDoc::SetComponentVisibility Method](#)
[IComponent2::GetVisibility Method](#)
[IComponent2::IGetVisibility Method](#)

[IComponent2::IsVisible Method](#)
[IComponent2::SetVisibility Method](#)
[IComponent2::IsHidden Method](#)
[IAssemblyDoc::CompConfigProperties5 Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0