

SOLIDWORKS API (.NET VBA C#) — Reference (53/337): IConfiguration (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IConfiguration (part 1 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IConfiguration Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConfiguration Interface

Allows you to manage different part or assembly states.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IConfiguration
```

Visual Basic (Usage)

```
Dim instance As IConfiguration
```

C#

```
public interface IConfiguration
```

C++/CLI

```
public interface class IConfiguration
```

Visual Basic for Applications (VBA) Syntax

See [Configuration](#).

Example

[Add Derived Configurations \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)

Remarks

You can hide or suppress features on a part and save that state as a configuration. In an assembly, you can hide or suppress assembly-level features or assembly components and save each state as a configuration.

Accessors

[IAssemblyDoc::AddComponentConfiguration](#)
[IConfiguration::GetChildren](#) and [IConfiguration::!GetChildren](#)
[IConfiguration::GetParent](#)
[IConfigurationManager::ActiveConfiguration](#)
[IConfigurationManager::AddCADFamilyConfiguration](#)
[IConfigurationManager::AddConfiguration](#)
[IModelDoc2::AddConfiguration3](#) and [IModelDoc2::!AddConfiguration3](#)
[IModelDoc2::GetConfigurationByName](#) and [IModelDoc2::!GetConfigurationByName](#)

Access Diagram

[Configuration](#)

See Also

IConfiguration Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : IConfiguration Interface

The following tables list the members exposed by [IConfiguration](#).

Public Properties

Name	Description
 AddRebuildSaveMark	Adds or removes the mark indicating whether the configuration needs to be rebuilt and its configuration data saved every time you save the model document.
 AlternateName	Gets or sets the configuration's alternate name (i.e., user-specified name).
 BOMPartNoSource	Gets or sets the source of the part number used in the BOM table.
 ChildComponentDisplayInBOM	Gets or sets the child component display option of this configuration in the Bill of Materials (BOM) for an assembly or for a cutlist part (weldment and/or sheet metal).
 Comment	Gets or sets the configuration comment.
 CustomPropertyManager	Gets the custom property information for this configuration.
 Description	Gets or sets the description of the configuration.
 DimXpertManager	Gets the DimXpert schema for this configuration.
 HideNewComponentModels	Gets or sets whether new components are hidden in this inactive configuration.
 LargeDesignReviewMark	Gets or sets whether to add display data to this configuration when the document is saved.
 Lock	Gets or sets whether the configuration is locked.
 Name	Gets or sets the configuration name.
 NeedsRebuild	Gets whether the configuration needs to be rebuilt.
 RepresentationShared	Gets or sets whether this SOLIDWORKS Design connected to the 3DEXPERIENCE platform Representation configuration is shared.
 ShowChildComponentsInBOM	Obsolete. Superseded by IConfiguration.ChildComponentDisplayInBOM.
 SuppressNewComponentModels	Gets or sets whether new components are suppressed in this configuration.
 SuppressNewFeatures	Gets or sets whether to suppress new features in this configuration.
 Type	Gets the type of configuration.
 UseAlternateNameInBOM	Gets or sets whether the alternate name (i.e., user-specified name) is displayed in the bill of materials for this configuration.
 UseDescriptionInBOM	Gets or sets whether the description of the configuration is displayed in the bill of materials.

[Top](#)

Public Methods

Name	Description
 AddExplodeStep	Obsolete. Superseded by IConfiguration.AddExplodeStep2.
 AddExplodeStep2	Adds a regular (translate and rotate) explode step to the explode view of the active configuration.
 AddPartExplodeStep	Adds an explode step to the specified explode view of a multibody part.
 AddRadialExplodeStep	Adds a radial explode step to the explode view of the active configuration.
 ApplyDisplayState	Applies the specified display state to this configuration.
 CopyDisplayStateFromConfiguration	Copies the specified display state from the specified configuration to this configuration.
 CreateDisplayState	Creates a display state for this configuration.
 DeleteDisplayState	Deletes the specified display state from this configuration.
 DeleteExplodeStep	Deletes the specified explode step.
 Get3DExperienceType	Gets how this configuration is viewed in SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
 GetChildren	Gets all of the children configurations of this derived configuration.

	GetChildrenCount	Gets the number of children for this configuration.
	GetComponentConfigName	Gets the referenced configuration name of the specified component in this configuration.
	GetComponentSuppressionState	Gets the suppression state of the specified component in this configuration.
	GetCurrentPartExplodeViewName	Gets the explode view name in the current configuration.
	GetCustomProperties	Obsolete. Superseded by IConfiguration:CustomPropertyManager .
	GetCustomPropertiesCount	Obsolete. Superseded by IConfiguration:CustomPropertyManager .
	GetCutListItems	Gets the cut list folders in this active or non-active configuration.
	GetDisplayStateBodyProperties	Gets the bodies and their material properties in the specified display state.
	GetDisplayStateComponentProperties	Gets the components and their material properties in the specified display state.
	GetDisplayStateComponentVisibility	Gets the components and their visibilities in the specified display state.
	GetDisplayStateFaceProperties	Gets the faces and their material properties in the specified display state.
	GetDisplayStateFeatureProperties	Gets the features and their material properties in the specified display state.
	GetDisplayStateProperties	Gets the material properties of the specified display state.
	GetDisplayStates	Gets the names of the display states for this configuration.
	GetDisplayStatesCount	Gets the number of display states for this configuration.
	GetExpanded	Gets whether this configuration's node is expanded in the specified pane of the ConfigurationManager.
	GetExplodeStep	Gets the specified explode step in this configuration's explode step sequence.
	GetID	Gets the configuration ID of this configuration.
	GetNumberOfExplodeSteps	Gets the number of explode steps for this configuration.
	GetNumberOfPartExplodeSteps	Gets the number of explode steps in the explode view of a multibody part.
	GetParameterCount	Gets the number of parameters for this configuration.
	GetParameters	Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	GetParent	Gets the parent configuration of this derived configuration.
	GetPartExplodeStep	Gets the specified explode step of an explode view of a multibody part.
	GetRepresentationParent	Gets the Physical Product represented by this configuration.
	GetRootComponent	Obsolete. Superseded by IConfiguration:GetRootComponent3 .
	GetRootComponent3	Gets the root component for this assembly configuration.
	GetScene	Gets the ISwScene object for this configuration.
	GetStreamName	Gets the name of the stream for the current configuration.
	IAddExplodeStep	Adds a new explode step to the configuration.
	IGetChildren	Gets all of the children configurations of this derived configuration.
	IGetCustomProperties	Obsolete. Superseded by IConfiguration:CustomPropertyManager .
	IGetDisplayStates	Gets the names of the display states for this configuration.
	IGetExplodeStep	Gets a pointer to the specified explode step in the configuration explode step sequence.
	IGetParameters	Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	IGetRootComponent	Obsolete. Superseded by IConfiguration:IGetRootComponent2 .
	IGetRootComponent2	Obsolete. Superseded by IConfiguration:GetRootComponent3 .
	IsDefeature	Gets whether this configuration is a defeature configuration.
	IsDerived	Gets whether this configuration is a derived configuration.
	IsDirty	Gets whether this configuration is dirty (i.e., needs to be updated).
	ISetParameters	Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	IsLoaded	Gets whether a configuration is loaded.
	IsSpeedPak	Gets whether the configuration is a SpeedPak.

		
	RenameDisplayState	Renames a display state of this configuration.
	Select	Obsolete. Superseded by IConfiguration.Select2 .
	Select2	Selects the configuration.
	Set3DExperienceType	Converts this configuration in SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
	SetColor	Sets the color for this configuration.
	SetExpanded	Sets whether to expand this configuration's node in the specified pane of the ConfigurationManager.
	SetParameters	Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	UpdateSpeedPak	Updates the SpeedPak configuration for this configuration.

[Top](#)

See Also

[IConfiguration Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICConfiguration Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConfiguration Interface

For a list of all members of this type, see [IConfiguration members](#).

Public Methods

Name	Description
 AddExplodeStep	Obsolete. Superseded by IConfiguration.AddExplodeStep2 .
 AddExplodeStep2	Adds a regular (translate and rotate) explode step to the explode view of the active configuration.
 AddPartExplodeStep	Adds an explode step to the specified explode view of a multibody part.
 AddRadialExplodeStep	Adds a radial explode step to the explode view of the active configuration.
 ApplyDisplayState	Applies the specified display state to this configuration.
 CopyDisplayStateFromConfiguration	Copies the specified display state from the specified configuration to this configuration.
 CreateDisplayState	Creates a display state for this configuration.
 DeleteDisplayState	Deletes the specified display state from this configuration.
 DeleteExplodeStep	Deletes the specified explode step.
 Get3DExperienceType	Gets how this configuration is viewed in SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
 GetChildren	Gets all of the children configurations of this derived configuration.
 GetChildrenCount	Gets the number of children for this configuration.
 GetComponentConfigName	Gets the referenced configuration name of the specified component in this configuration.
 GetComponentSuppressionState	Gets the suppression state of the specified component in this configuration.
 GetCurrentPartExplodeViewName	Gets the explode view name in the current configuration.
 GetCustomProperties	Obsolete. Superseded by IConfiguration.CustomPropertyManager .
 GetCustomPropertiesCount	Obsolete. Superseded by IConfiguration.CustomPropertyManager .
 GetCutListItems	Gets the cut list folders in this active or non-active configuration.
 GetDisplayStateBodyProperties	Gets the bodies and their material properties in the specified display state.
 GetDisplayStateComponentProperties	Gets the components and their material properties in the specified display state.
 GetDisplayStateComponentVisibility	Gets the components and their visibilities in the specified display state.
 GetDisplayStateFaceProperties	Gets the faces and their material properties in the specified display state.

	GetDisplayStateFeatureProperties	Gets the features and their material properties in the specified display state.
	GetDisplayStateProperties	Gets the material properties of the specified display state.
	GetDisplayStates	Gets the names of the display states for this configuration.
	GetDisplayStatesCount	Gets the number of display states for this configuration.
	GetExpanded	Gets whether this configuration's node is expanded in the specified pane of the ConfigurationManager.
	GetExplodeStep	Gets the specified explode step in this configuration's explode step sequence.
	GetID	Gets the configuration ID of this configuration.
	GetNumberOfExplodeSteps	Gets the number of explode steps for this configuration.
	GetNumberOfPartExplodeSteps	Gets the number of explode steps in the explode view of a multibody part.
	GetParameterCount	Gets the number of parameters for this configuration.
	GetParameters	Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	GetParent	Gets the parent configuration of this derived configuration.
	GetPartExplodeStep	Gets the specified explode step of an explode view of a multibody part.
	GetRepresentationParent	Gets the Physical Product represented by this configuration.
	GetRootComponent	Obsolete. Superseded by IConfiguration.GetRootComponent3 .
	GetRootComponent3	Gets the root component for this assembly configuration.
	GetScene	Gets the ISwScene object for this configuration.
	GetStreamName	Gets the name of the stream for the current configuration.
	IAddExplodeStep	Adds a new explode step to the configuration.
	IGetChildren	Gets all of the children configurations of this derived configuration.
	IGetCustomProperties	Obsolete. Superseded by IConfiguration.CustomPropertyManager .
	IGetDisplayStates	Gets the names of the display states for this configuration.
	IGetExplodeStep	Gets a pointer to the specified explode step in the configuration explode step sequence.
	IGetParameters	Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	IGetRootComponent	Obsolete. Superseded by IConfiguration.IGetRootComponent2 .
	IGetRootComponent2	Obsolete. Superseded by IConfiguration.GetRootComponent3 .
	IsDefeature	Gets whether this configuration is a defeature configuration.
	IsDerived	Gets whether this configuration is a derived configuration.
	IsDirty	Gets whether this configuration is dirty (i.e., needs to be updated).
	ISetParameters	Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	IsLoaded	Gets whether a configuration is loaded.
	IsSpeedPak	Gets whether the configuration is a SpeedPak.
	RenameDisplayState	Renames a display state of this configuration.
	Select	Obsolete. Superseded by IConfiguration.Select2 .
	Select2	Selects the configuration.
	Set3DEXperienceType	Converts this configuration in SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
	SetColor	Sets the color for this configuration.
	SetExpanded	Sets whether to expand this configuration's node in the specified pane of the ConfigurationManager.
	SetParameters	Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.
	UpdateSpeedPak	Updates the SpeedPak configuration for this configuration.

[Top](#)

IConfiguration Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IConfiguration Interface

For a list of all members of this type, see [IConfiguration members](#).

 Public Properties

Name	Description
 AddRebuildSaveMark	Adds or removes the mark indicating whether the configuration needs to be rebuilt and its configuration data saved every time you save the model document.
 AlternateName	Gets or sets the configuration's alternate name (i.e., user-specified name).
 BOMPartNoSource	Gets or sets the source of the part number used in the BOM table.
 ChildComponentDisplayInBOM	Gets or sets the child component display option of this configuration in the Bill of Materials (BOM) for an assembly or for a cutlist part (weldment and/or sheet metal).
 Comment	Gets or sets the configuration comment.
 CustomPropertyManager	Gets the custom property information for this configuration.
 Description	Gets or sets the description of the configuration.
 DimXpertManager	Gets the DimXpert schema for this configuration.
 HideNewComponentModels	Gets or sets whether new components are hidden in this inactive configuration.
 LargeDesignReviewMark	Gets or sets whether to add display data to this configuration when the document is saved.
 Lock	Gets or sets whether the configuration is locked.
 Name	Gets or sets the configuration name.
 NeedsRebuild	Gets whether the configuration needs to be rebuilt.
 RepresentationShared	Gets or sets whether this SOLIDWORKS Design connected to the 3DEXPERIENCE platform Representation configuration is shared.
 ShowChildComponentsInBOM	Obsolete. Superseded by IConfiguration.ChildComponentDisplayInBOM .
 SuppressNewComponentModels	Gets or sets whether new components are suppressed in this configuration.
 SuppressNewFeatures	Gets or sets whether to suppress new features in this configuration.
 Type	Gets the type of configuration.
 UseAlternateNameInBOM	Gets or sets whether the alternate name (i.e., user-specified name) is displayed in the bill of materials for this configuration.
 UseDescriptionInBOM	Gets or sets whether the description of the configuration is displayed in the bill of materials.

[Top](#)

 See Also

AddExplodeStep Method (IConfiguration)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AddExplodeStep Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::AddExplodeStep2](#)

 I.NET Syntax

Visual Basic (Declaration)

```
Function AddExplodeStep( _  
    ByVal ExplDist As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal RigidSubassembly As System.Boolean, _
```

```
ByVal ExplodeRelated As System.Boolean _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplDist As System.Double  
Dim ReverseDir As System.Boolean  
Dim RigidSubassembly As System.Boolean  
Dim ExplodeRelated As System.Boolean  
Dim value As System.Object  
  
value = instance.AddExplodeStep(ExplDist, ReverseDir, RigidSubassembly, ExplodeRelated)
```

C#

```
System.object AddExplodeStep(  
    System.double ExplDist,  
    System.bool ReverseDir,  
    System.bool RigidSubassembly,  
    System.bool ExplodeRelated  
)
```

C++/CLI

```
System.Object^ AddExplodeStep(  
& System.double ExplDist,  
& System.bool ReverseDir,  
& System.bool RigidSubassembly,  
& System.bool ExplodeRelated  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDist

Explode distance

ReverseDir

True to reverse the direction of the explode step, false to not

RigidSubassembly

True to explode entire sub assembly, false to explode just the selected component

ExplodeRelated

True to explode related components together, false to not

Return Value

Pointer to a newly created [explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::AddExplodeStep](#).

Remarks

This method is valid only if an explode view exists in the active configuration. To create an explode view, call [IAssemblyDoc::AutoExplode](#) or [IAssemblyDoc::CreateExplodedView](#).

Before calling this method, you must select by mark both a direction along which to explode and a component to move. For example:

```
boolstatus = Model.Extension.SelectByID2('', 'EDGE', -0.011, 0.06, 0.084, True,  
1, Nothing)  
  
boolstatus = Model.Extension.SelectByID2('squarebolt1-1@Assem1', 'COMPONENT', 0,  
0, 0, True, 2, Nothing, swSelectOptionDefault)
```

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)

[IConfiguration::DeleteExplodeStep Method](#)
[IConfiguration::GetExplodeStep Method](#)
[IConfiguration::GetNumberOfExplodeSteps Method](#)
[IConfiguration::IGetExplodeStep Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddExplodeStep2 Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AddExplodeStep2 Method (IConfiguration)

Adds a regular (translate and rotate) explode step to the explode view of the active configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function AddExplodeStep2( _  
    ByVal ExplDist As System.Double, _  
    ByVal ExplDirIndex As System.Integer, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal ExplAng As System.Double, _  
    ByVal RotAxisIndex As System.Integer, _  
    ByVal ReverseAng As System.Boolean, _  
    ByVal RotateAboutOrigin As System.Boolean, _  
    ByVal AutoSpaceComponentsOnDrag As System.Boolean, _  
    ByRef Error As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplDist As System.Double  
Dim ExplDirIndex As System.Integer  
Dim ReverseDir As System.Boolean  
Dim ExplAng As System.Double  
Dim RotAxisIndex As System.Integer  
Dim ReverseAng As System.Boolean  
Dim RotateAboutOrigin As System.Boolean  
Dim AutoSpaceComponentsOnDrag As System.Boolean  
Dim Error As System.Integer  
Dim value As System.Object
```

```
value = instance.AddExplodeStep2(ExplDist, ExplDirIndex, ReverseDir, ExplAng, RotAxisIndex,  
ReverseAng, RotateAboutOrigin, AutoSpaceComponentsOnDrag, Error)
```

C#

```
System.object AddExplodeStep2(  
    System.double ExplDist,  
    System.int ExplDirIndex,  
    System.bool ReverseDir,  
    System.double ExplAng,  
    System.int RotAxisIndex,  
    System.bool ReverseAng,  
    System.bool RotateAboutOrigin,  
    System.bool AutoSpaceComponentsOnDrag,  
    out System.int Error  
)
```

C++/CLI

```
System.Object^ AddExplodeStep2(  
    & System.double ExplDist,  
    & System.int ExplDirIndex,  
    & System.bool ReverseDir,  
    & System.double ExplAng,
```

```
& System.int RotAxisIndex,
& System.bool ReverseAng,
& System.bool RotateAboutOrigin,
& System.bool AutoSpaceComponentsOnDrag,
& [Out] System.int Error
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDist

Distance in meters to move the components in this explode step

ExplDirIndex

Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#) (see **Remarks**)

ReverseDir

True to reverse the explode direction, false to not

ExplAng

Angle in radians of component rotation (see **Remarks**)

RotAxisIndex

Rotation manipulator index as defined in [swRotationAxisIndex_e](#) (see **Remarks**)

ReverseAng

True to reverse the direction of ExplAng, false to not

RotateAboutOrigin

True if each component rotates about its origin, false if not (see **Remarks**)

AutoSpaceComponentsOnDrag

True to automatically space components on drag, false to not (see **Remarks**)

Error

Error code as defined in [swCreateExplodeStepError_e](#)

Return Value

[Explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::AddExplodeStep2](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This method:

- Is valid only for an active current explode view. To create an explode view, call [IAssemblyDoc::AutoExplode](#) or [IAssemblyDoc::CreateExplodedView](#).
- Always clears the selection list.
- Does not work if the Explode PropertyManager is open.
- Does not work if any component is being edited in the context of the assembly.

If [AutoSpaceComponentsOnDrag](#) is set to true, then [RotateAboutOrigin](#) is false and [ExplAng](#) is 0.0. Set [AutoSpaceComponentsOnDrag](#) to false to specify other values for [RotateAboutOrigin](#) and [ExplAng](#).

Before calling this method, you must:

1. Use [IConfigurationManager::ActiveConfiguration](#) to get the active configuration for the assembly.
2. Call [IAssemblyDoc::ShowExploded2](#) to activate an explode view.
3. Call [IModelDocExtension::SelectByID2](#) to select:
 - Components to move with Mark = 1.
 - (Optionally) An explode direction entity (cylindrical [face](#), conical face, linear [edge](#), or [axis](#)) with Mark = 2. Either, both, or neither of the direction entity and [ExplDirIndex](#) can be set. If neither, then the Z-direction manipulator index is used.
 - (Optionally) A rotation axis with Mark = 32. Valid only if [RotateAboutOrigin](#) is set to false. Either, both, or neither of the rotation axis and [RotAxisIndex](#) can be set. If neither, then the XY ring index is used.

After calling this method, call [IModelDoc2::EditRebuild3](#).

For C++, specify VARIANT_TRUE or VARIANT_FALSE for [ReverseDir](#), [ReverseAng](#), and [RotateAboutOrigin](#).

To edit a regular explode step, see the [IExplodeStep](#) remarks.

To create an explode step for the explode view of a multibody part, see [IConfiguration::AddPartExplodeStep](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddRadialExplodeStep Method \(\)](#)
[IConfiguration::DeleteExplodeStep Method \(\)](#)
[IConfiguration::GetExplodeStep Method \(\)](#)
[IConfiguration::GetNumberOfExplodeSteps Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

AddPartExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AddPartExplodeStep Method (IConfiguration)

Adds an explode step to the specified explode view of a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function AddPartExplodeStep( _
    ByVal ExplodeView As System.String, _
    ByVal ExplDist As System.Double, _
    ByVal ExplDirIndex As System.Integer, _
    ByVal ReverseDir As System.Boolean, _
    ByVal AutoSpaceBodiesOnDrag As System.Boolean, _
    ByRef Error As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim ExplodeView As System.String
Dim ExplDist As System.Double
Dim ExplDirIndex As System.Integer
Dim ReverseDir As System.Boolean
Dim AutoSpaceBodiesOnDrag As System.Boolean
Dim Error As System.Integer
Dim value As System.Object

value = instance.AddPartExplodeStep(ExplodeView, ExplDist, ExplDirIndex, ReverseDir,
AutoSpaceBodiesOnDrag, Error)
```

C#

```
System.object AddPartExplodeStep(
    System.string ExplodeView,
    System.double ExplDist,
    System.int ExplDirIndex,
    System.bool ReverseDir,
    System.bool AutoSpaceBodiesOnDrag,
    out System.int Error
)
```

C++/CLI

```
System.Object^ AddPartExplodeStep(
    & System.String^ ExplodeView,
    & System.double ExplDist,
    & System.int ExplDirIndex,
    & System.bool ReverseDir,
    & System.bool AutoSpaceBodiesOnDrag,
    & [Out] System.int Error
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeView

Name of the explode view to which to add this explode step

ExplDist

Distance in meters to move the selected bodies in this explode step

ExplDirIndex

Explode direction manipulator index as defined in [swExplodeDirectionIndex_e](#) (see [Remarks](#))

ReverseDir

True to reverse the explode direction, false to not

AutoSpaceBodiesOnDrag

True to automatically space selected bodies on drag, false to not

Error

Error code as defined in [swCreatePartExplodeStepError_e](#)

Return Value

Visual Basic for Applications (VBA) Syntax

See [Configuration::AddPartExplodeStep](#).

Example

See the [IPartExplodeStep](#) example.

Remarks

This method:

- Is valid only for an active, current explode view of a multibody part.
- Always clears the selection list.
- Does not work if the Explode PropertyManager is open.
- Does not work if any body is being edited in the context of the part.

Before calling this method, you must:

1. Create an explode view in the active, current configuration of the multibody part. To create an explode view, call [IPartDoc::CreateExplodedView](#).
2. Populate ExplodeView with [IConfiguration::GetCurrentPartExplodeViewName](#).
3. Call [IPartDoc::ShowExploded](#) to activate the explode view to which to add an explode step.
4. Call [IModelDocExtension::SelectByVID2](#) to select:
 - Bodies to move with Mark = 1.
 - (Optionally) An explode direction entity (cylindrical [face](#), conical face, linear [edge](#), or [axis](#)) with Mark = 2. Either, both, or neither of the direction entity and ExplDirIndex can be set. If neither, then the Z-direction manipulator index is used.

After calling this method, call [IModelDoc2::EditRebuild3](#).

For C++, specify VARIANT_TRUE or VARIANT_FALSE for ReverseDir.

To edit an explode step, see the [IPartExplodeStep](#) remarks.

To create an explode step for the explode view of an assembly, see [IConfiguration::AddExplodeStep2](#) and [IConfiguration::AddRadialExplodeStep](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::DeleteExplodeStep Method \(\)](#)
[IConfiguration::GetNumberOfPartExplodeSteps Method \(\)](#)
[IConfiguration::GetPartExplodeStep Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddRadialExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AddRadialExplodeStep Method (IConfiguration)

Adds a radial explode step to the explode view of the active configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function AddRadialExplodeStep( _  
    ByVal ExplDist As System.Double, _  
    ByVal ExplAng As System.Double, _  
    ByVal DivergeFromAxis As System.Boolean, _  
    ByRef Error As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplDist As System.Double  
Dim ExplAng As System.Double  
Dim DivergeFromAxis As System.Boolean  
Dim Error As System.Integer
```

```
Dim value As System.Object
```

```
value = instance.AddRadialExplodeStep(ExplDist, ExplAng, DivergeFromAxis, Error)
```

C#

```
System.Object AddRadialExplodeStep(  
    System.double ExplDist,  
    System.double ExplAng,  
    System.bool DivergeFromAxis,  
    out System.int Error  
)
```

C++/CLI

```
System.Object^ AddRadialExplodeStep(  
& System.double ExplDist,  
& System.double ExplAng,  
& System.bool DivergeFromAxis,  
& [Out] System.int Error  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDist

Distance in meters to move the components in this explode step

ExplAng

Angle in radians of rotation about component origins

DivergeFromAxis

True to move components at an angle from the selected explode direction, false to not (see **Remarks**)

Error

Error code as defined in [swCreateExplodeStepError_e](#)

Return Value

[Explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::AddRadialExplodeStep](#).

Remarks

This method:

- Is valid only for an active current explode view. To create an explode view, call [IAssemblyDoc::AutoExplode](#) or [IAssemblyDoc::CreateExplodedView](#).
- Always clears the selection list.
- Does not work if the Explode PropertyManager is open.
- Does not work if any component is being edited in the context of the assembly.

Before calling this method, you must:

- Use [IConfigurationManager::ActiveConfiguration](#) to get the active configuration for the assembly.
- Call [IAssemblyDoc::ShowExploded2](#) to activate an explode view.
- Call [IModelDocExtension::SelectByID2](#) to select:
 - Components to move with Mark = 1.
 - An explode direction entity (cylindrical [face](#), conical face, linear [edge](#), or [axis](#)) with Mark = 34.
 - A diverge direction entity (cylindrical face, conical face, linear edge, or axis) with Mark = 64. The selected entity must form an angle with the direction entity. If DivergeFromAxis is set to true and an invalid diverge direction is selected, then DivergeFromAxis is set to false, and the direction entity is set to null. If DivergeFromAxis is set to false, then the direction entity is set to null.

After calling this method, call [IModelDoc2::EditRebuild3](#).

For C++, specify VARIANT_TRUE or VARIANT_FALSE for ReverseDir and DivergeFromAxis.

To edit a radial explode step, see the [IExplodeStep](#) remarks.

To create an explode step for the explode view of a multibody part, see [IConfiguration::AddPartExplodeStep](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetNumberOfExplodeSteps Method \(\)](#)
[IConfiguration::GetExplodeStep Method \(\)](#)
[IConfiguration::DeleteExplodeStep Method \(\)](#)
[IConfiguration::AddExplodeStep2 Method \(\)](#)

Availability

AddRebuildSaveMark Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AddRebuildSaveMark Property (IConfiguration)

Adds or removes the mark indicating whether the configuration needs to be rebuilt and its configuration data saved every time you save the model document.

.NET Syntax

Visual Basic (Declaration)

Property AddRebuildSaveMark As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.AddRebuildSaveMark = value

value = instance.AddRebuildSaveMark
```

C#

```
System.bool AddRebuildSaveMark {get; set;}
```

C++/CLI

```
property System.bool AddRebuildSaveMark {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to mark the configuration as needing to be rebuilt and its configuration data saved every time you save the model document, false to mark the configuration as not needing to be rebuilt and its configuration data not saved every time you save the model document

Visual Basic for Applications (VBA) Syntax

See [Configuration::AddRebuildSaveMark](#).

Example

[Save Configuration Data \(C#\)](#)
[Save Configuration Data \(VB.NET\)](#)
[Save Configuration Data \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::NeedsRebuild Property](#)
[IModelDoc2::EditRebuild3 Method](#)
[IModelDoc2::ForceRebuild3 Method](#)
[IModelDocExtension::NeedsRebuild2 Property](#)
[IModelDocExtension::EditRebuildAll Method](#)
[IModelDocExtension::ForceRebuildAll Method](#)
[IConfigurationManager::AddRebuildSaveMark Method \(\)](#)
[IConfigurationManager::RemoveMarkForAllConfigurations Method \(\)](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

AlternateName Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : AlternateName Property (IConfiguration)

Gets or sets the configuration's alternate name (i.e., user-specified name).

Visual Basic Syntax

Visual Basic (Declaration)

```
Property AlternateName As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String
```

```
instance.AlternateName = value
```

```
value = instance.AlternateName
```

C#

```
System.string AlternateName {get; set;}
```

C++/CLI

```
property System.String^ AlternateName {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Alternate or user-specified name for the configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::AlternateName](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Get List of Configurations \(C#\)](#)
[Get List of Configurations \(VB.NET\)](#)
[Get List of Configurations \(VBA\)](#)

Remarks

To display the configuration's alternate name as the part number in the bill of materials, use [IConfiguration::UseAlternateNameInBOM](#).

Configuration names must not contain any special characters reserved by SOLIDWORKS.

If you specify [IConfiguration::BOMPartNoSource](#) with anything other than [swBOMPartNumberSource_e.swBOMPartNumber_UserSpecified](#), then this property is set to an empty string.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::Name Property](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplyDisplayState Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : ApplyDisplayState Method (IConfiguration)

Applies the specified display state to this configuration.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function ApplyDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim DisplayStateName As System.String  
Dim value As System.Boolean  
  
value = instance.ApplyDisplayState(DisplayStateName)
```

C#

```
System.bool ApplyDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.bool ApplyDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName

Name of the display state to apply to this configuration

Return Value

True if the display state is applied, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::ApplyDisplayState](#).

Remarks

Use [IConfiguration::GetDisplayStates](#) or [IConfiguration::IGetDisplayStates](#) to get the names of the display states for this configuration.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::CreateDisplayState Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::GetDisplayStatesCount Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IConfigurationManager::LinkDisplayStatesToConfigurations Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BOMPartNoSource Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : BOMPartNoSource Property (IConfiguration)

Gets or sets the source of the part number used in the BOM table.

Visual Basic Syntax

```
Property BOMPartNoSource As System.Integer
```



```
Dim instance As IConfiguration
Dim value As System.Integer

instance.BOMPartNoSource = value

value = instance.BOMPartNoSource
```

```
System.int BOMPartNoSource {get; set;}
```

```
property System.int BOMPartNoSource {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Source of part number as defined in [swBOMPartNumberSource_e](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::BOMPartNoSource](#).

Example

[Change Configuration Properties \(VBA\)](#)

Remarks

If you specify this property with anything other than swBOMPartNumberSource_e.swBOMPartNumber_UserSpecified, then [IConfiguration::AlternateName](#) is set to an empty string.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::Name Property](#)
[IConfiguration::UseAlternateNameInBOM Property](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

ChildComponentDisplayInBOM Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : ChildComponentDisplayInBOM Property (IConfiguration)

Gets or sets the child component display option of this configuration in the Bill of Materials (BOM) for an assembly or for a cutlist part (weldment and/or sheet metal).

.NET Syntax

```
Property ChildComponentDisplayInBOM As System.Integer
```



```

Dim instance As IConfiguration
Dim value As System.Integer

instance.ChildComponentDisplayInBOM = value

value = instance.ChildComponentDisplayInBOM

```

C#

```

System.int ChildComponentDisplayInBOM {get; set;}

```

C++/CLI

```

property System.int ChildComponentDisplayInBOM {
    System.int get();
    void set ( & System.int value);
}

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Child component display option as defined in [swChildComponentInBOMOption_e](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::ChildComponentDisplayInBOM](#).

Example

[Add Configuration and Promote Child Components in BOM \(C#\)](#)
[Add Configuration and Promote Child Components in BOM \(VB.NET\)](#)
[Add Configuration and Promote Child Components in BOM \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IModelDoc2::AddConfiguration3 Method \(\)](#)

Availability

SolidWorks 2013 SP3, Revision Number 22.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

Comment Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Comment Property (IConfiguration)

Gets or sets the configuration comment.

.NET Syntax

Visual Basic (Declaration)

```

Property Comment As System.String

```

Visual Basic (Usage)



```

Dim instance As IConfiguration
Dim value As System.String

instance.Comment = value

value = instance.Comment

```

C#

```
System.string Comment {get; set;}
```

C++/CLI

```
property System.String^ Comment {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Comment for the configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::Comment](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Get List of Configurations \(C#\)](#)
[Get List of Configurations \(VB.NET\)](#)
[Get List of Configurations \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CopyDisplayStateFromConfiguration Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : CopyDisplayStateFromConfiguration Method (IConfiguration)

Copies the specified display state from the specified configuration to this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function CopyDisplayStateFromConfiguration( _  
    ByVal CopyFromConfig As Configuration,  
    ByVal DisplayStateNameToCopy As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim CopyFromConfig As Configuration  
Dim DisplayStateNameToCopy As System.String  
Dim value As System.Boolean  
  
value = instance.CopyDisplayStateFromConfiguration(CopyFromConfig, DisplayStateNameToCopy)
```

C#

```
System.bool CopyDisplayStateFromConfiguration(  
    Configuration CopyFromConfig,  
    System.string DisplayStateNameToCopy  
)
```

C++/CLI

```
System.bool CopyDisplayStateFromConfiguration(  
& Configuration^ CopyFromConfig,
```

```
& System.String^ DisplayStateNameToCopy
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CopyFromConfig
Pointer to the [configuration](#) from which to copy the display state
DisplayStateNameToCopy
Name of the display state to copy

Return Value

True if the specified display is copied to this configuration, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::CopyDisplayStateFromConfiguration](#).

Remarks

Use [IConfiguration::GetDisplayStates](#) or [IConfiguration::IGetDisplayStates](#) to get the names of the display states from the configuration from which to copy the display state.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::CreateDisplayState Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::GetDisplayStatesCount Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IConfigurationManager::LinkDisplayStatesToConfigurations Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CreateDisplayState Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : CreateDisplayState Method (IConfiguration)

Creates a display state for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function CreateDisplayState( _
    ByVal DisplayStateName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim DisplayStateName As System.String
Dim value As System.Boolean

value = instance.CreateDisplayState(DisplayStateName)
```

C#

```
System.bool CreateDisplayState(
    System.string DisplayStateName
)
```

C++/CLI

```
System.bool CreateDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of display state to create for this configuration

Return Value

True if the display state is created, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::CreateDisplayState](#).

Example

[Create, Unlink, and Purge Display States in a Part \(C#\)](#)
[Create, Unlink, and Purge Display States in a Part \(VB.NET\)](#)
[Create, Unlink, and Purge Display States in a Part \(VBA\)](#)
[Add and Delete Appearances from Specific Display States \(C#\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::GetDisplayStatesCount Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IModelDocExtension::AddDisplayStateSpecificRenderMaterial Method](#)
[IModelDocExtension::IAddDisplayStateSpecificRenderMaterial Method](#)
[IConfigurationManager::LinkDisplayStatesToConfigurations Property](#)
[IConfiguration::GetDisplayStates Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CustomPropertyManager Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : CustomPropertyManager Property (IConfiguration)

Gets the custom property information for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CustomPropertyManager As CustomPropertyManager
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As CustomPropertyManager  
  
value = instance.CustomPropertyManager
```

C#

```
CustomPropertyManager CustomPropertyManager {get;}
```

C++/CLI

```
property CustomPropertyManager^ CustomPropertyManager {  
    CustomPropertyManager^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to [ICustomPropertyManager](#) object

Visual Basic for Applications (VBA) Syntax

See [Configuration::CustomPropertyManager](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IFeature::CustomPropertyManager Property](#)
[IModelDocExtension::CustomPropertyManager Property](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteDisplayState Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : DeleteDisplayState Method (IConfiguration)

Deletes the specified display state from this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteDisplayState( _  
    ByVal DisplayStateName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim DisplayStateName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteDisplayState(DisplayStateName)
```

C#

```
System.bool DeleteDisplayState(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.bool DeleteDisplayState(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of display state to delete from this configuration

Return Value

True if the specified display state is deleted, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::DeleteDisplayState](#).

Remarks

Use [IConfiguration::GetDisplayStates](#) or [IConfiguration::IGetDisplayStates](#) to get the names of the display states from the configuration from which to copy the display state.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::GetDisplayStatesCount Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IModelDocExtension::DeleteDisplayStateSpecificRenderMaterial Method](#)
[IModelDocExtension::IDeleteDisplayStateSpecificRenderMaterial Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DeleteExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : DeleteExplodeStep Method (IConfiguration)

Deletes the specified explode step.

.NET Syntax

Visual Basic (Declaration)

```
Function DeleteExplodeStep(  
    ByVal ExplodeStepName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplodeStepName As System.String  
Dim value As System.Boolean  
  
value = instance.DeleteExplodeStep(ExplodeStepName)
```

C#

```
System.bool DeleteExplodeStep(  
    System.string ExplodeStepName  
)
```

C++/CLI

```
System.bool DeleteExplodeStep(  
& System.String^ ExplodeStepName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeStepName
Name of the explode step to delete

Return Value

True if the explode step was deleted successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::DeleteExplodeStep](#).

Example

See the [IExplodeStep](#) examples.

Remarks

This method is valid only for the active configuration.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)
[IConfiguration::!AddExplodeStep Method](#)
[IConfiguration::GetExplodeStep Method](#)
[IConfiguration::GetNumberOfExplodeSteps Method](#)
[IConfiguration::!GetExplodeStep Method](#)
[IConfiguration::AddRadialExplodeStep Method](#)
[IConfiguration::AddPartExplodeStep Method \(\)](#)
[IConfiguration::GetPartExplodeStep Method \(\)](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Description Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Description Property (IConfiguration)

Gets or sets the description of the configuration.

.NET Syntax

Visual Basic (Declaration)

Property Description As System.String

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String
```

```
instance.Description = value
```

```
value = instance.Description
```

C#

```
System.string Description {get; set;}
```

C++/CLI

```
property System.String^ Description {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Description of the configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::Description](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Display Configuration Description in Bill of Materials \(C#\)](#)
[Display Configuration Description in Bill of Materials \(VB.NET\)](#)
[Display Configuration Description in Bill of Materials \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::UseDescriptionInBOM Property\(\)](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DimXpertManager Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : DimXpertManager Property (IConfiguration)

Gets the DimXpert schema for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DimXpertManager( _  
    ByVal CreateSchema As System.Boolean _  
) As DimXpertManager
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim CreateSchema As System.Boolean  
Dim value As DimXpertManager  
  
value = instance.DimXpertManager(CreateSchema)
```

C#

```
DimXpertManager DimXpertManager(  
    System.bool CreateSchema  
) {get;}
```

C++/CLI

```
property DimXpertManager^ DimXpertManager {  
    DimXpertManager^ get(System.bool CreateSchema);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CreateSchema
True to create DimXpert schema if it does not already exist; false otherwise

Property Value

Pointer to [IDimXpertManager](#) object

Visual Basic for Applications (VBA) Syntax

See [Configuration::DimXpertManager](#).

Example

[Get DimXpertManager Info \(VBA\)](#)
[Get DimXpertManager Info \(VB.NET\)](#)

Remarks

This interface retrieves the DimXpert schema information for opened parts which can be accessed in SOLIDWORKS via either the DimXpertManager tab of the Management Panel or the DimXpert tab of the CommandManager.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Get3DEXperienceType Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Get3DEXperienceType Method (IConfiguration)

Gets how this configuration is viewed in [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get3DEXperienceType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer  
  
value = instance.Get3DEXperienceType()
```

C#

```
System.int Get3DEXperienceType()
```

C++/CLI

```
System.int Get3DEXperienceType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of 3DEXPERIENCE configuration as defined in [sw3DEXperienceCfgType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::Get3DEXperienceType](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetRepresentationParent Method \(\)](#)
[IConfiguration::Set3DEXperienceType Method \(\)](#)
[IConfigurationManager::AddCADFamilyConfiguration Method \(\)](#)

Availability

SOLIDWORKS 2020 SP3.1, Revision Number 28.3.1

GetChildren Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetChildren Method (IConfiguration)

Gets all of the children configurations of this derived configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetChildren() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Object  
  
value = instance.GetChildren()
```

C#

```
System.object GetChildren()
```

C++/CLI

```
System.Object^ GetChildren();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array containing the children [configurations](#) of this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetChildren](#).

Example

[Traverse Hierarchy of Configurations \(VBA\)](#)
[Work with Configurations \(VBA\)](#)

Remarks

To determine if this configuration is derived, call [IConfiguration::IsDerived](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::IGetChildren Method](#)
[IConfiguration::GetParent Method](#)
[IConfiguration::GetChildrenCount Method](#)
[IConfiguration::GetRootComponent3 Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

GetChildrenCount Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetChildrenCount Method (IConfiguration)

Gets the number of children for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetChildrenCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Integer

value = instance.GetChildrenCount()
```

C#

```
System.int GetChildrenCount()
```

C++/CLI

```
System.int GetChildrenCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of children in this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetChildrenCount](#).

Example

[Work with Configurations \(VBA\)](#)

Remarks

Call this method before calling [IConfiguration::GetChildren](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetChildren Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponentConfigName Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetComponentConfigName Method (IConfiguration)

Gets the referenced configuration name of the specified component in this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentConfigName( _  
    ByVal CompName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim CompName As System.String
Dim value As System.String
```

```
value = instance.GetComponentConfigName(CompName)
```

C#

```
System.string GetComponentConfigName(  
    System.string CompName  
)
```

C++/CLI

```
System.String^ GetComponentConfigName(  
& System.String^ CompName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CompName
Component name

Return Value

Referenced configuration name

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetComponentConfigName](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetComponentSuppressionState Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetComponentSuppressionState Method (IConfiguration)

Gets the suppression state of the specified component in this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetComponentSuppressionState( _  
    ByVal CompName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IConfiguration  
Dim CompName As System.String  
Dim value As System.Boolean
```

```
value = instance.GetComponentSuppressionState(CompName)
```

C#

```
System.bool GetComponentSuppressionState(  
    System.string CompName  
)
```

C++/CLI



```
System.bool GetComponentSuppressionState(  
& System.String^ CompName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CompName
Component name

Return Value

True if the configuration is suppressed, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetComponentSuppressionState](#).

Example

[Get Whether Components Are Loaded \(C#\)](#)
[Get Whether Components Are Loaded \(VB.NET\)](#)
[Get Whether Components Are Loaded \(VBA\)](#)

Remarks

SOLIDWORKS 2001Plus SP1, Revision Number 10.1

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCurrentPartExplodeViewName Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetCurrentPartExplodeViewName Method (IConfiguration)

Gets the explode view name in the current configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCurrentPartExplodeViewName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String  
  
value = instance.GetCurrentPartExplodeViewName()
```

C#

```
System.string GetCurrentPartExplodeViewName()
```

C++/CLI

```
System.String^ GetCurrentPartExplodeViewName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Explode view name

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetCurrentPartExplodeViewName](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddPartExplodeStep Method \(\)](#)
[IConfiguration::GetNumberOfPartExplodeSteps Method \(\)](#)
[IConfiguration::GetPartExplodeStep Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetCustomProperties Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomProperties( _  
    ByRef PropNames As System.Object, _  
    ByRef PropValues As System.Object, _  
    ByRef PropTypes As System.Object _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim PropNames As System.Object  
Dim PropValues As System.Object  
Dim PropTypes As System.Object  
Dim value As System.Integer
```

```
value = instance.GetCustomProperties(PropNames, PropValues, PropTypes)
```

C#

```
System.int GetCustomProperties(  
    out System.object PropNames,  
    out System.object PropValues,  
    out System.object PropTypes  
)
```

C++/CLI

```
System.int GetCustomProperties(  
& [Out] System.Object^ PropNames,  
& [Out] System.Object^ PropValues,  
& [Out] System.Object^ PropTypes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropNames

PropValues

PropTypes

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetCustomProperties](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCustomPropertiesCount Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetCustomPropertiesCount Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomPropertiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer  
  
value = instance.GetCustomPropertiesCount()
```

C#

```
System.int GetCustomPropertiesCount()
```

C++/CLI

```
System.int GetCustomPropertiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetCustomPropertiesCount](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCutListItems Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetCutListItems Method (IConfiguration)

Gets the cut list folders in this active or non-active configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCutListItems() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Object  
  
value = instance.GetCutListItems()
```

C#

```
System.Object GetCutListItems()
```

C++/CLI

```
System.Object^ GetCutListItems();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [ICutListItems](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetCutListItems](#).

Example

See the [ICutListItem](#) examples.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayStateBodyProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateBodyProperties Method (IConfiguration)

Gets the bodies and their material properties in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateBodyProperties( _  
    ByVal DisplayStateName As System.String, _  
    ByRef Bodies As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim DisplayStateName As System.String  
Dim Bodies As System.Object  
Dim value As System.Object  
  
value = instance.GetDisplayStateBodyProperties(DisplayStateName, Bodies)
```

C#

```
System.Object GetDisplayStateBodyProperties(  
    System.string DisplayStateName,  
    out System.object Bodies  
)
```

C++/CLI

```
System.Object^ GetDisplayStateBodyProperties(
& System.String^ DisplayStateName,
& [Out] System.Object^ Bodies
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state
Bodies
Array of [IBody2](#) objects

Return Value

Array of body properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateBodyProperties](#).

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are from 0 to 1 for all variables.

If the return value is -1 values, then material property values are not assigned to the feature.

The format of the return value is an array of doubles as follows:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*]

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateComponentProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentVisibility Method \(\)](#)
[IConfiguration::GetDisplayStateFaceProperties Method \(\)](#)
[IConfiguration::GetDisplayStateFeatureProperties Method \(\)](#)
[IConfiguration::GetDisplayStateProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayStateComponentProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateComponentProperties Method (IConfiguration)

Gets the components and their material properties in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateComponentProperties( _
    ByVal DisplayStateName As System.String, _
    ByRef Components As System.Object _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As IConfiguration
Dim DisplayStateName As System.String
Dim Components As System.Object
Dim value As System.Object
```



```
value = instance.GetDisplayStateComponentProperties(DisplayStateName, Components)
```

C#

```
System.object GetDisplayStateComponentProperties(  
    System.string DisplayStateName,  
    out System.object Components  
)
```

C++/CLI

```
System.Object^ GetDisplayStateComponentProperties(  
& System.String^ DisplayStateName,  
[Out] System.Object^ Components  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state
Components
Array of [IComponent2](#)s

Return Value

Array of component properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateComponentProperties](#).

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are from 0 to 1 for all variables.

If the return value is all -1 values, then material property values are not assigned to the feature.

The format of the return value is an array of doubles as follows:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateBodyProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentVisibility Method \(\)](#)
[IConfiguration::GetDisplayStateFaceProperties Method \(\)](#)
[IConfiguration::GetDisplayStateFeatureProperties Method \(\)](#)
[IConfiguration::GetDisplayStateProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayStateComponentVisibility Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateComponentVisibility Method (IConfiguration)

Gets the components and their visibilities in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateComponentVisibility( _  
    ByVal DisplayStateName As System.String, _
```

```

    ByVal Onlyhidden As System.Boolean, _
    ByVal ToplevelOnly As System.Boolean, _
    ByRef Components As System.Object _
) As System.Object

```

Visual Basic (Usage)



```

Dim instance As IConfiguration
Dim DisplayStateName As System.String
Dim Onlyhidden As System.Boolean
Dim ToplevelOnly As System.Boolean
Dim Components As System.Object
Dim value As System.Object

```

```

value = instance.GetDisplayStateComponentVisibility(DisplayStateName, Onlyhidden, ToplevelOnly,
Components)

```

C#

```

System.object GetDisplayStateComponentVisibility(
    System.string DisplayStateName,
    System.bool Onlyhidden,
    System.bool ToplevelOnly,
    out System.object Components
)

```

C++/CLI

```

System.Object^ GetDisplayStateComponentVisibility(
    & System.String^ DisplayStateName,
    & System.bool Onlyhidden,
    & System.bool ToplevelOnly,
    & [Out] System.Object^ Components
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state
Onlyhidden
True to only return visibilities for hidden components, false to return visibilities for all components
ToplevelOnly
True to get the top-level components only, false to get all components
Components
Array of [IComponent2](#)s

Return Value

Array of longs or integers indicating component visibilities; 1 if visible, 0 if hidden

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateComponentVisibility](#).

Example

[Get Display States and Visibilities of Components \(C#\)](#)
[Get Display States and Visibilities of Components \(VB.NET\)](#)
[Get Display States and Visibilities of Components \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateBodyProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentProperties Method \(\)](#)
[IConfiguration::GetDisplayStateFaceProperties Method \(\)](#)
[IConfiguration::GetDisplayStateFeatureProperties Method \(\)](#)
[IConfiguration::GetDisplayStateProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

GetDisplayStateFaceProperties Method (IConfiguration)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateFaceProperties Method (IConfiguration)

Gets the faces and their material properties in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateFaceProperties( _
    ByVal DisplayStateName As System.String, _
    ByRef Faces As System.Object _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim DisplayStateName As System.String
Dim Faces As System.Object
Dim value As System.Object

value = instance.GetDisplayStateFaceProperties(DisplayStateName, Faces)
```

C#

```
System.object GetDisplayStateFaceProperties(
    System.string DisplayStateName,
    out System.object Faces
)
```

C++/CLI

```
System.Object^ GetDisplayStateFaceProperties(
    & System.String^ DisplayStateName,
    & [Out] System.Object^ Faces
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state
Faces
Array of [IFace2](#) objects

Return Value

Array of face properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateFaceProperties](#).

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are from 0 to 1 for all variables.

If the return value is all -1 values, then material property values are not assigned to the feature.

The format of return value is an array of doubles as follows:

[*R*, *G*, *B*, *Ambient*, *Diffuse*, *Specular*, *Shininess*, *Transparency*, *Emission*]

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateBodyProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentVisibility Method \(\)](#)
[IConfiguration::GetDisplayStateFeatureProperties Method \(\)](#)
[IConfiguration::GetDisplayStateProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayStateFeatureProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateFeatureProperties Method (IConfiguration)

Gets the features and their material properties in the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateFeatureProperties( _  
    ByVal DisplayStateName As System.String, _  
    ByRef Features As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim DisplayStateName As System.String  
Dim Features As System.Object  
Dim value As System.Object  
  
value = instance.GetDisplayStateFeatureProperties(DisplayStateName, Features)
```

C#

```
System.object GetDisplayStateFeatureProperties(  
    System.string DisplayStateName,  
    out System.object Features  
)
```

C++/CLI

```
System.Object^ GetDisplayStateFeatureProperties(  
& System.String^ DisplayStateName,  
& [Out] System.Object^ Features  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state
Features
Array of [IFeature](#) objects

Return Value

Array of feature properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateFeatureProperties](#).

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are from 0 to 1 for all variables.

If the return value is all -1 values, then material property values are not assigned to the feature.

The format of return value is an array of doubles as follows:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*]

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateBodyProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentVisibility Method \(\)](#)
[IConfiguration::GetDisplayStateFaceProperties Method \(\)](#)
[IConfiguration::GetDisplayStateProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetDisplayStateProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStateProperties Method (IConfiguration)

Gets the material properties of the specified display state.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStateProperties( _  
    ByVal DisplayStateName As System.String _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim DisplayStateName As System.String  
Dim value As System.Object  
  
value = instance.GetDisplayStateProperties(DisplayStateName)
```

C#

```
System.object GetDisplayStateProperties(  
    System.string DisplayStateName  
)
```

C++/CLI

```
System.Object^ GetDisplayStateProperties(  
& System.String^ DisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

DisplayStateName
Name of the display state

Return Value

Array of display state properties (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStateProperties](#).

Remarks

The material values returned include the face color (R,G,B values), reflectivity (ambient, diffuse, specular, shininess), transparency, and emission. Valid values are from 0 to 1 for all variables.

If the return value is all -1 values, then material property values are not assigned to the feature.

The format of return value is an array of doubles as follows:

[*R, G, B, Ambient, Diffuse, Specular, Shininess, Transparency, Emission*]

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetDisplayStateBodyProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentProperties Method \(\)](#)
[IConfiguration::GetDisplayStateComponentVisibility Method \(\)](#)
[IConfiguration::GetDisplayStateFaceProperties Method \(\)](#)
[IConfiguration::GetDisplayStateFeatureProperties Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::GetDisplayStatesCount Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayStates Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStates Method (IConfiguration)

Gets the names of the display states for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStates() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Object
```

```
value = instance.GetDisplayStates()
```

C#

```
System.object GetDisplayStates()
```

C++/CLI

```
System.Object^ GetDisplayStates();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of the names of the display states for this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStates](#).

Example

[Add and Delete Appearances from Specific Display States \(C#\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(VBA\)](#)
[Get Display States and Visibilities of Components \(C#\)](#)
[Get Display States and Visibilities of Components \(VB.NET\)](#)
[Get Display States and Visibilities of Components \(VBA\)](#)

Remarks

The first name in the list is the active display state. If more than one display state is active in the current model, call [IComponent2::ReferencedDisplayState](#) to obtain the active display state for each component in the model that references this configuration.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::GetDisplayStatesCount Method](#)
[IConfiguration::GetDisplayStates Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IConfiguration::CreateDisplayState Method](#)
[IConfigurationManager::LinkDisplayStatesToConfigurations Property](#)
[IConfiguration::GetDisplayStateBodyProperties Method](#)
[IConfiguration::GetDisplayStateComponentProperties Method](#)
[IConfiguration::GetDisplayStateComponentVisibility Method](#)
[IConfiguration::GetDisplayStateFaceProperties Method](#)
[IConfiguration::GetDisplayStateFeatureProperties Method](#)
[IConfiguration::GetDisplayStateProperties Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayStatesCount Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetDisplayStatesCount Method (IConfiguration)

Gets the number of display states for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayStatesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer
```

```
value = instance.GetDisplayStatesCount()
```

C#

```
System.int GetDisplayStatesCount()
```

C++/CLI

```
System.int GetDisplayStatesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of display states for this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetDisplayStatesCount](#).

Example

[Add and Delete Appearances from Specific Display States \(C#\)](#)
[Add and Delete Appearances from Specific Display States \(VB.NET\)](#)
[Add and Delete Appearances from Specific Display States \(VBA\)](#)

Remarks

Call this method before calling [IConfiguration::IGetDisplayStates](#) to determine the size of the array needed.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::GetDisplayStates Method](#)
[IConfiguration::IGetDisplayStates Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IConfiguration::GetDisplayStateBodyProperties Method](#)
[IConfiguration::GetDisplayStateComponentProperties Method](#)
[IConfiguration::GetDisplayStateComponentVisibility Method](#)
[IConfiguration::GetDisplayStateFaceProperties Method](#)
[IConfiguration::GetDisplayStateFeatureProperties Method](#)
[IConfiguration::GetDisplayStateProperties Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExpanded Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetExpanded Method (IConfiguration)

Gets whether this configuration's node is expanded in the specified pane of the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExpanded( _  
    ByVal WhichPane As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim WhichPane As System.Integer  
Dim value As System.Boolean  
  
value = instance.GetExpanded(WhichPane)
```

C#

```
System.bool GetExpanded(  
    System.int WhichPane  
)
```

C++/CLI

```
System.bool GetExpanded(  
& System.int WhichPane  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichPane

Valid options in [swFeatMgrPane_e](#):

- [swFeatMgrPaneTop](#)
- [swFeatMgrPaneBottom](#)

Return Value

True if node is expanded, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetExpanded](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::SetExpanded Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetExplodeStep Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetExplodeStep Method (IConfiguration)

Gets the specified explode step in this configuration's explode step sequence.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExplodeStep( _  
    ByVal ExplodeStepIndex As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplodeStepIndex As System.Integer  
Dim value As System.Object  
  
value = instance.GetExplodeStep(ExplodeStepIndex)
```

C#

```
System.object GetExplodeStep(  
    System.int ExplodeStepIndex  
)
```

C++/CLI

```
System.Object^ GetExplodeStep(  
& System.int ExplodeStepIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeStepIndex
Index of the explode step in the explode step sequence

Return Value

[Explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetExplodeStep](#).

Example

See the [IExplodeStep](#) examples.

Example

[Get Explode Step \(C#\)](#)
[Get Explode Step \(VB.NET\)](#)
[Get Explode Step \(VBA\)](#)

Remarks

Before calling this method, call [IConfiguration::GetNumberOfExplodeSteps](#) to get the number of explode steps in the explode step sequence.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)
[IConfiguration::DeleteExplodeStep Method](#)
[IConfiguration::IGetExplodeStep Method](#)
[IConfiguration::IAddExplodeStep Method](#)
[IConfiguration::AddRadialExplodeStep Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetID Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetID Method (IConfiguration)

Gets the configuration ID of this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetID() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer  
  
value = instance.GetID()
```

C#

```
System.int GetID()
```

C++/CLI

```
System.int GetID();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Configuration ID of this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetID](#).

Example

[Get ID of Active Configuration or Current Drawing Sheet \(VB.NET\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(VBA\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(C#\)](#)

Remarks

A configuration ID:

- is unique within the document.
- is persistent across SOLIDWORKS Design sessions and never changes, even if you [change the name of the configuration](#).
- can be used to identify a specific configuration when multiple configurations exist in a model.
- cannot be assigned by users.
- is not the same as a [persistent reference ID](#). You can get a configuration using its persistent reference ID, but you cannot get a configuration using this method.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNumberOfExplodeSteps Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetNumberOfExplodeSteps Method (IConfiguration)

Gets the number of explode steps for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNumberOfExplodeSteps() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer  
  
value = instance.GetNumberOfExplodeSteps()
```

C#

```
System.int GetNumberOfExplodeSteps()
```

C++/CLI

```
System.int GetNumberOfExplodeSteps();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of explode steps on this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetNumberOfExplodeSteps](#).

Remarks

Call this method before calling [IConfiguration::GetExplodeStep](#) or [IConfiguration::IGetExplodeStep](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)
[IConfiguration::DeleteExplodeStep Method](#)
[IConfiguration::!AddExplodeStep Method](#)
[IConfiguration::AddRadialExplodeStep Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNumberOfPartExplodeSteps Method (IConfiguration)

[See Also](#)



Gets the number of explode steps in the explode view of a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNumberOfPartExplodeSteps() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer
```

```
value = instance.GetNumberOfPartExplodeSteps()
```

C#

```
System.int GetNumberOfPartExplodeSteps()
```

C++/CLI

```
System.int GetNumberOfPartExplodeSteps();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of explode steps

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetNumberOfPartExplodeSteps](#).

Remarks

This method is valid only for the active configuration.

Before calling this method, call [IPartDoc::ShowExploded](#) to activate the explode view of interest.

Call this method before calling [IConfiguration::GetPartExplodeStep](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddPartExplodeStep Method \(\)](#)
[IConfiguration::GetCurrentPartExplodeViewName Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParameterCount Method (IConfiguration)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > IConfiguration Interface : GetParameterCount Method (IConfiguration)

Gets the number of parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParameterCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Integer

value = instance.GetParameterCount()
```

C#

```
System.int GetParameterCount()
```

C++/CLI

```
System.int GetParameterCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of parameters

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetParameterCount](#).

Remarks

Call this method before calling [IConfiguration::IGetParameters](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::ISetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::IGetConfigurationParams Method](#)
[IConfigurationManager::ISetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetParameters Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetParameters Method (IConfiguration)

Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub GetParameters( _
    ByRef Params As System.Object, _
    ByRef Values As System.Object _
)
```

Visual Basic (Usage)

```
Dim instance As IConfiguration
Dim Params As System.Object
Dim Values As System.Object

instance.GetParameters(Params, Values)
```

C#



```
void GetParameters(
    out System.object Params,
    out System.object Values
)
```

C++/CLI

```
void GetParameters(
    & [Out] System.Object^ Params,
    & [Out] System.Object^ Values
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Params

Array of the names of the parameters

Values

Array of the values of the parameters

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetParameters](#).

Remarks

The output values may not be accurate if a design table was not added to the model.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetParameterCount Method](#)
[IConfiguration::IGetParameters Method](#)
[IConfiguration::ISetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::IGetConfigurationParams Method](#)
[IConfigurationManager::ISetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetParent Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetParent Method (IConfiguration)

Gets the parent configuration of this derived configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetParent() As Configuration
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As Configuration
```

```
value = instance.GetParent()
```

C#

```
Configuration GetParent()
```

C++/CLI

```
Configuration^ GetParent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Parent configuration of this derived configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetParent](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Work with Configurations \(VBA\)](#)

Remarks

To determine if this configuration is derived, call [IConfiguration::IsDerived](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetChildren Method](#)
[IConfiguration::GetChildrenCount Method](#)
[IConfiguration::IGetChildren Method](#)
[IConfiguration::GetRootComponent3 Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPartExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetPartExplodeStep Method (IConfiguration)

Gets the specified explode step of an explode view of a multibody part.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPartExplodeStep( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetPartExplodeStep(Index)
```

C#

```
System.object GetPartExplodeStep(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetPartExplodeStep(  
&    System.int Index
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of the explode step (see **Remarks**)

Return Value

[IPartExplodeStep](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetPartExplodeStep](#).

Remarks

This method is valid only for the active configuration.

Before calling this method, call [IPartDoc::ShowExploded](#) to activate the explode view of interest.

To specify Index, call [IConfiguration::GetNumberOfPartExplodeSteps](#) to get the number of explode steps in the explode view.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddPartExplodeStep Method \(\)](#)
[IConfiguration::DeleteExplodeStep Method \(\)](#)
[IConfiguration::GetCurrentPartExplodeViewName Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0