

SOLIDWORKS API (.NET VBA C#) — Reference (54/337): IConfiguration (part 2 of 2)

SOLIDWORKS API Documentation (converted from CHM)

IConfiguration (part 2 of 2) (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRepresentationParent Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetRepresentationParent Method (IConfiguration)

Gets the Physical Product represented by this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRepresentationParent() As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String
```

```
value = instance.GetRepresentationParent()
```

C#

```
System.string GetRepresentationParent()
```

C++/CLI

```
System.String^ GetRepresentationParent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Physical Product/Family member name

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetRepresentationParent](#).

Remarks

This method is valid only:

- For [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#)
- and -
- If [IConfiguration::Get3DExperienceType](#) is not 0

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2020 SP3.1, Revision Number 28.3.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRootComponent Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetRootComponent Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::GetRootComponent3](#).

.NET Syntax

```
Function GetRootComponent() As System.Object
```



```
Dim instance As IConfiguration
Dim value As System.Object

value = instance.GetRootComponent()
```

```
System.Object GetRootComponent()
```

```
System.Object^ GetRootComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Root component and an [IComponent2](#) object

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetRootComponent](#).

Example

[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Names of Bodies in Multibody Part \(VBA\)](#)
[Get Transforms of Assembly Components \(VBA\)](#)
[Make All Assembly Components Visible \(VBA\)](#)
[Traverse Assembly At Component and Feature Levels \(VBA\)](#)

Remarks

Because every assembly has at least one configuration, you can use this method to begin traversing an assembly and its components.

This method returns a component object that is, essentially, a launching point for your assembly traversal. It is useful only for calling [IComponent2::GetChildren](#). Most other IComponent2 object functions do not work with this root component object and return null or Nothing or an error condition. You can call [IComponent2::IsRoot](#) to determine if you have the root component.

An IComponent2 object is based on the currently active configuration; one assembly configuration might suppress the component, while another might display it. Therefore, your traversal of IComponent2 objects might vary if you switch to a different configuration.

The order of calls used in a typical assembly traversal is:

1. [IConfigurationManager::ActiveConfiguration](#) (called only once)
2. [IConfiguration::GetRootComponent](#) (called only once)
3. [IComponent2::GetChildren](#) (called recursively)

From the SOLIDWORKS API, the IConfiguration and IComponent2 objects provide access to all the child components, their transforms, their bodies, as seen in a specific assembly configuration. The component body objects and component transforms can vary based on the configuration; therefore, you should traverse components for each configuration. For example, one assembly configuration might include an assembly-level feature that cuts a hole through each of the components in the assembly.

You can use [IComponent2::GetBody](#) on each assembly component to get the body of each component with the hole feature that was applied in this configuration. If you switch to a configuration without the assembly-level hole and re-traverse the component objects, then IComponent2::IGetBody returns the body object without the hole feature.

SOLIDWORKS generates an IAssemblyDoc [RegenNotify](#) event to indicate that a change might have taken place in one of your components. If you receive an IAssemblyDoc RegenNotify event, then you should re-traverse your components to be sure that your information is up-to-date.

If this method is called from the configuration of a part document, SOLIDWORKS returns null or Nothing.

You should use this method of assembly traversal to replace previous calls to the member class.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IAssemblyDoc::GetComponentCount Method](#)
[IAssemblyDoc::GetComponents Method](#)
[IAssemblyDoc::IGetComponents Method](#)
[IComponent2::GetChildren Method](#)
[IComponent2::IGetChildren Method](#)
[IComponent2::GetParent Method](#)

[IConfiguration::GetChildren Method](#)
[IConfiguration::GetParent Method](#)
[IConfiguration::IGetChildren Method](#)
[IConfiguration::IGetRootComponent2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetRootComponent3 Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetRootComponent3 Method (IConfiguration)

Gets the root component for this assembly configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRootComponent3( _  
    ByVal Resolve As System.Boolean _  
) As Component2
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim Resolve As System.Boolean  
Dim value As Component2  
  
value = instance.GetRootComponent3(Resolve)
```

C#

```
Component2 GetRootComponent3(  
    System.bool Resolve  
)
```

C++/CLI

```
Component2^ GetRootComponent3(  
& System.bool Resolve  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Resolve

True to load additional components required by this configuration, false to not

Return Value

- [IComponent2](#), if Resolve is set to true
- [IComponent2](#), if Resolve is set to false, and the configuration is active
- Null or Nothing, if Resolve is set to false and the configuration is not active

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetRootComponent3](#).

Example

[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Change Color of Component in Specific Display State \(VBA\)](#)
[Change Color of Component in Specific Display State \(VB.NET\)](#)
[Change Color of Component in Specific Display State \(C#\)](#)

Remarks

Because every assembly has at least one configuration, you can use this method to begin traversing an assembly and its components.

This method returns a component object that is, essentially, a launching point for your assembly traversal. It is useful only for calling [IComponent2::GetChildren](#). Most other IComponent2 object functions do not work with this root component object and return null or Nothing or an error condition. You can call [IComponent2::IsRoot](#) to determine if you have the root component.

An IComponent2 object is based on the currently active configuration; one assembly configuration might suppress the component, while another might display it. Therefore, your traversal of IComponent2 objects might vary if you switch to a different configuration.

The order of calls used in a typical assembly traversal is:

1. [IModelDoc2::GetConfigurationByName](#) (called only once)
2. [IConfiguration::GetRootComponent3](#) (called only once)
3. [IComponent2::GetChildren](#) (called recursively)

From the SOLIDWORKS API, the IConfiguration and IComponent2 objects provide access to all the child components, their transforms, their bodies, as seen in a specific assembly configuration. The component body objects and component transforms can vary based on the configuration; therefore, you should traverse components for each configuration. For example, one assembly configuration might include an assembly-level feature that cuts a hole through each of the components in the assembly.

You can use [IComponent2::GetBody](#) on each assembly component to get the body of each component with the hole feature that was applied in this configuration. If you switch to a configuration without the assembly-level hole and re-traverse the component objects, then IComponent2::GetBody returns the body object without the hole feature.

SOLIDWORKS generates an IAssemblyDoc [RegenNotify](#) event to indicate that a change might have taken place in one of your components. If you receive an IAssemblyDoc RegenNotify event, then you should re-traverse your components to be sure that your information is up-to-date.

If this method is called from the configuration of a part document, SOLIDWORKS returns null or Nothing.

You should use this method of assembly traversal to replace previous calls to the member class.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IAssemblyDoc::GetComponentCount Method](#)
[IAssemblyDoc::GetComponents Method](#)
[IAssemblyDoc::IGetComponents Method](#)
[IComponent2::GetChildren Method](#)
[IComponent2::IGetChildren Method](#)
[IComponent2::GetParent Method](#)
[IConfiguration::GetChildren Method](#)
[IConfiguration::GetParent Method](#)
[IConfiguration::IGetChildren Method](#)

Availability

SOLIDWORKS 2010 FCS, Revision Number 18.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetScene Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetScene Method (IConfiguration)

Gets the ISwScene object for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetScene() As SWScene
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As SWScene

value = instance.GetScene()
```

C#

```
SWScene GetScene()
```

C++/CLI

```
SWScene^ GetScene();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ISwScene](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetScene](#).

Example

[Get and Set Scene Properties \(VBA\)](#)
[Get and Set Scene Properties \(VB.NET\)](#)
[Get and Set Scene Properties \(C#\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IModelDocExtension::InsertScene Method \(\)](#)
[IModelDocExtension::DeleteScene Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetStreamName Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : GetStreamName Method (IConfiguration)

Gets the name of the stream for the current configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStreamName() As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String  
  
value = instance.GetStreamName()
```

C#

```
System.string GetStreamName()
```

C++/CLI

```
System.String^ GetStreamName();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Name of the stream

Visual Basic for Applications (VBA) Syntax

See [Configuration::GetStreamName](#).

Example

[Traverse Hierarchy of Configurations \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

HideNewComponentModels Property (IConfiguration)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : HideNewComponentModels Property (IConfiguration)

Gets or sets whether new components are hidden in this inactive configuration.

.NET Syntax

Visual Basic (Declaration)

Property HideNewComponentModels As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.HideNewComponentModels = value

value = instance.HideNewComponentModels
```

C#

```
System.bool HideNewComponentModels {get; set;}
```

C++/CLI

```
property System.bool HideNewComponentModels {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).**Property Value**

True hides new components, false create new components as shown in this configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::HideNewComponentModels](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)

Remarks

This setting is only valid when the configuration is not the active configuration.

This property applies only to assembly configurations. SOLIDWORKS always returns false when you get this property on a part configuration. This property has no effect on part configurations.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[SuppressNewComponentModels Property](#)

Availability

SOLIDWORKS 99, datecode 1999207

IAddExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : [IAddExplodeStep Method \(IConfiguration\)](#)

Adds a new explode step to the configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IAddExplodeStep( _  
    ByVal ExplDist As System.Double, _  
    ByVal ReverseDir As System.Boolean, _  
    ByVal RigidSubassembly As System.Boolean, _  
    ByVal ExplodeRelated As System.Boolean _  
) As ExplodeStep
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplDist As System.Double  
Dim ReverseDir As System.Boolean  
Dim RigidSubassembly As System.Boolean  
Dim ExplodeRelated As System.Boolean  
Dim value As ExplodeStep  
  
value = instance.IAddExplodeStep(ExplDist, ReverseDir, RigidSubassembly, ExplodeRelated)
```

C#

```
ExplodeStep IAddExplodeStep(  
    System.double ExplDist,  
    System.bool ReverseDir,  
    System.bool RigidSubassembly,  
    System.bool ExplodeRelated  
)
```

C++/CLI

```
ExplodeStep^ IAddExplodeStep(  
& System.double ExplDist,  
& System.bool ReverseDir,  
& System.bool RigidSubassembly,  
& System.bool ExplodeRelated  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplDist
Explode distance

ReverseDir
True to reverse the direction of the explode step, false to not

RigidSubassembly
True to explode entire sub assembly, false to explode just the selected component

ExplodeRelated
True to explode related components together, false to not

Return Value

Pointer to a newly created [explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration.IAddExplodeStep](#).

Remarks

Before calling this method, you must select by mark both an edge direction to explode along and a component to move. For example:

```
boolstatus = Model.Extension.SelectByID2('', 'EDGE', -0.011, 0.06, 0.084, True, 1, Nothing)

boolstatus = Model.Extension.SelectByID2('squarebolt1-1@Assem1', 'COMPONENT', 0, 0, 0, True, 2, Nothing, swSelectOptionDefault)
```

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)
[IConfiguration::DeleteExplodeStep Method](#)
[IConfiguration::GetExplodeStep Method](#)
[IConfiguration::GetNumberOfExplodeSteps Method](#)
[IConfiguration::IGetExplodeStep Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetChildren Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetChildren Method (IConfiguration)

Gets all of the children configurations of this derived configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetChildren( _
    ByVal NumChildren As System.Integer _
) As Configuration
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim NumChildren As System.Integer
Dim value As Configuration

value = instance.IGetChildren(NumChildren)
```

C#

```
Configuration IGetChildren(
    System.int NumChildren
)
```

C++/CLI

```
Configuration^ IGetChildren(
    & System.int NumChildren
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumChildren
Number of children configurations of this configuration

Return Value

- in-process, unmanaged C++: Pointer to an array containing the children [configurations](#) of this configuration
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

To determine if this configuration is derived, call [IConfiguration::IsDerived](#).

Before calling this method, call [IConfiguration::GetChildrenCount](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetChildren Method](#)
[IConfiguration::GetParent Method](#)
[IConfiguration::GetRootComponent3 Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetCustomProperties Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetCustomProperties Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::CustomPropertyManager](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetCustomProperties( _  
    ByVal NumProps As System.Integer, _  
    ByRef PropNames As System.String, _  
    ByRef PropValues As System.String, _  
    ByRef PropTypes As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim NumProps As System.Integer  
Dim PropNames As System.String  
Dim PropValues As System.String  
Dim PropTypes As System.Integer
```

```
instance.IGetCustomProperties(NumProps, PropNames, PropValues, PropTypes)
```

C#

```
void IGetCustomProperties(  
    System.int NumProps,  
    out System.string PropNames,  
    out System.string PropValues,  
    out System.int PropTypes  
)
```

C++/CLI

```
void IGetCustomProperties(  
& System.int NumProps,  
& [Out] System.String^ PropNames,  
& [Out] System.String^ PropValues,  
& [Out] System.int PropTypes  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NumProps

PropNames

PropValues

PropTypes

Visual Basic for Applications (VBA) Syntax

See [Configuration::IGetCustomProperties](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetDisplayStates Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetDisplayStates Method (IConfiguration)

Gets the names of the display states for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetDisplayStates( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetDisplayStates(Count)
```

C#

```
System.string IGetDisplayStates(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetDisplayStates(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of displays states for this configuration

Return Value

- in-process, unmanaged C++: Pointer to an array of names of the display states for this configuration
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [IConfiguration::GetDisplayStatesCount](#) to determine the size of array for the output.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)
[IConfiguration::CreateDisplayState Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::GetDisplayStates Method](#)
[IConfiguration::RenameDisplayState Method](#)
[IConfigurationManager::LinkDisplayStatesToConfigurations Property\(\)](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetExplodeStep Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetExplodeStep Method (IConfiguration)

Gets a pointer to the specified explode step in the configuration explode step sequence.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetExplodeStep( _  
    ByVal ExplodeStepIndex As System.Integer _  
) As ExplodeStep
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ExplodeStepIndex As System.Integer  
Dim value As ExplodeStep  
  
value = instance.IGetExplodeStep(ExplodeStepIndex)
```

C#

```
ExplodeStep IGetExplodeStep(  
    System.int ExplodeStepIndex  
)
```

C++/CLI

```
ExplodeStep^ IGetExplodeStep(  
& System.int ExplodeStepIndex  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ExplodeStepIndex

Index number of the explode step in the explode step sequence

Return Value

Pointer to the [explode step](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::IGetExplodeStep](#).

Remarks

Before calling this method, call [IConfiguration::GetNumberOfExplodeSteps](#) to get the number of explode steps in the sequence.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AddExplodeStep Method](#)
[IConfiguration::DeleteExplodeStep Method](#)
[IConfiguration::GetExplodeStep Method](#)
[IConfiguration::IAddExplodeStep Method](#)

Availability

SOLIDWORKS 2001 FCS, Revision Number 9.0

IGetParameters Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetParameters Method (IConfiguration)

Gets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetParameters( _
    ByVal NParamCount As System.Integer, _
    ByRef Params As System.String, _
    ByRef Values As System.String _
)
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim NParamCount As System.Integer
Dim Params As System.String
Dim Values As System.String

instance.IGetParameters(NParamCount, Params, Values)
```

C#

```
void IGetParameters(
    System.int NParamCount,
    out System.string Params,
    out System.string Values
)
```

C++/CLI

```
void IGetParameters(
    & System.int NParamCount,
    & [Out] System.String^ Params,
    & [Out] System.String^ Values
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NParamCount

Number of parameters

Params

- in-process, unmanaged C++: Pointer to an array of the names of the parameters of size NParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Values

- in-process, unmanaged C++: Pointer to an array of the values of the parameters of size NParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Call [IConfiguration::GetParameterCount](#) before calling this method.

The output values may not be accurate if a design table was not added to the model.

See Also

[IConfiguration Interface](#)

[IConfiguration Members](#)

[IConfiguration::GetParameters Method](#)

[IConfiguration::SetParameters Method](#)

[IConfiguration::SetParameters Method](#)

[IConfigurationManager::GetConfigurationParams Method](#)

[IConfigurationManager::GetConfigurationParamsCount Method](#)

[IConfigurationManager::IGetConfigurationParams Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetRootComponent Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetRootComponent Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::IGetRootComponent2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRootComponent() As Component
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As Component
```

```
value = instance.IGetRootComponent()
```

C#

```
Component IGetRootComponent()
```

C++/CLI

```
Component^ IGetRootComponent();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [Configuration::IGetRootComponent](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetRootComponent2 Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IGetRootComponent2 Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::IGetRootComponent3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRootComponent2() As Component2
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As Component2
```

```
value = instance.IGetRootComponent2()
```

C#

Component2 IGetRootComponent2()

C++/CLI

```
Component2^ IGetRootComponent2();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the root component, an [IComponent2](#) object

Visual Basic for Applications (VBA) Syntax

See [Configuration::IGetRootComponent2](#).

Remarks

Because every assembly has at least one configuration, you can use this method to begin traversing an assembly and its components.

This method returns a component object that is, essentially, a launching point for your assembly traversal. It is useful only for calling [IComponent2::IGetChildren](#). Most other IComponent2 object functions do not work with this root component object and return NULL or an error condition. You can call [IComponent2::IsRoot](#) to determine if you have the root component.

An IComponent2 object is based on the currently active configuration; one assembly configuration might suppress the component, while another might display it. Therefore, your traversal of IComponent2 objects might vary if you switch to a different configuration.

The order of calls used in a typical assembly traversal is:

1. [IConfigurationManager::ActiveConfiguration](#) (called only once)
2. [IConfiguration::IGetRootComponent2](#) (called only once)
3. [IComponent2::IGetChildren](#) (called recursively)

From the SOLIDWORKS API, the IConfiguration and IComponent2 objects provide access to all the child components, their transforms, their bodies, as seen in a specific assembly configuration. The component body objects and component transforms can vary based on the configuration; therefore, you should traverse components for each configuration. For example, one assembly configuration might include an assembly-level feature that cuts a hole through each of the components in the assembly.

You can use [IComponent2::IGetBody](#) on each assembly component to get the body of each component with the hole feature that was applied in this configuration. If you switch to a configuration without the assembly-level hole and re-traverse the component objects, then IComponent2::IGetBody returns the body object without the hole feature.

SOLIDWORKS generates an IAssemblyDoc [RegenNotify](#) event to indicate that a change might have taken place in one of your components. If you receive an IAssemblyDoc RegenNotify event, then you should re-traverse your components to be sure that your information is up-to-date.

If this method is called from the configuration of a part document, SOLIDWORKS returns NULL.

You should use this method of assembly traversal to replace previous calls to the member class.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IAssemblyDoc::GetComponentCount Method](#)
[IAssemblyDoc::GetComponents Method](#)
[IAssemblyDoc::IGetComponents Method](#)
[IConfiguration::GetChildren Method](#)
[IConfiguration::GetChildrenCount Method](#)
[IConfiguration::IGetChildren Method](#)
[IConfiguration::GetParent Method](#)
[IComponent2::GetChildren Method](#)
[IComponent2::GetParent Method](#)
[IComponent2::IGetChildren Method](#)
[IComponent2::IGetChildrenCount Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDefeature Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IsDefeature Method (IConfiguration)

Gets whether this configuration is a defeature configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDefeature() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IConfiguration  
Dim value As System.Boolean  
  
value = instance.IsDefeature()
```

C#

```
System.bool IsDefeature()
```

C++/CLI

```
System.bool IsDefeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this configuration is a defeature configuration, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::IsDefeature](#).

Remarks

A defeature configuration is a type of derived configuration. After using the Defeature tool to remove details from assemblies, multibody parts, and single-body parts, you can save the less-detailed model as a configuration and maintain references to the original part or assembly.

For more information see the **SOLIDWORKS Design user-interface help > Assemblies > Other Assembly Techniques > Defeature** topic.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::IsDerived Method \(\)](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDerived Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IsDerived Method (IConfiguration)

Gets whether this configuration is a derived configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IsDerived() As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IConfiguration  
Dim value As System.Boolean  
  
value = instance.IsDerived()
```

C#

```
System.bool IsDerived()
```

C++/CLI

```
System.bool IsDerived();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if this configuration is a derived configuration, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::IsDerived](#).

Example

[Traverse Hierarchy of Configurations \(VBA\)](#)
[Work with Configurations \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::IsDefeature Method \(\)](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsDirty Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IsDirty Method (IConfiguration)

Gets whether this configuration is dirty (i.e., needs to be updated).

.NET Syntax

Visual Basic (Declaration)

```
Function IsDirty() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Boolean
```

```
value = instance.IsDirty()
```

C#

```
System.bool IsDirty()
```

C++/CLI

```
System.bool IsDirty();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the configuration is dirty, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::IsDirty](#).

Example

[Are the Assembly Configurations Loaded \(C#\)](#)
[Are the Assembly Configurations Loaded \(VB.NET\)](#)
[Are the Assembly Configurations Loaded \(VBA\)](#)

Remarks

If the configuration is dirty, then you can update its date by:

1. [Activating the configuration](#).
2. [Saving the document](#) while the configuration is active.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::NeedsRebuild Property](#)
[IModelDoc2::GetSaveFlag Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)

Availability

SOLIDWORKS 2012 FCS, Revision Number 20.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetParameters Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : ISetParameters Method (IConfiguration)

Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetParameters( _  
    ByVal NParamCount As System.Integer, _  
    ByRef Params As System.String, _  
    ByRef Values As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim NParamCount As System.Integer  
Dim Params As System.String  
Dim Values As System.String  
  
instance.ISetParameters(NParamCount, Params, Values)
```

C#

```
void ISetParameters(  
    System.int NParamCount,  
    ref System.string Params,  
    ref System.string Values  
)
```

C++/CLI

```
void ISetParameters(  
& System.int NParamCount,  
& System.String^% Params,  
& System.String^% Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

NParamCount
Number of parameters
Params

- in-process, unmanaged C++: Pointer to an array of the names of the parameters of size NParamCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.
- Values
- in-process, unmanaged C++: Points to an array of the values for the parameters of size NParamCount
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

To get the number of parameters to set for this configuration, call [IConfiguration::GetParameterCount](#).

You can control these parameters in a part document:

- Dimension values. Specify the dimension name in params for example, D1@Sketch1) and the value in values (for example, 60.0mm).
- Suppression state of features. Specify the feature name in params (for example, \$STATE@Extrude2) and the suppression state in values (S=suppressed or U=Unsuppressed).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetParameterCount Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::IGetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::IGetConfigurationParams Method](#)
[IConfigurationManager::ISetConfigurationParams Method](#)
[IConfigurationManager::IConfigurationManager::SetConfigurationParams Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsLoaded Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IsLoaded Method (IConfiguration)

Gets whether a configuration is loaded.

.NET Syntax

Visual Basic (Declaration)

```
Function IsLoaded() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean
```

```
value = instance.IsLoaded()
```

C#

```
System.bool IsLoaded()
```

C++/CLI

```
System.bool IsLoaded();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if the configuration is loaded, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::IsLoaded](#).

Example

[Are the Assembly Configurations Loaded \(VB.NET\)](#)
[Are the Assembly Configurations Loaded \(VBA\)](#)
[Are the Assembly Configurations Loaded \(C#\)](#)

Remarks

When a configuration is activated, SOLIDWORKS loads it. For example, if a part or assembly document has three configurations named DC1, DC2, and DC3, and DC1 is the active configuration when you open the document, then this method will return true for DC1 and false for DC2 and DC3.

If you activate the configuration named DC2, then this method will return true for DC1 and DC2 because DC1 was previously loaded. If you activate the configuration named DC3, then this method will return true for DC1, DC2, and DC3 because DC1 and DC2 were previously loaded and DC3 is now loaded.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2009 SP03, Revision Number 17.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsSpeedPak Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : IsSpeedPak Method (IConfiguration)

Gets whether the configuration is a SpeedPak.

.NET Syntax

Visual Basic (Declaration)

```
Function IsSpeedPak() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

value = instance.IsSpeedPak()
```

C#

```
System.bool IsSpeedPak()
```

C++/CLI

```
System.bool IsSpeedPak();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if a SpeedPak, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::IsSpeedPak](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfigurationManager::AddSpeedPak Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LargeDesignReviewMark Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : LargeDesignReviewMark Property (IConfiguration)

Gets or sets whether to add display data to this configuration when the document is saved.

.NET Syntax

Visual Basic (Declaration)

Property LargeDesignReviewMark As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.LargeDesignReviewMark = value
value = instance.LargeDesignReviewMark
```

C#

```
System.bool LargeDesignReviewMark {get; set;}
```

C++/CLI

```
property System.bool LargeDesignReviewMark {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to add display data, false to not

Visual Basic for Applications (VBA) Syntax

See [Configuration::LargeDesignReviewMark](#).

Example

[Get and Set Large Design Review Marks for Configurations \(C#\)](#)
[Get and Set Large Design Review Marks for Configurations \(VB.NET\)](#)
[Get and Set Large Design Review Marks for Configurations \(VBA\)](#)

Remarks

This property is valid only if this configuration is one of multiple configurations defined for the assembly or part.

Before SOLIDWORKS 2019, this property specified whether to generate a display list for the configuration of an assembly when it is saved. As of SOLIDWORKS 2019, this property specifies whether to generate a display list for this configuration of:

- an assembly on save. If this property is set to true, the assembly configuration's display list is saved, making the configuration visible in Large Design Review mode. In the user interface, this corresponds to selecting the assembly's **ConfigurationManager** > *configuration_name* **RMB menu** > **Add Display Data Mark**.
- OR -
- a part on save. If this property is set to true, the part configuration's display list is saved, making the configuration visible in other applications, such as eDrawings. In the user interface, this corresponds to selecting the part's **ConfigurationManager** > *configuration_name* **RMB menu** > **Add Display Data Mark**.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IDocumentSpecification::ViewOnly_Property\(\)](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Lock Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Lock Property (IConfiguration)

Gets or sets whether the configuration is locked.

.NET Syntax

Visual Basic (Declaration)

Property Lock As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Boolean
```

```
instance.Lock = value
```

```
value = instance.Lock
```

C#

```
System.bool Lock {get; set;}
```

C++/CLI

```
property System.bool Lock {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True for locked configuration, false for unlocked configuration

Visual Basic for Applications (VBA) Syntax

See [Configuration::Lock](#).

Example

[Change Configuration Properties \(VBA\)](#)

Remarks

The names of configurations should not contain any of the special characters reserved by SOLIDWORKS.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

Name Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Name Property (IConfiguration)

Gets or sets the configuration name.

.NET Syntax

Visual Basic (Declaration)

Property Name As System.String

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.String
```

```
instance.Name = value
```

```
value = instance.Name
```

C#

```
System.string Name {get; set;}
```

C++/CLI

```
property System.String^ Name {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Configuration name

Visual Basic for Applications (VBA) Syntax

See [Configuration::Name](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Get Dimension Values in All Configurations \(VBA\)](#)
[Get Material Property Names \(VBA\)](#)
[Set Component State \(VBA\)](#)
[Set Dimensions to Mid-Tolerance \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(VB.NET\)](#)
[Get ID of Active Configuration or Current Drawing Sheet \(C#\)](#)

Remarks

The names of configurations should not contain any of the special characters reserved by SOLIDWORKS.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::AlternateName Property](#)

NeedsRebuild Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : NeedsRebuild Property (IConfiguration)

Gets whether the configuration needs to be rebuilt.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property NeedsRebuild As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

value = instance.NeedsRebuild
```

C#

```
System.bool NeedsRebuild {get;}
```

C++/CLI

```
property System.bool NeedsRebuild {
    System.bool get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the configuration needs to be rebuilt, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::NeedsRebuild](#).

Example

[Are the Assembly Configurations Loaded \(C#\)](#)
[Are the Assembly Configurations Loaded \(VB.NET\)](#)
[Are the Assembly Configurations Loaded \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IModelDocExtension::NeedsRebuild2 Property \(\)](#)
[IConfiguration::AddRebuildSaveMark Property \(\)](#)
[IModelDocExtension::EditRebuildAll Method \(\)](#)
[IModelDocExtension::ForceRebuildAll Method \(\)](#)
[IModelDoc2::EditRebuild3 Method \(\)](#)
[IModelDoc2::ForceRebuild3 Method \(\)](#)

Availability

SOLIDWORKS 2010 SP3, Revision Number 18.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

RenameDisplayState Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : RenameDisplayState Method (IConfiguration)

Renames a display state of this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function RenameDisplayState( _
    ByVal OldDisplayStateName As System.String, _
    ByVal NewDisplayStateName As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IConfiguration  
Dim OldDisplayStateName As System.String  
Dim NewDisplayStateName As System.String  
Dim value As System.Boolean  
  
value = instance.RenameDisplayState(OldDisplayStateName, NewDisplayStateName)
```

C#

```
System.bool RenameDisplayState(  
    System.string OldDisplayStateName,  
    System.string NewDisplayStateName  
)
```

C++/CLI

```
System.bool RenameDisplayState(  
& System.String^ OldDisplayStateName,  
& System.String^ NewDisplayStateName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

OldDisplayStateName
Existing name of the display state
NewDisplayStateName
New name for the display state

Return Value

True if the display state is renamed, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::RenameDisplayState](#).

Remarks

Use [IConfiguration::GetDisplayStates](#) or [IConfiguration::IGetDisplayStates](#) to get a list of the names of the existing display states for this configuration.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::ApplyDisplayState Method](#)
[IConfiguration::DeleteDisplayState Method](#)
[IConfiguration::CreateDisplayState Method](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

RepresentationShared Property (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : RepresentationShared Property (IConfiguration)

Gets or sets whether this [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#) Representation configuration is shared.

.NET Syntax

Visual Basic (Declaration)

Property RepresentationShared As System.Boolean

Visual Basic (Usage)

```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.RepresentationShared = value
value = instance.RepresentationShared
```

C#

```
System.bool RepresentationShared {get; set;}
```

C++/CLI

```
property System.bool RepresentationShared {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if this Representation configuration is shared, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::RepresentationShared](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

Select Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Select Method (IConfiguration)

Obsolete. Superseded by [IConfiguration::Select2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Select( _
    ByVal AppendFlag As System.Boolean _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim AppendFlag As System.Boolean
Dim value As System.Boolean
```

```
value = instance.Select(AppendFlag)
```

C#

```
System.bool Select(
    System.bool AppendFlag
)
```

C++/CLI

```
System.bool Select(  
& System.bool AppendFlag.  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

Visual Basic for Applications (VBA) Syntax

See [Configuration::Select](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Select2 Method (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Select2 Method (IConfiguration)

Selects the configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function Select2( _  
    ByVal AppendFlag As System.Boolean, _  
    ByVal SelectData As SelectData _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim AppendFlag As System.Boolean  
Dim SelectData As SelectData  
Dim value As System.Boolean
```

```
value = instance.Select2(AppendFlag, SelectData)
```

C#

```
System.bool Select2(  
    System.bool AppendFlag,  
    SelectData SelectData  
)
```

C++/CLI

```
System.bool Select2(  
& System.bool AppendFlag,  
& SelectData^ SelectData  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

AppendFlag

True appends the configuration to the selection list, false replaces the selection list with the configuration

SelectData

Pointer to the [ISelectData](#) object

Return Value

True if the configuration is selected, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::Select2](#).

Example

[Add Derived Configurations \(VBA\)](#)
[Add Derived Configurations \(VB.NET\)](#)
[Add Derived Configurations \(C#\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Set3DExperienceType Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : Set3DExperienceType Method (IConfiguration)

Converts this configuration in [SOLIDWORKS Design](#) connected to the 3DEXPERIENCE platform.

.NET Syntax

Visual Basic (Declaration)

```
Function Set3DExperienceType( _  
    ByVal IsPhysicalProduct As System.Boolean, _  
    ByVal RepresentationParentName As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim IsPhysicalProduct As System.Boolean  
Dim RepresentationParentName As System.String  
Dim value As System.Boolean  
  
value = instance.Set3DExperienceType(IsPhysicalProduct, RepresentationParentName)
```

C#

```
System.bool Set3DExperienceType(  
    System.bool IsPhysicalProduct,  
    System.string RepresentationParentName  
)
```

C++/CLI

```
System.bool Set3DExperienceType(  
& System.bool IsPhysicalProduct,  
& System.String^ RepresentationParentName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

IsPhysicalProduct

True to convert this configuration to a parent configuration (Physical Product/Family), false to convert it to a derived configuration (Representation)

RepresentationParentName

Parent Physical Product/Family name of derived configuration (Representation); valid only if IsPhysicalProduct is false

Return Value

True if configuration successfully converted, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::Set3DExperienceType](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::Get3DExperienceType Method \(\)](#)
[IConfiguration::AddCADFamilyConfiguration Method \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetColor Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : SetColor Method (IConfiguration)

Sets the color for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetColor( _  
    ByVal ColorIn As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim ColorIn As System.Integer  
Dim value As System.Boolean
```

```
value = instance.SetColor(ColorIn)
```

C#

```
System.bool SetColor(  
    System.int ColorIn  
)
```

C++/CLI

```
System.bool SetColor(  
& System.int ColorIn  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ColorIn
COLORREF value of the color

Return Value

True if the color is set, false if not

Visual Basic for Applications (VBA) Syntax

See [Configuration::SetColor](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExpanded Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : SetExpanded Method (IConfiguration)

Sets whether to expand this configuration's node in the specified pane of the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetExpanded( _  
    ByVal WhichPane As System.Integer, _  
    ByVal Expanded As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim WhichPane As System.Integer  
Dim Expanded As System.Boolean  
  
instance.SetExpanded(WhichPane, Expanded)
```

C#

```
void SetExpanded(  
    System.int WhichPane,  
    System.bool Expanded  
)
```

C++/CLI

```
void SetExpanded(  
& System.int WhichPane,  
& System.bool Expanded  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichPane

Display pane as defined in [swFeatMgrPane e](#):

- swFeatMgrPaneTop
- swFeatMgrPaneBottom

Expanded

True to expand the node, false to collapse it

Visual Basic for Applications (VBA) Syntax

See [Configuration::SetExpanded](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetExpanded Method \(\)](#)
[IConfigurationManager::SetExpanded Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetParameters Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : SetParameters Method (IConfiguration)

Sets the parameters (suppression state of features, suppression state or visibility of components, dimensions, and so on) for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetParameters( _  
    ByRef Params As System.Object, _  
    ByRef Values As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim Params As System.Object  
Dim Values As System.Object  
  
instance.SetParameters(Params, Values)
```

C#

```
void SetParameters(  
    ref System.object Params,  
    ref System.object Values  
)
```

C++/CLI

```
void SetParameters(  
& System.Object^% Params,  
& System.Object^% Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Params

Array of the names of the parameters

Values

Array of the values for the parameters

Visual Basic for Applications (VBA) Syntax

See [Configuration::SetParameters](#).

Remarks

You can control these parameters in a part document:

- Dimension values. Specify the dimension name in Params for example, D1@Sketch1) and the value in Values (for example, 60.0mm).
- Suppression state of features. Specify the feature name in Params (for example, \$STATE@Extrude2) and the suppression state in Values (S=Suppressed or R=Resolved).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::GetParameterCount Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::!GetParameters Method](#)
[IConfiguration::!SetParameters Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::!GetConfigurationParams Method](#)
[IConfigurationManager::!SetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)

Availability

ShowChildComponentsInBOM Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : ShowChildComponentsInBOM Property (IConfiguration)

Obsolete. Superseded by [IConfiguration::ChildComponentDisplayInBOM](#).

.NET Syntax

Visual Basic (Declaration)

Property ShowChildComponentsInBOM As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.ShowChildComponentsInBOM = value

value = instance.ShowChildComponentsInBOM
```

C#

```
System.bool ShowChildComponentsInBOM {get; set;}
```

C++/CLI

```
property System.bool ShowChildComponentsInBOM {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays child components in a BOM, false does not

Visual Basic for Applications (VBA) Syntax

See [Configuration::ShowChildComponentsInBOM](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)

Remarks

This property applies only to assembly configurations. SOLIDWORKS always returns false when you get this property on a part configuration. Setting this property on a part configuration has no effect.

How the components appear in the report is mainly controlled by the display format of a BOM. However, this property does affect the output format. Specifically, if this property is set to false, the report includes only the subassembly, not the component parts of this model configuration (even if the BOM report requests that all parts be displayed).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2000 SP01, Revision Number 8.1

SuppressNewComponentModels Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : SuppressNewComponentModels Property (IConfiguration)

Gets or sets whether new components are suppressed in this configuration.

.NET Syntax

Visual Basic (Declaration)

Property SuppressNewComponentModels As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.SuppressNewComponentModels = value

value = instance.SuppressNewComponentModels
```

C#

```
System.bool SuppressNewComponentModels {get; set;}
```

C++/CLI

```
property System.bool SuppressNewComponentModels {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True suppresses the new component in this configuration, false resolves it

Visual Basic for Applications (VBA) Syntax

See [Configuration::SuppressNewComponentModels](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)

Remarks

This setting applies only to inactive configurations.

This property applies only to assembly configurations. SOLIDWORKS always returns false when you get this property on a part configuration. Setting this property on a part configuration has no effect.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::HideNewComponentModels Property](#)
[IConfiguration::GetComponentSuppressionState Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SuppressNewFeatures Property (IConfiguration)

[See Also](#) [Example](#)



Gets or sets whether to suppress new features in this configuration.

.NET Syntax

Visual Basic (Declaration)

Property SuppressNewFeatures As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.SuppressNewFeatures = value

value = instance.SuppressNewFeatures
```

C#

```
System.bool SuppressNewFeatures {get; set;}
```

C++/CLI

```
property System.bool SuppressNewFeatures {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True suppresses the new feature in this configuration, false does not

Visual Basic for Applications (VBA) Syntax

See [Configuration::SuppressNewFeatures](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)

Remarks

This setting applies only to inactive configurations. This property applies to new mates and features for assembly configurations.

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (IConfiguration)

[See Also](#) [Example](#)



SolidWorks.Interop.sldworks Namespace > IConfiguration Interface : Type Property (IConfiguration)

Gets the type of configuration.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Integer
```

```
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of configuration as defined in [swConfigurationType_e](#)

Visual Basic for Applications (VBA) Syntax

See [Configuration::Type](#).

Example

[Are the Assembly Configurations Loaded \(C#\)](#)
[Are the Assembly Configurations Loaded \(VB.NET\)](#)
[Are the Assembly Configurations Loaded \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2010 SP4, Revision Number 18.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

UpdateSpeedPak Method (IConfiguration)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : UpdateSpeedPak Method (IConfiguration)

Updates the SpeedPak configuration for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function UpdateSpeedPak() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfiguration  
Dim value As System.Boolean
```

```
value = instance.UpdateSpeedPak()
```

C#

```
System.bool UpdateSpeedPak()
```

C++/CLI

```
System.bool UpdateSpeedPak();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True to update the SpeedPak configuration, false to not

Visual Basic for Applications (VBA) Syntax

See [Configuration::UpdateSpeedPak](#).

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)
[IConfiguration::IsSpeedPak Method](#)
[IConfigurationManager::AddSpeedPak Method](#)
[IAssemblyDoc::UpdateSpeedPak Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

UseAlternateNameInBOM Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : UseAlternateNameInBOM Property (IConfiguration)

Gets or sets whether the [alternate name](#) (i.e., user-specified name) is displayed in the bill of materials for this configuration.

.NET Syntax

Visual Basic (Declaration)

Property UseAlternateNameInBOM As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.UseAlternateNameInBOM = value

value = instance.UseAlternateNameInBOM
```

C#

```
System.bool UseAlternateNameInBOM {get; set;}
```

C++/CLI

```
property System.bool UseAlternateNameInBOM {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays the alternate name in the bill of materials, false does not

Visual Basic for Applications (VBA) Syntax

See [Configuration::UseAlternateNameInBOM](#).

Example

[Change Configuration Properties \(VBA\)](#)
[Traverse Hierarchy of Configurations \(VBA\)](#)
[Get List of Configurations \(C#\)](#)
[Get List of Configurations \(VB.NET\)](#)
[Get List of Configurations \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDescriptionInBOM Property (IConfiguration)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfiguration Interface](#) : UseDescriptionInBOM Property (IConfiguration)

Gets or sets whether the [description](#) of the configuration is displayed in the bill of materials.

.NET Syntax

Visual Basic (Declaration)

Property UseDescriptionInBOM As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfiguration
Dim value As System.Boolean

instance.UseDescriptionInBOM = value

value = instance.UseDescriptionInBOM
```

C#

```
System.bool UseDescriptionInBOM {get; set;}
```

C++/CLI

```
property System.bool UseDescriptionInBOM {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True displays the description of the configuration in the bill of materials, false does not

Visual Basic for Applications (VBA) Syntax

See [Configuration::UseDescriptionInBOM](#).

Example

[Display Configuration Description in Bill of Materials \(C#\)](#)
[Display Configuration Description in Bill of Materials \(VB.NET\)](#)
[Display Configuration Description in Bill of Materials \(VBA\)](#)

See Also

[IConfiguration Interface](#)
[IConfiguration Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0