

SOLIDWORKS API (.NET VBA C#) — Reference

(55/337): IConfigurationManager- IConnectionPointFeatureData

SOLIDWORKS API Documentation (converted from CHM)

IConfigurationManager (Type)

IConfigurationManager Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConfigurationManager Interface

Allows access to a configuration in a model.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IConfigurationManager
```

Visual Basic (Usage)

```
Dim instance As IConfigurationManager
```

C#

```
public interface IConfigurationManager
```

C++/CLI

```
public interface class IConfigurationManager
```

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)
[Work With Configurations \(VBA\)](#)

Accessors

[IModelDoc2::ConfigurationManager](#)

Access Diagram

[ConfigurationManager](#)

See Also

[IConfigurationManager Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IConfiguration Interface](#)

IConfigurationManager Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConfigurationManager Interface

The following tables list the members exposed by [IConfigurationManager](#).

Public Properties

Name	Description
 ActiveConfiguration	Gets the active configuration.

 Document	Gets the related model document.
 EnableConfigurationTree	Gets or sets whether to update the ConfigurationManager tree.
 LinkDisplayStatesToConfigurations	Gets or sets whether to link or unlink display states to or from the active configuration.
 ShowConfigurationDescriptions	Gets or sets whether to display configuration descriptions in ConfigurationManager.
 ShowConfigurationNames	Gets or sets whether to display configuration names in ConfigurationManager.
 ShowPreview	Gets or sets whether to display the preview of a selected configuration.

[Top](#)

Public Methods

Name	Description
 AddCADFamilyConfiguration	Adds the specified configuration to SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
 AddConfiguration	Obsolete. Superseded by IConfigurationManager.AddConfiguration2 .
 AddConfiguration2	Creates a new configuration.
 AddRebuildSaveMark	Adds marks indicating whether the specified configurations need to be rebuilt and their configuration data saved every time the model document is saved.
 AddSpeedPak	Obsolete. Superseded by IConfigurationManager.AddSpeedPak2 .
 AddSpeedPak2	Creates a SpeedPak configuration that includes all faces and the specified threshold of parts or bodies for the active assembly configuration.
 GetConfigurationParams	Gets the parameters for this configuration.
 GetConfigurationParamsCount	Gets the number of parameters for this configuration.
 IGetConfigurationParams	Gets the parameters for this configuration.
 ISetConfigurationParams	Sets the parameters for this configuration.
 RemoveMarkForAllConfigurations	Remove all marks indicating whether configurations need to be rebuilt and their configuration data saved every time the model document is saved.
 SetConfigurationParams	Sets the parameters for this configuration.
 SetExpanded	Sets whether to display and expand all of the configuration nodes in the specified pane of the ConfigurationManager.
 SortConfigurationTree	Specifies the order in which to list configurations in the ConfigurationManager.

[Top](#)

See Also

[IConfigurationManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IConfiguration Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IConfigurationManager Interface Methods

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IConfigurationManager Interface

For a list of all members of this type, see [IConfigurationManager members](#).

Public Methods

Name	Description
 AddCADFamilyConfiguration	Adds the specified configuration to SOLIDWORKS Design connected to the 3DEXPERIENCE platform .
 AddConfiguration	Obsolete. Superseded by IConfigurationManager.AddConfiguration2 .
 AddConfiguration2	Creates a new configuration.
 AddRebuildSaveMark	Adds marks indicating whether the specified configurations need to be rebuilt and their configuration data saved every time the model document is saved.
 AddSpeedPak	Obsolete. Superseded by IConfigurationManager.AddSpeedPak2 .
 AddSpeedPak2	Creates a SpeedPak configuration that includes all faces and the specified threshold of parts or bodies for the active assembly configuration.
 GetConfigurationParams	Gets the parameters for this configuration.
 GetConfigurationParamsCount	Gets the number of parameters for this configuration.

		
	IGetConfigurationParams	Gets the parameters for this configuration.
	ISetConfigurationParams	Sets the parameters for this configuration.
	RemoveMarkForAllConfigurations	Remove all marks indicating whether configurations need to be rebuilt and their configuration data saved every time the model document is saved.
	SetConfigurationParams	Sets the parameters for this configuration.
	SetExpanded	Sets whether to display and expand all of the configuration nodes in the specified pane of the ConfigurationManager.
	SortConfigurationTree	Specifies the order in which to list configurations in the ConfigurationManager.

[Top](#)

 See Also

[IConfigurationManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IConfiguration Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IConfigurationManager Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConfigurationManager Interface

For a list of all members of this type, see [IConfigurationManager members](#).

 Public Properties

Name	Description
 ActiveConfiguration	Gets the active configuration.
 Document	Gets the related model document.
 EnableConfigurationTree	Gets or sets whether to update the ConfigurationManager tree.
 LinkDisplayStatesToConfigurations	Gets or sets whether to link or unlink display states to or from the active configuration.
 ShowConfigurationDescriptions	Gets or sets whether to display configuration descriptions in ConfigurationManager.
 ShowConfigurationNames	Gets or sets whether to display configuration names in ConfigurationManager.
 ShowPreview	Gets or sets whether to display the preview of a selected configuration.

[Top](#)

 See Also

[IConfigurationManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IConfiguration Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ActiveConfiguration Property (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : ActiveConfiguration Property (IConfigurationManager)

Gets the active configuration.

 .NET Syntax

Visual Basic (Declaration)

ReadOnly Property ActiveConfiguration As Configuration

Visual Basic (Usage)



```
Dim instance As IConfigurationManager
Dim value As Configuration

value = instance.ActiveConfiguration
```

C#

```
Configuration ActiveConfiguration {get;}
```

C++/CLI

```
property Configuration^ ActiveConfiguration {  
    Configuration^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IConfiguration](#) object

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager.ActiveConfiguration](#).

Example

[Add Derived Configurations \(VBA\)](#)
[Get Dimension Values in All Configurations \(VBA\)](#)
[Get Display Dimensions, GTols, and Surface-finish Symbols \(VBA\)](#)
[Get Names of Bodies in Multibody Part \(VBA\)](#)
[Select Bodies \(VBA\)](#)
[Set All Assembly Components Lightweight or Resolved \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VBA\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(VB.NET\)](#)
[Traverse Assembly at Component and Feature Levels Using Recursion \(C#\)](#)

Remarks

If this document is an assembly, then you could use this property to begin your traversal of the assembly components by making a subsequent call to [IConfiguration::GetRootComponent](#) or [IConfiguration::IGetRootComponent2](#).

An [IComponent2](#) object is based on the currently active configuration; one assembly configuration might suppress the component, while another might display it. Therefore, your traversal of IComponent2 objects might vary if you switch to a different configuration. You should use this method of assembly traversal to replace previous calls to the Member class.

The order of calls used in a typical assembly traversal is:

1. [IConfigurationManager.ActiveConfiguration](#) (called only once)
2. [IConfiguration::GetRootComponent](#) or [IConfiguration::IGetRootComponent2](#) (called only once)
3. [IComponent2::GetChildren](#) or [IComponent::IGetChildren](#) (called recursively)

From the SOLIDWORKS API, the [IConfiguration](#) and [IComponent2](#) objects provide access to all the child components, their transforms, their bodies, as seen in a specific assembly configuration. The component body objects and component transforms can vary based on the configuration; therefore, you should traverse components for each configuration.

You can use [IComponent2::GetBody](#) on each assembly component to get the body of each component with the hole feature that was applied in this configuration. If you switch to a configuration without the assembly-level hole and re-traverse the component objects, then [IComponent2::IGetBody](#) returns the body object without the hole feature.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IAssemblyDoc::AddComponentConfiguration Method](#)
[IConfiguration::GetParameterCount Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::IGetParameters Method](#)
[IConfiguration::ISetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::AddConfiguration Method](#)
[IConfigurationManager::IGetConfigurationParams Method](#)
[IConfigurationManager::ISetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IModelDoc2::AddConfiguration3 Method](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

Adds the specified configuration to [SOLIDWORKS Design connected to the 3DEXPERIENCE platform](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddCADFamilyConfiguration( _
    ByVal Name As System.String, _
    ByVal Description As System.String, _
    ByVal IsPhysicalProduct As System.Boolean, _
    ByVal RepresentationParentName As System.String, _
    ByVal ConfigOptions As System.Integer, _
    ByVal ChildCompDisplayOption As System.Integer, _
    ByVal Rebuild As System.Boolean _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager
Dim Name As System.String
Dim Description As System.String
Dim IsPhysicalProduct As System.Boolean
Dim RepresentationParentName As System.String
Dim ConfigOptions As System.Integer
Dim ChildCompDisplayOption As System.Integer
Dim Rebuild As System.Boolean
Dim value As System.Object

value = instance.AddCADFamilyConfiguration(Name, Description, IsPhysicalProduct,
RepresentationParentName, ConfigOptions, ChildCompDisplayOption, Rebuild)
```

C#

```
System.object AddCADFamilyConfiguration(
    System.string Name,
    System.string Description,
    System.bool IsPhysicalProduct,
    System.string RepresentationParentName,
    System.int ConfigOptions,
    System.int ChildCompDisplayOption,
    System.bool Rebuild
)
```

C++/CLI

```
System.Object^ AddCADFamilyConfiguration(
    & System.String^ Name,
    & System.String^ Description,
    & System.bool IsPhysicalProduct,
    & System.String^ RepresentationParentName,
    & System.int ConfigOptions,
    & System.int ChildCompDisplayOption,
    & System.bool Rebuild
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the configuration to add

Description

Details about the configuration

IsPhysicalProduct

True to add a parent configuration (Physical Product), false to add a derived configuration (Representation)

RepresentationParentName

Parent Physical Product name of derived configuration (Representation); valid only if IsPhysicalProduct is false

ConfigOptions

Configuration options as defined by [swCADFamilyCfgOptions_e](#)

ChildCompDisplayOption

Child component display option as defined in [swChildComponentInBOMOption_e](#)

Rebuild

True to rebuild the model after adding this configuration, false to not

Return Value

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddCADFamilyConfiguration](#).

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfiguration::Get3DExperienceType Method \(\)](#)
[IConfiguration::Set3DExperienceType Method \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddConfiguration Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : AddConfiguration Method (IConfigurationManager)

Obsolete. Superseded by [IConfigurationManager::AddConfiguration2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddConfiguration( _  
    ByVal Name As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal Options As System.Integer, _  
    ByVal ParentConfigName As System.String, _  
    ByVal Description As System.String _  
    ) As Configuration
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim Name As System.String  
Dim Comment As System.String  
Dim AlternateName As System.String  
Dim Options As System.Integer  
Dim ParentConfigName As System.String  
Dim Description As System.String  
Dim value As Configuration  
  
value = instance.AddConfiguration(Name, Comment, AlternateName, Options, ParentConfigName,  
Description)
```

C#

```
Configuration AddConfiguration(  
    System.string Name,  
    System.string Comment,  
    System.string AlternateName,  
    System.int Options,  
    System.string ParentConfigName,  
    System.string Description  
)
```

C++/CLI

```
Configuration^ AddConfiguration(  
& System.String^ Name,  
& System.String^ Comment,  
& System.String^ AlternateName,
```

```
& System.int Options,  
& System.String^ ParentConfigName,  
& System.String^ Description  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the configuration

Comment

Comment displayed in Configuration Properties

AlternateName

Alternate configuration name (i.e., user-specified name); used if swConfigOption_UseAlternateName is set to true

Options

Combination of one or more Boolean configuration options as defined in [swConfigurationOptions2 e](#) (see **Remarks**)

ParentConfigName

Name of parent configuration

Description

Text that identifies the configuration

Return Value

Newly created [configuration](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddConfiguration](#).

Example

[Set Dimensions to Mid-Tolerance \(VBA\)](#)

[Add Derived Configurations \(VBA\)](#)

Remarks

The Options argument can be a combination of any of the following values:

- swConfigOption_SuppressByDefault - True if you want to suppress newly added features and mates in this configuration, false if not
- swConfigOption_HideByDefault - True if you want newly added components to be hidden, false if not
- swConfigOption_MinFeatureManager - True if you want newly added components to only display their component name in the FeatureManager design tree, false if you want newly added components to display their name and each of their features in the FeatureManager design tree

See Also

[IConfigurationManager Interface](#)

[IConfigurationManager Members](#)

[IAssembly::AddComponentConfiguration Method](#)

[IComponent2::Name2 Property](#)

[IConfiguration::AlternateName Property](#)

[IConfiguration::GetParent Method](#)

[IConfiguration::GetChildren Method](#)

[IConfiguration::IGetChildren Method](#)

[IConfiguration::Name Property](#)

[IConfigurationManager::ActiveConfiguration Property](#)

[IModelDoc2::AddConfiguration3 Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddConfiguration2 Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : AddConfiguration2 Method (IConfigurationManager)

Creates a new configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function AddConfiguration2( _  
    ByVal Name As System.String, _  
    ByVal Comment As System.String, _  
    ByVal AlternateName As System.String, _  
    ByVal Options As System.Integer, _
```

```

    ByVal ParentConfigName As System.String, _
    ByVal Description As System.String, _
    ByVal Rebuild As System.Boolean _
) As Configuration

```

Visual Basic (Usage)



```

Dim instance As IConfigurationManager
Dim Name As System.String
Dim Comment As System.String
Dim AlternateName As System.String
Dim Options As System.Integer
Dim ParentConfigName As System.String
Dim Description As System.String
Dim Rebuild As System.Boolean
Dim value As Configuration

```

```

value = instance.AddConfiguration2(Name, Comment, AlternateName, Options, ParentConfigName,
Description, Rebuild)

```

C#

```

Configuration AddConfiguration2(
    System.string Name,
    System.string Comment,
    System.string AlternateName,
    System.int Options,
    System.string ParentConfigName,
    System.string Description,
    System.bool Rebuild
)

```

C++/CLI

```

Configuration^ AddConfiguration2(
    & System.String^ Name,
    & System.String^ Comment,
    & System.String^ AlternateName,
    & System.int Options,
    & System.String^ ParentConfigName,
    & System.String^ Description,
    & System.bool Rebuild
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Name

Name of the configuration

Comment

Comment displayed in Configuration Properties

AlternateName

Alternate configuration name (i.e., user-specified name); used if Options is set to swConfigurationOptions2_e_UseAlternateName

Options

Combination of one or more configuration options as defined in [swConfigurationOptions2_e](#) (see **Remarks**)

ParentConfigName

Name of parent configuration

Description

Text that identifies the configuration

Rebuild

True to rebuild the model after adding this configuration, false to not

Return Value

Newly created [configuration](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddConfiguration2](#).

Example

[Work with Configurations \(VBA\)](#)

Remarks

The Options argument can be a combination of any of the following values:

- swConfigOption_SuppressByDefault
- swConfigOption_HideByDefault
- swConfigOption_MinFeatureManager
- swConfigOption_UseAlternateName

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IAssemblyDoc::AddComponentConfiguration Method \(\)](#)
[IModelDoc2::AddConfiguration3 Method \(\)](#)
[IConfiguration::GetChildren Method \(\)](#)
[IConfiguration::GetParent Method \(\)](#)
[IConfiguration::Name Property \(\)](#)
[IConfigurationManager::ActiveConfiguration Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddRebuildSaveMark Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : AddRebuildSaveMark Method (IConfigurationManager)

Adds marks indicating whether the specified configurations need to be rebuilt and their configuration data saved every time the model document is saved.

.NET Syntax

Visual Basic (Declaration)

```
Function AddRebuildSaveMark( _  
    ByVal WhichConfigurations As System.Integer, _  
    ByVal ConfigNames As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim WhichConfigurations As System.Integer  
Dim ConfigNames As System.Object  
Dim value As System.Boolean  
  
value = instance.AddRebuildSaveMark(WhichConfigurations, ConfigNames)
```

C#

```
System.bool AddRebuildSaveMark(  
    System.int WhichConfigurations,  
    System.object ConfigNames  
)
```

C++/CLI

```
System.bool AddRebuildSaveMark(  
& System.int WhichConfigurations,  
& System.Object^ ConfigNames  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichConfigurations

One of the following options in [swInConfigurationOpts_e](#):

- swAllConfiguration
- swSpecifyConfiguration
- swThisConfiguration
- swSpeedpakConfiguration

ConfigNames

Array of configuration names to which to apply the mark; valid only if WhichConfigurations is set to swInConfigurationOpts_e.swSpecifyConfiguration

Return Value

True if configurations marked successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddRebuildSaveMark](#).

Example

[Work With Configurations \(VBA\)](#)

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfiguration::NeedsRebuild Property \(\)](#)
[IModelDoc2::EditRebuild3 Method \(\)](#)
[IModelDocExtension::EditRebuildAll Method \(\)](#)
[IModelDocExtension::ForceRebuildAll Method \(\)](#)
[IConfiguration::AddRebuildSaveMark Property \(\)](#)
[IConfigurationManager::RemoveMarkForAllConfigurations Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

AddSpeedPak Method (IConfigurationManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : AddSpeedPak Method (IConfigurationManager)

Obsolete. Superseded by [IConfigurationManager::AddSpeedPak2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function AddSpeedPak( _  
    ByVal Type As System.Integer, _  
    ByVal PartThreshold As System.Double, _  
    ByVal FaceThreshold As System.Double _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim Type As System.Integer  
Dim PartThreshold As System.Double  
Dim FaceThreshold As System.Double  
Dim value As System.Object
```

```
value = instance.AddSpeedPak(Type, PartThreshold, FaceThreshold)
```

C#

```
System.object AddSpeedPak(  
    System.int Type,  
    System.double PartThreshold,  
    System.double FaceThreshold  
)
```

C++/CLI

```
System.Object^ AddSpeedPak(  
& System.int Type,  
& System.double PartThreshold,
```

```
& System.double FaceThreshold  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

- 1 = Geometry
- 2 = Graphics

PartThreshold

FaceThreshold

See **Remarks**

Return Value

SpeedPak [configuration](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddSpeedPak](#).

Remarks

The SOLIDWORKS Design user-interface control corresponding to the FaceThreshold parameter was removed from SOLIDWORKS 2013 and later. Regardless of the value that you specify for the FaceThreshold parameter, the value 0 is passed, which results in no faces being included for SpeedPak by a call to this method.

This method was revised as described so that existing applications that call this method will not fail.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfiguration::IsSpeedPak Method](#)
[IConfiguration::UpdateSpeedPak Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddSpeedPak2 Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : AddSpeedPak2 Method (IConfigurationManager)

Creates a SpeedPak configuration that includes all faces and the specified threshold of parts or bodies for the active assembly configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function AddSpeedPak2(  
    ByVal Type As System.Integer, _  
    ByVal PartThreshold As System.Double _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim Type As System.Integer  
Dim PartThreshold As System.Double  
Dim value As System.Object
```

```
value = instance.AddSpeedPak2(Type, PartThreshold)
```

C#

```
System.object AddSpeedPak2(  
    System.int Type,
```

```
System.double PartThreshold  
)
```

C++/CLI

```
System.Object^ AddSpeedPak2(  
& System.int Type,  
& System.double PartThreshold  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type

Selection type:

- 1 = Geometry
- 2 = Graphics

PartThreshold

1.0 >= Double value for part or body selection threshold >= 0.0; 1.0 selects nothing, and 0.0 selects all (see **Remarks**)

Return Value

SpeedPak [configuration](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::AddSpeedPak2](#).

Example

[Create a SpeedPak Configuration \(VBA\)](#)
[Create a Speedpak Configuration \(VB.NET\)](#)
[Create a Speedpak Configuration \(C#\)](#)

Remarks

PartThreshold corresponds to the value of the **Bodies to Include** slider on the SpeedPak PropertyManager page.

This method includes all faces in the SpeedPak configuration.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfiguration::IsSpeedPak Method](#)
[IConfiguration::UpdateSpeedPak Method](#)
[IAssemblyDoc::CreateSpeedPak Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Document Property (IConfigurationManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : Document Property (IConfigurationManager)

Gets the related model document.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Document As ModelDoc2
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim value As ModelDoc2
```

```
value = instance.Document
```

C#

```
ModelDoc2 Document {get;}
```

C++/CLI

```
property ModelDoc2^ Document {  
    ModelDoc2^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Document to get

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::Document](#).

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnableConfigurationTree Property (IConfigurationManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : EnableConfigurationTree Property (IConfigurationManager)

Gets or sets whether to update the ConfigurationManager tree.

.NET Syntax

Visual Basic (Declaration)

```
Property EnableConfigurationTree As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim value As System.Boolean  
  
instance.EnableConfigurationTree = value  
value = instance.EnableConfigurationTree
```

C#

```
System.bool EnableConfigurationTree {get; set;}
```

C++/CLI

```
property System.bool EnableConfigurationTree {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to update the ConfigurationManager tree, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::EnableConfigurationTree](#).

Remarks

This property is set to true by default. Setting this property to false will increase the performance of SOLIDWORKS when performing multiple operations that affect the ConfigurationManager tree, such as deleting configurations. However, set this property back to true after performing such operations so that the ConfigurationManager tree will update thereafter.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKSs 2007 SP4, Revision Number 15.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationParams Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : GetConfigurationParams Method (IConfigurationManager)

Gets the parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationParams( _  
    ByVal ConfigName As System.String, _  
    ByRef Params As System.Object, _  
    ByRef Values As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim ConfigName As System.String  
Dim Params As System.Object  
Dim Values As System.Object  
Dim value As System.Boolean  
  
value = instance.GetConfigurationParams(ConfigName, Params, Values)
```

C#

```
System.bool GetConfigurationParams(  
    System.string ConfigName,  
    out System.object Params,  
    out System.object Values  
)
```

C++/CLI

```
System.bool GetConfigurationParams(  
& System.String^ ConfigName,  
& [Out] System.Object^ Params,  
& [Out] System.Object^ Values  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName
Name of the configuration

Params

Array of the names of the parameters for this configuration

Values

Array of values of the parameters for this configuration

Return Value

True if successful in getting the names and values of the parameters for this configuration, false if unsuccessful

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::GetConfigurationParams](#).

Example

[Extract Configuration-specific Parameters \(VBA\)](#)

Remarks

The output values may not be accurate if a design table was not added to the model.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfiguration::SetParameters Method](#)
[IConfiguration::GetParameterCount Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConfigurationParamsCount Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : GetConfigurationParamsCount Method (IConfigurationManager)

Gets the number of parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConfigurationParamsCount( _  
    ByVal ConfigName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim ConfigName As System.String  
Dim value As System.Integer
```

```
value = instance.GetConfigurationParamsCount(ConfigName)
```

C#

```
System.int GetConfigurationParamsCount(  
    System.string ConfigName  
)
```

C++/CLI

```
System.int GetConfigurationParamsCount(  
& System.String^ ConfigName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName
Name of the configuration

Return Value

Number of parameters in this configuration

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::GetConfigurationParamsCount](#).

Example

[Get Configuration Parameters \(C++\)](#)

Remarks

Call this method before calling [IConfigurationManager::!GetConfigurationParams](#).

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::!SetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)
[IConfiguration::GetParameterCount Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::!GetParameters Method](#)
[IConfiguration::!SetParameters Method](#)
[IConfiguration::SetParameters Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConfigurationParams Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : IGetConfigurationParams Method (IConfigurationManager)

Gets the parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConfigurationParams( _  
    ByVal ConfigName As System.String, _  
    ByVal ParamCount As System.Integer, _  
    ByRef ParamNames As System.String, _  
    ByRef ParamValues As System.String _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As IConfigurationManager  
Dim ConfigName As System.String  
Dim ParamCount As System.Integer  
Dim ParamNames As System.String  
Dim ParamValues As System.String
```



```
Dim value As System.Boolean
```

```
value = instance.IGetConfigurationParams(ConfigName, ParamCount, ParamNames, ParamValues)
```

C#

```
System.bool IGetConfigurationParams(  
    System.string ConfigName,  
    System.int ParamCount,  
    out System.string ParamNames,  
    out System.string ParamValues  
)
```

C++/CLI

```
System.bool IGetConfigurationParams(  
& System.String^ ConfigName,  
& System.int ParamCount,  
& [Out] System.String^ ParamNames,  
& [Out] System.String^ ParamValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName

Name of the configuration

ParamCount

Number of parameters for this configuration

ParamNames

- in-process, unmanaged C++: Pointer to an array of the names of the parameters for this configuration of size ParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

ParamValues

- in-process, unmanaged C++: Pointer to an array of values of the parameters for this configuration of size ParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if successful in getting the names and values of the parameters for this configuration, false if unsuccessful

Example

[Get Configuration Parameters \(C++\)](#)

Remarks

Call [IConfigurationManager::GetConfigurationParamsCount](#) before calling this method to get the value for ParamCount.

The output values may not be accurate if a design table was not added to the model.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)
[IConfiguration::SetParameters Method](#)
[IConfiguration::ISetParameters Method](#)
[IConfiguration::IGetParameters Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::GetParameterCount Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0



Sets the parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function ISetConfigurationParams( _  
    ByVal ConfigName As System.String, _  
    ByVal ParamCount As System.Integer, _  
    ByRef ParamNames As System.String, _  
    ByRef ParamValues As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim ConfigName As System.String  
Dim ParamCount As System.Integer  
Dim ParamNames As System.String  
Dim ParamValues As System.String  
Dim value As System.Boolean  
  
value = instance.ISetConfigurationParams(ConfigName, ParamCount, ParamNames, ParamValues)
```

C#

```
System.bool ISetConfigurationParams(  
    System.string ConfigName,  
    System.int ParamCount,  
    ref System.string ParamNames,  
    ref System.string ParamValues  
)
```

C++/CLI

```
System.bool ISetConfigurationParams(  
& System.String^ ConfigName,  
& System.int ParamCount,  
& System.String^% ParamNames,  
& System.String^% ParamValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName

Name of the configuration

ParamCount

Number of parameters

ParamNames

- in-process, unmanaged C++: Pointer to an array of the names of the parameters for this configuration of size ParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

ParamValues

- in-process, unmanaged C++: Pointer to an array of values for the parameters for this configuration of size ParamCount

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

True if the names and values of the parameters for this configuration are set, false if unsuccessful

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::GetConfigurationParamsCount Method](#)
[IConfigurationManager::IGetConfigurationParams Method](#)
[IConfigurationManager::SetConfigurationParams Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)
[IConfiguration::SetParameters Method](#)

[IConfiguration::ISetParameters Method](#)
[IConfiguration::IGetParameters Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::GetParameterCount Method](#)

Availability

SOLIDWORKS 2004 SP3, Revision Number 12.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

LinkDisplayStatesToConfigurations Property (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : LinkDisplayStatesToConfigurations Property (IConfigurationManager)

Gets or sets whether to link or unlink display states to or from the active configuration.

.NET Syntax

Visual Basic (Declaration)

Property LinkDisplayStatesToConfigurations As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfigurationManager
Dim value As System.Boolean

instance.LinkDisplayStatesToConfigurations = value
value = instance.LinkDisplayStatesToConfigurations
```

C#

```
System.bool LinkDisplayStatesToConfigurations {get; set;}
```

C++/CLI

```
property System.bool LinkDisplayStatesToConfigurations {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep specific display states linked to the active configuration, false to unlink specific display states and make all display states available to the active configuration

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::LinkDisplayStatesToConfigurations](#).

Example

[Link Display States to Configurations \(C#\)](#)
[Link Display States to Configurations \(VB.NET\)](#)
[Link Display States to Configurations \(VBA\)](#)

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IComponent2::ReferencedDisplayState Property \(\)](#)
[IConfiguration::ApplyDisplayState Method \(\)](#)
[IConfiguration::CopyDisplayStateFromConfiguration Method \(\)](#)
[IConfiguration::CreateDisplayState Method \(\)](#)
[IConfiguration::GetDisplayStates Method \(\)](#)
[IConfiguration::IGetDisplayStates Method \(\)](#)
[IModelDocExtension::LinkedDisplayState Property \(\)](#)
[IPartDoc::RemoveAllDisplayStates Method \(\)](#)
[IAssemblyDoc ActiveDisplayStateChangePostNotify Event](#)
[IAssemblyDoc ActiveDisplayStateChangePreNotify Event](#)
[IPartDoc ActiveDisplayStateChangePostNotify Event](#)
[IPartDoc ActiveDisplayStateChangePreNotify Event](#)

Availability

SOLIDWORKS 2012 SP03, Revision Number 20.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

RemoveMarkForAllConfigurations Method (IConfigurationManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : RemoveMarkForAllConfigurations Method (IConfigurationManager)

Remove all marks indicating whether configurations need to be rebuilt and their configuration data saved every time the model document is saved.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveMarkForAllConfigurations() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim value As System.Boolean
```

```
value = instance.RemoveMarkForAllConfigurations()
```

C#

```
System.bool RemoveMarkForAllConfigurations()
```

C++/CLI

```
System.bool RemoveMarkForAllConfigurations();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

True if marks removed successfully, false if not

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::RemoveMarkForAllConfigurations](#).

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::AddRebuildSaveMark Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetConfigurationParams Method (IConfigurationManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : SetConfigurationParams Method (IConfigurationManager)

Sets the parameters for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function SetConfigurationParams( _  
    ByVal ConfigName As System.String, _  
    ByRef ParamNames As System.Object, _
```

```
ByRef ParamValues As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim ConfigName As System.String  
Dim ParamNames As System.Object  
Dim ParamValues As System.Object  
Dim value As System.Boolean
```

```
value = instance.SetConfigurationParams(ConfigName, ParamNames, ParamValues)
```

C#

```
System.bool SetConfigurationParams(  
    System.string ConfigName,  
    ref System.object ParamNames,  
    ref System.object ParamValues  
)
```

C++/CLI

```
System.bool SetConfigurationParams(  
& System.String^ ConfigName,  
& System.Object^% ParamNames,  
& System.Object^% ParamValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ConfigName

Name of the configuration (see **Remarks**)

ParamNames

Array of the names of the parameters for ConfigName (see **Remarks**)

ParamValues

Array of values for the parameters for ConfigName (see **Remarks**)

Return Value

True if the names and values of parameters for the specified configuration are set, false if not

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::SetConfigurationParams](#).

Remarks

In ConfigName, if you specify the name of a configuration that:

- does not exist, this method creates a new configuration with ParamNames and ParamValues.
- exists, this method sets that configuration with ParamNames and ParamValues.

You can control these parameters in a part document:

- Dimension values. Specify the dimension name in ParamNames for example, D1@Sketch1) and the value in ParamValues (for example, 60.0mm).
- Suppression state of features. Specify the feature name in ParamNames (for example, \$STATE@Extrude2) and the suppression state in ParamValues (S=Suppressed or R=Resolved).

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfigurationManager::!SetConfigurationParams Method](#)
[IConfigurationManager::!GetConfigurationParams Method](#)
[IConfigurationManager::!GetConfigurationParamsCount Method](#)
[IConfigurationManager::GetConfigurationParams Method](#)
[IConfigurationManager::ActiveConfiguration Property](#)
[IConfiguration::SetParameters Method](#)
[IConfiguration::!SetParameters Method](#)
[IConfiguration::!GetParameters Method](#)
[IConfiguration::GetParameters Method](#)
[IConfiguration::GetParameterCount Method](#)

Availability

SetExpanded Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : SetExpanded Method (IConfigurationManager)

Sets whether to display and expand all of the configuration nodes in the specified pane of the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetExpanded( _  
    ByVal WhichPane As System.Integer, _  
    ByVal Expand As System.Boolean _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim WhichPane As System.Integer  
Dim Expand As System.Boolean  
  
instance.SetExpanded(WhichPane, Expand)
```

C#

```
void SetExpanded(  
    System.int WhichPane,  
    System.bool Expand  
)
```

C++/CLI

```
void SetExpanded(  
& System.int WhichPane,  
& System.bool Expand  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichPane

Display pane as defined in [swFeatMgrPane_e](#):

- swFeatMgrPaneTop
- swFeatMgrPaneBottom

Expand

True to expand all of the nodes, false to collapse them

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::SetExpanded](#).

Example

[Work With Configurations \(VBA\)](#)

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)
[IConfiguration::SetExpanded Method\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : ShowConfigurationDescriptions Property (IConfigurationManager)

Gets or sets whether to display configuration descriptions in ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

Property ShowConfigurationDescriptions As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConfigurationManager
Dim value As System.Boolean

instance.ShowConfigurationDescriptions = value

value = instance.ShowConfigurationDescriptions
```

C#

```
System.bool ShowConfigurationDescriptions {get; set;}
```

C++/CLI

```
property System.bool ShowConfigurationDescriptions {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display configuration descriptions, false to not

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::ShowConfigurationDescriptions](#).

Example

[Work With Configurations \(VBA\)](#)

Remarks

If you set this property to false, you cannot set [IConfigurationManager::ShowConfigurationNames](#) to false. Either the name or the description of a configuration must be shown.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ShowConfigurationNames Property (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : ShowConfigurationNames Property (IConfigurationManager)

Gets or sets whether to display configuration names in ConfigurationManager.

.NET Syntax

```
Property ShowConfigurationNames As System.Boolean
```



```
Dim instance As IConfigurationManager
Dim value As System.Boolean

instance.ShowConfigurationNames = value

value = instance.ShowConfigurationNames
```

```
System.bool ShowConfigurationNames {get; set;}
```

```
property System.bool ShowConfigurationNames {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display configuration names, false to not

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::ShowConfigurationNames](#).

Example

[Work With Configurations \(VBA\)](#)

Remarks

If you set this property to false, you cannot set [IConfigurationManager::ShowConfigurationDescriptions](#) to false. Either the name or the description of a configuration must be shown.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

ShowPreview Property (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : ShowPreview Property (IConfigurationManager)

Gets or sets whether to display the preview of a selected configuration.

.NET Syntax

```
Property ShowPreview As System.Boolean
```



```
Dim instance As IConfigurationManager
Dim value As System.Boolean
```

```
instance.ShowPreview = value  
value = instance.ShowPreview
```

C#

```
System.bool ShowPreview {get; set;}
```

C++/CLI

```
property System.bool ShowPreview {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to display the preview, false to restore the original ConfigurationManager

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::ShowPreview](#).

Example

[Work With Configurations \(VBA\)](#)

Remarks

Before using this property, you must activate and select the configuration to preview. If multiple configurations are selected, the last one's preview is displayed. The preview displays in the configuration pane below or above the pane of the selected configuration.

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SortConfigurationTree Method (IConfigurationManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConfigurationManager Interface](#) : SortConfigurationTree Method (IConfigurationManager)

Specifies the order in which to list configurations in the ConfigurationManager.

.NET Syntax

Visual Basic (Declaration)

```
Sub SortConfigurationTree( _  
    ByVal InSelType As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As IConfigurationManager  
Dim InSelType As System.Integer  
  
instance.SortConfigurationTree(InSelType)
```

C#

```
void SortConfigurationTree(  
    System.int InSelType  
)
```

C++/CLI

```
void SortConfigurationTree(  
&    System.int InSelType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

InSelType

Order in which to list configurations in the ConfigurationManager as defined in [swConfigTreeSortType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConfigurationManager::SortConfigurationTree](#).

Example

[Specify Order of Configurations \(C#\)](#)
[Specify Order of Configurations \(VB.NET\)](#)
[Specify Order of Configurations \(VBA\)](#)

See Also

[IConfigurationManager Interface](#)
[IConfigurationManager Members](#)

Availability

SOLIDWORKS 2017 FCS, Revision Number 25.0

ICorrelationPointFeatureData (Type)

ICorrelationPointFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICorrelationPointFeatureData Interface

Allows access to a correlation point feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

Visual Basic Syntax

Visual Basic (Declaration)

```
Public Interface ICorrelationPointFeatureData
```

Visual Basic (Usage)



```
Dim instance As ICorrelationPointFeatureData
```

C#

```
public interface ICorrelationPointFeatureData
```

C++/CLI

```
public interface class ICorrelationPointFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CorrelationPointFeatureData](#).

Example

[Get and Set Correlation Point Feature Data \(VBA\)](#)
[Get and Set Correlation Point Feature Data \(VB.NET\)](#)
[Get and Set Correlation Point Feature Data \(C#\)](#)

Remarks

See SOLIDWORKS Help for more information about correlation point features.

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[CorrelationPointFeatureData](#)

See Also

[ICorrelationPointFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCorrelationPoint Method](#)

ICorrelationPointFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICorrelationPointFeatureData Interface

The following tables list the members exposed by [ICorrelationPointFeatureData](#).

Public Properties

Name	Description
 Direction	Gets the x, y, z coordinates of the direction vector of this connection point feature.
 ElectricalPinID	Gets and sets the electrical pin ID of this connection point feature.
 Location	Gets the x,y,z coordinates of this connection point feature.
 Name2	Gets and sets the name of this connection point feature.
 PortID	Gets and sets the port ID for this connection point feature.
 RouteDiameter	Gets and sets the route diameter at this connection point.
 RouteSubType	Gets and sets the route sub-type of this connection point feature.
 RouteType	Gets and sets the route type of this connection point feature.
 StubLength	Gets and sets the stub length that extends from the connector or fitting when inserted into routes.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this connection point feature.
 IAccessSelections	Allows access to the selections that describe this connection point feature.
 ReleaseSelectionAccess	Releases access to selections that describe this connection point feature.

[Top](#)

See Also

[IConnectionPointFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertConnectionPoint Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IConnectionPointFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConnectionPointFeatureData Interface

For a list of all members of this type, see [IConnectionPointFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this connection point feature.
 IAccessSelections	Allows access to the selections that describe this connection point feature.
 ReleaseSelectionAccess	Releases access to selections that describe this connection point feature.

[Top](#)

See Also

[IConnectionPointFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertConnectionPoint Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IConnectionPointFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConnectionPointFeatureData Interface

For a list of all members of this type, see [IConnectionPointFeatureData members](#).

Public Properties

Name	Description
 Direction	Gets the x, y, z coordinates of the direction vector of this connection point feature.

 ElectricalPinID	Gets and sets the electrical pin ID of this connection point feature.
 Location	Gets the x,y,z coordinates of this connection point feature.
 Name2	Gets and sets the name of this connection point feature.
 PortID	Gets and sets the port ID for this connection point feature.
 RouteDiameter	Gets and sets the route diameter at this connection point.
 RouteSubType	Gets and sets the route sub-type of this connection point feature.
 RouteType	Gets and sets the route type of this connection point feature.
 StubLength	Gets and sets the stub length that extends from the connector or fitting when inserted into routes.

[Top](#)

See Also

[IConnectionPointFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertConnectionPoint Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IConnectionPointFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : AccessSelections Method (IConnectionPointFeatureData)

Allows access to the selections that describe this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code.](#)

Parameters

TopDoc
 Top-level document
Component
 Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [IConnectionPointFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)
[IConnectionPointFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Direction Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : Direction Property (IConnectionPointFeatureData)

Gets the x, y, z coordinates of the direction vector of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Direction As System.Object

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.Object
```

```
value = instance.Direction
```

C#

```
System.Object Direction {get;}
```

C++/CLI

```
property System.Object^ Direction {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of doubles of the coordinates of the direction vector of this connection point

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::Direction](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ElectricalPinID Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : ElectricalPinID Property (IConnectionPointFeatureData)

Gets and sets the electrical pin ID of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

Property ElectricalPinID As System.String

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.String
```

```
instance.ElectricalPinID = value
```

```
value = instance.ElectricalPinID
```

C#

```
System.string ElectricalPinID {get; set;}
```

C++/CLI

```
property System.String^ ElectricalPinID {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Electrical pin ID

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::ElectricalPinID](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

IAccessSelections Method (IConnectionPointFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : IAccessSelections Method (IConnectionPointFeatureData)

Allows access to the selections that describe this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document

Component

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [IConnectionPointFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[IConnectionPointFeatureData Interface](#)

[IConnectionPointFeatureData Members](#)

[IConnectionPointFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Location Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : Location Property (IConnectionPointFeatureData)

Gets the x,y,z coordinates of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Location As System.Object

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData
Dim value As System.Object

value = instance.Location
```

C#

```
System.Object Location {get;}
```

C++/CLI

```
property System.Object^ Location {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Coordinates of this feature

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::Location](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Name2 Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : Name2 Property (IConnectionPointFeatureData)

Gets and sets the name of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Name2 As System.String
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.String  
  
instance.Name2 = value  
  
value = instance.Name2
```

C#

```
System.string Name2 {get; set;}
```

C++/CLI

```
property System.String^ Name2 {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of this feature

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::Name2](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

PortID Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : PortID Property (IConnectionPointFeatureData)

Gets and sets the port ID for this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Property PortID As System.String
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.String  
  
instance.PortID = value
```

```
value = instance.PortID
```

C#

```
System.string PortID {get; set;}
```

C++/CLI

```
property System.String^ PortID {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Port ID of this feature

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::PortID](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (IConnectionPointFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : ReleaseSelectionAccess Method (IConnectionPointFeatureData)

Releases access to selections that describe this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::ReleaseSelectionAccess](#).

Remarks

[IConnectionPointFeatureData::AccessSelections](#) and [IConnectionPointFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define the connection point feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

RouteDiameter Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : RouteDiameter Property (IConnectionPointFeatureData)

Gets and sets the route diameter at this connection point.

.NET Syntax

Visual Basic (Declaration)

```
Property RouteDiameter As System.Double
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.Double
```

```
instance.RouteDiameter = value
```

```
value = instance.RouteDiameter
```

C#

```
System.double RouteDiameter {get; set;}
```

C++/CLI

```
property System.double RouteDiameter {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Route diameter at this connection point

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::RouteDiameter](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

RouteSubType Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : RouteSubType Property (IConnectionPointFeatureData)

Gets and sets the route sub-type of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

```
Property RouteSubType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData  
Dim value As System.Integer
```

```
instance.RouteSubType = value
```

```
value = instance.RouteSubType
```

C#

```
System.int RouteSubType {get; set;}
```

C++/CLI

```
property System.int RouteSubType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Electrical route sub-type as defined in [swElectricalSubType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData.RouteSubType](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

RouteType Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : RouteType Property (IConnectionPointFeatureData)

Gets and sets the route type of this connection point feature.

.NET Syntax

Visual Basic (Declaration)

Property RouteType As System.Integer

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData
Dim value As System.Integer
```

```
instance.RouteType = value
```

```
value = instance.RouteType
```

C#

```
System.int RouteType {get; set;}
```

C++/CLI

```
property System.int RouteType {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Route type as defined in [swModelRouteType_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::RouteType](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

StubLength Property (IConnectionPointFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConnectionPointFeatureData Interface](#) : StubLength Property (IConnectionPointFeatureData)

Gets and sets the stub length that extends from the connector or fitting when inserted into routes.

.NET Syntax

Visual Basic (Declaration)

Property StubLength As System.Double

Visual Basic (Usage)



```
Dim instance As IConnectionPointFeatureData
Dim value As System.Double

instance.StubLength = value

value = instance.StubLength
```

C#

```
System.double StubLength {get; set;}
```

C++/CLI

```
property System.double StubLength {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of stub that extends from this connection point

Visual Basic for Applications (VBA) Syntax

See [ConnectionPointFeatureData::StubLength](#).

Example

[Get and Set Connection Point Feature Data \(VBA\)](#)
[Get and Set Connection Point Feature Data \(VB.NET\)](#)
[Get and Set Connection Point Feature Data \(C#\)](#)

See Also

[IConnectionPointFeatureData Interface](#)
[IConnectionPointFeatureData Members](#)

Availability

SOLIDWORKS 2010 SP01, Revision Number 18.1