

SOLIDWORKS API (.NET VBA C#) — Reference

(56/337): IConvertSolidFeatureData- ICoordinateSystemElement

SOLIDWORKS API Documentation (converted from CHM)

IConvertSolidFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IConvertSolidFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConvertSolidFeatureData Interface

Allows access to a convert solid feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface IConvertSolidFeatureData
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
```

C#

```
public interface IConvertSolidFeatureData
```

C++/CLI

```
public interface class IConvertSolidFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData](#).

Example

'VBA

'This example demonstrates how to convert a solid to sheet metal.

'-----

'Preconditions:

'1. Open *public_documents\SOLIDWORKS\SOLIDWORKS*
2025\samples\tutorial\api\sweepcutextrude.sldprt.

'2. Ensure that the Sheet Metal tab is visible on the Command Manager toolbar.

'3. Open an Immediate window.

'

'Postconditions:

' 1. Creates **Convert-Solid1** and **Sheet-Metal1**.

' 2. Inspect the FeatureManager design tree and the Immediate window.

'

' NOTE: Because the model may be used elsewhere, do not save changes to it.

'-----

Option Explicit

Sub main()

Dim swApp As SldWorks.SldWorks

Dim swModel As SldWorks.ModelDoc2

Dim swFeat As SldWorks.Feature

Dim FeatMgr As SldWorks.FeatureManager

```

Dim swConvertSolidFeatData As SldWorks.ConvertSolidFeatureData
Dim FeatData As SldWorks.ConvertSolidFeatureData
Dim boolstatus As Boolean
Dim cba As SldWorks.CustomBendAllowance
Dim face As SldWorks.Face2
Dim faceId As Variant

Set swApp = Application.SldWorks
Set swModel = swApp.ActiveDoc
Set FeatMgr = swModel.FeatureManager

    boolstatus = swModel.Extension.SelectByID2("", "FACE", 4.130570195002E-04,
0.02357994168921, 0.02568415695742, True, 0, Nothing, 0)

    boolstatus = swModel.Extension.SelectByID2("", "EDGE", -0.00190522473838,
0.02387533864419, 0.04979931166838, True, 1, Nothing, 0)

    boolstatus = swModel.Extension.SelectByID2("", "EDGE", 0.02911271681069,
0.02376277320678, 0.02892436699148, True, 1, Nothing, 0)

    boolstatus = swModel.Extension.SelectByID2("", "EDGE", -0.004838857104858,
0.02387396382323, -1.997542986487E-04, True, 1, Nothing, 0)
    'Create a feature data object
Set swConvertSolidFeatData = FeatMgr.CreateDefinition(swFmSolidToSheetMetal)

Set cba = swConvertSolidFeatData.GetCustomBendAllowance()

cba.Type = swBendAllowanceKFactor
cba.KFactor = 0.08

'Initialize the feature data object with custom bend allowance
swConvertSolidFeatData.Initialize True, False, cba

'Create the feature
Set swFeat = FeatMgr.CreateFeature(swConvertSolidFeatData)

Set FeatData = swFeat.GetDefinition()

Set cba = swConvertSolidFeatData.GetCustomBendAllowance()

Debug.Print "Type of custom bend allowance as defined in swBendAllowanceTypes_e:
" & cba.Type
Debug.Print "K factor: " & cba.KFactor
Debug.Print "SheetMetal thickness : " & FeatData.SheetThickness
Debug.Print "Bend Radius : " & FeatData.BendRadius
Debug.Print "Reverse thickness : " & FeatData.ReverseThickness
Debug.Print "Keep body : " & FeatData.KeepBody
Debug.Print "Overlap type : " & FeatData.CornerDefaults
Debug.Print "Rip gaps : " & FeatData.RipGap

```

```

Debug.Print "Rip overlap ratio : " & FeatData.RipOverlapRatio
Debug.Print "Auto relief type : " & FeatData.ReliefType
Debug.Print "Auto relief ratio : " & FeatData.ReliefRatio

FeatData.AccessSelections swModel, Nothing

Set face = FeatData.GetFixedFace
faceId = face.GetFaceId()
Debug.Print "Fixed face ID: " & faceId

'Modify initial values
FeatData.SheetThickness = 0.014
FeatData.BendRadius = 0.0006

'Modify the feature definition
swFeat.ModifyDefinition FeatData, swModel, Nothing
Debug.Print "-----After Setting Values-----"
-----"

Debug.Print "SheetMetal thickness : " & FeatData.SheetThickness
Debug.Print "Bend Radius : " & FeatData.BendRadius
Debug.Print "Reverse thickness : " & FeatData.ReverseThickness
Debug.Print "Keep body : " & FeatData.KeepBody
Debug.Print "Overlap type : " & FeatData.CornerDefaults
Debug.Print "Rip gaps : " & FeatData.RipGap
Debug.Print "Rip overlap ratio : " & FeatData.RipOverlapRatio
Debug.Print "Auto relief type : " & FeatData.ReliefType
Debug.Print "Auto relief ratio : " & FeatData.ReliefRatio

```

End Sub

Example

[Create ConvertSolid Feature \(VB.NET\)](#)
[Create ConvertSolid Feature \(C#\)](#)

Remarks

To create a ConvertSolid feature:

1. Ensure that the Sheet Metal tab is visible on the CommandManager toolbar.
2. Call [IModelDocExtension::SelectByID2](#) to select the fixed face (with Mark=0) and bend edges (with Mark=1).
3. Call [IFeatureManager::CreateDefinition](#)(swFmSolidToSheetMetal) to create this feature data object.
4. Instantiate and specify the [ICustomBendAllowance](#) object.
5. Call [IConvertSolidFeatureData::Initialize](#).
6. Call [IFeatureManager::CreateFeature](#) to create the ConvertSolid feature.

To modify a ConvertSolid feature:

1. Call [IFeature::GetDefinition](#) to obtain this feature data object.
2. Call [IConvertSolidFeatureData::AccessSelections](#).
3. Modify properties as needed.
4. Call [IFeature::ModifyDefinition](#) to finalize any changes or [IConvertSolidFeatureData::ReleaseSelectionAccess](#) if no changes were made.

For more information about converting solids or surface bodies to sheet metal parts, see the **SOLIDWORKS Design user-interface online help > Sheet Metal > Comparing Sheet Metal Design Methods > Convert to Sheet Metal Tool** topics.

Accessors

IFeature::GetDefinition
IFeatureManager::CreateDefinition

 Access Diagram

[ConvertSolidFeatureData](#)

 See Also

[IConvertSolidFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

IConvertSolidFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConvertSolidFeatureData Interface

For a list of all members of this type, see [IConvertSolidFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this convert solid feature.
 GetBendEdgesCount	Gets the number of bend edges in this convert solid feature.
 GetCustomBendAllowance	Gets custom bend allowance for this convert solid feature.
 GetFixedFace	Gets the face that remains in place when the part is flattened in this convert solid feature.
 Initialize	Initializes this convert solid feature to have the specified properties.
 ReleaseSelectionAccess	Releases access to selections that describe this convert solid feature.
 SetFixedFace	Sets the face that remains in place when the part is flattened in this convert solid feature.

[Top](#)

 See Also

[IConvertSolidFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

IConvertSolidFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : IConvertSolidFeatureData Interface

The following tables list the members exposed by [IConvertSolidFeatureData](#).

 Public Properties

Name	Description
 BendEdges	Gets or sets the bend edges and faces in this convert solid feature.
 BendRadius	Gets or sets the default radius for bends in this convert solid feature.
 CornerDefaults	Gets or sets the sheet metal corner type in this convert solid feature.
 GaugeBendRadius	Gets or sets the gauge bend radius in this convert solid feature.
 GaugeTableFile	Gets or sets the gauge table file in this convert solid feature.
 GaugeThickness	See ConvertSolidFeatureData.GaugeTableFile .
 KeepBody	Gets or sets whether to keep the original solid body when converting to sheet metal.
 OverrideBendRadius	Gets or sets whether to override the gauge bend radius for this convert solid feature.
 OverrideDefaultAutoReliefParameters	Gets or sets whether to override the default sheet metal auto relief parameters such as relief type and relief ratio for this convert solid feature.
 OverrideDefaultBendAllowanceParameters	Sets whether to override the default custom bend allowance.

 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters such as sheet thickness and default bend radius for this convert solid feature.
 OverrideSheetThickness	Gets or sets whether to override the gauge thickness for this convert solid feature.
 ReliefRatio	Gets or sets the bend relief ratio for this convert solid feature.
 ReliefType	Gets or sets the bend relief type in this convert solid feature.
 ReverseThickness	Gets or sets whether to reverse the thickness direction of this convert solid feature.
 RipGap	Gets or sets the default gap for all rips in this convert solid feature.
 RipOverlapRatio	Gets or sets the default ratio for all overlap and underlap rips in this convert solid feature.
 RipSketches	Gets or sets the sketches to use to define required rips in this convert solid feature.
 SheetMetalProcess	Gets the sheet metal process name for this convert solid feature.
 SheetThickness	Gets or sets the sheet thickness of this convert solid feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this convert solid feature.
 GetBendEdgesCount	Gets the number of bend edges in this convert solid feature.
 GetCustomBendAllowance	Gets custom bend allowance for this convert solid feature.
 GetFixedFace	Gets the face that remains in place when the part is flattened in this convert solid feature.
 Initialize	Initializes this convert solid feature to have the specified properties.
 ReleaseSelectionAccess	Releases access to selections that describe this convert solid feature.
 SetFixedFace	Sets the face that remains in place when the part is flattened in this convert solid feature.

[Top](#)

See Also

[IConvertSolidFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IConvertSolidFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : IConvertSolidFeatureData Interface

For a list of all members of this type, see [IConvertSolidFeatureData members](#).

Public Properties

Name	Description
 BendEdges	Gets or sets the bend edges and faces in this convert solid feature.
 BendRadius	Gets or sets the default radius for bends in this convert solid feature.
 CornerDefaults	Gets or sets the sheet metal corner type in this convert solid feature.
 GaugeBendRadius	Gets or sets the gauge bend radius in this convert solid feature.
 GaugeTableFile	Gets or sets the gauge table file in this convert solid feature.
 GaugeThickness	See ConvertSolidFeatureData.GaugeTableFile .
 KeepBody	Gets or sets whether to keep the original solid body when converting to sheet metal.
 OverrideBendRadius	Gets or sets whether to override the gauge bend radius for this convert solid feature.
 OverrideDefaultAutoReliefParameters	Gets or sets whether to override the default sheet metal auto relief parameters such as relief type and relief ratio for this convert solid feature.
 OverrideDefaultBendAllowanceParameters	Sets whether to override the default custom bend allowance.
 OverrideDefaultSheetMetalParameters	Gets or sets whether to override the default sheet metal parameters such as sheet thickness and default bend radius for this convert solid feature.

 OverrideSheetThickness	Gets or sets whether to override the gauge thickness for this convert solid feature.
 ReliefRatio	Gets or sets the bend relief ratio for this convert solid feature.
 ReliefType	Gets or sets the bend relief type in this convert solid feature.
 ReverseThickness	Gets or sets whether to reverse the thickness direction of this convert solid feature.
 RipGap	Gets or sets the default gap for all rips in this convert solid feature.
 RipOverlapRatio	Gets or sets the default ratio for all overlap and underlap rips in this convert solid feature.
 RipSketches	Gets or sets the sketches to use to define required rips in this convert solid feature.
 SheetMetalProcess	Gets the sheet metal process name for this convert solid feature.
 SheetThickness	Gets or sets the sheet thickness of this convert solid feature.

[Top](#)

See Also

[IConvertSolidFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : AccessSelections Method (IConvertSolidFeatureData)

Allows access to the selections that describe this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _
    ByVal TopDoc As System.Object, _
    ByVal Component As System.Object _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(
    System.object TopDoc,
    System.object Component
)
```

C++/CLI

```
System.bool AccessSelections(
    & System.Object^ TopDoc,
    & System.Object^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

 Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::AccessSelections](#).

 Example

See the [IConvertSolidFeatureData](#) examples.

 Remarks

To modify a feature in a...	Then...
Part	• TopDoc argument is the IModelDoc2 for the part • Component argument is NULL
Assembly	• TopDoc is the IModelDoc2 object for the assembly • Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [IConvertSolidFeatureData::ReleaseSelectionAccess](#) if you did not

 See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

 Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendEdges Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : BendEdges Property (IConvertSolidFeatureData)

Gets or sets the bend edges and faces in this convert solid feature.

 .NET Syntax

Visual Basic (Declaration)

Property BendEdges As System.Object

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Object  
  
instance.BendEdges = value  
  
value = instance.BendEdges
```

C#

```
System.object BendEdges {get; set;}
```

C++/CLI

```
property System.Object^ BendEdges {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of bend [edges](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::BendEdges](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

BendRadius Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : BendRadius Property (IConvertSolidFeatureData)

Gets or sets the default radius for bends in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property BendRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Double
```

```
instance.BendRadius = value
```

```
value = instance.BendRadius
```

C#

```
System.double BendRadius {get; set;}
```

C++/CLI

```
property System.double BendRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend radius

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::BendRadius](#).

Example

See the [IConvertSolidFeatureData](#) examples.

Remarks

The setter of this property is valid only if [IConvertSolidFeatureData::OverrideDefaultSheetMetalParameters](#) is true.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerDefaults Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : CornerDefaults Property (IConvertSolidFeatureData)

Gets or sets the sheet metal corner type in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property CornerDefaults As System.Integer

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Integer
```

```
instance.CornerDefaults = value
```

```
value = instance.CornerDefaults
```

C#

```
System.int CornerDefaults {get; set;}
```

C++/CLI

```
property System.int CornerDefaults {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheet metal corner type as defined by [swSheetMetalOverlapTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::CornerDefaults](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

GaugeBendRadius Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GaugeBendRadius Property (IConvertSolidFeatureData)

Gets or sets the gauge bend radius in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property GaugeBendRadius As System.Double

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Double

instance.GaugeBendRadius = value

value = instance.GaugeBendRadius
```

C#

```
System.double GaugeBendRadius {get; set;}
```

C++/CLI

```
property System.double GaugeBendRadius {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gauge bend radius

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GaugeBendRadius](#).

Remarks

This property is related to the gauge table only. This property is valid only before calling [IFeatureManager::CreateFeature](#) to create a new sheet metal feature.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GaugeTableFile Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GaugeTableFile Property (IConvertSolidFeatureData)

Gets or sets the gauge table file in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property GaugeTableFile As System.String

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.String  
  
instance.GaugeTableFile = value  
  
value = instance.GaugeTableFile
```

C#

```
System.string GaugeTableFile {get; set;}
```

C++/CLI

```
property System.String^ GaugeTableFile {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pathname of gauge table file

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GaugeTableFile](#).

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GaugeThickness Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GaugeThickness Property (IConvertSolidFeatureData)

See [ConvertSolidFeatureData::GaugeTableFile](#).

.NET Syntax

Visual Basic (Declaration)

Property GaugeThickness As System.String

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.String  
  
instance.GaugeThickness = value  
  
value = instance.GaugeThickness
```

C#

```
System.string GaugeThickness {get; set;}
```

C++/CLI

```
property System.String^ GaugeThickness {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gauge thickness

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GaugeThickness](#).

Remarks

This property is related to the gauge table only. This property is valid only before calling [IFeatureManager::CreateFeature](#) to create a new sheet metal feature.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBendEdgesCount Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GetBendEdgesCount Method (IConvertSolidFeatureData)

Gets the number of bend edges in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBendEdgesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Integer
```

```
value = instance.GetBendEdgesCount()
```

C#

```
System.int GetBendEdgesCount()
```

C++/CLI

```
System.int GetBendEdgesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of bend edges

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GetBendEdgesCount](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)
[IConvertSolidFeatureData::BendEdges Property \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCustomBendAllowance Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GetCustomBendAllowance Method (IConvertSolidFeatureData)

Gets custom bend allowance for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCustomBendAllowance() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Object  
  
value = instance.GetCustomBendAllowance()
```

C#

```
System.object GetCustomBendAllowance()
```

C++/CLI

```
System.Object^ GetCustomBendAllowance();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Custom bend allowance](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GetCustomBendAllowance](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFixedFace Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : GetFixedFace Method (IConvertSolidFeatureData)

Gets the face that remains in place when the part is flattened in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFixedFace() As System.Object
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Object  
  
value = instance.GetFixedFace()
```

C#

```
System.object GetFixedFace()
```

C++/CLI

```
System.Object^ GetFixedFace();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::GetFixedFace](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)
[IConvertSolidFeatureData::SetFixedFace Method \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

Initialize Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : Initialize Method (IConvertSolidFeatureData)

Initializes this convert solid feature to have the specified properties.

.NET Syntax

Visual Basic (Declaration)

```
Sub Initialize( _  
    ByVal UseMaterialSheetMetalParameters As System.Boolean, _  
    ByVal UseGaugeTableParameters As System.Boolean, _  
    ByVal CustomBendAllowance As System.Object _  
)
```

```

Dim instance As IConvertSolidFeatureData
Dim UseMaterialSheetMetalParameters As System.Boolean
Dim UseGaugeTableParameters As System.Boolean
Dim CustomBendAllowance As System.Object

instance.Initialize(UseMaterialSheetMetalParameters, UseGaugeTableParameters, CustomBendAllowance)

```

C#

```

void Initialize(
    System.bool UseMaterialSheetMetalParameters,
    System.bool UseGaugeTableParameters,
    System.object CustomBendAllowance
)

```

C++/CLI

```

void Initialize(
    & System.bool UseMaterialSheetMetalParameters,
    & System.bool UseGaugeTableParameters,
    & System.Object^ CustomBendAllowance
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

UseMaterialSheetMetalParameters

True to use sheet metal parameters attached to the selected material, false to not (see **Remarks**)

UseGaugeTableParameters

True to use a gauge table values (material thickness, bend radius, and bend calculation method) as the basis of this feature, false to not

CustomBendAllowance

[ICustomBendAllowance](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::Initialize](#).

Example

See the [IConvertSolidFeatureData](#) examples.

Remarks

UseMaterialSheetMetalParameters is valid only if a material is applied to the solid.

See Also

[IConvertSolidFeatureData Interface](#)

[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

KeepBody Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : KeepBody Property (IConvertSolidFeatureData)

Gets or sets whether to keep the original solid body when converting to sheet metal.

.NET Syntax

Visual Basic (Declaration)

Property KeepBody As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Boolean

instance.KeepBody = value

value = instance.KeepBody
```

C#

```
System.bool KeepBody {get; set;}
```

C++/CLI

```
property System.bool KeepBody {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to keep the original solid body, false to let the original body be consumed by the convert solid feature

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::KeepBody](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideBendRadius Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : OverrideBendRadius Property (IConvertSolidFeatureData)

Gets or sets whether to override the gauge bend radius for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property OverrideBendRadius As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Boolean

instance.OverrideBendRadius = value

value = instance.OverrideBendRadius
```

C#

```
System.bool OverrideBendRadius {get; set;}
```

C++/CLI

```
property System.bool OverrideBendRadius {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the gauge bend radius, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::OverrideBendRadius](#).

Remarks

This property is related to the gauge table only. This property is valid only before calling [IFeatureManager::CreateFeature](#) to create a new sheet metal feature.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultAutoReliefParameters Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : OverrideDefaultAutoReliefParameters Property (IConvertSolidFeatureData)

Gets or sets whether to override the default sheet metal auto relief parameters such as relief type and relief ratio for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideDefaultAutoReliefParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Boolean
```

```
instance.OverrideDefaultAutoReliefParameters = value
```

```
value = instance.OverrideDefaultAutoReliefParameters
```

C#

```
System.bool OverrideDefaultAutoReliefParameters {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultAutoReliefParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the default sheet metal auto relief parameters, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::OverrideDefaultAutoReliefParameters](#).

Remarks

If this property is set to true, you can set:

- [IConvertSolidFeatureData::ReliefRatio](#)
- [IConvertSolidFeatureData::ReliefType](#)

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultBendAllowanceParameters Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : OverrideDefaultBendAllowanceParameters Property (IConvertSolidFeatureData)

Sets whether to override the default custom bend allowance.

.NET Syntax

Visual Basic (Declaration)

```
Property OverrideDefaultBendAllowanceParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Boolean  
  
instance.OverrideDefaultBendAllowanceParameters = value  
  
value = instance.OverrideDefaultBendAllowanceParameters
```

C#

```
System.bool OverrideDefaultBendAllowanceParameters {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultBendAllowanceParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::OverrideDefaultBendAllowanceParameters](#).

Remarks

Set this property to true when you want to override the bend allowance that is inherited by default from a parent sheet metal feature. Then [Initialize](#) IConvertSolidFeatureData with new [ICustomBendAllowance](#) values for the subsequent sheet metal features.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

OverrideDefaultSheetMetalParameters Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : OverrideDefaultSheetMetalParameters Property (IConvertSolidFeatureData)

Gets or sets whether to override the default sheet metal parameters such as sheet thickness and default bend radius for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property OverrideDefaultSheetMetalParameters As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Boolean
```

```
instance.OverrideDefaultSheetMetalParameters = value
```

```
value = instance.OverrideDefaultSheetMetalParameters
```

C#

```
System.bool OverrideDefaultSheetMetalParameters {get; set;}
```

C++/CLI

```
property System.bool OverrideDefaultSheetMetalParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the default sheet metal parameters, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::OverrideDefaultSheetMetalParameters](#).

Remarks

If this property is set to true, you can set:

- [IConvertSolidFeatureData::SheetThickness](#)
- [IConvertSolidFeatureData::BendRadius](#)

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

OverrideSheetThickness Property (IConvertSolidFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : OverrideSheetThickness Property (IConvertSolidFeatureData)

Gets or sets whether to override the gauge thickness for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property OverrideSheetThickness As System.Boolean

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Boolean
```

```
instance.OverrideSheetThickness = value
```

```
value = instance.OverrideSheetThickness
```

C#

```
System.bool OverrideSheetThickness {get; set;}
```

C++/CLI

```
property System.bool OverrideSheetThickness {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the gauge thickness, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::OverrideSheetThickness](#).

Remarks

This property is related to the gauge table only. This property is valid only before calling [IFeatureManager::CreateFeature](#) to create a new sheet metal feature.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

ReleaseSelectionAccess Method (IConvertSolidFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : ReleaseSelectionAccess Method (IConvertSolidFeatureData)

Releases access to selections that describe this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::ReleaseSelectionAccess](#).

Remarks

[IConvertSolidFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define the convert solid feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefRatio Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : ReliefRatio Property (IConvertSolidFeatureData)

Gets or sets the bend relief ratio for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReliefRatio As System.Double
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Double  
  
instance.ReliefRatio = value  
  
value = instance.ReliefRatio
```

C#

```
System.double ReliefRatio {get; set;}
```

C++/CLI

```
property System.double ReliefRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0.05 <= Relief ratio <= 2.0

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::ReliefRatio](#).

Example

See the [IConvertSolidFeatureData](#) examples.

Remarks

The setter of this property is valid only if:

[IConvertSolidFeatureData::OverrideDefaultAutoReliefParameters](#) is true

- and -

ReliefType is Rectangular or Obround.

Relief ratio = d / part thickness,

where:

d = the width of the relief cut and the depth by which it extends past the bend region

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReliefType Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : ReliefType Property (IConvertSolidFeatureData)

Gets or sets the bend relief type in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property ReliefType As System.Integer

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Integer
```

```
instance.ReliefType = value
```

```
value = instance.ReliefType
```

C#

```
System.int ReliefType {get; set;}
```

C++/CLI

```
property System.int ReliefType {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Send relief type as defined by [swSheetMetalAutoReliefTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::ReliefType](#).

Example

See the [IConvertSolidFeatureData](#) examples.

Remarks

The setter of this property is valid only if [IConvertSolidFeatureData::OverrideDefaultAutoReliefParameters](#) is true.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseThickness Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : ReverseThickness Property (IConvertSolidFeatureData)

Gets or sets whether to reverse the thickness direction of this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseThickness As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseThickness = value
```

```
value = instance.ReverseThickness
```

C#

```
System.bool ReverseThickness {get; set;}
```

C++/CLI

```
property System.bool ReverseThickness {  
    System.bool get();
```



```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse thickness direction, false to not

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::ReverseThickness](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

RipGap Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : RipGap Property (IConvertSolidFeatureData)

Gets or sets the default gap for all rips in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property RipGap As System.Double

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Double  
  
instance.RipGap = value  
value = instance.RipGap
```

C#

```
System.double RipGap {get; set;}
```

C++/CLI

```
property System.double RipGap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Rip gap

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::RipGap](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

RipOverlapRatio Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : RipOverlapRatio Property (IConvertSolidFeatureData)

Gets or sets the default ratio for all overlap and underlap rips in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property RipOverlapRatio As System.Double

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData  
Dim value As System.Double
```

```
instance.RipOverlapRatio = value
```

```
value = instance.RipOverlapRatio
```

C#

```
System.double RipOverlapRatio {get; set;}
```

C++/CLI

```
property System.double RipOverlapRatio {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default ratio for overlap and underlap rips; 0.0 <= Rip overlap ratio <= 1.0

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::RipOverlapRatio](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

RipSketches Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : RipSketches Property (IConvertSolidFeatureData)

Gets or sets the sketches to use to define required rips in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

Property RipSketches As System.Object

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Object

instance.RipSketches = value

value = instance.RipSketches
```

C#

```
System.Object RipSketches {get; set;}
```

C++/CLI

```
property System.Object^ RipSketches {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of rip [sketches](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::RipSketches](#).

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SetFixedFace Method (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : SetFixedFace Method (IConvertSolidFeatureData)

Sets the face that remains in place when the part is flattened in this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetFixedFace( _
    ByVal FaceIn As System.Object _
)
```

```
Dim instance As IConvertSolidFeatureData
Dim FaceIn As System.Object

instance.SetFixedFace(FaceIn)
```

C#

```
void SetFixedFace(
    System.Object FaceIn
)
```

C++/CLI

```
void SetFixedFace(
    & System.Object^ FaceIn
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FaceIn
[IFace2](#)

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::SetFixedFace](#).

Example

See the [IConvertSolidFeatureData](#) examples.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)
[IConvertSolidFeatureData::GetFixedFace Method \(\)](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

SOLIDWORKS API Help

[Send comments](#) on this topic.

SheetMetalProcess Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : SheetMetalProcess Property (IConvertSolidFeatureData)

Gets the sheet metal process name for this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property SheetMetalProcess As System.String
```

Visual Basic (Usage)

```
Dim instance As IConvertSolidFeatureData
Dim value As System.String

value = instance.SheetMetalProcess
```

C#

```
System.string SheetMetalProcess {get;}
```

C++/CLI

```
property System.String^ SheetMetalProcess {
    System.String^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Name of sheet metal process

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::SheetMetalProcess](#).

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments](#) on this topic.

SheetThickness Property (IConvertSolidFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [IConvertSolidFeatureData Interface](#) : SheetThickness Property (IConvertSolidFeatureData)

Gets or sets the sheet thickness of this convert solid feature.

.NET Syntax

Visual Basic (Declaration)

```
Property SheetThickness As System.Double
```

Visual Basic (Usage)



```
Dim instance As IConvertSolidFeatureData
Dim value As System.Double
```

```
instance.SheetThickness = value
```

```
value = instance.SheetThickness
```

C#

```
System.double SheetThickness {get; set;}
```

C++/CLI

```
property System.double SheetThickness {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Sheet thickness

Visual Basic for Applications (VBA) Syntax

See [ConvertSolidFeatureData::SheetThickness](#).

Example

See the [IConvertSolidFeatureData](#) examples.

Remarks

The setter of this property is valid only if [IConvertSolidFeatureData.OverrideDefaultSheetMetalParameters](#) is true.

See Also

[IConvertSolidFeatureData Interface](#)
[IConvertSolidFeatureData Members](#)

Availability

SOLIDWORKS 2025 SP02, Revision Number 33.2

ICoordinateSystemElement (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICoordinateSystemElement Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemElement Interface

Allows access to a coordinate system element.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICoordinateSystemElement
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemElement
```

C#

```
public interface ICoordinateSystemElement
```

C++/CLI

```
public interface class ICoordinateSystemElement
```

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemElement](#).

Example

â€™ VBA

```
' .....  
' Preconditions:  
' 1. Open a part with a coordinate system.  
' 2. Select any coordinate system element.  
' 3. Open the Immediate window.  
'  
' Postconditions: Examine the Immediate window for the type of coordinate system  
element selected.  
' .....  
  
Option Explicit  
Dim swApp As SldWorks.SldWorks  
Dim swModel As SldWorks.ModelDoc2  
Dim swSelMgr As SldWorks.SelectionMgr  
Dim swFeat As SldWorks.Feature  
Dim swComponent As SldWorks.Component2  
Dim swCoordSysFeat As SldWorks.CoordinateSystemFeatureData  
Dim iSelType As Long  
Dim isCoordSysElmSelected As Boolean  
Dim swCordSysElement As SldWorks.CoordinateSystemElement
```

```

Dim boolstatus As Boolean
Sub main()
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
    'boolstatus = swModel.Extension.SelectByID2("Coordinate System1\X Axis",
    "COORDSYS", 0, 0, 0, False, 0, Nothing, 0)
    'Select any coordinate system element
    'Stop
    Set swSelMgr = swModel.SelectionManager
    Set swComponent = swSelMgr.GetSelectedObjectsComponent4(1, -1)
    iSelType = swSelMgr.GetSelectedObjectType3(1, -1)
    If iSelType = swSelCOORDSYS Then
        isCoordSysElmSelected = swSelMgr.IsCoordSysElementSelected(1, -1)
        If isCoordSysElmSelected = True Then
            Set swCordSysElement = swSelMgr.GetSelectedCoordSysElement(1, -1)
            Dim ElementType As Long
            ElementType = swCordSysElement.GetElementType
            Debug.Print "ElementType: " & ElementType
            Set swFeat = swCordSysElement.GetCoordinateSystem
            Set swCoordSysFeat = swFeat.GetDefinition
            swCoordSysFeat.AccessSelections swModel, swComponent
            'Stop
            swCoordSysFeat.ReleaseSelectionAccess
        End If
    End If
End Sub

```

Remarks

The normal channel of feature editing (IFeature::CreateDefinition, IFeature::ModifyDefinition) will not work for features created with coordinate system elements. In order to edit a feature created with a coordinate system element, you must:

1. Select the feature created with a coordinate system element.
2. Call the IModelDocExtension::RunCommand swCommands_e.swCommands_EditFeature to open a PropertyManager dialog for the selected object.
3. Call ISelectionMgr::GetSelectedObjectType3 to obtain the selection.
4. Test whether the selection is a coordinate system element.
5. If the selection is a coordinate system element, obtain the CoordinateSystemElement object.

'VBA

```

'-----
' Preconditions:
' 1. Open a part that contains an Axis1 created using a coordinate system element.
' 2. Open the Immediate window.
'
' Postconditions:
' 1. Examine the Immediate window to see the coordinate system element type as defined by swCoordSysElementType_e.
' 2. Examine the user interface. The specified coordinate system element should be selected.
'-----

```

```

Option Explicit
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swSelMgr As SldWorks.SelectionMgr
Dim iSelType As Long
Dim isCoordSysElmSelected As Boolean
Dim swCordSysElement As SldWorks.CoordinateSystemElement
Dim boolstatus As Boolean

```



```
Sub main()

    Set swApp = Application.SldWorks

    Set swModel = swApp.ActiveDoc
    boolstatus = swModel.Extension.SelectByID2("Axis1", "AXIS", 0, 0, 0, False, 0, Nothing, 0)
    swModel.Extension.RunCommand swCommands_e.swCommands_EditFeature, ""

    Set swSelMgr = swModel.SelectionManager
    iSelType = swSelMgr.GetSelectedObjectType3(1, -1)

    If iSelType = swSelCOORDSYS Then Then

        isCoordSysElmSelected = swSelMgr.IsCoordSysElementSelected(1, -1)

        If isCoordSysElmSelected Then

            Set swCordSysElement = swSelMgr.GetSelectedCoordSysElement(1, -1)
            Debug.Print "Element type: " & swCordSysElement.GetElementType

        End If

    End If

    swModel.Extension.RunCommand swCommands_e.swCommands_Dve_Rmb_Cancel, ""
    Set swCordSysElement = Nothing

End Sub
```

 Accessors

[ISelectionMgr::GetSelectedCoordSysElement](#)

 Access Diagram

[CoordinateSystemElement](#)

 See Also

[ICoordinateSystemElement Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICoordinateSystemElement Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemElement Interface

The following tables list the members exposed by [ICoordinateSystemElement](#).

 Public Methods

Name	Description
 GetCoordinateSystem	Gets the coordinate system of this coordinate system element.
 GetElementType	Gets the type of this coordinate system element.

[Top](#)

 See Also

[ICoordinateSystemElement Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICoordinateSystemElement Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemElement Interface

For a list of all members of this type, see [ICoordinateSystemElement members](#).

 Public Methods

Name	Description
------	-------------

 GetCoordinateSystem	Gets the coordinate system of this coordinate system element.
 GetElementType	Gets the type of this coordinate system element.

[Top](#)

See Also

[ICoordinateSystemElement Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCoordinateSystem Method (ICoordinateSystemElement)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemElement Interface](#) : GetCoordinateSystem Method (ICoordinateSystemElement)

Gets the coordinate system of this coordinate system element.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCoordinateSystem() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemElement  
Dim value As System.Object  
  
value = instance.GetCoordinateSystem()
```

C#

```
System.object GetCoordinateSystem()
```

C++/CLI

```
System.Object^ GetCoordinateSystem();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemElement::GetCoordinateSystem](#).

Example

See the [ICoordinateSystemElement](#) examples.

See Also

[ICoordinateSystemElement Interface](#)
[ICoordinateSystemElement Members](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetElementType Method (ICoordinateSystemElement)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemElement Interface](#) : GetElementType Method (ICoordinateSystemElement)

Gets the type of this coordinate system element.

.NET Syntax

Visual Basic (Declaration)

```
Function GetElementType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemElement  
Dim value As System.Integer  
  
value = instance.GetElementType()
```

C#

```
System.int GetElementType()
```

C++/CLI

```
System.int GetElementType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Coordinate system element type as defined by [swCoordSysElementType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemElement::GetElementType](#).

Example

See the [ICoordinateSystemElement](#) examples.

See Also

[ICoordinateSystemElement Interface](#)
[ICoordinateSystemElement Members](#)

Availability

SOLIDWORKS 2025 SP01, Revision Number 33.1