

SOLIDWORKS API (.NET VBA C#) — Reference

(57/337): ICoordinateSystemFeatureData- ICoreFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ICoordinateSystemFeatureData (Type)

ICoordinateSystemFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemFeatureData Interface

Allows access to a coordinate system feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICoordinateSystemFeatureData
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
```

C#

```
public interface ICoordinateSystemFeatureData
```

C++/CLI

```
public interface class ICoordinateSystemFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData](#).

Example

[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)
[Create Coordinate System Feature \(VBA\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

Remarks

See SOLIDWORKS Help for more information about coordinate system features.

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[CoordinateSystemFeatureData](#)

See Also

[ICoordinateSystemFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateCoordinateSystem Method \(\)](#)
[IFeatureManager::InsertCoordinateSystem Method \(\)](#)

ICoordinateSystemFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemFeatureData Interface

The following tables list the members exposed by [ICoordinateSystemFeatureData](#).

Public Properties

Name	Description
 OriginEntity	Gets or sets the entity for the origin of this coordinate system feature.
 Transform	Gets the math transform for this coordinate system feature.
 XAxisEntities	Gets or sets the entities for the x axis of this coordinate system feature.
 XFlipped	Gets or sets whether to flip the x axis of this coordinate system feature.
 YAxisEntities	Gets or sets the entities for the y axis of this coordinate system.
 YFlipped	Gets or sets whether to flip the y axis of this coordinate system feature.
 ZAxisEntities	Gets or sets the entities for the z axis of this coordinate system feature.
 ZFlipped	Gets or sets whether to flip the z axis of this coordinate system feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this coordinate system feature.
 GetOriginEntityType	Gets the type of entity of the origin.
 GetXAxisEntitiesCount	Gets the number of entities for the x axis of this coordinate system feature.
 GetXAxisEntitiesTypes	Gets the x-axis type of entities.
 GetYAxisEntitiesCount	Gets the number of entities for the y axis of this coordinate system feature.
 GetYAxisEntitiesTypes	Gets the y-axis type of entities.
 GetZAxisEntitiesCount	Gets the number of entities for the z axis for this coordinate system feature.
 GetZAxisEntitiesTypes	Gets the z-axis type of entities.
 IAccessSelections	Allows access to the selections that describe this coordinate system feature.
 IGetOriginEntity	Gets the entity for the origin of this coordinate system feature.
 IGetOriginEntityType	Gets the type of entity of the origin.
 IGetXAxisEntities	Gets the entities for the x axis of this coordinate system feature.
 IGetXAxisEntitiesTypes	Gets the x-axis type of entities.
 IGetYAxisEntities	Gets the entities for the y axis of this coordinate system feature.
 IGetYAxisEntitiesTypes	Gets the y-axis type of entities.
 IGetZAxisEntities	Gets the entities for the z axis for this coordinate system feature.
 IGetZAxisEntitiesTypes	Gets the z-axis type of entities.
 ISetOriginEntity	Sets the entity for the origin of this coordinate feature data.
 ISetXAxisEntities	Sets the entities for the x axis of this coordinate system feature.
 ISetYAxisEntities	Sets the entities for the y axis of this coordinate system feature.
 ISetZAxisEntities	Sets the entities for the z axis of this coordinate system feature.
 ReleaseSelectionAccess	Releases access to selections that describe this coordinate system feature.

[Top](#)

See Also

[ICoordinateSystemFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateCoordinateSystem Method \(\)](#)
[IFeatureManager::InsertCoordinateSystem Method \(\)](#)

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemFeatureData Interface

For a list of all members of this type, see [ICoordinateSystemFeatureData members](#).

 Public Methods

Name	Description
 AccessSelections	Allows access to the selections that describe this coordinate system feature.
 GetOriginEntityType	Gets the type of entity of the origin.
 GetXAxisEntitiesCount	Gets the number of entities for the x axis of this coordinate system feature.
 GetXAxisEntitiesTypes	Gets the x-axis type of entities.
 GetYAxisEntitiesCount	Gets the number of entities for the y axis of this coordinate system feature.
 GetYAxisEntitiesTypes	Gets the y-axis type of entities.
 GetZAxisEntitiesCount	Gets the number of entities for the z axis for this coordinate system feature.
 GetZAxisEntitiesTypes	Gets the z-axis type of entities.
 IAccessSelections	Allows access to the selections that describe this coordinate system feature.
 IGetOriginEntity	Gets the entity for the origin of this coordinate system feature.
 IGetOriginEntityType	Gets the type of entity of the origin.
 IGetXAxisEntities	Gets the entities for the x axis of this coordinate system feature.
 IGetXAxisEntitiesTypes	Gets the x-axis type of entities.
 IGetYAxisEntities	Gets the entities for the y axis of this coordinate system feature.
 IGetYAxisEntitiesTypes	Gets the y-axis type of entities.
 IGetZAxisEntities	Gets the entities for the z axis for this coordinate system feature.
 IGetZAxisEntitiesTypes	Gets the z-axis type of entities.
 ISetOriginEntity	Sets the entity for the origin of this coordinate feature data.
 ISetXAxisEntities	Sets the entities for the x axis of this coordinate system feature.
 ISetYAxisEntities	Sets the entities for the y axis of this coordinate system feature.
 ISetZAxisEntities	Sets the entities for the z axis of this coordinate system feature.
 ReleaseSelectionAccess	Releases access to selections that describe this coordinate system feature.

[Top](#)

 See Also

[ICoordinateSystemFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateCoordinateSystem Method \(\)](#)
[IFeatureManager::InsertCoordinateSystem Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICoordinateSystemFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICoordinateSystemFeatureData Interface

For a list of all members of this type, see [ICoordinateSystemFeatureData members](#).

 Public Properties

Name	Description
 OriginEntity	Gets or sets the entity for the origin of this coordinate system feature.
 Transform	Gets the math transform for this coordinate system feature.
 XAxisEntities	Gets or sets the entities for the x axis of this coordinate system feature.
XFlipped	Gets or sets whether to flip the x axis of this coordinate system feature.

[YAxisEntities](#)

Gets or sets the entities for the y axis of this coordinate system.

[YFlipped](#)

Gets or sets whether to flip the y axis of this coordinate system feature.

[ZAxisEntities](#)

Gets or sets the entities for the z axis of this coordinate system feature.

[ZFlipped](#)

Gets or sets whether to flip the z axis of this coordinate system feature.

[Top](#)

See Also

[ICoordinateSystemFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::CreateCoordinateSystem Method \(\)](#)
[IFeatureManager::InsertCoordinateSystem Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : AccessSelections Method (ICoordinateSystemFeatureData)

Allows access to the selections that describe this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```

Function AccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean

```

Visual Basic (Usage)



```

Dim instance As ICoordinateSystemFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)

```

C#

```

System.bool AccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)

```

C++/CLI

```

System.bool AccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
 Top-level document
Component
 Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::AccessSelections](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICoordinateSystemFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetOriginEntityType Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetOriginEntityType Method (ICoordinateSystemFeatureData)

Gets the type of entity of the origin.

.NET Syntax

Visual Basic (Declaration)

```
Function GetOriginEntityType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Integer
```

```
value = instance.GetOriginEntityType()
```

C#

```
System.int GetOriginEntityType()
```

C++/CLI

```
System.int GetOriginEntityType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of entity of the origin as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetOriginEntityType](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData.IGetOriginEntity Method](#)
[ICoordinateSystemFeatureData.IGetOriginEntityType Method](#)
[ICoordinateSystemFeatureData.ISetOriginEntity Method](#)
[ICoordinateSystemFeatureData.OriginEntity Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetXAxisEntitiesCount Method (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetXAxisEntitiesCount Method (ICoordinateSystemFeatureData)

Gets the number of entities for the x axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetXAxisEntitiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Integer
```

```
value = instance.GetXAxisEntitiesCount()
```

C#

```
System.int GetXAxisEntitiesCount()
```

C++/CLI

```
System.int GetXAxisEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities for the x axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetXAxisEntitiesCount](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)

Remarks

Call this method before calling [ICoordinateSystemFeatureData.IGetXAxisEntities](#) to determine the size of the array for that method.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData.ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData.XAxisEntities Property](#)
[ICoordinateSystemFeatureData.XFlipped Property](#)
[ICoordinateSystemFeatureData.GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData.IGetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData.IGetXAxisEntities Method](#)

Availability

GetXAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetXAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the x-axis type of entities.

.NET Syntax

Visual Basic (Declaration)

```
Function GetXAxisEntitiesTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Object

value = instance.GetXAxisEntitiesTypes()
```

C#

```
System.object GetXAxisEntitiesTypes()
```

C++/CLI

```
System.Object^ GetXAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers (see [Long vs. Integer](#)) representing the x-axis type of entities as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetXAxisEntitiesTypes](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XAxisEntities Property](#)
[ICoordinateSystemFeatureData::XFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

GetYAxisEntitiesCount Method (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetYAxisEntitiesCount Method (ICoordinateSystemFeatureData)

Gets the number of entities for the y axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetYAxisEntitiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Integer

value = instance.GetYAxisEntitiesCount()
```

C#

```
System.int GetYAxisEntitiesCount()
```

C++/CLI

```
System.int GetYAxisEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities for the y axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetYAxisEntitiesCount](#).

Example

[Create Coordinate System Feature \(VBA\)](#)

Remarks

Call this method before calling [ICoordinateSystemFeatureData::IGetYAxisEntities](#) to determine the size of the array for that method.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::YFlipped Property](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetYAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetYAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the y-axis type of entities.

.NET Syntax

Visual Basic (Declaration)

```
Function GetYAxisEntitiesTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Object

value = instance.GetYAxisEntitiesTypes()
```

C#

```
System.Object GetYAxisEntitiesTypes()
```

C++/CLI

```
System.Object^ GetYAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers (see [Long vs. Integer](#)) representing the y-axis type of entities as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetYAxisEntitiesTypes](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::ISetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::YFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetZAxisEntitiesCount Method (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetZAxisEntitiesCount Method (ICoordinateSystemFeatureData)

Gets the number of entities for the z axis for this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetZAxisEntitiesCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Integer
```

```
value = instance.GetZAxisEntitiesCount()
```

C#

```
System.int GetZAxisEntitiesCount()
```

C++/CLI

```
System.int GetZAxisEntitiesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of entities for the z axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetZAxisEntitiesCount](#).

Example

[Create Coordinate System Feature \(VBA\)](#)

Remarks

Call this method before calling [ICoordinateSystemFeatureData::IGetZAxisEntities](#) to determine the size of the array for that method.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetZAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : GetZAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the z-axis type of entities.

.NET Syntax

Visual Basic (Declaration)

```
Function GetZAxisEntitiesTypes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Object  
  
value = instance.GetZAxisEntitiesTypes()
```

C#

```
System.object GetZAxisEntitiesTypes()
```

C++/CLI

```
System.Object^ GetZAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of longs or integers (see [Long vs. Integer](#)) representing the z-axis type of entities as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::GetZAxisEntitiesTypes](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IAccessSelections Method (ICoordinateSystemFeatureData)

Allows access to the selections that describe this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool IAccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) and [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICoordinateSystemFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetOriginEntity Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetOriginEntity Method (ICoordinateSystemFeatureData)

Gets the entity for the origin of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetOriginEntity() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Object  
  
value = instance.IGetOriginEntity()
```

C#

```
System.object IGetOriginEntity()
```

C++/CLI

```
System.Object^ IGetOriginEntity();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Entity

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::IGetOriginEntity](#).

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IGetOriginEntity Method](#)
[ICoordinateSystemFeatureData::OriginEntity Property](#)
[ICoordinateSystemFeatureData::GetOriginEntityType Method](#)
[ICoordinateSystemFeatureData::IGetOriginEntityType Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetOriginEntityType Method (ICoordinateSystemFeatureData)

[See Also](#)



Gets the type of entity of the origin.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetOriginEntityType() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Integer

value = instance.IGetOriginEntityType()
```

C#

```
System.int IGetOriginEntityType()
```

C++/CLI

```
System.int IGetOriginEntityType();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Type of entity of the origin as defined by [swSelectType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::IGetOriginEntityType](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetOriginEntityType Method](#)
[ICoordinateSystemFeatureData::IGetOriginEntity Method](#)
[ICoordinateSystemFeatureData::ISetOriginEntity Method](#)
[ICoordinateSystemFeatureData::OriginEntity Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetXAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > ICoordinateSystemFeatureData Interface : IGetXAxisEntities Method (ICoordinateSystemFeatureData)

Gets the entities for the x axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetXAxisEntities( _
    ByVal Count As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim Count As System.Integer
Dim value As System.Object

value = instance.IGetXAxisEntities(Count)
```

C#

```
System.object IGetXAxisEntities(
    System.int Count
)
```

C++/CLI

```
System.Object^ IGetXAxisEntities(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of entites for the x axis

Return Value

- in-process, unmanaged C++: Pointer to an an array of entities for the x axis
- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICoordinateSystemFeatureData::GetXAxisEntitiesCount](#) before calling this method to get Count.
See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XAxisEntities Property](#)
[ICoordinateSystemFeatureData::XFlipped Property](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetXAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetXAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the x-axis type of entities.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetXAxisEntitiesTypes() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Integer

value = instance.IGetXAxisEntitiesTypes()
```

C#

```
System.int IGetXAxisEntitiesTypes()
```

C++/CLI

```
System.int IGetXAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of longs representing the x-axis type of entities as defined by [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XAxisEntities Property](#)
[ICoordinateSystemFeatureData::XFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

IGetYAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetYAxisEntities Method (ICoordinateSystemFeatureData)

Gets the entities for the y axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetYAxisEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetYAxisEntities(Count)
```

C#

```
System.object IGetYAxisEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetYAxisEntities(  
&    System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities for the y axis

Return Value

- in-process, unmanaged C++: Pointer to an array of entities for the y axis
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICoordinateSystemFeatureData::GetYAxisEntitiesCount](#) before calling this method to get Count.

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::ICoordinateSystemFeatureData::ISetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::ICoordinateSystemFeatureData::YFlipped Property](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetYAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetYAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the y-axis type of entities.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetYAxisEntitiesTypes() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Integer
```

```
value = instance.IGetYAxisEntitiesTypes()
```

C#

```
System.int IGetYAxisEntitiesTypes()
```

C++/CLI

```
System.int IGetYAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of longs representing the y-axis type of entities as defined by [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::IGetYAxisEntitiesTypes](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::YFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

[SOLIDWORKS API Help](#)

[Send comments on this topic.](#)

IGetZAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetZAxisEntities Method (ICoordinateSystemFeatureData)

Gets the entities for the z axis for this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetZAxisEntities( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetZAxisEntities(Count)
```

C#

```
System.object IGetZAxisEntities(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetZAxisEntities(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of entities for the z axis

Return Value

- in-process, unmanaged C++: Pointer to an array of entities for the z axis
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICoordinateSystemFeatureData::GetZAxisEntitiesCount](#) before calling this method to get Count.

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetZAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : IGetZAxisEntitiesTypes Method (ICoordinateSystemFeatureData)

Gets the z-axis type of entities.

.NET Syntax

Visual Basic (Declaration)

Function IGetZAxisEntitiesTypes() As System.Integer

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Integer
```

```
value = instance.IGetZAxisEntitiesTypes()
```

C#

```
System.int IGetZAxisEntitiesTypes()
```

C++/CLI

```
System.int IGetZAxisEntitiesTypes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

- in-process, unmanaged C++: Pointer to an array of longs representing the z-axis type of entities as defined by [swSelectType_e](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::IGetZAxisEntitiesTypes](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::ISetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)

Availability

SOLIDWORKS 2009 FCS, revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetOriginEntity Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ISetOriginEntity Method (ICoordinateSystemFeatureData)

Sets the entity for the origin of this coordinate feature data.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetOriginEntity( _  
    ByVal Ent As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim Ent As System.Object  
  
instance.ISetOriginEntity(Ent)
```

C#

```
void ISetOriginEntity(  
    System.object Ent  
)
```

C++/CLI

```
void ISetOriginEntity(  
    & System.Object^ Ent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Ent
Entity for origin

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::ISetOriginEntity](#).

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IGetOriginEntity Method](#)
[ICoordinateSystemFeatureData::OriginEntity Property](#)
[ICoordinateSystemFeatureData::GetOriginEntityType Method](#)
[ICoordinateSystemFeatureData::IGetOriginEntityType Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetXAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ISetXAxisEntities Method (ICoordinateSystemFeatureData)

Sets the entities for the x axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetXAxisEntities( _
    ByVal Count As System.Integer, _
    ByRef EntArray As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim Count As System.Integer
Dim EntArray As System.Object

instance.ISetXAxisEntities(Count, EntArray)
```

C#

```
void ISetXAxisEntities(
    System.int Count,
    ref System.object EntArray
)
```

C++/CLI

```
void ISetXAxisEntities(
    & System.int Count,
    & System.Object^% EntArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities for the x axis

EntArray

- in-process, unmanaged C++: Pointer to an array of entities for the x axis

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XAxisEntities Property](#)
[ICoordinateSystemFeatureData::XFlipped Property](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetYAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ISetYAxisEntities Method (ICoordinateSystemFeatureData)

Sets the entities for the y axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetYAxisEntities( _
    ByVal Count As System.Integer, _
```

```
ByRef EntArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim Count As System.Integer  
Dim EntArray As System.Object
```

```
instance.ISetYAxisEntities(Count, EntArray)
```

C#

```
void ISetYAxisEntities(  
    System.int Count,  
    ref System.object EntArray  
)
```

C++/CLI

```
void ISetYAxisEntities(  
& System.int Count,  
& System.Object^% EntArray  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of entities for the y axis

EntArray

- in-process, unmanaged C++: Pointer to an array of entities for the y axis

VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::YFlipped Property](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetZAxisEntities Method (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ISetZAxisEntities Method (ICoordinateSystemFeatureData)

Sets the entities for the z axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetZAxisEntities( _  
    ByVal Count As System.Integer, _  
    ByRef EntArray As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim Count As System.Integer
Dim EntArray As System.Object

instance.ISetZAxisEntities(Count, EntArray)
```

C#

```
void ISetZAxisEntities(
    System.int Count,
    ref System.object EntArray
)
```

C++/CLI

```
void ISetZAxisEntities(
    & System.int Count,
    & System.Object^% EntArray
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of enties for the z axis

EntArray

• in-process, unmanaged C++: Pointer to an an array of entities for the z axis

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

OriginEntity Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : OriginEntity Property (ICoordinateSystemFeatureData)

Gets or sets the entity for the origin of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property OriginEntity As System.Object

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Object

instance.OriginEntity = value

value = instance.OriginEntity
```

C#

```
System.Object OriginEntity {get; set;}
```

C++/CLI

```
property System.Object^ OriginEntity {
    System.Object^ get();
    void set ( &    System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entity for the origin

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::OriginEntity](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::IGetOriginEntity Method](#)
[ICoordinateSystemFeatureData::ISetOriginEntity Method](#)
[ICoordinateSystemFeatureData::GetOriginEntityType Method](#)
[ICoordinateSystemFeatureData::IGetOriginEntityType Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ReleaseSelectionAccess Method (ICoordinateSystemFeatureData)

Releases access to selections that describe this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData

instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::ReleaseSelectionAccess](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

Remarks

[ICoordinateSystemFeatureData::AccessSelections](#) and [ICoordinateSystemFeatureData::IAccessSelections](#) puts the model into a rollback state to allow access to the selections that define the coordinate system feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Transform Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : Transform Property (ICoordinateSystemFeatureData)

Gets the math transform for this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Transform As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As MathTransform  
  
value = instance.Transform
```

C#

```
MathTransform Transform {get;}
```

C++/CLI

```
property MathTransform^ Transform {  
    MathTransform^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Math transform](#)

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::Transform](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(C#\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VB.NET\)](#)
[Get Points of Repeating Elements in Table-driven Pattern \(VBA\)](#)

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

XAxisEntities Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : XAxisEntities Property (ICoordinateSystemFeatureData)

Gets or sets the entities for the x axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property XAxisEntities As System.Object

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Object

instance.XAxisEntities = value

value = instance.XAxisEntities
```

C#

```
System.object XAxisEntities {get; set;}
```

C++/CLI

```
property System.Object^ XAxisEntities {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entities for the x axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::XAxisEntities](#).

Example

[Create Coordinate System Feature \(VBA\)](#)
[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::!GetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::!SetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XFlipped Property](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::!GetXAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

XFlipped Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : XFlipped Property (ICoordinateSystemFeatureData)

Gets or sets whether to flip the x axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property XFlipped As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Boolean
```

```
instance.XFlipped = value  
value = instance.XFlipped
```

C#

```
System.bool XFlipped {get; set;}
```

C++/CLI

```
property System.bool XFlipped {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the x axis, false to not

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::XFlipped](#).

Example

[Insert Coordinate System Feature at Center of Mass \(VBA\)](#)
[Create Coordinate System Feature \(VBA\)](#)

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetXAxisEntities Method](#)
[ICoordinateSystemFeatureData::XAxisEntities Property](#)
[ICoordinateSystemFeatureData::GetXAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetXAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

YAxisEntities Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : YAxisEntities Property (ICoordinateSystemFeatureData)

Gets or sets the entities for the y axis of this coordinate system.

.NET Syntax

Visual Basic (Declaration)

Property YAxisEntities As System.Object

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Object
```

```
instance.YAxisEntities = value
```

```
value = instance.YAxisEntities
```

C#

```
System.Object YAxisEntities {get; set;}
```

C++/CLI

```
property System.Object^ YAxisEntities {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entities for y axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::YAxisEntities](#).

Example

[Create Coordinate System Feature \(VBA\)](#)

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YFlipped Property](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

YFlipped Property (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : YFlipped Property (ICoordinateSystemFeatureData)

Gets or sets whether to flip the y axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property YFlipped As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Boolean
```

```
instance.YFlipped = value
```

```
value = instance.YFlipped
```

C#

```
System.bool YFlipped {get; set;}
```

C++/CLI

```
property System.bool YFlipped {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the y axis, false to not

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::YFlipped](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetYAxisEntities Method](#)
[ICoordinateSystemFeatureData::YAxisEntities Property](#)
[ICoordinateSystemFeatureData::GetYAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetYAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ZAxisEntities Property (ICoordinateSystemFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ZAxisEntities Property (ICoordinateSystemFeatureData)

Gets or sets the entities for the z axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property ZAxisEntities As System.Object

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData
Dim value As System.Object
```

```
instance.ZAxisEntities = value
```

```
value = instance.ZAxisEntities
```

C#

```
System.object ZAxisEntities {get; set;}
```

C++/CLI

```
property System.Object^ ZAxisEntities {
    System.Object^ get();
    void set ( & System.Object^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Entities for the z axis

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData::ZAxisEntities](#).

Example

[Create Coordinate System Feature \(VBA\)](#)

Remarks

See SOLIDWORKS Help for a list of valid entities.

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZFlipped Property](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ZFlipped Property (ICoordinateSystemFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoordinateSystemFeatureData Interface](#) : ZFlipped Property (ICoordinateSystemFeatureData)

Gets or sets whether to flip the z axis of this coordinate system feature.

.NET Syntax

Visual Basic (Declaration)

Property ZFlipped As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICoordinateSystemFeatureData  
Dim value As System.Boolean  
  
instance.ZFlipped = value  
value = instance.ZFlipped
```

C#

```
System.bool ZFlipped {get; set;}
```

C++/CLI

```
property System.bool ZFlipped {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to flip the z axis, false to not

Visual Basic for Applications (VBA) Syntax

See [CoordinateSystemFeatureData.ZFlipped](#).

See Also

[ICoordinateSystemFeatureData Interface](#)
[ICoordinateSystemFeatureData Members](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesCount Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ISetZAxisEntities Method](#)
[ICoordinateSystemFeatureData::ZAxisEntities Property](#)
[ICoordinateSystemFeatureData::GetZAxisEntitiesTypes Method](#)
[ICoordinateSystemFeatureData::IGetZAxisEntitiesTypes Method](#)

Availability

SOLIDWORKS 2009 FCS, Revision Number 17.0

ICoreFeatureData (Type)

ICoreFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoreFeatureData Interface

Allows access to a core feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ICoreFeatureData

Visual Basic (Usage)



Dim instance As [ICoreFeatureData](#)

C#

public interface ICoreFeatureData

C++/CLI

public interface class ICoreFeatureData

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::!GetDefinition](#)

Access Diagram

[CoreFeatureData](#)

See Also

[ICoreFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[IFeatureManager::MoldUndercutDetect2 Method](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IFeatureManager::InsertMoldCoreCavitySolids Method](#)
[IMoveFaceFeatureData Interface](#)

ICoreFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoreFeatureData Interface

The following tables list the members exposed by [ICoreFeatureData](#).

Public Properties

Name	Description
 BoundingSketch	Gets or sets the bounding sketch for this core feature.
 CapEnds	Gets or sets whether the ends are capped on this core feature.
 Depth	Gets or sets the depth in the specified direction of this core feature.
 DraftAngle	Gets or sets the angle of the draft for this core feature.
 DraftOutward	Gets or sets whether draft is applied outward on this core feature.
 EndCondition	Gets or sets the end condition in the specified direction for this core feature.
 ReverseDirection	Gets or sets the direction of the extraction for this core feature.
 TargetBody	Gets or sets the target body for this core feature.
 UseDraft	Gets or sets whether draft is applied to this core feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this core feature.
 GetExtractionDirection	Gets the entities that define the extraction direction of this core feature.
 ReleaseSelectionAccess	Releases access to the selections that describe this core feature.
 SetExtractionDirection	Sets the entities that define the extraction direction of this core feature.

[Top](#)

See Also

[ICoreFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[IFeatureManager::MoldUndercutDetect2 Method](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IFeatureManager::InsertMoldCoreCavitySolids Method](#)
[IMoveFaceFeatureData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICoreFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICoreFeatureData Interface

For a list of all members of this type, see [ICoreFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that describe this core feature.
 GetExtractionDirection	Gets the entities that define the extraction direction of this core feature.
 ReleaseSelectionAccess	Releases access to the selections that describe this core feature.
 SetExtractionDirection	Sets the entities that define the extraction direction of this core feature.

[Top](#)

See Also

[ICoreFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[IFeatureManager::MoldUndercutDetect2 Method](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)

ICoreFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICoreFeatureData Interface

For a list of all members of this type, see [ICoreFeatureData members](#).

Public Properties

Name	Description
 BoundingSketch	Gets or sets the bounding sketch for this core feature.
 CapEnds	Gets or sets whether the ends are capped on this core feature.
 Depth	Gets or sets the depth in the specified direction of this core feature.
 DraftAngle	Gets or sets the angle of the draft for this core feature.
 DraftOutward	Gets or sets whether draft is applied outward on this core feature.
 EndCondition	Gets or sets the end condition in the specified direction for this core feature.
 ReverseDirection	Gets or sets the direction of the extraction for this core feature.
 TargetBody	Gets or sets the target body for this core feature.
 UseDraft	Gets or sets whether draft is applied to this core feature.

[Top](#)

See Also

[ICoreFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICavityFeatureData Interface](#)
[IFeatureManager::MoldUndercutDetect2 Method](#)
[IPartingLineFeatureData Interface](#)
[IPartingSurfaceFeatureData Interface](#)
[IRuledSurfaceFeatureData Interface](#)
[IShutoffSurfaceFeatureData Interface](#)
[IToolingSplitFeatureData Interface](#)
[IFeatureManager::InsertMoldCoreCavitySolids Method](#)
[IMoveFaceFeatureData Interface](#)

AccessSelections Method (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : AccessSelections Method (ICoreFeatureData)

Gains access to the selections that describe this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal PTopDoc As ModelDoc2, _  
    ByVal PComponent As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ICoreFeatureData  
Dim PTopDoc As ModelDoc2  
Dim PComponent As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(PTopDoc, PComponent)
```

C#



```
System.bool AccessSelections(  
    ModelDoc2 PTopDoc,  
    Component2 PComponent  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ PTopDoc,  
& Component2^ PComponent  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PTopDoc

Top-level document

PComponent

Component in which the feature is to be modified

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::AccessSelections](#).

Example

[Get Core Feature Data \(C#\)](#)

[Get Core Feature Data \(VB.NET\)](#)

[Get Core Feature Data \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICoreFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICoreFeatureData Interface](#)

[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BoundingSketch Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : BoundingSketch Property (ICoreFeatureData)

Gets or sets the bounding sketch for this core feature.

.NET Syntax

Visual Basic (Declaration)

Property BoundingSketch As Feature

```
Dim instance As ICoreFeatureData
Dim value As Feature

instance.BoundingSketch = value

value = instance.BoundingSketch
```

C#

```
Feature BoundingSketch {get; set;}
```

C++/CLI

```
property Feature^ BoundingSketch {
    Feature^ get();
    void set ( & Feature^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [IFeature](#) object

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::BoundingSketch](#).

Example

[Get Core Feature Data \(VBA\)](#)
[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CapEnds Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : CapEnds Property (ICoreFeatureData)

Gets or sets whether the ends are capped on this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property CapEnds As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ICoreFeatureData
Dim value As System.Boolean

instance.CapEnds = value
```

```
value = instance.CapEnds
```

C#

```
System.bool CapEnds {get; set;}
```

C++/CLI

```
property System.bool CapEnds {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if ends are capped, false if not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::CapEnds](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Depth Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : Depth Property (ICoreFeatureData)

Gets or sets the depth in the specified direction of this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property Depth(  
    ByVal Index As System.Integer  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim Index As System.Integer  
Dim value As System.Double
```

```
instance.Depth(Index) = value
```

```
value = instance.Depth(Index)
```

C#

```
System.double Depth(  
    System.int Index  
) {get; set;}
```

```
property System.double Depth {
    System.double get(System.int Index);
    void set (System.int Index, System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Direction to extract core as defined in [swCoreFeatureDirection_e](#)

Property Value

Depth

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::Depth](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftAngle Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : DraftAngle Property (ICoreFeatureData)

Gets or sets the angle of the draft for this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData
Dim value As System.Double
```

```
instance.DraftAngle = value
```

```
value = instance.DraftAngle
```

C#

```
System.double DraftAngle {get; set;}
```

C++/CLI

```
property System.double DraftAngle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle of draft

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::DraftAngle](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

Remarks

To set this property, [ICoreFeatureData::UseDraft](#) must be true.

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)
[ICoreFeatureData::DraftOutward Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DraftOutward Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : DraftOutward Property (ICoreFeatureData)

Gets or sets whether draft is applied outward on this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property DraftOutward As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim value As System.Boolean
```

```
instance.DraftOutward = value
```

```
value = instance.DraftOutward
```

C#

```
System.bool DraftOutward {get; set;}
```

C++/CLI

```
property System.bool DraftOutward {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if draft is applied outward, false if not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::DraftOutward](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

Remarks

To set this property, [ICoreFeatureData::UseDraft](#) must be true.

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)
[ICoreFeatureData::DraftAngle Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndCondition Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : EndCondition Property (ICoreFeatureData)

Gets or sets the end condition in the specified direction for this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property EndCondition( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim Index As System.Integer  
Dim value As System.Integer  
  
instance.EndCondition(Index) = value  
  
value = instance.EndCondition(Index)
```

C#

```
System.int EndCondition(  
    System.int Index  
) {get; set;}
```

C++/CLI

```
property System.int EndCondition {  
    System.int get(System.int Index);  
    void set (System.int Index, System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
Direction of end conditions as defined in [swCoreFeatureDirection_e](#)

Property Value

Type of end conditions as defined in [swEndConditions_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::EndCondition](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

Remarks

Valid end conditions are swEndConditions_e:

- swEndCondBlind
- swEndCondThroughAll
- swEndCondThroughNext

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetExtractionDirection Method (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : GetExtractionDirection Method (ICoreFeatureData)

Gets the entities that define the extraction direction of this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetExtractionDirection( _  
    ByRef Type1 As System.Integer, _  
    ByRef PDir1 As System.Object, _  
    ByRef Type2 As System.Integer, _  
    ByRef PDir2 As System.Object _  
    ) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim Type1 As System.Integer  
Dim PDir1 As System.Object  
Dim Type2 As System.Integer  
Dim PDir2 As System.Object  
Dim value As System.Integer  
  
value = instance.GetExtractionDirection(Type1, PDir1, Type2, PDir2)
```

C#

```
System.int GetExtractionDirection(  
    out System.int Type1,  
    out System.object PDir1,  
    out System.int Type2,  
    out System.object PDir2  
)
```

C++/CLI

```
System.int GetExtractionDirection(  
& [Out] System.int Type1,  
& [Out] System.Object^ PDir1,  
& [Out] System.int Type2,  
& [Out] System.Object^ PDir2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Type1

Type of entity as defined in [swSelectType_e](#)

PDir1

Entity that defines the extraction direction (see **Remarks**)

Type2

Type of entity as defined in [swSelectType_e](#)

PDir2

Entity that defines the extraction direction (see **Remarks**)

Return Value

Number of entities that define the extraction direction

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::GetExtractionDirection](#).

Example

[Get Core Feature Data \(C#\)](#)

[Get Core Feature Data \(VB.NET\)](#)

[Get Core Feature Data \(VBA\)](#)

Remarks

The types of entities that define the extraction direction are:

- Face
- Plane
- Edge
- Vertex
- Sketch line
- Sketch point

There can be two entities because two sketch points can specify a direction.

See Also

[ICoreFeatureData Interface](#)

[ICoreFeatureData Members](#)

[ICoreFeatureData::SetExtractionDirection Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : ReleaseSelectionAccess Method (ICoreFeatureData)

Releases access to the selections that describe this core feature.

.NET Syntax

[Visual Basic \(Declaration\)](#)

Sub ReleaseSelectionAccess()

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::ReleaseSelectionAccess](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

Remarks

[ICoreFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : ReverseDirection Property (ICoreFeatureData)

Gets or sets the direction of the extraction for this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim value As System.Boolean  
  
instance.ReverseDirection = value  
  
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction, false to not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::ReverseDirection](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetExtractionDirection Method (ICoreFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : SetExtractionDirection Method (ICoreFeatureData)

Sets the entities that define the extraction direction of this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Function SetExtractionDirection( _  
    ByVal PDir1 As System.Object, _  
    ByVal PDir2 As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim PDir1 As System.Object  
Dim PDir2 As System.Object  
Dim value As System.Boolean  
  
value = instance.SetExtractionDirection(PDir1, PDir2)
```

C#

```
System.bool SetExtractionDirection(  
    System.object PDir1,  
    System.object PDir2  
)
```

C++/CLI

```
System.bool SetExtractionDirection(  
& System.Object^ PDir1,  
& System.Object^ PDir2  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PDir1

Entity that defines the extraction direction (see **Remarks**)

PDir2

Entity that defines the extraction direction (see **Remarks**)

Return Value

True if the entities that define the extraction direction of this core feature are set, false if not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::SetExtractionDirection](#).

Remarks

The types of entities that define the extraction direction are:

- Face
- Plane
- Edge
- Vertex
- Sketch line
- Sketch point

There can be two entities because two sketch points can specify a direction.

See Also

[ICoreFeatureData Interface](#)

[ICoreFeatureData Members](#)

[ICoreFeatureData::GetExtractionDirection Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TargetBody Property (ICoreFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : TargetBody Property (ICoreFeatureData)

Gets or sets the target body for this core feature.

.NET Syntax

Visual Basic (Declaration)

Property TargetBody As Body2

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim value As Body2
```

```
instance.TargetBody = value
```

```
value = instance.TargetBody
```

C#

```
Body2 TargetBody {get; set;}
```

C++/CLI

```
property Body2^ TargetBody {  
    Body2^ get();  
    void set ( &    Body2^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [body](#) from which this core will be extracted

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::TargetBody](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseDraft Property (ICoreFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICoreFeatureData Interface](#) : UseDraft Property (ICoreFeatureData)

Gets or sets whether draft is applied to this core feature.

.NET Syntax

Visual Basic (Declaration)

```
Property UseDraft As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICoreFeatureData  
Dim value As System.Boolean  
  
instance.UseDraft = value  
  
value = instance.UseDraft
```

C#

```
System.bool UseDraft {get; set;}
```

C++/CLI

```
property System.bool UseDraft {  
    System.bool get();  
    void set ( &    System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply draft, false to not

Visual Basic for Applications (VBA) Syntax

See [CoreFeatureData::UseDraft](#).

Example

[Get Core Feature Data \(C#\)](#)
[Get Core Feature Data \(VB.NET\)](#)
[Get Core Feature Data \(VBA\)](#)

See Also

[ICoreFeatureData Interface](#)
[ICoreFeatureData Members](#)
[ICoreFeatureData::DraftAngle Property](#)
[ICoreFeatureData::DraftOutward Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0