

SOLIDWORKS API (.NET VBA C#) — Reference

(58/337): ICornerManagementFolder- ICornerTreatmentGroupFolder

SOLIDWORKS API Documentation (converted from CHM)

ICornerManagementFolder (Type)

ICornerManagementFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerManagementFolder Interface

Allows access to a corner management folder in a structure system.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICornerManagementFolder
```

Visual Basic (Usage)



```
Dim instance As ICornerManagementFolder
```

C#

```
public interface ICornerManagementFolder
```

C++/CLI

```
public interface class ICornerManagementFolder
```

Visual Basic for Applications (VBA) Syntax

See [CornerManagementFolder](#).

Example

[Access Structure System Corner Treatments \(VBA\)](#)
[Access Structure System Corner Treatments \(VB.NET\)](#)
[Access Structure System Corner Treatments \(C#\)](#)

Remarks

A Corner Management folder is automatically created in the FeatureManager design tree when a [structure system](#) is created.

For more information, see the **SOLIDWORKS Design user-interface help > Weldments and Structure System > Structure System > Corner Management** topic.

Accessors

[IFeatureManager::GetCornerManagementFolders](#) and then [IFeature::GetSpecificFeature2](#)

Access Diagram

[CornerManagementFolder](#)

See Also

[ICornerManagementFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICornerManagementFolder Interface Members

[See Also](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerManagementFolder Interface

The following tables list the members exposed by [ICornerManagementFolder](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this corner management folder.
 GetStructureSystemFolder	Gets the structure system folder containing this corner management folder.
 GetTreatmentGroupFolderCount	Gets the number of corner treatment group folders.
 GetTreatmentGroupFolders	Gets the corner treatment group folders.

[Top](#)

See Also

[ICornerManagementFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICornerManagementFolder Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [ICornerManagementFolder Interface](#)

For a list of all members of this type, see [ICornerManagementFolder members](#).

Public Methods

Name	Description
 GetFeature	Gets the feature for this corner management folder.
 GetStructureSystemFolder	Gets the structure system folder containing this corner management folder.
 GetTreatmentGroupFolderCount	Gets the number of corner treatment group folders.
 GetTreatmentGroupFolders	Gets the corner treatment group folders.

[Top](#)

See Also

[ICornerManagementFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (ICornerManagementFolder)

[See Also](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [ICornerManagementFolder Interface](#) : [GetFeature Method \(ICornerManagementFolder\)](#)

Gets the feature for this corner management folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As ICornerManagementFolder  
Dim value As Feature  
  
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CornerManagementFolder::GetFeature](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerManagementFolder Interface](#)
[ICornerManagementFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetStructureSystemFolder Method (ICornerManagementFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerManagementFolder Interface](#) : GetStructureSystemFolder Method (ICornerManagementFolder)

Gets the structure system folder containing this corner management folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetStructureSystemFolder() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICornerManagementFolder  
Dim value As System.Object  
  
value = instance.GetStructureSystemFolder()
```

C#

```
System.object GetStructureSystemFolder()
```

C++/CLI

```
System.Object^ GetStructureSystemFolder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CornerManagementFolder::GetStructureSystemFolder](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

After calling this method to get the IFeature, use [IFeature::GetSpecificFeature2](#) to get an [IStructureSystemFolder](#).

See Also

[ICornerManagementFolder Interface](#)
[ICornerManagementFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTreatmentGroupFolderCount Method (ICornerManagementFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerManagementFolder Interface](#) : GetTreatmentGroupFolderCount Method (ICornerManagementFolder)

Gets the number of corner treatment group folders.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTreatmentGroupFolderCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerManagementFolder  
Dim value As System.Integer  
  
value = instance.GetTreatmentGroupFolderCount()
```

C#

```
System.int GetTreatmentGroupFolderCount()
```

C++/CLI

```
System.int GetTreatmentGroupFolderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of corner treatment group folders

Visual Basic for Applications (VBA) Syntax

See [CornerManagementFolder::GetTreatmentGroupFolderCount](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerManagementFolder Interface](#)
[ICornerManagementFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTreatmentGroupFolders Method (ICornerManagementFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerManagementFolder Interface](#) : GetTreatmentGroupFolders Method (ICornerManagementFolder)

Gets the corner treatment group folders.

.NET Syntax

Visual Basic (Declaration)

```
Function GetTreatmentGroupFolders() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICornerManagementFolder  
Dim value As System.Object  
  
value = instance.GetTreatmentGroupFolders()
```

C#

```
System.object GetTreatmentGroupFolders()
```

C++/CLI

```
System.Object^ GetTreatmentGroupFolders();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [ICornerTreatmentGroupFolders](#)

Visual Basic for Applications (VBA) Syntax

See [CornerManagementFolder::GetTreatmentGroupFolders](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerManagementFolder Interface](#)
[ICornerManagementFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

ICornerMember (Type)

ICornerMember Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerMember Interface

Allows access to a corner member of a complex or two member structure system corner treatment feature.
NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICornerMember
```

Visual Basic (Usage)

```
Dim instance As ICornerMember
```

C#

```
public interface ICornerMember
```

C++/CLI

```
public interface class ICornerMember
```

Visual Basic for Applications (VBA) Syntax

See [CornerMember](#).

Example

See the [ICornerManagementFolder](#) examples.

Accessors

[IComplexCornerTreatmentFeatureData::GetBodyTrimMembers](#) and then cast to ICornerMember
[IComplexCornerTreatmentFeatureData::GetPlanarTrimMembers](#) and then cast to ICornerMember
[IComplexCornerTreatmentFeatureData::GetTrimToolMember](#) and then cast to ICornerMember
[ITwoMemberCornerTreatmentFeatureData::GetCornerGroupMembers](#) and then cast to ICornerMember

Access Diagram

[CornerMember](#)

See Also

[ICornerMember Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICornerMember Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerMember Interface

For a list of all members of this type, see [ICornerMember members](#).

Public Methods

Name	Description
------	-------------



[GetUnderlyingMemberFeature](#)

Gets the feature for this corner member.

[Top](#)

See Also

[ICornerMember Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICornerMember Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerMember Interface

The following tables list the members exposed by [ICornerMember](#).

Public Properties

Name	Description
 TrimOrder	Gets and sets the trim order of this corner member.
 WeldGap	Gets and sets the weld gap of this corner member.

[Top](#)

Public Methods

Name	Description
 GetUnderlyingMemberFeature	Gets the feature for this corner member.

[Top](#)

See Also

[ICornerMember Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICornerMember Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerMember Interface

For a list of all members of this type, see [ICornerMember members](#).

Public Properties

Name	Description
 TrimOrder	Gets and sets the trim order of this corner member.
 WeldGap	Gets and sets the weld gap of this corner member.

[Top](#)

See Also

[ICornerMember Interface](#)

[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetUnderlyingMemberFeature Method (ICornerMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerMember Interface](#) : GetUnderlyingMemberFeature Method (ICornerMember)

Gets the feature for this corner member.

.NET Syntax

Visual Basic (Declaration)

Function GetUnderlyingMemberFeature() As System.Object

Visual Basic (Usage)



```
Dim instance As ICornerMember  
Dim value As System.Object  
  
value = instance.GetUnderlyingMemberFeature()
```

C#

```
System.object GetUnderlyingMemberFeature()
```

C++/CLI

```
System.Object^ GetUnderlyingMemberFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CornerMember::GetUnderlyingMemberFeature](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

After calling this method to get the IFeature, use [IFeature::GetSpecificFeature2](#) to get an [IStructureSystemMemberFeatureData](#).

See Also

[ICornerMember Interface](#)
[ICornerMember Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

TrimOrder Property (ICornerMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerMember Interface](#) : TrimOrder Property (ICornerMember)

Gets and sets the trim order of this corner member.

.NET Syntax

Visual Basic (Declaration)

```
Property TrimOrder As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerMember  
Dim value As System.Integer  
  
instance.TrimOrder = value  
  
value = instance.TrimOrder
```

C#

```
System.int TrimOrder {get; set;}
```

C++/CLI

```
property System.int TrimOrder {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Trim order

Visual Basic for Applications (VBA) Syntax

See [CornerMember::TrimOrder](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerMember Interface](#)
[ICornerMember Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

WeldGap Property (ICornerMember)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerMember Interface](#) : WeldGap Property (ICornerMember)

Gets and sets the weld gap of this corner member.

.NET Syntax

Visual Basic (Declaration)

```
Property WeldGap As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICornerMember  
Dim value As System.Double
```

```
instance.WeldGap = value
```

```
value = instance.WeldGap
```

C#

```
System.double WeldGap {get; set;}
```

C++/CLI

```
property System.double WeldGap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld gap in meters between members; default is 0.0

Visual Basic for Applications (VBA) Syntax

See [CornerMember.WeldGap](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerMember Interface](#)
[ICornerMember Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

ICornerReliefFeatureData (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICornerReliefFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerReliefFeatureData Interface

Allows access to sheet metal corner relief feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICornerReliefFeatureData
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData
```

C#

```
public interface ICornerReliefFeatureData
```

C++/CLI

```
public interface class ICornerReliefFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData](#).

Example

'VBA

'=====

'Preconditions:

'1. Ensure that the specified part template exists.

'2. Open an Immediate window.

'

'Postconditions:

' 1. Press F5.

' 2. Creates:

' - **Base-Flange1**

' - **Sketched Bend1**

' - **Sketched Bend2**

' - **Sketched Bend3**

' - **Sketched Bend4**

' 3. Selects the sheet metal solid body.

' 4. Sets rectangular reliefs for the four corners.

' 5. Creates **Corner Relief1**.

' 6. Press F5.

' 7. Changes four corners to have circular reliefs.

' 8. Press F5.

' 9. Changes four corners to have constant width reliefs.

'10. Inspect the Immediate window and the graphics area after each change.

```
'=====
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim featMgr As SldWorks.FeatureManager
Dim cornerReliefFeatData As SldWorks.CornerReliefFeatureData
Dim swBody As SldWorks.Body2
Dim selMgr As SldWorks.SelectionMgr
Dim SMCorner As SldWorks.SMCornerReliefData
Dim getCornerVar As Variant
Dim cntr1 As Long
Dim cornerItr As SldWorks.SMCornerReliefData
Dim Feat As SldWorks.Feature
Dim featModData As SldWorks.CornerReliefFeatureData
Dim cornerReliefMod3Data As SldWorks.CornerReliefFeatureData
Dim UseRatio As Boolean
Dim CFace1 As SldWorks.face2
Dim CFace2 As SldWorks.face2
Dim CFace3 As SldWorks.face2
Dim boolstatus As Boolean
Dim longstatus As Long, longwarnings As Long
Sub PrintReliefData(ByVal cornerIndex As Long, ByVal cornerReliefFeatData As
SldWorks.CornerReliefFeatureData)
    Dim smCornerReliefData1 As SldWorks.SMCornerReliefData
    boolstatus = cornerReliefFeatData.GetCornerAtIndex(cornerIndex,
smCornerReliefData1)

    Debug.Print "Add filleted corners? " & smCornerReliefData1.AddFilletedCorners
    Debug.Print "Corner fillet diameter = " &
smCornerReliefData1.CornerFilletDiameter
    Debug.Print "Use ratio to thickness? " & smCornerReliefData1.RatioToThickness
    Debug.Print "Relief type as defined by swCornerBendReliefType_e = " &
smCornerReliefData1.ReliefType
    Debug.Print "Slot length = " & smCornerReliefData1.SlotLength
    Debug.Print "Slot width = " & smCornerReliefData1.SlotWidth
    Debug.Print "Center on bend lines? " & smCornerReliefData1.CenterOnBendLines
    Debug.Print "Tangent to bend? " & smCornerReliefData1.TangentToBend

    Call smCornerReliefData1.GetFaces(CFace1, CFace2, CFace3)
End Sub
Sub main()
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
```

```

Dim swSheetWidth As Double
swSheetWidth = 0
Dim swSheetHeight As Double
swSheetHeight = 0
Set swModel = swApp.NewDocument("C:\ProgramData\SolidWorks\SOLIDWORKS
2022\templates\Part.PRTDOT", 0, swSheetWidth, swSheetHeight)
Set featMgr = swModel.FeatureManager
boolstatus = swModel.Extension.SelectByID2("Front Plane", "PLANE",
-7.54055245830957E-02, 5.42345258765876E-02, 2.94433115750138E-03, False, 0, Nothing,
0)
swModel.SketchManager.InsertSketch True
swModel.ClearSelection2 True
Dim skSegment As Object
Set skSegment = swModel.SketchManager.CreateLine(-0.049594, 0.029143, 0#,
0.026075, 0.029143, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.026075, 0.029143, 0#,
0.026075, 0.015645, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.026075, 0.015645, 0#, 0.04305,
0.015645, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.04305, 0.015645, 0#, 0.04305,
-0.034869, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.04305, -0.034869, 0#,
0.026075, -0.034869, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.026075, -0.034869, 0#,
0.026075, -0.048571, 0#)
Set skSegment = swModel.SketchManager.CreateLine(0.026075, -0.048571, 0#,
-0.049594, -0.048571, 0#)
Set skSegment = swModel.SketchManager.CreateLine(-0.049594, -0.048571, 0#,
-0.049594, -0.034869, 0#)
Set skSegment = swModel.SketchManager.CreateLine(-0.049594, -0.034869, 0#,
-0.066568, -0.034869, 0#)
Set skSegment = swModel.SketchManager.CreateLine(-0.066568, -0.034869, 0#,
-0.066568, 0.015645, 0#)
Set skSegment = swModel.SketchManager.CreateLine(-0.066568, 0.015645, 0#,
-0.049594, 0.015645, 0#)
Set skSegment = swModel.SketchManager.CreateLine(-0.049594, 0.015645, 0#,
-0.049594, 0.029143, 0#)
swModel.ClearSelection2 True
swModel.SketchManager.InsertSketch True

swModel.ShowNamedView2 "*Trimetric", 8
swModel.ViewZoomtofit2
swModel.SketchManager.InsertSketch True
Dim customBendAllowanceData As SldWorks.CustomBendAllowance
Set customBendAllowanceData = swModel.FeatureManager.CreateCustomBendAllowance()
customBendAllowanceData.KFactor = 0.5
Dim myFeature As SldWorks.Feature
Set myFeature = swModel.FeatureManager.InsertSheetMetalBaseFlange2(0.0007366,
False, 0.0007366, 0.02, 0.01, False, 0, 0, 1, customBendAllowanceData, False, 0,
0.0001, 0.0001, 0.5, True, False, True, True)

```

```

    boolstatus = swModel.Extension.SelectByRay(-1.45172925108454E-02,
-3.87700058865903E-03, 0, -0.5, -0.707106781186547, -0.5, 5.56802642645787E-04, 2,
False, 0, 0)
    swModel.SketchManager.InsertSketch True
    swModel.ClearSelection2 True
    Set skSegment = swModel.SketchManager.CreateLine(-0.049594, 0.015645, 0#,
-0.049594, -0.034869, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True
    swModel.SketchManager.InsertSketch True
    boolstatus = swModel.Extension.SelectByRay(-2.54254889823514E-02,
-6.75397704068888E-03, 0, 0, 0, -1, 4.28258640921609E-04, 2, True, 0, 0)
    Dim CBAObject As SldWorks.CustomBendAllowance
    Set myFeature = swModel.FeatureManager.InsertSheetMetal3dBend(1.5707963267949,
True, 0.0007366, False, 3, CBAObject)
    boolstatus = swModel.Extension.SelectByRay(-2.46697384395485E-02,
-2.97522432667467E-03, 0, 0, 0, -1, 4.28258640921609E-04, 2, False, 0, 0)
    swModel.SketchManager.InsertSketch True
    swModel.ClearSelection2 True
    boolstatus = swModel.Extension.SelectByRay(-0.049594, 0.015645, 0, 0, 0, -1,
3.92913800359539E-04, 3, False, 0, 0)
    swModel.ClearSelection2 True
    Set skSegment = swModel.SketchManager.CreateLine(-0.049594, 0.015645, 0#,
0.026075, 0.015645, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True
    swModel.SketchManager.InsertSketch True
    boolstatus = swModel.Extension.SelectByRay(-2.35965085767476E-02,
-4.34032596567101E-03, 0, 0, 0, -1, 3.92913800359539E-04, 2, True, 0, 0)
    Set myFeature = swModel.FeatureManager.InsertSheetMetal3dBend(1.5707963267949,
True, 0.0007366, False, 3, CBAObject)
    boolstatus = swModel.Extension.SelectByRay(-2.34809456942889E-02,
-1.97101893326765E-02, 0, 0, 0, -1, 3.92913800359539E-04, 2, False, 0, 0)
    swModel.SketchManager.InsertSketch True
    swModel.ClearSelection2 True
    Set skSegment = swModel.SketchManager.CreateLine(-0.049594, -0.034869, 0#,
0.026075, -0.034869, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True
    swModel.SketchManager.InsertSketch True
    boolstatus = swModel.Extension.SelectByRay(-1.71484564194607E-02,
-3.99245414393841E-03, 0, 0, 0, -1, 3.67699685812068E-04, 2, True, 0, 0)
    Set myFeature = swModel.FeatureManager.InsertSheetMetal3dBend(1.5707963267949,
True, 0.0007366, False, 3, CBAObject)
    boolstatus = swModel.Extension.SelectByRay(-1.07677854009571E-02,
-9.72424336395007E-03, 0, 0, 0, -1, 3.67699685812068E-04, 2, False, 0, 0)
    swModel.SketchManager.InsertSketch True
    swModel.ClearSelection2 True

```

```

    Set skSegment = swModel.SketchManager.CreateLine(0.026075, -0.034869, 0#,
0.026075, 0.015645, 0#)
    swModel.ClearSelection2 True
    swModel.SketchManager.InsertSketch True
    swModel.SketchManager.InsertSketch True
    boolstatus = swModel.Extension.SelectByRay(-2.59083606991011E-02,
-6.2053705579176E-03, 0, 0, 0, -1, 3.67699685812068E-04, 2, True, 0, 0)
    Set myFeature = swModel.FeatureManager.InsertSheetMetal3dBend(1.5707963267949,
True, 0.0007366, False, 3, CBAObject)
    ' Zoom to Area
    swModel.ViewZoomTo2 1.52447662706814E-02, 2.18199896815251E-03,
-8.86660359613402E-03, 0.022429935049572, -6.38493303744786E-03, -8.86660359613402E-
03

    Set cornerReliefFeatData = featMgr.CreateDefinition(swFmCornerRelief)

    boolstatus = swModel.Extension.SelectByID2("Sketched Bend4", "SOLIDBODY", 0, 0,
0, False, 0, Nothing, 0)

    Set selMgr = swModel.SelectionManager

    Set swBody = selMgr.GetSelectedObject6(1, -1)

    cornerReliefFeatData.Initialize swCornerReliefBendType_TwoBend
    cornerReliefFeatData.SetBodyScope swBody

    'Create corners (tear reliefs are the default reliefs for Sketched Bends)
    longstatus = cornerReliefFeatData.CollectAllCorners(swCornerTearRelief,
getCornerVar)

    Debug.Print ""
    Debug.Print "-----Changing corners to rectangular reliefs-----"
    --- "
    For cntr1 = 0 To UBound(getCornerVar)

        Set cornerItr = getCornerVar(cntr1)

        cornerItr.AddFilletCorners = True
        cornerItr.CornerFilletDiameter = 0.00025
        cornerItr.CenterOnBendLines = True
        cornerItr.TangentToBend = True
        cornerItr.ReliefType = swCornerRectangularRelief

        UseRatio = True

        If Not UseRatio Then
            cornerItr.SlotLength = 0.009

```

```

Else
    cornerItr.RatioToThickness = True
End If

PrintReliefData cntr1 + 1, cornerReliefFeatData
Debug.Print ""
Next

Set Feat = featMgr.CreateFeature(cornerReliefFeatData)

Stop

Set featModData = Feat.GetDefinition()

featModData.AccessSelections swModel, Nothing

getCornerVar = featModData.GetCorners(-1)

Debug.Print ""
Debug.Print "-----Changing corners to circular reliefs-----"
"

For cntr1 = 0 To UBound(getCornerVar)

    Set cornerItr = getCornerVar(cntr1)

    cornerItr.ReliefType = swCornerCircularRelief

    UseRatio = False

    If Not UseRatio Then
        cornerItr.SlotWidth = 0.0008
    Else
        cornerItr.RatioToThickness = True
    End If

    PrintReliefData cntr1 + 1, featModData
    Debug.Print ""

Next

Feat.ModifyDefinition featModData, swModel, Nothing

Stop

```

```

Set cornerReliefMod3Data = Feat.GetDefinition()

cornerReliefMod3Data.AccessSelections swModel, Nothing

getCornerVar = cornerReliefMod3Data.GetCorners(-1)

Debug.Print ""
Debug.Print "-----Changing corners to constant width reliefs-----"
----- "

For cntr1 = 0 To UBound(getCornerVar)

    Set cornerItr = getCornerVar(cntr1)

    cornerItr.ReliefType = swCornerConstantWidthRelief

    PrintReliefData cntr1 + 1, cornerReliefMod3Data
    Debug.Print ""

Next

Feat.ModifyDefinition cornerReliefMod3Data, swModel, Nothing
End Sub

```

Example

[Create Sheet Metal Corner Relief Feature \(VB.NET\)](#)
[Create Sheet Metal Corner Relief Feature \(C#\)](#)

Remarks

For more information see the **SOLIDWORKS Design** user-interface help > Sheet Metal > Using Sheet Metal Tools > Corner Reliefs and Bend Transitions topics.

Accessors

[IFeature::GetDefinition](#)
[IFeatureManager::CreateDefinition](#)

Access Diagram

[CornerReliefFeatureData](#)

See Also

[ICornerReliefFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

Public Properties

Name	Description
 CornerCount	Gets the number of corner objects in this corner relief feature.
 CornerType	Gets the bend type of this corner relief feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this sheet metal corner relief feature.
 AddNewCorner	Adds a corner with the specified parameters to this sheet metal corner relief feature.
 CollectAllCorners	Creates corners, all with the specified relief, in a selected sheet-metal body.
 GetBodyScope	Gets the sheet metal body to which this corner relief feature is applied.
 GetCornerAtIndex	Gets the corner at the specified index of this corner relief feature.
 GetCorners	Gets all corners of the specified type in this corner relief feature.
 Initialize	Initializes this corner relief feature to have specified corner relief bend type.
 ReleaseSelectionAccess	Releases access to the selections that define this sheet metal corner relief feature.
 RemoveCorner	Removes the specified corner from this corner relief feature.
 SetBodyScope	Sets the sheet metal body to which this corner relief feature is applied.

[Top](#)

See Also

[ICornerReliefFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICornerReliefFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerReliefFeatureData Interface

For a list of all members of this type, see [ICornerReliefFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this sheet metal corner relief feature.
 AddNewCorner	Adds a corner with the specified parameters to this sheet metal corner relief feature.
 CollectAllCorners	Creates corners, all with the specified relief, in a selected sheet-metal body.
 GetBodyScope	Gets the sheet metal body to which this corner relief feature is applied.
 GetCornerAtIndex	Gets the corner at the specified index of this corner relief feature.
 GetCorners	Gets all corners of the specified type in this corner relief feature.
 Initialize	Initializes this corner relief feature to have specified corner relief bend type.
 ReleaseSelectionAccess	Releases access to the selections that define this sheet metal corner relief feature.
 RemoveCorner	Removes the specified corner from this corner relief feature.
 SetBodyScope	Sets the sheet metal body to which this corner relief feature is applied.

[Top](#)

See Also

[ICornerReliefFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICornerReliefFeatureData Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ICornerReliefFeatureData Interface

For a list of all members of this type, see [ICornerReliefFeatureData members](#).

Public Properties

Name	Description
 CornerCount	Gets the number of corner objects in this corner relief feature.
 CornerType	Gets the bend type of this corner relief feature.

[Top](#)

See Also

[ICornerReliefFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

AccessSelections Method (ICornerReliefFeatureData)

[See Also](#)

 

[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : AccessSelections Method (ICornerReliefFeatureData)

Gains access to the selections that define this sheet metal corner relief feature.

.NET Syntax

Visual Basic (Declaration)

Function AccessSelections(_
 ByVal [TopDoc](#) As System.Object, _
 ByVal [Component](#) As System.Object _
) As System.Boolean

Visual Basic (Usage)  [Copy Code](#)

Dim instance As [ICornerReliefFeatureData](#)
Dim TopDoc As System.Object
Dim Component As System.Object
Dim value As System.Boolean

value = instance.AccessSelections(TopDoc, Component)

C#

System.bool AccessSelections(
 System.object [TopDoc](#),
 System.object [Component](#)
)

C++/CLI

System.bool AccessSelections(
& System.Object^ [TopDoc](#),
& System.Object^ [Component](#)
)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::AccessSelections](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ICornerReliefFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

AddNewCorner Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : AddNewCorner Method (ICornerReliefFeatureData)

Adds a corner with the specified parameters to this sheet metal corner relief feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AddNewCorner( _  
    ByVal Face1 As System.Object, _  
    ByVal Face2 As System.Object, _  
    ByVal Face3 As System.Object, _  
    ByVal ReliefType As System.Integer, _  
    ByRef Corner As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim Face1 As System.Object  
Dim Face2 As System.Object  
Dim Face3 As System.Object  
Dim ReliefType As System.Integer  
Dim Corner As System.Object  
Dim value As System.Integer
```

```
value = instance.AddNewCorner(Face1, Face2, Face3, ReliefType, Corner)
```

C#

```
System.int AddNewCorner(  
    System.object Face1,  
    System.object Face2,  
    System.object Face3,  
    System.int ReliefType,
```

```
    out System.Object Corner
)
```

C++/CLI

```
System.int AddNewCorner(
& System.Object^ Face1,
& System.Object^ Face2,
& System.Object^ Face3,
& System.int ReliefType,
& [Out] System.Object^ Corner
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Face1

First [IFace2](#) that defines this two- or three-bend corner

Face2

Second [IFace2](#) that defines this two- or three-bend corner

Face3

Third [IFace2](#) that defines this three-bend corner; valid only if [ICornerReliefFeatureData::CornerReliefBendType](#) is [swCornerReliefBendType_e.swCornerReliefBendType_ThreeBend](#); specify nu or Nothing for a two-bend corner

ReliefType

Corner relief type as defined by [swCornerReliefType_e](#)

Corner

[ISMCornerReliefData](#)

Return Value

Error code as defined by [swCornerReliefError_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::AddNewCorner](#).

See Also

[ICornerReliefFeatureData Interface](#)

[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CollectAllCorners Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : CollectAllCorners Method (ICornerReliefFeatureData)

Creates corners, all with the specified relief, in a selected sheet-metal body.

.NET Syntax

Visual Basic (Declaration)

```
Function CollectAllCorners( _
    ByVal ReliefType As System.Integer, _
    ByRef Corners As System.Object _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData
Dim ReliefType As System.Integer
Dim Corners As System.Object
Dim value As System.Integer
```

```
value = instance.CollectAllCorners(ReliefType, Corners)
```

C#

```
System.int CollectAllCorners(  
    System.int ReliefType,  
    out System.object Corners  
)
```

C++/CLI

```
System.int CollectAllCorners(  
& System.int ReliefType,  
& [Out] System.Object^ Corners  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

ReliefType

Corner relief type as defined by [swCornerReliefType_e](#)

Corners

Array of [ISMCornerReliefData](#)s

Return Value

Error code as defined by [swCornerReliefError_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::CollectAllCorners](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

Before calling this method, call [ICornerReliefFeatureData::SetBodyScope](#).

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

CornerCount Property (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : CornerCount Property (ICornerReliefFeatureData)

Gets the number of corner objects in this corner relief feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CornerCount As System.Integer

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim value As System.Integer
```

```
value = instance.CornerCount
```

C#

```
System.int CornerCount {get;}
```

C++/CLI

```
property System.int CornerCount {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of [ISMCornerReliefData](#) objects

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::CornerCount](#).

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

CornerType Property (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : CornerType Property (ICornerReliefFeatureData)

Gets the bend type of this corner relief feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CornerType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim value As System.Integer  
  
value = instance.CornerType
```

C#

```
System.int CornerType {get;}
```

C++/CLI

```
property System.int CornerType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Corner relief bend type as defined by [swCornerReliefBendType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::CornerType](#).

Remarks

This property cannot be changed after it is set by [ICornerReliefFeatureData::Initialize](#).

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetBodyScope Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : GetBodyScope Method (ICornerReliefFeatureData)

Gets the sheet metal body to which this corner relief feature is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function GetBodyScope() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim value As System.Object  
  
value = instance.GetBodyScope()
```

C#

```
System.object GetBodyScope()
```

C++/CLI

```
System.Object^ GetBodyScope();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IBody2](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::GetBodyScope](#).

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetCornerAtIndex Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : GetCornerAtIndex Method (ICornerReliefFeatureData)

Gets the corner at the specified index of this corner relief feature.

.NET Syntax

```
Function GetCornerAtIndex( _
    ByVal CornerIndex As System.Integer, _
    ByRef Corner As System.Object _
) As System.Integer
```

```
Dim instance As ICornerReliefFeatureData
Dim CornerIndex As System.Integer
Dim Corner As System.Object
Dim value As System.Integer

value = instance.GetCornerAtIndex(CornerIndex, Corner)
```

```
System.int GetCornerAtIndex(
    System.int CornerIndex,
    out System.object Corner
)
```

```
System.int GetCornerAtIndex(
    & System.int CornerIndex,
    & [Out] System.Object^ Corner
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CornerIndex
One-based index of corner to retrieve
Corner
[ISMCornerReliefData](#)

Return Value

Error code as defined by [swCornerReliefError_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::GetCornerAtIndex](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

GetCorners Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : GetCorners Method (ICornerReliefFeatureData)

Gets all corners of the specified type in this corner relief feature.

.NET Syntax

```
Function GetCorners( _  
    ByVal CornerReliefType As System.Integer _  
    ) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim CornerReliefType As System.Integer  
Dim value As System.Object  
  
value = instance.GetCorners(CornerReliefType)
```

C#

```
System.object GetCorners(  
    System.int CornerReliefType  
)
```

C++/CLI

```
System.Object^ GetCorners(  
& System.int CornerReliefType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CornerReliefType
Corner relief type as defined by [swCornerReliefType_e](#)

Return Value

Array of [ISMCornerReliefDatas](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::GetCorners](#).

Example

See the [ICornerReliefFeatureData](#) examples.

Remarks

If CornerReliefType is specified with -1, then this method retrieves corners of all types.

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

Initialize Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : Initialize Method (ICornerReliefFeatureData)

Initializes this corner relief feature to have specified corner relief bend type.

.NET Syntax

Visual Basic (Declaration)

```
Function Initialize( _  
    ByVal CornerType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim CornerType As System.Integer  
Dim value As System.Boolean  
  
value = instance.Initialize(CornerType)
```

C#

```
System.bool Initialize(  
    System.int CornerType  
)
```

C++/CLI

```
System.bool Initialize(  
&    System.int CornerType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CornerType
Corner relief bend type as defined by [swCornerReliefBendType_e](#)

Return Value

True if the corner relief feature is initialized to the specified bend type, false if not

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::Initialize](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)
[ICornerReliefFeatureData::CornerType Property \(\)](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : ReleaseSelectionAccess Method (ICornerReliefFeatureData)

Releases access to the selections that define this sheet metal corner relief feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::ReleaseSelectionAccess](#).

Remarks

[ICornerReliefFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments](#) on this topic.

RemoveCorner Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : RemoveCorner Method (ICornerReliefFeatureData)

Removes the specified corner from this corner relief feature.

.NET Syntax

Visual Basic (Declaration)

```
Function RemoveCorner( _  
    ByVal CornerIndex As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim CornerIndex As System.Integer  
Dim value As System.Boolean  
  
value = instance.RemoveCorner(CornerIndex)
```

C#

```
System.bool RemoveCorner(  
    System.int CornerIndex  
)
```

C++/CLI

```
System.bool RemoveCorner(  
& System.int CornerIndex
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

CornerIndex

One-based index of corner to remove

Return Value

True if specified corner successfully removed, false if not

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::RemoveCorner](#).

See Also

[ICornerReliefFeatureData Interface](#)

[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetBodyScope Method (ICornerReliefFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerReliefFeatureData Interface](#) : SetBodyScope Method (ICornerReliefFeatureData)

Sets the sheet metal body to which this corner relief feature is applied.

.NET Syntax

Visual Basic (Declaration)

```
Function SetBodyScope( _  
    ByVal SheetBody As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerReliefFeatureData  
Dim SheetBody As System.Object  
Dim value As System.Integer
```

```
value = instance.SetBodyScope(SheetBody)
```

C#

```
System.int SetBodyScope(  
    System.object SheetBody  
)
```

C++/CLI

```
System.int SetBodyScope(  
& System.Object^ SheetBody  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

SheetBody

[IBody2](#) sheet metal body

Return Value

Error code as defined by [swCornerReliefError_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerReliefFeatureData::SetBodyScope](#).

Example

See the [ICornerReliefFeatureData](#) examples.

See Also

[ICornerReliefFeatureData Interface](#)
[ICornerReliefFeatureData Members](#)

Availability

SOLIDWORKS 2022 FCS, Revision Number 30

ICornerTreatmentFeatureData (Type)

ICornerTreatmentFeatureData Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentFeatureData Interface

Allows access to a corner treatment feature of a structure system.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICornerTreatmentFeatureData
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData
```

C#

```
public interface ICornerTreatmentFeatureData
```

C++/CLI

```
public interface class ICornerTreatmentFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

This interface is the base class for the following interfaces:

- [IComplexCornerTreatmentFeatureData](#)
- [ISimpleCornerTreatmentFeatureData](#)
- [ITwoMemberCornerTreatmentFeatureData](#)

Accessors

[ICornerTreatmentGroupFolder::GetCornerTreatments](#)

Access Diagram

[CornerTreatmentFeatureData](#)

See Also

[ICornerTreatmentFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICornerTreatmentFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentFeatureData Interface

The following tables list the members exposed by [ICornerTreatmentFeatureData](#).

Public Properties

Name	Description
 AllowExtension	Gets and sets whether to extend structural members.
 CornerType	Gets the type of this corner treatment.
 IgnoreCornerTreatment	Gets and sets whether to ignore this corner treatment.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this corner treatment feature.
 GetFeature	Gets the feature for this corner treatment.
 ReleaseSelectionAccess	Releases access to the selections that define this corner treatment feature.

[Top](#)

See Also

[ICornerTreatmentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICornerTreatmentFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentFeatureData Interface

For a list of all members of this type, see [ICornerTreatmentFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this corner treatment feature.
 GetFeature	Gets the feature for this corner treatment.
 ReleaseSelectionAccess	Releases access to the selections that define this corner treatment feature.

[Top](#)

See Also

[ICornerTreatmentFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICornerTreatmentFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentFeatureData Interface

For a list of all members of this type, see [ICornerTreatmentFeatureData members](#).

Public Properties

Name	Description
 AllowExtension	Gets and sets whether to extend structural members.
 CornerType	Gets the type of this corner treatment.
 IgnoreCornerTreatment	Gets and sets whether to ignore this corner treatment.

[Top](#)

See Also

AccessSelections Method (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : AccessSelections Method (ICornerTreatmentFeatureData)

Gains access to the selections that define this corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::AccessSelections](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) if you modified the feature
- [ICornerTreatmentFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

AllowExtension Property (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : AllowExtension Property (ICornerTreatmentFeatureData)

Gets and sets whether to extend structural members.

.NET Syntax

Visual Basic (Declaration)

Property AllowExtension As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData
Dim value As System.Boolean
```

```
instance.AllowExtension = value
```

```
value = instance.AllowExtension
```

C#

```
System.bool AllowExtension {get; set;}
```

C++/CLI

```
property System.bool AllowExtension {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to extend structural members, false to not

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::AllowExtension](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

CornerType Property (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : CornerType Property (ICornerTreatmentFeatureData)

Gets the type of this corner treatment.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CornerType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData  
Dim value As System.Integer  
  
value = instance.CornerType
```

C#

```
System.int CornerType {get;}
```

C++/CLI

```
property System.int CornerType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of corner treatment as defined by [swCornerType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::CornerType](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

GetFeature Method (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : GetFeature Method (ICornerTreatmentFeatureData)

Gets the feature for this corner treatment.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeature() As Feature
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData
Dim value As Feature

value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::GetFeature](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

IgnoreCornerTreatment Property (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : IgnoreCornerTreatment Property (ICornerTreatmentFeatureData)

Gets and sets whether to ignore this corner treatment.

.NET Syntax

Visual Basic (Declaration)

```
Property IgnoreCornerTreatment As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData
Dim value As System.Boolean

instance.IgnoreCornerTreatment = value
value = instance.IgnoreCornerTreatment
```

C#

```
System.bool IgnoreCornerTreatment {get; set;}
```

C++/CLI

```
property System.bool IgnoreCornerTreatment {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to ignore the corner treatment, false to not

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::IgnoreCornerTreatment](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICornerTreatmentFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentFeatureData Interface](#) : ReleaseSelectionAccess Method (ICornerTreatmentFeatureData)

Releases access to the selections that define this corner treatment feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentFeatureData::ReleaseSelectionAccess](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

[ICornerTreatmentFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) if you did.

See Also

[ICornerTreatmentFeatureData Interface](#)
[ICornerTreatmentFeatureData Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

ICornerTreatmentGroupFolder (Type)

ICornerTreatmentGroupFolder Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentGroupFolder Interface

Allows access to a corner treatment group folder of a structure system.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICornerTreatmentGroupFolder
```

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentGroupFolder
```

C#

```
public interface ICornerTreatmentGroupFolder
```

C++/CLI

```
public interface class ICornerTreatmentGroupFolder
```

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentGroupFolder](#).

Example

See the [ICornerManagementFolder](#) examples.

Accessors

[ICornerManagementFolder::GetTreatmentGroupFolders](#)

Access Diagram

[CornerTreatmentGroupFolder](#)

See Also

[ICornerTreatmentGroupFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICornerTreatmentGroupFolder Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentGroupFolder Interface

For a list of all members of this type, see [ICornerTreatmentGroupFolder members](#).

Public Methods

Name	Description
 GetCornerTreatmentCount	Gets the number of corner treatments in this corner treatment group folder.
 GetCornerTreatments	Gets the corner treatments in this corner treatment group folder.
 GetFeature	Gets the feature for this corner treatment group folder.

[Top](#)

See Also

[ICornerTreatmentGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICornerTreatmentGroupFolder Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentGroupFolder Interface

The following tables list the members exposed by [ICornerTreatmentGroupFolder](#).

Public Properties

Name	Description
 Type	Gets the type of corner treatments in this corner treatment group folder.

[Top](#)

Public Methods

Name	Description
 GetCornerTreatmentCount	Gets the number of corner treatments in this corner treatment group folder.
 GetCornerTreatments	Gets the corner treatments in this corner treatment group folder.
 GetFeature	Gets the feature for this corner treatment group folder.

[Top](#)

See Also

[ICornerTreatmentGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICornerTreatmentGroupFolder Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICornerTreatmentGroupFolder Interface

For a list of all members of this type, see [ICornerTreatmentGroupFolder members](#).

Public Properties

Name	Description
 Type	Gets the type of corner treatments in this corner treatment group folder.

[Top](#)

See Also

[ICornerTreatmentGroupFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCornerTreatmentCount Method (ICornerTreatmentGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentGroupFolder Interface](#) : GetCornerTreatmentCount Method (ICornerTreatmentGroupFolder)

Gets the number of corner treatments in this corner treatment group folder.

.NET Syntax

Visual Basic (Declaration)

Function GetCornerTreatmentCount() As System.Integer

```
Dim instance As ICornerTreatmentGroupFolder
Dim value As System.Integer

value = instance.GetCornerTreatmentCount()
```

C#

```
System.int GetCornerTreatmentCount()
```

C++/CLI

```
System.int GetCornerTreatmentCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of corner treatments

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentGroupFolder::GetCornerTreatmentCount](#).

See Also

[ICornerTreatmentGroupFolder Interface](#)
[ICornerTreatmentGroupFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetCornerTreatments Method (ICornerTreatmentGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentGroupFolder Interface](#) : GetCornerTreatments Method (ICornerTreatmentGroupFolder)

Gets the corner treatments in this corner treatment group folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetCornerTreatments() As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICornerTreatmentGroupFolder
Dim value As System.Object

value = instance.GetCornerTreatments()
```

C#

```
System.object GetCornerTreatments()
```

C++/CLI

```
System.Object^ GetCornerTreatments();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFeatures](#)

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentGroupFolder::GetCornerTreatments](#).

Example

See the [ICornerManagementFolder](#) examples.

Remarks

Cast the returned features to [ICornerTreatmentFeatureData](#) or call [IFeature::GetDefinition](#).

See Also

[ICornerTreatmentGroupFolder Interface](#)
[ICornerTreatmentGroupFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFeature Method (ICornerTreatmentGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentGroupFolder Interface](#) : GetFeature Method (ICornerTreatmentGroupFolder)

Gets the feature for this corner treatment group folder.

.NET Syntax

Visual Basic (Declaration)

Function GetFeature() As Feature

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentGroupFolder  
Dim value As Feature
```

```
value = instance.GetFeature()
```

C#

```
Feature GetFeature()
```

C++/CLI

```
Feature^ GetFeature();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[IFeature](#)

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentGroupFolder::GetFeature](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentGroupFolder Interface](#)
[ICornerTreatmentGroupFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31

SOLIDWORKS API Help

[Send comments on this topic.](#)

Type Property (ICornerTreatmentGroupFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICornerTreatmentGroupFolder Interface](#) : Type Property (ICornerTreatmentGroupFolder)

Gets the type of corner treatments in this corner treatment group folder.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As ICornerTreatmentGroupFolder  
Dim value As System.Integer
```

```
value = instance.Type
```

C#

```
System.int Type {get;}
```

C++/CLI

```
property System.int Type {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of corner treatment as defined by [swCornerType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CornerTreatmentGroupFolder::Type](#).

Example

See the [ICornerManagementFolder](#) examples.

See Also

[ICornerTreatmentGroupFolder Interface](#)
[ICornerTreatmentGroupFolder Members](#)

Availability

SOLIDWORKS 2023 FCS, Revision Number 31