

SOLIDWORKS API (.NET, VBA, C#) — Reference

(59/337): ICosmeticThreadFeatureData- ICosmeticWeldBeadFeatureData

SOLIDWORKS API Documentation (converted from CHM)

ICosmeticThreadFeatureData (Type)

ICosmeticThreadFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticThreadFeatureData Interface

Allows access to a cosmetic thread feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICosmeticThreadFeatureData
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
```

C#

```
public interface ICosmeticThreadFeatureData
```

C++/CLI

```
public interface class ICosmeticThreadFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData](#).

Example

[Traverse All Cosmetic Threads \(VBA\)](#)
[Traverse All Cosmetic Threads \(VB.NET\)](#)
[Traverse All Cosmetic Threads \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[CosmeticThreadFeatureData](#)

See Also

[ICosmeticThreadFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICThread Interface](#)
[IFeatureManager::InsertCosmeticThread2 Method](#)

ICosmeticThreadFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticThreadFeatureData Interface

For a list of all members of this type, see [ICosmeticThreadFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this cosmetic thread feature.
GetPatternedTransformsCount	Gets the number of instances of this cosmetic thread that are patterns of this feature.

		
	IAccessSelections	Gains access to the selections that define this cosmetic thread feature.
	IGetPatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
	ReleaseSelectionAccess	Releases access to the selections that define this cosmetic thread feature.

[Top](#)

See Also

[ICosmeticThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICThread Interface](#)
[IFeatureManager::InsertCosmeticThread2 Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICosmeticThreadFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticThreadFeatureData Interface

The following tables list the members exposed by [ICosmeticThreadFeatureData](#).

Public Properties

Name	Description
 ApplyThread	Gets or sets how to apply the cosmetic thread.
 BlindDepth	Gets or sets the depth of a blind cosmetic thread.
 ConfigurationNames	Gets or sets the thread configuration names.
 ConfigurationOption	Gets or sets the thread configuration option.
 Diameter	Gets or sets the value of the diameter of the cosmetic thread.
 DiameterType	Gets the type of diameter for the cosmetic thread.
 Edge	Gets or sets the circular edge to which this cosmetic thread is attached.
 EndCondition	Gets or sets the thread end condition.
 PatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
 Size	Gets or sets the thread size.
 Standard	Gets or sets the thread standard.
 StandardType	Gets or sets the thread standard type.
 StartFromFacePlane	Gets or sets the start face or plane.
 ThreadCallout	Gets or sets the callout text for this cosmetic thread feature in a drawing.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this cosmetic thread feature.
 GetPatternedTransformsCount	Gets the number of instances of this cosmetic thread that are patterns of this feature.
 IAccessSelections	Gains access to the selections that define this cosmetic thread feature.
 IGetPatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
 ReleaseSelectionAccess	Releases access to the selections that define this cosmetic thread feature.

[Top](#)

See Also

[ICosmeticThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICThread Interface](#)
[IFeatureManager::InsertCosmeticThread2 Method](#)

ICosmeticThreadFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticThreadFeatureData Interface

For a list of all members of this type, see [ICosmeticThreadFeatureData members](#).

Public Properties

Name	Description
 ApplyThread	Gets or sets how to apply the cosmetic thread.
 BlindDepth	Gets or sets the depth of a blind cosmetic thread.
 ConfigurationNames	Gets or sets the thread configuration names.
 ConfigurationOption	Gets or sets the thread configuration option.
 Diameter	Gets or sets the value of the diameter of the cosmetic thread.
 DiameterType	Gets the type of diameter for the cosmetic thread.
 Edge	Gets or sets the circular edge to which this cosmetic thread is attached.
 EndCondition	Gets or sets the thread end condition.
 PatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
 Size	Gets or sets the thread size.
 Standard	Gets or sets the thread standard.
 StandardType	Gets or sets the thread standard type.
 StartFromFacePlane	Gets or sets the start face or plane.
 ThreadCallout	Gets or sets the callout text for this cosmetic thread feature in a drawing.

[Top](#)

See Also

[ICosmeticThreadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICThread Interface](#)
[IFeatureManager::InsertCosmeticThread2 Method](#)

AccessSelections Method (ICosmeticThreadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : AccessSelections Method (ICosmeticThreadFeatureData)

Gains access to the selections that define this cosmetic thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections(  
    ByVal TopDoc As System.Object,   
    ByVal Component As System.Object   
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::AccessSelections](#).

Example

[Get Cosmetic Threads Features in a Part \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICosmeticThreadFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::IAccessSelections Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ApplyThread Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : ApplyThread Property (ICosmeticThreadFeatureData)

Gets or sets how to apply the cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

Property ApplyThread As System.Integer

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Integer

instance.ApplyThread = value

value = instance.ApplyThread
```

C#

```
System.int ApplyThread {get; set;}
```

C++/CLI

```
property System.int ApplyThread {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

How to apply the thread as defined in [swCosmeticThreadType_e](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::ApplyThread](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

Remarks

If the value is swApplyCosmeticThread_Blind, then call [ICosmeticThreadFeatureData::BlindDepth](#) to get or set the depth of the thread.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::BlindDepth Property](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

BlindDepth Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : BlindDepth Property (ICosmeticThreadFeatureData)

Gets or sets the depth of a blind cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Property BlindDepth As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Double

instance.BlindDepth = value

value = instance.BlindDepth
```

C#

```
System.double BlindDepth {get; set;}
```

C++/CLI

```
property System.double BlindDepth {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Depth of the cosmetic thread (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::BlindDepth](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

Remarks

If [ICosmeticThreadFeatureData::ApplyThread](#) is swApplyCosmeticThread_Blind, then use this property to get or set the depth of the cosmetic thread.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConfigurationNames Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : ConfigurationNames Property (ICosmeticThreadFeatureData)

Gets or sets the thread configuration names.

.NET Syntax

Visual Basic (Declaration)

```
Property ConfigurationNames As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Object

instance.ConfigurationNames = value
```



```
value = instance.ConfigurationNames
```

C#

```
System.Object ConfigurationNames {get; set;}
```

C++/CLI

```
property System.Object^ ConfigurationNames {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of configuration names

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::ConfigurationNames](#).

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConfigurationOption Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : ConfigurationOption Property (ICosmeticThreadFeatureData)

Gets or sets the thread configuration option.

.NET Syntax

Visual Basic (Declaration)

```
Property ConfigurationOption As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.Integer  
  
instance.ConfigurationOption = value  
  
value = instance.ConfigurationOption
```

C#

```
System.int ConfigurationOption {get; set;}
```

C++/CLI

```
property System.int ConfigurationOption {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread configuration option as defined in [swCosmeticConfigOptions_e](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::ConfigurationOption](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Diameter Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : Diameter Property (ICosmeticThreadFeatureData)

Gets or sets the value of the diameter of the cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

Property Diameter As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Double

instance.Diameter = value

value = instance.Diameter
```

C#

```
System.double Diameter {get; set;}
```

C++/CLI

```
property System.double Diameter {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Depth of the diameter (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::Diameter](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

Remarks

If ICosmeticThreadFeatureData::DiameterType ...	Then the value of Diameter is the...
swCosmeticThread_MajorDiameter - or - swCosmeticThread_MinorDiameter	Diameter of the cosmetic thread
swCosmeticThread_ConicalOffset	Offset of the cosmetic thread from the edge of the conical hole

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::DiameterType Property](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

DiameterType Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : DiameterType Property (ICosmeticThreadFeatureData)

Gets the type of diameter for the cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property DiameterType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.Integer
```

```
value = instance.DiameterType
```

C#

```
System.int DiameterType {get;}
```

C++/CLI

```
property System.int DiameterType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of value for the diameter as defined in [swCosmeticThreadDiameterType_e](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::DiameterType](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

Remarks

Use [ICosmeticThreadFeatureData::Diameter](#) to get or set the diameter of the cosmetic thread.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edge Property (ICosmeticThreadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : Edge Property (ICosmeticThreadFeatureData)

Gets or sets the circular edge to which this cosmetic thread is attached.

.NET Syntax

Visual Basic (Declaration)

Property Edge As Edge

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As Edge
```

```
instance.Edge = value
```

```
value = instance.Edge
```

C#

```
Edge Edge {get; set;}
```

C++/CLI

```
property Edge^ Edge {  
    Edge^ get();  
    void set ( & Edge^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Circular [edge](#) to which this cosmetic thread is attached

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::Edge](#).

Example

[Get Cosmetic Threads Features in a Part \(VBA\)](#)

Remarks

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

EndCondition Property (ICosmeticThreadFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : EndCondition Property (ICosmeticThreadFeatureData)

Gets or sets the thread end condition.

.NET Syntax

Visual Basic (Declaration)

Property EndCondition As System.Integer

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Integer

instance.EndCondition = value

value = instance.EndCondition
```

C#

System.int EndCondition {get; set;}

C++/CLI

```
property System.int EndCondition {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread end condition as defined in [swCosmeticEndConditions_e](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::EndCondition](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

GetPatternedTransformsCount Method (ICosmeticThreadFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : GetPatternedTransformsCount Method (ICosmeticThreadFeatureData)

Gets the number of instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

Function GetPatternedTransformsCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Integer

value = instance.GetPatternedTransformsCount()
```

C#

```
System.int GetPatternedTransformsCount()
```

C++/CLI

```
System.int GetPatternedTransformsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of instances of this cosmetic thread that are patterns of this feature

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::GetPatternedTransformsCount](#).

Example

[Get Cosmetic Threads Features in a Part \(VBA\)](#)

Remarks

The value returned by this method does not include this cosmetic thread, which is the seed feature and not an instance of the pattern. Therefore if this cosmetic thread is not used in any pattern feature, then this method returns 0.

Use this method before using [ICosmeticThreadFeatureData::IGetPatternedTransforms](#) to determine the size of the array to pass to that method.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::PatternedTransforms Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IAccessSelections Method (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : IAccessSelections Method (ICosmeticThreadFeatureData)

Gains access to the selections that define this cosmetic thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _
    ByVal TopDoc As ModelDoc2, _
    ByVal Component As Component2 _
) As System.Boolean
```

Visual Basic (Usage)



```

Dim instance As ICosmeticThreadFeatureData
Dim TopDoc As ModelDoc2
Dim Component As Component2
Dim value As System.Boolean

value = instance.IAccessSelections(TopDoc, Component)

```

C#

```

System.bool IAccessSelections(
    ModelDoc2 TopDoc,
    Component2 Component
)

```

C++/CLI

```

System.bool IAccessSelections(
    & ModelDoc2^ TopDoc,
    & Component2^ Component
)

```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document
Component
Component in which the feature is to be modified

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICosmeticThreadFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::AccessSelections Method](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetPatternedTransforms Method (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : IGetPatternedTransforms Method (ICosmeticThreadFeatureData)

Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternedTransforms( _  
    ByVal Count As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim Count As System.Integer  
Dim value As MathTransform  
  
value = instance.IGetPatternedTransforms(Count)
```

C#

```
MathTransform IGetPatternedTransforms(  
    System.int Count  
)
```

C++/CLI

```
MathTransform^ IGetPatternedTransforms(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of the output array (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of interface pointers to the [IMathTransform](#) objects of the instances of this cosmetic thread
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICosmeticThreadFeatureData::GetPatternedTransformsCount](#) before calling this method to determine the size of the output array.

The value returned by this method does not include this cosmetic thread, which is the seed feature and not a pattern instance. Therefore, if this cosmetic thread is not used in a pattern feature, then [ICosmeticThreadFeatureData::GetPatternedTransformsCount](#) returns 0 and nothing is put into the output array.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::PatternedTransforms Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternedTransforms Property (ICosmeticThreadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : PatternedTransforms Property (ICosmeticThreadFeatureData)

Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property PatternedTransforms As System.Object

Visual Basic (Usage)

```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.Object  
  
value = instance.PatternedTransforms
```

C#

```
System.Object PatternedTransforms {get;}
```

C++/CLI

```
property System.Object^ PatternedTransforms {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of the transforms of the instances of this cosmetic thread

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::PatternedTransforms](#).

Example

[Get Cosmetic Threads Features in a Part \(VBA\)](#)

Remarks

The value returned by this property does not include this cosmetic thread, which is the seed feature and not a pattern instance. Therefore, if this cosmetic thread is not used in a pattern feature, then [ICosmeticThreadFeatureData::GetPatternedTransformsCount](#) returns 0 and this property returns an empty array.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)
[ICosmeticThreadFeatureData::IGetPatternedTransforms Method](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICosmeticThreadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : ReleaseSelectionAccess Method (ICosmeticThreadFeatureData)

Releases access to the selections that define this cosmetic thread feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)

```
Dim instance As ICosmeticThreadFeatureData  
  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::ReleaseSelectionAccess](#).

Example

[Get Cosmetic Threads Features in a Part \(VBA\)](#)

Remarks

[ICosmeticThreadFeatureData::AccessSelections](#) and [ICosmeticThreadFeatureData::!AccessSelections](#) put the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature or use [IFeature::ModifyDefinition](#) or [IFeature::!ModifyDefinition2](#) if you did.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

SOLIDWORKS API Help

[Send comments on this topic.](#)

Size Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : Size Property (ICosmeticThreadFeatureData)

Gets or sets the thread size.

.NET Syntax

Visual Basic (Declaration)

Property Size As System.String

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.String
```

```
instance.Size = value
```

```
value = instance.Size
```

C#

```
System.string Size {get; set;}
```

C++/CLI

```
property System.String^ Size {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread size

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::Size](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Standard Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : Standard Property (ICosmeticThreadFeatureData)

Gets or sets the thread standard.

.NET Syntax

Visual Basic (Declaration)

Property Standard As System.Integer

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData
Dim value As System.Integer

instance.Standard = value
value = instance.Standard
```

C#

```
System.int Standard {get; set;}
```

C++/CLI

```
property System.int Standard {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread standard as defined in [swCosmeticStandardType](#) e

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::Standard](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StandardType Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : StandardType Property (ICosmeticThreadFeatureData)

Gets or sets the thread standard type.

.NET Syntax

Visual Basic (Declaration)

Property StandardType As System.String

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.String
```

```
instance.StandardType = value
```

```
value = instance.StandardType
```

C#

```
System.string StandardType {get; set;}
```

C++/CLI

```
property System.String^ StandardType {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Thread standard type

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::StandardType](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

StartFromFacePlane Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : StartFromFacePlane Property (ICosmeticThreadFeatureData)

Gets or sets the start face or plane.

Visual Basic Syntax

Visual Basic (Declaration)

Property StartFromFacePlane As System.Object

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.Object
```

```
instance.StartFromFacePlane = value
```

```
value = instance.StartFromFacePlane
```

C#

```
System.Object StartFromFacePlane {get; set;}
```

C++/CLI

```
property System.Object^ StartFromFacePlane {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IFace2](#) or [IRefPlane](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::StartFromFacePlane](#).

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadCallout Property (ICosmeticThreadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticThreadFeatureData Interface](#) : ThreadCallout Property (ICosmeticThreadFeatureData)

Gets or sets the callout text for this cosmetic thread feature in a drawing.

Visual Basic Syntax

Visual Basic (Declaration)

Property ThreadCallout As System.String

Visual Basic (Usage)



```
Dim instance As ICosmeticThreadFeatureData  
Dim value As System.String
```

```
instance.ThreadCallout = value
```

```
value = instance.ThreadCallout
```

C#

```
System.string ThreadCallout {get; set;}
```

C++/CLI

```
property System.String^ ThreadCallout {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Callout text for this cosmetic thread feature in a drawing

Visual Basic for Applications (VBA) Syntax

See [CosmeticThreadFeatureData::ThreadCallout](#).

Example

See the [ICosmeticThreadFeatureData](#) examples.

See Also

[ICosmeticThreadFeatureData Interface](#)
[ICosmeticThreadFeatureData Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1

ICosmeticWeldBeadFeatureData (Type)

ICosmeticWeldBeadFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFeatureData Interface

Allows access to a cosmetic weld bead feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICosmeticWeldBeadFeatureData
```

Visual Basic (Usage)

```
Dim instance As ICosmeticWeldBeadFeatureData
```

C#

```
public interface ICosmeticWeldBeadFeatureData
```

C++/CLI

```
public interface class ICosmeticWeldBeadFeatureData
```

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData](#).

Example

[Insert Cosmetic Weld Bead \(VBA\)](#)
[Insert Cosmetic Weld Bead \(VB.NET\)](#)
[Insert Cosmetic Weld Bead \(C#\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[CosmeticWeldBeadFeatureData](#)

See Also

[ICosmeticWeldBeadFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICosmeticWeldBeadFolder Interface](#)
[IFeatureManager::InsertCosmeticWeldBead2 Method \(\)](#)

ICosmeticWeldBeadFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFeatureData Interface

The following tables list the members exposed by [ICosmeticWeldBeadFeatureData](#).

Public Properties

Name	Description
 BeadSize	Gets or sets the thickness of a weld bead.
FromToLength	Gets or sets whether to enable the from/to length properties.

[FromToReverse](#)

Gets or sets whether to start the weld from the opposite end.

[FromToStartPoint](#)

Gets or sets the position of the first weld bead with respect to the end of the selected face or edge.

[FromToWeldLength](#)

Gets or sets the length of the weld.

[Gap](#)

Gets or sets the gap between intermittent weld beads.

[GapOrPitch](#)

Gets or sets whether to use gap or pitch spacing for intermittent weld beads.

[IntermittentWeld](#)

Gets or sets whether to enable intermittent weld properties.

[IntermittentWeldLength](#)

Gets or sets the length of the weld for intermittent weld beads.

[Pitch](#)

Gets or sets the pitch of intermittent weld beads.

[Side](#)

Gets or sets how the weld bead is applied to selected faces or edges.

[Staggered](#)

Gets or sets whether to alternate the positioning of the weld beads on both sides of the weld body.

[TangentPropagation](#)

Gets or sets whether to apply the weld bead to all edges that are tangent to the selected faces or edges.

[WeldSymbol](#)

Gets or sets the weld symbol for this weld bead.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this cosmetic weld bead feature.
 GetEntities	Obsolete. Superseded by ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom and ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo .
 GetEntitiesWeldFrom	Gets the weld-from entity type and weld-from entities for this cosmetic weld bead, which was created using weld geometry.
 GetEntitiesWeldPath	Gets the entities for this cosmetic weld bead, which was created using a weld path.
 GetEntitiesWeldTo	Gets the weld-to entity type and weld-to entities for this cosmetic weld bead, which was created using weld geometry.
 GetReferenceEdges	Gets the reference edges created by this cosmetic weld bead feature.
 GetWeldBeadFolder	Gets the weld bead folder.
 ReleaseSelectionAccess	Releases access to the selections that define this cosmetic weld bead feature.
 SetEntities	Obsolete. Superseded by ICosmeticWeldBeadFeatureData::SetEntitiesWeldFrom and ICosmeticWeldBeadFeatureData::SetEntitiesWeldTo .
 SetEntitiesWeldFrom	Sets the weld-from entities for this cosmetic weld bead, which was created using weld geometry.
 SetEntitiesWeldPath	Sets the entities for this cosmetic weld bead, which was created using a weld path.
 SetEntitiesWeldTo	Sets the weld-to entities for this cosmetic weld bead, which was created using weld geometry.

[Top](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICosmeticWeldBeadFolder Interface](#)
[IFeatureManager::InsertCosmeticWeldBead2 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICosmeticWeldBeadFeatureData Interface Methods

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFeatureData InterfaceFor a list of all members of this type, see [ICosmeticWeldBeadFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Gains access to the selections that define this cosmetic weld bead feature.
 GetEntities	Obsolete. Superseded by ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom and ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo .
 GetEntitiesWeldFrom	Gets the weld-from entity type and weld-from entities for this cosmetic weld bead, which was created using weld geometry.

		
	GetEntitiesWeldPath	Gets the entities for this cosmetic weld bead, which was created using a weld path.
	GetEntitiesWeldTo	Gets the weld-to entity type and weld-to entities for this cosmetic weld bead, which was created using weld geometry.
	GetReferenceEdges	Gets the reference edges created by this cosmetic weld bead feature.
	GetWeldBeadFolder	Gets the weld bead folder.
	ReleaseSelectionAccess	Releases access to the selections that define this cosmetic weld bead feature.
	SetEntities	Obsolete. Superseded by ICosmeticWeldBeadFeatureData.SetEntitiesWeldFrom and ICosmeticWeldBeadFeatureData.SetEntitiesWeldTo .
	SetEntitiesWeldFrom	Sets the weld-from entities for this cosmetic weld bead, which was created using weld geometry.
	SetEntitiesWeldPath	Sets the entities for this cosmetic weld bead, which was created using a weld path.
	SetEntitiesWeldTo	Sets the weld-to entities for this cosmetic weld bead, which was created using weld geometry.

[Top](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICosmeticWeldBeadFolder Interface](#)
[IFeatureManager.InsertCosmeticWeldBead2 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICosmeticWeldBeadFeatureData Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFeatureData Interface

For a list of all members of this type, see [ICosmeticWeldBeadFeatureData members](#).

Public Properties

Name	Description
 BeadSize	Gets or sets the thickness of a weld bead.
 FromToLength	Gets or sets whether to enable the from/to length properties.
 FromToReverse	Gets or sets whether to start the weld from the opposite end.
 FromToStartPoint	Gets or sets the position of the first weld bead with respect to the end of the selected face or edge.
 FromToWeldLength	Gets or sets the length of the weld.
 Gap	Gets or sets the gap between intermittent weld beads.
 GapOrPitch	Gets or sets whether to use gap or pitch spacing for intermittent weld beads.
 IntermittentWeld	Gets or sets whether to enable intermittent weld properties.
 IntermittentWeldLength	Gets or sets the length of the weld for intermittent weld beads.
 Pitch	Gets or sets the pitch of intermittent weld beads.
 Side	Gets or sets how the weld bead is applied to selected faces or edges.
 Staggered	Gets or sets whether to alternate the positioning of the weld beads on both sides of the weld body.
 TangentPropagation	Gets or sets whether to apply the weld bead to all edges that are tangent to the selected faces or edges.
 WeldSymbol	Gets or sets the weld symbol for this weld bead.

[Top](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICosmeticWeldBeadFolder Interface](#)
[IFeatureManager.InsertCosmeticWeldBead2 Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



Gains access to the selections that define this cosmetic weld bead feature.

VB.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& ModelDoc2^ TopDoc,  
& Component2^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::AccessSelections](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is null or Nothing
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICosmeticWeldBeadFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BeadSize Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : BeadSize Property (ICosmeticWeldBeadFeatureData)

Gets or sets the thickness of a weld bead.

.NET Syntax

Visual Basic (Declaration)

Property BeadSize As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Double

instance.BeadSize = value
value = instance.BeadSize
```

C#

```
System.double BeadSize {get; set;}
```

C++/CLI

```
property System.double BeadSize {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld bead thickness

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::BeadSize](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FromToLength Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : FromToLength Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to enable the from/to length properties.

Visual Basic Syntax

Visual Basic (Declaration)

Property FromToLength As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Boolean

instance.FromToLength = value

value = instance.FromToLength
```

C#

```
System.bool FromToLength {get; set;}
```

C++/CLI

```
property System.bool FromToLength {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable the from/to length properties, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::FromToLength](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if:

- [ICosmeticWeldBeadFeatureData::TangentPropagation](#) is true
- or -
- [ICosmeticWeldBeadFeatureData::Side](#) is either [swCosmeticWeldBeadSide_e.swCosmeticWeldBeadSide_Selection](#) or [swCosmeticWeldBeadSide_e.swCosmeticWeldBeadSide_BothSides](#).

If this property is true, you can use the following properties:

- [ICosmeticWeldBeadFeatureData::FromToStartPoint](#)
- [ICosmeticWeldBeadFeatureData::FromToReverse](#)
- [ICosmeticWeldBeadFeatureData::FromToWeldLength](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FromToReverse Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : FromToReverse Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to start the weld from the opposite end.

.NET Syntax

Visual Basic (Declaration)

Property FromToReverse As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Boolean  
  
instance.FromToReverse = value  
value = instance.FromToReverse
```

C#

```
System.bool FromToReverse {get; set;}
```

C++/CLI

```
property System.bool FromToReverse {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if the weld starts at the end opposite to [ICosmeticWeldBeadFeatureData::FromToStartPoint](#), false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::FromToReverse](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::FromToLength](#) is true.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::FromToStartPoint Property](#)
[ICosmeticWeldBeadFeatureData::FromToWeldLength Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FromToStartPoint Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : FromToStartPoint Property (ICosmeticWeldBeadFeatureData)

Gets or sets the position of the first weld bead with respect to the end of the selected face or edge.

.NET Syntax

Visual Basic (Declaration)

Property FromToStartPoint As System.Double

```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Double

instance.FromToStartPoint = value

value = instance.FromToStartPoint
```

C#

```
System.double FromToStartPoint {get; set;}
```

C++/CLI

```
property System.double FromToStartPoint {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Position of the first weld bead (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::FromToStartPoint](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::FromToLength](#) is true.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::FromToReverse Property](#)
[ICosmeticWeldBeadFeatureData::FromToWeldLength Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FromToWeldLength Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : FromToWeldLength Property (ICosmeticWeldBeadFeatureData)

Gets or sets the length of the weld.

.NET Syntax

Visual Basic (Declaration)

```
Property FromToWeldLength As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Double

instance.FromToWeldLength = value
```

```
value = instance.FromToWeldLength
```

C#

```
System.double FromToWeldLength {get; set;}
```

C++/CLI

```
property System.double FromToWeldLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of this weld (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::FromToWeldLength](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::FromToLength](#) is true.

The length of the weld is the distance from [ICosmeticWeldBeadFeatureData::FromToStartPoint](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::FromToReverse Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Gap Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : Gap Property (ICosmeticWeldBeadFeatureData)

Gets or sets the gap between intermittent weld beads.

.NET Syntax

Visual Basic (Declaration)

```
Property Gap As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Double
```

```
instance.Gap = value
```

```
value = instance.Gap
```

C#

```
System.double Gap {get; set;}
```

C++/CLI

```
property System.double Gap {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Gap between intermittent weld beads (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::Gap](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::GapOrPitch](#) is true and [ICosmeticWeldBeadFeatureData::IntermittentWeld](#) is true.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GapOrPitch Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GapOrPitch Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to use gap or pitch spacing for intermittent weld beads.

.NET Syntax

Visual Basic (Declaration)

```
Property GapOrPitch As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Boolean  
  
instance.GapOrPitch = value  
  
value = instance.GapOrPitch
```

C#

```
System.bool GapOrPitch {get; set;}
```

C++/CLI

```
property System.bool GapOrPitch {  
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use gap spacing, false to use pitch spacing (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GapOrPitch](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::IntermittentWeld](#) is true.

If this property is...	Then to get and set the gap between the weld beads, call...
True	ICosmeticWeldBeadFeatureData::Gap
False	ICosmeticWeldBeadFeatureData::Pitch

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::IntermittentWeldLength Property](#)
[ICosmeticWeldBeadFeatureData::Staggered Property](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntities Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetEntities Method (ICosmeticWeldBeadFeatureData)

Obsolete. Superseded by [ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom](#) and [ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntities( _  
    ByRef EntType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim EntType As System.Integer  
Dim value As System.Object  
  
value = instance.GetEntities(EntType)
```

C#

```
System.object GetEntities(  
    out System.int EntType  
)
```

C++/CLI

```
System.Object^ GetEntities(  
& [Out] System.int EntType
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntType

Entity type as defined in [swSelectType_e](#)

Return Value

Array of [faces](#) and [edges](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetEntities](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::SetEntities Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetEntitiesWeldFrom Method (ICosmeticWeldBeadFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetEntitiesWeldFrom Method (ICosmeticWeldBeadFeatureData)

Gets the weld-from entity type and weld-from entities for this cosmetic weld bead, which was created using weld geometry.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntitiesWeldFrom( _  
    ByRef EntType As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim EntType As System.Integer  
Dim value As System.Object  
  
value = instance.GetEntitiesWeldFrom(EntType)
```

C#

```
System.object GetEntitiesWeldFrom(  
    out System.int EntType  
)
```

C++/CLI

```
System.Object^ GetEntitiesWeldFrom(  
& [Out] System.int EntType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

EntType

Weld-from entity type as defined in [swSelectType_e](#); i.e., either swSelFACES or swSelEDGES

Return Value

Array of weld-from entities of [faces](#) or [edges](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetEntitiesWeldFrom](#).

Example

[Insert Cosmetic Weld Bead Using Geometric Entities \(C#\)](#)
[Insert Cosmetic Weld Bead Using Geometric Entities \(VB.NET\)](#)
[Insert Cosmetic Weld Bead Using Geometric Entities \(VBA\)](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldFrom Method \(\)](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo Method \(\)](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldTo Method \(\)](#)

Availability

SOLIDWORKS 2105 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEntitiesWeldPath Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetEntitiesWeldPath Method (ICosmeticWeldBeadFeatureData)

Gets the entities for this cosmetic weld bead, which was created using a weld path.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntitiesWeldPath() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Object  
  
value = instance.GetEntitiesWeldPath()
```

C#

```
System.object GetEntitiesWeldPath()
```

C++/CLI

```
System.Object^ GetEntitiesWeldPath();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of entities of [edges](#) or [sketches](#) or a combination of edges and sketches

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetEntitiesWeldPath](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldPath Method \(\)](#)

Availability

GetEntitiesWeldTo Method (ICosmeticWeldBeadFeatureData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetEntitiesWeldTo Method (ICosmeticWeldBeadFeatureData)

Gets the weld-to entity type and weld-to entities for this cosmetic weld bead, which was created using weld geometry.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEntitiesWeldTo( _
    ByRef EntType As System.Integer _
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim EntType As System.Integer
Dim value As System.Object
```

```
value = instance.GetEntitiesWeldTo(EntType)
```

C#

```
System.object GetEntitiesWeldTo(
    out System.int EntType
)
```

C++/CLI

```
System.Object^ GetEntitiesWeldTo(
    & [Out] System.int EntType
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

*EntType*Weld-to entity type as defined in [swSelectType_e](#); i.e., either swSelFACES or swSelEDGES

Return Value

Array of weld-to entities of [faces](#) or [edges](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetEntitiesWeldTo](#).

Example

[Insert Cosmetic Weld Bead Using Geometric Entities \(C#\)](#)
[Insert Cosmetic Weld Bead Using Geometric Entities \(VB.NET\)](#)
[Insert Cosmetic Weld Bead Using Geometric Entities \(VBA\)](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldTo](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldFrom Method \(\)](#)

Availability

GetReferenceEdges Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetReferenceEdges Method (ICosmeticWeldBeadFeatureData)

Gets the reference edges created by this cosmetic weld bead feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetReferenceEdges() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Object
```

```
value = instance.GetReferenceEdges()
```

C#

```
System.object GetReferenceEdges()
```

C++/CLI

```
System.Object^ GetReferenceEdges();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of reference [edges](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetReferenceEdges](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2016 SP2, Revision Number 24.2

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetWeldBeadFolder Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : GetWeldBeadFolder Method (ICosmeticWeldBeadFeatureData)

Gets the weld bead folder.

.NET Syntax

Visual Basic (Declaration)

```
Function GetWeldBeadFolder() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Object

value = instance.GetWeldBeadFolder()
```

C#

```
System.Object GetWeldBeadFolder()
```

C++/CLI

```
System.Object^ GetWeldBeadFolder();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[ICosmeticWeldBeadFolder](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::GetWeldBeadFolder](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IntermittentWeld Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : IntermittentWeld Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to enable intermittent weld properties.

.NET Syntax

Visual Basic (Declaration)

```
Property IntermittentWeld As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Boolean

instance.IntermittentWeld = value

value = instance.IntermittentWeld
```

C#

```
System.bool IntermittentWeld {get; set;}
```

C++/CLI

```
property System.bool IntermittentWeld {
    System.bool get();
```

```
void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable intermittent weld properties, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::IntermittentWeld](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

If this property is true, you can use the following properties:

- [ICosmeticWeldBeadFeatureData::Gap](#)
- [ICosmeticWeldBeadFeatureData::GapOrPitch](#)
- [ICosmeticWeldBeadFeatureData::Pitch](#)
- [ICosmeticWeldBeadFeatureData::IntermittentWeldLength](#)
- [ICosmeticWeldBeadFeatureData::Staggered](#)

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IntermittentWeldLength Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : IntermittentWeldLength Property (ICosmeticWeldBeadFeatureData)

Gets or sets the length of the weld for intermittent weld beads.

.NET Syntax

Visual Basic (Declaration)

```
Property IntermittentWeldLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Double
```

```
instance.IntermittentWeldLength = value
```

```
value = instance.IntermittentWeldLength
```

C#

```
System.double IntermittentWeldLength {get; set;}
```

C++/CLI

```
property System.double IntermittentWeldLength {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Length of weld for intermittent weld beads (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::IntermittentWeldLength](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::IntermittentWeld](#) is true.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Pitch Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : Pitch Property (ICosmeticWeldBeadFeatureData)

Gets or sets the pitch of intermittent weld beads.

.NET Syntax

Visual Basic (Declaration)

Property Pitch As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Double
```

```
instance.Pitch = value
```

```
value = instance.Pitch
```

C#

```
System.double Pitch {get; set;}
```

C++/CLI

```
property System.double Pitch {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pitch of intermittent weld beads (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::Pitch](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::GapOrPitch](#) is false and [ICosmeticWeldBeadFeatureData::IntermittentWeld](#) is true. Pitch is the length from the center of one weld bead to the center of the next weld bead.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReleaseSelectionAccess Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : ReleaseSelectionAccess Method (ICosmeticWeldBeadFeatureData)

Releases access to the selections that define this cosmetic weld bead feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::ReleaseSelectionAccess](#).

Remarks

[ICosmeticWeldBeadFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature. Use this method to restore the rollback state if you did not modify the feature. Use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SetEntities Method (ICosmeticWeldBeadFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : SetEntities Method (ICosmeticWeldBeadFeatureData)Obsolete. Superseded by [ICosmeticWeldBeadFeatureData::SetEntitiesWeldFrom](#) and [ICosmeticWeldBeadFeatureData::SetEntitiesWeldTo](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEntities( _
    ByVal Entities As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim Entities As System.Object

instance.SetEntities(Entities)
```

C#

```
void SetEntities(
    System.object Entities
)
```

C++/CLI

```
void SetEntities(
    & System.Object^ Entities
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entities
Array of [IFace2s](#) and [IEdges](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::SetEntities](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::GetEntities Method](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SetEntitiesWeldFrom Method (ICosmeticWeldBeadFeatureData)

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : SetEntitiesWeldFrom Method (ICosmeticWeldBeadFeatureData)

Sets the weld-from entities for this cosmetic weld bead, which was created using weld geometry.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEntitiesWeldFrom( _  
    ByVal Entities As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim Entities As System.Object  
  
instance.SetEntitiesWeldFrom(Entities)
```

C#

```
void SetEntitiesWeldFrom(  
    System.object Entities  
)
```

C++/CLI

```
void SetEntitiesWeldFrom(  
& System.Object^ Entities  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entities

Array of weld-from entities of [faces](#) or [edges](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::SetEntitiesWeldFrom](#).

Remarks

The weld-from entities must be the same type of entities; e.g., all faces or all edges.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom Method \(\)](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo Method \(\)](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldTo Method \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEntitiesWeldPath Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : SetEntitiesWeldPath Method (ICosmeticWeldBeadFeatureData)

Sets the entities for this cosmetic weld bead, which was created using a weld path.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEntitiesWeldPath( _  
    ByVal Entities As System.Object _  
)
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim Entities As System.Object

instance.SetEntitiesWeldPath(Entities)
```

C#

```
void SetEntitiesWeldPath(
    System.object Entities
)
```

C++/CLI

```
void SetEntitiesWeldPath(
    & System.Object^ Entities
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entities
Array of entities of [edges](#), [sketches](#), or a combination of edges and sketches (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::SetEntitiesWeldPath](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldPath](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

SetEntitiesWeldTo Method (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : SetEntitiesWeldTo Method (ICosmeticWeldBeadFeatureData)

Sets the weld-to entities for this cosmetic weld bead, which was created using weld geometry.

.NET Syntax

Visual Basic (Declaration)

```
Sub SetEntitiesWeldTo( _
    ByVal Entities As System.Object _
)
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim Entities As System.Object

instance.SetEntitiesWeldTo(Entities)
```

C#

```
void SetEntitiesWeldTo(
    System.object Entities
)
```

C++/CLI

```
void SetEntitiesWeldTo(
& System.Object^ Entities
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entities

Array of weld-to entities of [faces](#) or [edges](#) (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::SetEntitiesWeldTo](#).

Remarks

The weld-to entities must be the same type of entities; e.g., all faces or all edges.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldTo](#)
[ICosmeticWeldBeadFeatureData::GetEntitiesWeldFrom](#)
[ICosmeticWeldBeadFeatureData::SetEntitiesWeldFrom](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Side Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : Side Property (ICosmeticWeldBeadFeatureData)

Gets or sets how the weld bead is applied to selected faces or edges.

.NET Syntax

Visual Basic (Declaration)

Property Side As System.Integer

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData
Dim value As System.Integer
```

```
instance.Side = value
```

```
value = instance.Side
```

C#

```
System.int Side {get; set;}
```

C++/CLI

```
property System.int Side {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld bead configuration as defined in [swCosmeticWeldBeadSide](#) e

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::Side](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::TangentPropagation](#) is false.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Staggered Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : Staggered Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to alternate the positioning of the weld beads on both sides of the weld body.

.NET Syntax

Visual Basic (Declaration)

Property Staggered As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Boolean
```

```
instance.Staggered = value
```

```
value = instance.Staggered
```

C#

```
System.bool Staggered {get; set;}
```

C++/CLI

```
property System.bool Staggered {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to alternate positioning of the weld beads, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::Staggered](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

This property is valid only if [ICosmeticWeldBeadFeatureData::Side](#) = [swCosmeticWeldBeadSide_e.swCosmeticWeldBeadSide_BothSides](#) and [ICosmeticWeldBeadFeatureData::IntermittentWe](#) is true.

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TangentPropagation Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : TangentPropagation Property (ICosmeticWeldBeadFeatureData)

Gets or sets whether to apply the weld bead to all edges that are tangent to the selected faces or edges.

.NET Syntax

Visual Basic (Declaration)

```
Property TangentPropagation As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Boolean
```

```
instance.TangentPropagation = value
```

```
value = instance.TangentPropagation
```

C#

```
System.bool TangentPropagation {get; set;}
```

C++/CLI

```
property System.bool TangentPropagation {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to apply the weld bead to all edges that are tangent to the selected faces or edges, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::TangentPropagation](#).

Example

See [ICosmeticWeldBeadFeatureData](#) examples.

Remarks

If this property is...	Then use...
True	ICosmeticWeldBeadFeatureData::FromToLength to enable the from/to length properties
False	ICosmeticWeldBeadFeatureData::Side to define how to apply the weld bead to the selected faces or edges

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

WeldSymbol Property (ICosmeticWeldBeadFeatureData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFeatureData Interface](#) : WeldSymbol Property (ICosmeticWeldBeadFeatureData)

Gets or sets the weld symbol for this weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Property WeldSymbol As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFeatureData  
Dim value As System.Object
```

```
instance.WeldSymbol = value
```

```
value = instance.WeldSymbol
```

C#

```
System.object WeldSymbol {get; set;}
```

C++/CLI

```
property System.Object^ WeldSymbol {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[IWeldSymbol](#)

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFeatureData::WeldSymbol](#).

See Also

[ICosmeticWeldBeadFeatureData Interface](#)
[ICosmeticWeldBeadFeatureData Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0