

SOLIDWORKS API (.NET, VBA, C#) — Reference (607337): ICosmeticWeldBeadFolder-ICThread

SOLIDWORKS API Documentation (converted from CHM)

ICosmeticWeldBeadFolder (Type)

ICosmeticWeldBeadFolder Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFolder Interface

Allows access to the properties of cosmetic weld beads.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICosmeticWeldBeadFolder
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder
```

C#

```
public interface ICosmeticWeldBeadFolder
```

C++/CLI

```
public interface class ICosmeticWeldBeadFolder
```

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder](#).

Example

[Insert Cosmetic Weld Bead \(VBA\)](#)
[Insert Cosmetic Weld Bead \(VB.NET\)](#)
[Insert Cosmetic Weld Bead \(C#\)](#)

Accessors

[ICosmeticWeldBeadFeatureData::GetWeldBeadFolder](#)

[IFeature::GetSpecificFeature2](#)

Access Diagram

[CosmeticWeldBeadFolder](#)

See Also

[ICosmeticWeldBeadFolder Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICosmeticWeldBeadFolder Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFolder Interface

The following tables list the members exposed by [ICosmeticWeldBeadFolder](#).

Public Properties

Name	Description
 CostPerUnitMass	Gets or sets the welding cost per unit mass.
MassPerUnitLength	Gets or sets the weld mass per unit length.

		
	Material	Gets or sets the material of the weld bead.
	NumberOfWeldPasses	Gets or sets the number of weld passes required to deposit the correct amount of welding material.
	Process	Gets or sets the weld process.
	TimePerUnitLength	Gets or sets the welding time per unit length.
	TotalCost	Gets the total welding cost.
	TotalLength	Gets the total weld length.
	TotalMass	Gets the total weld mass.
	TotalNumber	Gets the total number of welds.
	TotalTime	Gets the total welding time.

[Top](#)

 See Also

[ICosmeticWeldBeadFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICosmeticWeldBeadFolder Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ICosmeticWeldBeadFolder Interface

For a list of all members of this type, see [ICosmeticWeldBeadFolder members](#).

 Public Properties

Name	Description
 CostPerUnitMass	Gets or sets the welding cost per unit mass.
 MassPerUnitLength	Gets or sets the weld mass per unit length.
 Material	Gets or sets the material of the weld bead.
 NumberOfWeldPasses	Gets or sets the number of weld passes required to deposit the correct amount of welding material.
 Process	Gets or sets the weld process.
 TimePerUnitLength	Gets or sets the welding time per unit length.
 TotalCost	Gets the total welding cost.
 TotalLength	Gets the total weld length.
 TotalMass	Gets the total weld mass.
 TotalNumber	Gets the total number of welds.
 TotalTime	Gets the total welding time.

[Top](#)

 See Also

[ICosmeticWeldBeadFolder Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CostPerUnitMass Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : CostPerUnitMass Property (ICosmeticWeldBeadFolder)

Gets or sets the welding cost per unit mass.

 .NET Syntax

Visual Basic (Declaration)

Property CostPerUnitMass As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double  
  
instance.CostPerUnitMass = value  
value = instance.CostPerUnitMass
```

C#

```
System.double CostPerUnitMass {get; set;}
```

C++/CLI

```
property System.double CostPerUnitMass {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Welding cost per unit mass

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::CostPerUnitMass](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

MassPerUnitLength Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : MassPerUnitLength Property (ICosmeticWeldBeadFolder)

Gets or sets the weld mass per unit length.

.NET Syntax

Visual Basic (Declaration)

Property MassPerUnitLength As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double  
  
instance.MassPerUnitLength = value  
value = instance.MassPerUnitLength
```

C#

```
System.double MassPerUnitLength {get; set;}
```

C++/CLI

```
property System.double MassPerUnitLength {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld mass per unit length

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::MassPerUnitLength](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Material Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : Material Property (ICosmeticWeldBeadFolder)

Gets or sets the material of the weld bead.

.NET Syntax

Visual Basic (Declaration)

```
Property Material As System.String
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.String  
  
instance.Material = value  
  
value = instance.Material
```

C#

```
System.string Material {get; set;}
```

C++/CLI

```
property System.String^ Material {  
    System.String^ get();  
    void set ( &    System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld material

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::Material](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

NumberOfWeldPasses Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : NumberOfWeldPasses Property (ICosmeticWeldBeadFolder)

Gets or sets the number of weld passes required to deposit the correct amount of welding material.

.NET Syntax

Visual Basic (Declaration)

```
Property NumberOfWeldPasses As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Integer
```

```
instance.NumberOfWeldPasses = value
```

```
value = instance.NumberOfWeldPasses
```

C#

```
System.int NumberOfWeldPasses {get; set;}
```

C++/CLI

```
property System.int NumberOfWeldPasses {  
    System.int get();  
    void set ( & System.int value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of weld passes

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::NumberOfWeldPasses](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Process Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : Process Property (ICosmeticWeldBeadFolder)

Gets or sets the weld process.

.NET Syntax

Visual Basic (Declaration)

Property Process As System.String

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder
Dim value As System.String

instance.Process = value
value = instance.Process
```

C#

```
System.string Process {get; set;}
```

C++/CLI

```
property System.String^ Process {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Weld process

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::Process](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TimePerUnitLength Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TimePerUnitLength Property (ICosmeticWeldBeadFolder)

Gets or sets the welding time per unit length.

.NET Syntax

Visual Basic (Declaration)

```
Property TimePerUnitLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double  
  
instance.TimePerUnitLength = value  
value = instance.TimePerUnitLength
```

C#

```
System.double TimePerUnitLength {get; set;}
```

C++/CLI

```
property System.double TimePerUnitLength {  
    System.double get();  
    void set ( &    System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Welding time per unit length

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TimePerUnitLength](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

TotalCost Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TotalCost Property (ICosmeticWeldBeadFolder)

Gets the total welding cost.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalCost As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double
```

```
value = instance.TotalCost
```

C#

```
System.double TotalCost {get;}
```

C++/CLI

```
property System.double TotalCost {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total welding cost

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TotalCost](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)

[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalLength Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TotalLength Property (ICosmeticWeldBeadFolder)

Gets the total weld length.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalLength As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double
```

```
value = instance.TotalLength
```

C#

```
System.double TotalLength {get;}
```

C++/CLI

```
property System.double TotalLength {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total weld length

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TotalLength](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalMass Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TotalMass Property (ICosmeticWeldBeadFolder)

Gets the total weld mass.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalMass As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double  
  
value = instance.TotalMass
```

C#

```
System.double TotalMass {get;}
```

C++/CLI

```
property System.double TotalMass {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total weld mass

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TotalMass](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalNumber Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TotalNumber Property (ICosmeticWeldBeadFolder)

Gets the total number of welds.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property TotalNumber As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double  
  
value = instance.TotalNumber
```

C#

```
System.double TotalNumber {get;}
```

C++/CLI

```
property System.double TotalNumber {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total number of welds

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TotalNumber](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

TotalTime Property (ICosmeticWeldBeadFolder)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICosmeticWeldBeadFolder Interface](#) : TotalTime Property (ICosmeticWeldBeadFolder)

Gets the total welding time.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property TotalTime As System.Double

Visual Basic (Usage)



```
Dim instance As ICosmeticWeldBeadFolder  
Dim value As System.Double
```

```
value = instance.TotalTime
```

C#

```
System.double TotalTime {get;}
```

C++/CLI

```
property System.double TotalTime {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Total welding time

Visual Basic for Applications (VBA) Syntax

See [CosmeticWeldBeadFolder::TotalTime](#).

Example

See [ICosmeticWeldBeadFolder](#) examples.

See Also

[ICosmeticWeldBeadFolder Interface](#)
[ICosmeticWeldBeadFolder Members](#)

Availability

SOLIDWORKS 2013 FCS, Revision Number 21.0

ICounterboreElementData (Type)

ICounterboreElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICounterboreElementData Interface

Allows access to the data of a counterbore hole element in an Advanced Hole.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICounterboreElementData
```

Visual Basic (Usage)

```
Dim instance As ICounterboreElementData
```

C#

```
public interface ICounterboreElementData
```

C++/CLI

```
public interface class ICounterboreElementData
```

Visual Basic for Applications (VBA) Syntax

See [CounterboreElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IAdvancedHoleFeatureData::GetFarSideElements](#)
[IAdvancedHoleFeatureData::GetNearSideElements](#)

Access Diagram

[CounterboreElementData](#)

See Also

[ICounterboreElementData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICountersinkElementData Interface](#)
[IStraightElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

ICounterboreElementData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [ICounterboreElementData](#).

 Public Properties

Name	Description
 EndConditionOverride	Gets or sets whether to override the end condition of this counterbore hole element.
 UseStandardDepth	Gets or sets whether to use the standard offset distance for the end condition of this counterbore hole element.

[Top](#)

 See Also

- [ICounterboreElementData Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [ICountersinkElementData Interface](#)
- [IStraightElementData Interface](#)
- [IStraightTapElementData Interface](#)
- [ITaperedTapElementData Interface](#)
- [IFeatureManager::AdvancedHole Method \(\)](#)
- [IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
- [IAdvancedHoleElementData Interface](#)

ICounterboreElementData Interface Properties

[See Also](#)

For a list of all members of this type, see [ICounterboreElementData members](#).

 Public Properties

Name	Description
 EndConditionOverride	Gets or sets whether to override the end condition of this counterbore hole element.
 UseStandardDepth	Gets or sets whether to use the standard offset distance for the end condition of this counterbore hole element.

[Top](#)

 See Also

- [ICounterboreElementData Interface](#)
- [SolidWorks.Interop.sldworks Namespace](#)
- [ICountersinkElementData Interface](#)
- [IStraightElementData Interface](#)
- [IStraightTapElementData Interface](#)
- [ITaperedTapElementData Interface](#)
- [IFeatureManager::AdvancedHole Method \(\)](#)
- [IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
- [IAdvancedHoleElementData Interface](#)

EndConditionOverride Property (ICounterboreElementData)

[See Also](#)

 .NET Syntax

Visual Basic (Declaration)

Property EndConditionOverride As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICounterboreElementData  
Dim value As System.Boolean
```

```
instance.EndConditionOverride = value
```

```
value = instance.EndConditionOverride
```

C#

```
System.bool EndConditionOverride {get; set;}
```

C++/CLI

```
property System.bool EndConditionOverride {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the end condition, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CounterboreElementData::EndConditionOverride](#).

Example

See the [ICounterboreElementData](#) examples.

Remarks

This property can be set only if [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false.

Set this property to true and specify [IAdvancedHoleElementData::EndCondition](#) to override the end condition.

See Also

[ICounterboreElementData Interface](#)
[ICounterboreElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseStandardDepth Property (ICounterboreElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICounterboreElementData Interface](#) : UseStandardDepth Property (ICounterboreElementData)

Gets or sets whether to use the standard offset distance for the end condition of this counterbore hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property UseStandardDepth As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICounterboreElementData  
Dim value As System.Boolean
```

```
instance.UseStandardDepth = value
```

```
value = instance.UseStandardDepth
```

C#

```
System.bool UseStandardDepth {get; set;}
```

C++/CLI

```
property System.bool UseStandardDepth {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the standard offset distance, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CounterboreElementData::UseStandardDepth](#).

Remarks

This property is valid only if [AdvancedHoleFeatureData::UseBaselineDimensions](#) is set to true.

If this property is set to false, then use [AdvancedHoleElementData::OffsetDistance](#) to set the custom offset distance.

See Also

[ICounterboreElementData Interface](#)
[ICounterboreElementData Members](#)
[AdvancedHoleElementData::OffsetReverseDirection Property\(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

ICountersinkElementData (Type)

ICountersinkElementData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICountersinkElementData Interface

Allows access to the data of a countersink hole element in an Advanced Hole.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICountersinkElementData
```

Visual Basic (Usage)



```
Dim instance As ICountersinkElementData
```

C#

```
public interface ICountersinkElementData
```

C++/CLI

```
public interface class ICountersinkElementData
```

Visual Basic for Applications (VBA) Syntax

See [CountersinkElementData](#).

Example

[Create Advanced Hole Feature \(VBA\)](#)
[Create Advanced Hole Feature \(VB.NET\)](#)
[Create Advanced Hole Feature \(C#\)](#)

Remarks

To create an Advanced Hole feature, see the [IFeatureManager::AdvancedHole](#) Remarks.

Accessors

[IAdvancedHoleFeatureData::GetFarSideElements](#)
[IAdvancedHoleFeatureData::GetNearSideElements](#)

Access Diagram

[CountersinkElementData](#)

See Also

[ICountersinkElementData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[IStraightElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

ICountersinkElementData Interface Members

[See Also](#) [Properties](#)



The following tables list the members exposed by [ICountersinkElementData](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle of this countersink hole element.
 AngleOverride	Gets or sets whether to override the angle of this countersink hole element.
 EndConditionOverride	Gets or sets whether to override the end condition of this countersink hole element.
 UseStandardDepth	Gets or sets whether to use the standard offset distance for the end condition of this countersink hole element.

[Top](#)

 See Also

[ICountersinkElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[IStraightElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

ICountersinkElementData Interface Properties

[See Also](#)



For a list of all members of this type, see [ICountersinkElementData members](#).

 Public Properties

Name	Description
 Angle	Gets or sets the angle of this countersink hole element.
 AngleOverride	Gets or sets whether to override the angle of this countersink hole element.
 EndConditionOverride	Gets or sets whether to override the end condition of this countersink hole element.
 UseStandardDepth	Gets or sets whether to use the standard offset distance for the end condition of this countersink hole element.

[Top](#)

 See Also

[ICountersinkElementData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[ICounterboreElementData Interface](#)
[IStraightElementData Interface](#)
[IStraightTapElementData Interface](#)
[ITaperedTapElementData Interface](#)
[IFeatureManager::AdvancedHole Method \(\)](#)
[IModelDocExtension::CreateAdvancedHoleElementData Method \(\)](#)
[IAdvancedHoleElementData Interface](#)

Angle Property (ICountersinkElementData)

[See Also](#)



Gets or sets the angle of this countersink hole element.

 .NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ICountersinkElementData
Dim value As System.Double

instance.Angle = value

value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle in radians

Visual Basic for Applications (VBA) Syntax

See [CountersinkElementData::Angle](#).

Remarks

This property is valid only if [ICountersinkElementData::AngleOverride](#) is set to true.

See Also

[ICountersinkElementData Interface](#)
[ICountersinkElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AngleOverride Property (ICountersinkElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICountersinkElementData Interface](#) : AngleOverride Property (ICountersinkElementData)

Gets or sets whether to override the angle of this countersink hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property AngleOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICountersinkElementData
Dim value As System.Boolean
```

```
instance.AngleOverride = value
```

```
value = instance.AngleOverride
```

C#

```
System.bool AngleOverride {get; set;}
```

C++/CLI

```
property System.bool AngleOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the angle, false to not

Visual Basic for Applications (VBA) Syntax

See [CountersinkElementData::AngleOverride](#).

Example

See the [ICountersinkElementData](#) examples.

See Also

[ICountersinkElementData Interface](#)
[ICountersinkElementData Members](#)
[ICountersinkElementData::Angle Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndConditionOverride Property (ICountersinkElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICountersinkElementData Interface](#) : EndConditionOverride Property (ICountersinkElementData)

Gets or sets whether to override the end condition of this countersink hole element.

.NET Syntax

Visual Basic (Declaration)

```
Property EndConditionOverride As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICountersinkElementData
Dim value As System.Boolean
```

```
instance.EndConditionOverride = value
```

```
value = instance.EndConditionOverride
```

C#

```
System.bool EndConditionOverride {get; set;}
```

C++/CLI

```
property System.bool EndConditionOverride {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to override the end condition, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CountersinkElementData::EndConditionOverride](#).

Example

See the [ICountersinkElementData](#) examples.

Remarks

This property can be set only if [AdvancedHoleFeatureData::UseBaselineDimensions](#) is set to false.

Set this property to true and specify [AdvancedHoleElementData::EndCondition](#) to override the end condition.

See Also

[ICountersinkElementData Interface](#)
[ICountersinkElementData Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UseStandardDepth Property (ICountersinkElementData)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICountersinkElementData Interface](#) : UseStandardDepth Property (ICountersinkElementData)

Gets or sets whether to use the standard offset distance for the end condition of this countersink hole element.

.NET Syntax

Visual Basic (Declaration)

Property UseStandardDepth As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICountersinkElementData  
Dim value As System.Boolean
```

```
instance.UseStandardDepth = value
```

```
value = instance.UseStandardDepth
```

C#

```
System.bool UseStandardDepth {get; set;}
```

C++/CLI

```
property System.bool UseStandardDepth {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to use the standard offset distance, false to not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CountersinkElementData::UseStandardDepth](#).

Remarks

This property is valid only if [IAdvancedHoleFeatureData::UseBaselineDimensions](#) is set to true.

If this property is set to false, then use [IAdvancedHoleElementData::OffsetDistance](#) to set the custom offset distance.

See Also

[ICountersinkElementData Interface](#)

[ICountersinkElementData Members](#)

[IAdvancedHoleElementData::OffsetReverseDirection Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

ICrossBreakFeatureData (Type)

ICrossBreakFeatureData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICrossBreakFeatureData Interface

Gets or sets cross break feature data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

Public Interface ICrossBreakFeatureData

Visual Basic (Usage)



Dim instance As [ICrossBreakFeatureData](#)

C#

public interface ICrossBreakFeatureData

C++/CLI

public interface class ICrossBreakFeatureData

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

Accessors

[IFeature::GetDefinition](#) and [IFeature::IGetDefinition](#)

Access Diagram

[CrossBreakFeatureData](#)

See Also

[ICrossBreakFeatureData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCrossBreak Method \(\)](#)

ICrossBreakFeatureData Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICrossBreakFeatureData Interface

The following tables list the members exposed by [ICrossBreakFeatureData](#).

Public Properties

Name	Description
 BreakAngle	Gets or sets the angle for this cross break feature.
 BreakRadius	Gets or sets the radius for this cross break feature.

 Face	Gets or sets the face to which to apply this cross break feature.
 ReverseDirection	Gets or sets whether to reverse the direction of this cross break feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that define this cross break feature.
 ReleaseSelectionAccess	Releases access to the selections that define this cross break feature.

[Top](#)

See Also

[ICrossBreakFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCrossBreak Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICrossBreakFeatureData Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICrossBreakFeatureData Interface

For a list of all members of this type, see [ICrossBreakFeatureData members](#).

Public Methods

Name	Description
 AccessSelections	Allows access to the selections that define this cross break feature.
 ReleaseSelectionAccess	Releases access to the selections that define this cross break feature.

[Top](#)

See Also

[ICrossBreakFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCrossBreak Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICrossBreakFeatureData Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICrossBreakFeatureData Interface

For a list of all members of this type, see [ICrossBreakFeatureData members](#).

Public Properties

Name	Description
 BreakAngle	Gets or sets the angle for this cross break feature.
 BreakRadius	Gets or sets the radius for this cross break feature.
 Face	Gets or sets the face to which to apply this cross break feature.
 ReverseDirection	Gets or sets whether to reverse the direction of this cross break feature.

[Top](#)

See Also

[ICrossBreakFeatureData Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IFeatureManager::InsertCrossBreak Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

AccessSelections Method (ICrossBreakFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : AccessSelections Method (ICrossBreakFeatureData)

Allows access to the selections that define this cross break feature.

.NET Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc
Top-level document (see **Remarks**)
Component
Component in which to modify the feature (see **Remarks**)

Return Value

True if the selections are successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::AccessSelections](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is Nothing or null
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which to modify the feature

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use one of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ICrossBreakFeatureData::ReleaseSelectionAccess](#) if you did not

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

BreakAngle Property (ICrossBreakFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : BreakAngle Property (ICrossBreakFeatureData)

Gets or sets the angle for this cross break feature.

.NET Syntax

Visual Basic (Declaration)

```
Property BreakAngle As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData  
Dim value As System.Double
```

```
instance.BreakAngle = value
```

```
value = instance.BreakAngle
```

C#

```
System.double BreakAngle {get; set;}
```

C++/CLI

```
property System.double BreakAngle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Angle

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::BreakAngle](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

BreakRadius Property (ICrossBreakFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : BreakRadius Property (ICrossBreakFeatureData)

Gets or sets the radius for this cross break feature.

.NET Syntax

Visual Basic (Declaration)

Property BreakRadius As System.Double

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData  
Dim value As System.Double
```

```
instance.BreakRadius = value
```

```
value = instance.BreakRadius
```

C#

```
System.double BreakRadius {get; set;}
```

C++/CLI

```
property System.double BreakRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Radius

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::BreakRadius](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Face Property (ICrossBreakFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : Face Property (ICrossBreakFeatureData)

Gets or sets the face to which to apply this cross break feature.

.NET Syntax

Visual Basic (Declaration)

Property Face As System.Object

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData  
Dim value As System.Object
```

```
instance.Face = value
```

```
value = instance.Face
```

C#

```
System.object Face {get; set;}
```

C++/CLI

```
property System.Object^ Face {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Face](#) to which to apply this cross break feature

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::Face](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ReleaseSelectionAccess Method (ICrossBreakFeatureData)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : ReleaseSelectionAccess Method (ICrossBreakFeatureData)

Releases access to the selections that define this cross break feature.

.NET Syntax

Visual Basic (Declaration)

```
Sub ReleaseSelectionAccess()
```

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData
```

```
instance.ReleaseSelectionAccess()
```

C#

```
void ReleaseSelectionAccess()
```

C++/CLI

```
void ReleaseSelectionAccess();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::ReleaseSelectionAccess](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

Remarks

[ICrossBreakFeatureData::AccessSelections](#) puts the model into a rollback state to allow access to the selections that define this feature.

Use this method to restore the rollback state if you did not modify the feature. Use [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you did.

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ReverseDirection Property (ICrossBreakFeatureData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICrossBreakFeatureData Interface](#) : ReverseDirection Property (ICrossBreakFeatureData)

Gets or sets whether to reverse the direction of this cross break feature.

.NET Syntax

Visual Basic (Declaration)

```
Property ReverseDirection As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICrossBreakFeatureData  
Dim value As System.Boolean
```

```
instance.ReverseDirection = value
```

```
value = instance.ReverseDirection
```

C#

```
System.bool ReverseDirection {get; set;}
```

C++/CLI

```
property System.bool ReverseDirection {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to reverse the direction of this cross break feature, false to not

Visual Basic for Applications (VBA) Syntax

See [CrossBreakFeatureData::ReverseDirection](#).

Example

[Get Cross Break Feature Data in Sheet Metal Part \(C#\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VB.NET\)](#)
[Get Cross Break Feature Data in Sheet Metal Part \(VBA\)](#)

See Also

[ICrossBreakFeatureData Interface](#)
[ICrossBreakFeatureData Members](#)

Availability

SOLIDWORKS 2016 FCS, Revision Number 24.0

ICThread (Type)

ICThread Interface

[See Also](#) [Members](#) [Example](#)

 

[SolidWorks.Interop.sldworks Namespace](#) : ICThread Interface

Allows access to a cosmetic thread.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

 .NET Syntax

Visual Basic (Declaration)

Public Interface ICThread

Visual Basic (Usage)

Dim instance As [ICThread](#)

C#

public interface ICThread

C++/CLI

public interface class ICThread

 Visual Basic for Applications (VBA) Syntax

See [CThread](#).

 Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

 Remarks

A cosmetic thread annotation in a drawing is typically associated with a cosmetic thread feature in the underlying model. The name of the annotation is the same as the name of the feature.

Use:

- [IAnnotation::GetName](#) to get the name of the CThread annotation in the drawing.
- [IPartDoc::FeatureByName](#) or [IPartDoc::IFeatureByName](#) with that name, to get that feature in the model.
- [ICosmeticThreadFeatureData](#) to access the cosmetic thread model data once you have the feature.

 Accessors

[IAnnotation::GetSpecificAnnotation](#) or [IAnnotation::IGetSpecificAnnotation](#)
[ICThread::GetNext](#) and [ICThread::IGetNext](#)
[IView::GetFirstCThread](#) and [IView::IGetFirstCThread](#)
[IView::GetCThreads](#) and [IView::IGetCThreads](#)

 Access Diagram

[CThread](#)

 See Also

ICThread Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICThread Interface

For a list of all members of this type, see [ICThread members](#).

Public Methods

Name	Description
GetAnnotation	Gets the annotation for this cosmetic thread.
GetDisplayData	Gets the display data for this cosmetic thread.
GetNext	Gets the next cosmetic thread.
GetPatternedTransformsCount	Gets the number of instances of this cosmetic thread that are patterns of this feature.
IGetAnnotation	Gets the annotation for this cosmetic thread.
IGetDisplayData	Gets the display data for this cosmetic thread.
IGetNext	Gets the next cosmetic thread.
IGetPatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

[Top](#)

See Also

[ICThread Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::HasLegacyCThreads Method \(\)](#)

ICThread Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICThread Interface

The following tables list the members exposed by [ICThread](#).

Public Properties

Name	Description
PatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
ThreadCallout	Gets the note for this cosmetic thread callout in a drawing.

[Top](#)

Public Methods

Name	Description
GetAnnotation	Gets the annotation for this cosmetic thread.
GetDisplayData	Gets the display data for this cosmetic thread.
GetNext	Gets the next cosmetic thread.
GetPatternedTransformsCount	Gets the number of instances of this cosmetic thread that are patterns of this feature.
IGetAnnotation	Gets the annotation for this cosmetic thread.
IGetDisplayData	Gets the display data for this cosmetic thread.
IGetNext	Gets the next cosmetic thread.
IGetPatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

[Top](#)

See Also

[ICThread Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::HasLegacyCThreads Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICThread Interface Properties

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ICThread Interface

For a list of all members of this type, see [ICThread members](#).

Public Properties

Name	Description
 PatternedTransforms	Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.
 ThreadCallout	Gets the note for this cosmetic thread callout in a drawing.

[Top](#)

See Also

[ICThread Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IModelDocExtension::HasLegacyCThreads Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAnnotation Method (ICThread)

[See Also](#) [Example](#)

  [SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : GetAnnotation Method (ICThread)

Gets the annotation for this cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Annotation](#)

Visual Basic for Applications (VBA) Syntax

See [CThread::GetAnnotation](#).

Example

[Get Annotation Object \(VBA\)](#)
[Get Annotation Object \(VB.NET\)](#)

[Get Annotation Object \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

Remarks

This method gets the owning IAnnotation object for this cosmetic thread. The IAnnotation object is a higher-level object that contains methods and properties that apply to all types of annotations

See Also

[ICThread Interface](#)
[ICThread Members](#)
[IAnnotation::GetNext3 Method](#)
[IModelDocExtension::GetAnnotations Method](#)
[IView::GetAnnotations Method](#)
[IView::IGetAnnotations Method](#)
[IView::GetFirstAnnotation3 Method](#)
[ICThread::IGetAnnotation Method](#)

Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDisplayData Method (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : GetDisplayData Method (ICThread)

Gets the display data for this cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDisplayData() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As System.Object  
  
value = instance.GetDisplayData()
```

C#

```
System.object GetDisplayData()
```

C++/CLI

```
System.Object^ GetDisplayData();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

[Display data](#)

Visual Basic for Applications (VBA) Syntax

See [CThread::GetDisplayData](#).

See Also

[ICThread Interface](#)
[ICThread Members](#)
[ICThread::IGetDisplayData Method](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNext Method (ICThread)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : GetNext Method (ICThread)

Gets the next cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.Object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Next [cosmetic thread](#)

Visual Basic for Applications (VBA) Syntax

See [CThread::GetNext](#).

Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

See Also

[ICThread Interface](#)
[ICThread Members](#)
[View::GetFirstCThread Method](#)
[View::IGetFirstCThread Method](#)
[ICThread::IGetNext Method](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetPatternedTransformsCount Method (ICThread)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : GetPatternedTransformsCount Method (ICThread)

Gets the number of instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetPatternedTransformsCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As System.Integer  
  
value = instance.GetPatternedTransformsCount()
```

C#

```
System.int GetPatternedTransformsCount()
```

C++/CLI

```
System.int GetPatternedTransformsCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of instances of this cosmetic thread that are patterns of this feature

Visual Basic for Applications (VBA) Syntax

See [CThread::GetPatternedTransformsCount](#).

Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

Remarks

The value returned by this method does not include this cosmetic thread, which is the seed feature and not an instance of the pattern. Therefore if this cosmetic thread is not used in any pattern feature, then this method returns 0.

Use this method before using [ICThread::IGetPatternedTransforms](#) to determine the size of the array to pass to that method.

See Also

[ICThread Interface](#)
[ICThread Members](#)
[ICThread::PatternedTransforms Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetAnnotation Method (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : IGetAnnotation Method (ICThread)

Gets the annotation for this cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As Annotation  
  
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IAnnotation](#) object

 Visual Basic for Applications (VBA) Syntax

See [CThread::IGetAnnotation](#).

 Remarks

This method gets the owning IAnnotation object for this cosmetic thread. The IAnnotation object is a higher-level object that contains methods and properties that apply to all types of annotation

 See Also

- [ICThread Interface](#)
- [ICThread Members](#)
- [ICThread::GetAnnotation Method](#)
- [IAnnotation::GetNext3 Method](#)
- [IModelDocExtension::GetAnnotations Method](#)
- [IView::GetAnnotations Method](#)
- [IView::GetFirstAnnotation3 Method](#)
- [IView::IGetAnnotations Method](#)

 Availability

SOLIDWORKS 99, datecode 1999207

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetDisplayData Method (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : IGetDisplayData Method (ICThread)

Gets the display data for this cosmetic thread.

 .NET Syntax

Visual Basic (Declaration)

Function IGetDisplayData() As DisplayData

Visual Basic (Usage)



```
Dim instance As ICThread
Dim value As DisplayData

value = instance.IGetDisplayData()
```

C#

DisplayData IGetDisplayData()

C++/CLI

DisplayData^ IGetDisplayData();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the [IDisplayData](#) object

 Visual Basic for Applications (VBA) Syntax

See [CThread::IGetDisplayData](#).

 See Also

IGetNext Method (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : IGetNext Method (ICThread)

Gets the next cosmetic thread.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As CThread
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As CThread  
  
value = instance.IGetNext()
```

C#

```
CThread IGetNext()
```

C++/CLI

```
CThread^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Pointer to the next [cosmetic thread](#)

Visual Basic for Applications (VBA) Syntax

See [CThread::IGetNext](#).

See Also

[ICThread Interface](#)
[ICThread Members](#)
[ICThread::GetNext Method](#)
[IView::GetFirstCThread Method](#)
[IView::IGetFirstCThread Method](#)

IGetPatternedTransforms Method (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : IGetPatternedTransforms Method (ICThread)

Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetPatternedTransforms( _  
    ByVal Count As System.Integer _  
) As MathTransform
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim Count As System.Integer  
Dim value As MathTransform
```

```
value = instance.IGetPatternedTransforms(Count)
```

C#

```
MathTransform IGetPatternedTransforms(  
    System.int Count  
)
```

C++/CLI

```
MathTransform^ IGetPatternedTransforms(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Size of the output array (see **Remarks**)

Return Value

- in-process, unmanaged C++: Pointer to an array of interface pointers to the [IMathTransform](#) objects of the instances of this cosmetic thread
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICThreadFeatureData::GetPatternedTransformsCount](#) before calling this method to determine the size of the output array.

The value returned by this method does not include this cosmetic thread, which is the seed feature and not an pattern instance. Therefore, if this cosmetic thread is not used in a pattern feature, then ICThreadFeatureData::GetPatternedTransformsCount returns 0 and this method returns an empty array.

See Also

[ICThread Interface](#)
[ICThread Members](#)
[ICThread::PatternedTransforms Property](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

PatternedTransforms Property (ICThread)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : PatternedTransforms Property (ICThread)

Gets the transforms from this cosmetic thread for all of the instances of this cosmetic thread that are patterns of this feature.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property PatternedTransforms As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As System.Object
```

```
value = instance.PatternedTransforms
```

C#

```
System.object PatternedTransforms {get;}
```

C++/CLI

```
property System.Object^ PatternedTransforms {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of [transforms](#) for the instances of this cosmetic thread

Visual Basic for Applications (VBA) Syntax

See [CThread::PatternedTransforms](#).

Example

[Get Patterned Cosmetic Thread Annotations Data \(C#\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VB.NET\)](#)
[Get Patterned Cosmetic Thread Annotations Data \(VBA\)](#)

Remarks

The value returned by this property does not include this cosmetic thread, which is the seed feature and not a pattern instance. Therefore, if this cosmetic thread is not used in a pattern feature, then [ICThreadFeatureData::GetTransformsPatternedCount](#) returns 0 and this property returns an empty array.

See Also

[ICThread Interface](#)
[ICThread Members](#)

Availability

SOLIDWORKS 2006 FCS, Revision Number 14.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ThreadCallout Property (ICThread)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICThread Interface](#) : ThreadCallout Property (ICThread)

Gets the note for this cosmetic thread callout in a drawing.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property ThreadCallout As Note

Visual Basic (Usage)



```
Dim instance As ICThread  
Dim value As Note
```

```
value = instance.ThreadCallout
```

C#

```
Note ThreadCallout {get;}
```

C++/CLI

```
property Note^ ThreadCallout {  
    Note^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to the [INote](#) object for this cosmetic thread callout in a drawing

Visual Basic for Applications (VBA) Syntax

See [CThread::ThreadCallout](#).

Remarks

By getting the INote interface, you have access to all of its methods and properties, such as the ability to get or set the text or change the text format.

See Also

[ICThread Interface](#)
[ICThread Members](#)

Availability

SOLIDWORKS 2003 SP1, Revision Number 11.1