

SOLIDWORKS API (NET VBA C#) — Reference

(64/337): ICurveParamData- ICustomPropertyManager

SOLIDWORKS API Documentation (converted from CHM)

ICurveParamData (Type)

ICurveParamData Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICurveParamData Interface

Allows access to curve parameterization data.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICurveParamData
```

Visual Basic (Usage)



```
Dim instance As ICurveParamData
```

C#

```
public interface ICurveParamData
```

C++/CLI

```
public interface class ICurveParamData
```

Visual Basic for Applications (VBA) Syntax

See [CurveParamData](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

Remarks

Accessors

[IEdge::GetCurveParams3](#)

Access Diagram

[CurveParamData](#)

See Also

[ICurveParamData Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICurveParamData Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICurveParamData Interface

The following tables list the members exposed by [ICurveParamData](#).

Public Properties

Name	Description
CurveTag	Gets the ID for this curve.

[CurveType](#)

Gets the type of curve.

[EndPoint](#)

Gets the x, y, and z coordinates for the end point of this curve.

[Sense](#)

Gets whether the curve and edge are in the same direction.

[StartPoint](#)

Gets the x, y, and z coordinates for the start point of the curve.

[UMaxValue](#)

Gets the maximum U parameter value.

[UMinValue](#)

Gets the minimum U parameter value.

[Top](#)

See Also

[ICurveParamData Interface](#)[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICurveParamData Interface Properties

[See Also](#)[SolidWorks.Interop.sldworks Namespace](#) : [ICurveParamData Interface](#)For a list of all members of this type, see [ICurveParamData members](#).

Public Properties

[CurveTag](#)

Description

Gets the ID for this curve.

[CurveType](#)

Gets the type of curve.

[EndPoint](#)

Gets the x, y, and z coordinates for the end point of this curve.

[Sense](#)

Gets whether the curve and edge are in the same direction.

[StartPoint](#)

Gets the x, y, and z coordinates for the start point of the curve.

[UMaxValue](#)

Gets the maximum U parameter value.

[UMinValue](#)

Gets the minimum U parameter value.

[Top](#)

See Also

[ICurveParamData Interface](#)[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurveTag Property (ICurveParamData)

[See Also](#) [Example](#)[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : [CurveTag Property \(ICurveParamData\)](#)

Gets the ID for this curve.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property CurveTag As System.Integer

Visual Basic (Usage)

Dim instance As [ICurveParamData](#)

Dim value As System.Integer

value = instance.CurveTag

C#

```
System.int CurveTag {get;}
```

C++/CLI

```
property System.int CurveTag {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

ID of the curve

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::CurveTag](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

CurveType Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : CurveType Property (ICurveParamData)

Gets the type of curve.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CurveType As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICurveParamData  
Dim value As System.Integer  
  
value = instance.CurveType
```

C#

```
System.int CurveType {get;}
```

C++/CLI

```
property System.int CurveType {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of curve as defined in [swCurveTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::CurveType](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EndPoint Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : EndPoint Property (ICurveParamData)

Gets the x, y, and z coordinates for the end point of this curve.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property EndPoint As System.Object

Visual Basic (Usage)



```
Dim instance As ICurveParamData  
Dim value As System.Object
```

```
value = instance.EndPoint
```

C#

```
System.object EndPoint {get;}
```

C++/CLI

```
property System.Object^ EndPoint {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of three doubles

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::EndPoint](#).

Example

If [ICurveParamData::Sense](#) returns false, then the curve and edge are in opposite directions. In that case, [ICurveParamData::StartPoint](#) corresponds to the end of the edge, and end point corresponds to the start of the edge.

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Sense Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : Sense Property (ICurveParamData)

Gets whether the curve and edge are in the same direction.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Sense As System.Boolean

Visual Basic (Usage)



```
Dim instance As ICurveParamData  
Dim value As System.Boolean
```

```
value = instance.Sense
```

C#

```
System.bool Sense {get;}
```

C++/CLI

```
property System.bool Sense {  
    System.bool get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if curve and edge are in the same direction, false if not

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::Sense](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

Remarks

If this method returns False, then the curve and edge are in opposite directions. In that case, [ICurveParamData::StartPoint](#) corresponds to the end of the edge, [ICurveParamData::EndPoint](#) corresponds to the start of the edge.

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)
[ICurveParamData::UMaxValue Property \(\)](#)
[ICurveParamData::UMinValue Property \(\)](#)

Availability

StartPoint Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : StartPoint Property (ICurveParamData)

Gets the x, y, and z coordinates for the start point of the curve.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property StartPoint As System.Object

Visual Basic (Usage)



```
Dim instance As ICurveParamData
Dim value As System.Object

value = instance.StartPoint
```

C#

```
System.Object StartPoint {get;}
```

C++/CLI

```
property System.Object^ StartPoint {
    System.Object^ get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of three doubles

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::StartPoint](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

Remarks

If [ICurveParamData::Sense](#) returns false, then the curve and edge are in opposite directions. In that case, start point corresponds to the end of the edge, and [ICurveParamData::EndPoint](#) corresponds to the start of the edge.

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

UMaxValue Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : UMaxValue Property (ICurveParamData)

Gets the maximum U parameter value.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property UMaxValue As System.Double

Visual Basic (Usage)



```
Dim instance As ICurveParamData  
Dim value As System.Double
```

```
value = instance.UMaxValue
```

C#

```
System.double UMaxValue {get;}
```

C++/CLI

```
property System.double UMaxValue {  
    System.double get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Maximum U parameter value

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::UMaxValue](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

Remarks

The minimum U parameter must always be smaller than the maximum U parameter.

If the curve and edge are in opposite directions ([ICurveParamData::Sense](#) returns false) and the minimum U parameter is larger than the maximum U parameter, then the parameters are in negative parameter space. For example, if [ICurveParamData::Sense](#) is false, minimum U parameter is 10, and maximum U parameter is 5, then [ICurveParamData::UMinValue](#) = -10 and [ICurveParamData::UMaxValue](#) = -5. To normalize the values in positive parameter space, swap the two U parameter values and then negate them, so that the values of the minimum U parameter is 5 and the maximum U parameter is 10.

If the curve is closed and the curve starts and ends at the same point, then [ICurveParamData::UMinValue](#) and [ICurveParamData::UMaxValue](#) are a period apart.

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

UMinValue Property (ICurveParamData)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICurveParamData Interface](#) : UMinValue Property (ICurveParamData)

Gets the minimum U parameter value.

.NET Syntax

ReadOnly Property UMinValue As System.Double



```
Dim instance As ICurveParamData
Dim value As System.Double

value = instance.UMinValue
```

```
System.double UMinValue {get;}
```

```
property System.double UMinValue {
    System.double get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Minimum U parameter value

Visual Basic for Applications (VBA) Syntax

See [CurveParamData::UMinValue](#).

Example

[Get Edge Curve Parameterization \(C#\)](#)
[Get Edge Curve Parameterization \(VB.NET\)](#)
[Get Edge Curve Parameterization \(VBA\)](#)

Remarks

The minimum U parameter must always be smaller than the maximum U parameter.

If the curve and edge are in opposite directions ([ICurveParamData::Sense](#) returns false) and the minimum U parameter is larger than the maximum U parameter, then the parameters are in negative parameter space. For example, if [ICurveParamData::Sense](#) is false, minimum U parameter is 10, and maximum U parameter is 5, then [ICurveParamData::UMinValue](#) = -10 and [ICurveParamData::UMaxValue](#) = -5. To normalize the values in positive parameter space, swap the two U parameter values and then negate them, so that the values of the minimum U parameter is 5 and the maximum U parameter is 10.

If the curve is closed and the curve starts and ends at the same point, then [ICurveParamData::UMinValue](#) and [ICurveParamData::UMaxValue](#) are a period apart.

See Also

[ICurveParamData Interface](#)
[ICurveParamData Members](#)

Availability

SOLIDWORKS 2011 FCS, Revision Number 19.0

ICustomBendAllowance (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICustomBendAllowance Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomBendAllowance Interface

Allows access to the custom bend allowance of a feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICustomBendAllowance
```

Visual Basic (Usage)

```
Dim instance As ICustomBendAllowance
```

C#

```
public interface ICustomBendAllowance
```

C++/CLI

```
public interface class ICustomBendAllowance
```

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance](#).

Example

[Get All Sheet Metal Feature Data \(VBA\)](#)
[Get All Sheet Metal Feature Data \(VB.NET\)](#)
[Get All Sheet Metal Feature Data \(C#\)](#)

Remarks

In your application, the [ICustomBendAllowance::Type](#) must always be set last, after the other properties of this interface have been set. The property last set automatically overrides any previously set ICustomBendAllowance::Type.

For example:

```
cba.Type = swBendAllowanceTypes_e.swBendAllowanceDeduction '***set first, so will not hold***
```

```
'***RESET THE VALUES***
```

```
cba.KFactor = 0.08
```

```
cba.BendDeduction = 0.1
```

```
cba.BendAllowance = 0.11
```

```
cba.BendTableFile = "E:\AAA Projects\sw2025\QA\SP02\Convert To Sheetmetal FUN156195\1-Staal.xls"
```

```
cba.BendCalculationTableFile = "E:\AAA Projects\sw2025\QA\SP02\Convert To Sheetmetal FUN156195\1-Staal.xls"
```

```
cba.Type = swBendAllowanceTypes_e.swBendAllowanceDirect '***set last, so holds***
```

The above code sets the ICustomBendAllowance::Type as swBendAllowanceTypes_e.swBendAllowanceDirect.

Another example:

```
    cba.Type = swBendAllowanceTypes_e.swBendAllowanceDeduction '***set first, so will
not hold***

    '***RESET THE VALUES***

    cba.KFactor = 0.08
    cba.BendDeduction = 0.1
    cba.BendAllowance = 0.11

    cba.BendTableFile = "E:\AAA Projects\sw2025\QA\SP02\Convert To Sheetmetal
FUN156195\1-Staal.xls"

    cba.BendCalculationTableFile = "E:\AAA Projects\sw2025\QA\SP02\Convert To
Sheetmetal FUN156195\1-Staal.xls"

    cba.Type = swBendAllowanceTypes_e.swBendAllowanceDirect '***set last would
hold*** BUT COMMENTED OUT
```

The above code sets the ICustomBendAllowance::Type as swBendAllowanceTypes_e.swBendAllowanceBendCalculationTable, because the last property set was BendCalculationTableFile.

The last ICustomBendAllowance property that is set automatically re-sets the type of bend allowance. You can always explicitly specify the [ICustomBendAllowance::Type](#), but you must set it after all other properties of this interface have been set.

 Accessors

- [IBaseFlangeFeatureData::GetCustomBendAllowance](#)
- [IBendsFeatureData::GetCustomBendAllowance](#)
- [IEdgeFlangeFeatureData::GetCustomBendAllowance](#)
- [IFeatureManager::CreateCustomBendAllowance](#)
- [IHemFeatureData::GetCustomBendAllowance](#)
- [IJogFeatureData::GetCustomBendAllowance](#)
- [IMiterFlangeFeatureData::GetCustomBendAllowance](#)
- [IOneBendFeatureData::GetCustomBendAllowance](#)
- [ISheetMetalFeatureData::GetCustomBendAllowance](#)
- [ISketchedBendFeatureData::GetCustomBendAllowance](#)
- [ISweptFlangeFeatureData::GetCustomBendAllowance](#)

 Access Diagram

[CustomBendAllowance](#)

 See Also

- [ICustomBendAllowance Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

ICustomBendAllowance Interface Members

[See Also](#) [Properties](#)

	SolidWorks.Interop.sldworks Namespace : ICustomBendAllowance Interface
---	--

The following tables list the members exposed by [ICustomBendAllowance](#).

 Public Properties

Name	Description
 BendAllowance	Gets or sets the value of the bend allowance.
 BendCalculationTableFile	Gets or sets the bend calculation table file path name.
 BendDeduction	Gets or sets the value of the bend deduction.
 BendTableFile	Gets or sets the path and file name for the bend table.

 KFactor	Gets or sets the K-factor.
 Type	Gets or sets the bend allowance type.

[Top](#)

See Also

[ICustomBendAllowance Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICustomBendAllowance Interface Properties

[See Also](#)

 SolidWorks.Interop.sldworks Namespace : ICustomBendAllowance Interface
--

For a list of all members of this type, see [ICustomBendAllowance members](#).

Public Properties

Name	Description
 BendAllowance	Gets or sets the value of the bend allowance.
 BendCalculationTableFile	Gets or sets the bend calculation table file path name.
 BendDeduction	Gets or sets the value of the bend deduction.
 BendTableFile	Gets or sets the path and file name for the bend table.
 KFactor	Gets or sets the K-factor.
 Type	Gets or sets the bend allowance type.

[Top](#)

See Also

[ICustomBendAllowance Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendAllowance Property (ICustomBendAllowance)

[See Also](#) [Example](#)

 
SolidWorks.Interop.sldworks Namespace > ICustomBendAllowance Interface : BendAllowance Property (ICustomBendAllowance)
Gets or sets the value of the bend allowance.

.NET Syntax

Visual Basic (Declaration)

Property BendAllowance As System.Double

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance
Dim value As System.Double

instance.BendAllowance = value

value = instance.BendAllowance
```

C#

```
System.double BendAllowance {get; set;}
```

C++/CLI

```
property System.double BendAllowance {
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value (m) of the bend allowance

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::BendAllowance](#).

Example

See the [ICustomBendAllowance](#) examples.

See the [IBaseFlangeFeatureData](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

If using this property to set a value for the bend allowance, then the [type of custom bend allowance](#) is set to this type. However, the last ICustomBendAllowance property set also re-sets the type of bend allowance to its type.

See the ICustomBendAllowance Remarks.

See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendCalculationTableFile Property (ICustomBendAllowance)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomBendAllowance Interface](#) : BendCalculationTableFile Property (ICustomBendAllowance)

Gets or sets the bend calculation table file path name.

.NET Syntax

Visual Basic (Declaration)

```
Property BendCalculationTableFile As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance  
Dim value As System.String  
  
instance.BendCalculationTableFile = value  
value = instance.BendCalculationTableFile
```

C#

```
System.string BendCalculationTableFile {get; set;}
```

C++/CLI

```
property System.String^ BendCalculationTableFile {
    System.String^ get();
    void set ( & System.String^ value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend calculation table file path name

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::BendCalculationTableFile](#).

Example

See the [ICustomBendAllowance](#) example.

Remarks

If using this property to set a value for the bend deduction, then the [type of custom bend allowance](#) is set to this type. However, the last ICustomBendAllowance property called to set a value also re-sets the type of custom bend allowance to its type.

See the ICustomBendAllowance Remarks.

See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

Availability

SOLIDWORKS 2025 SP03, Revision Number 33.3

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendDeduction Property (ICustomBendAllowance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomBendAllowance Interface](#) : BendDeduction Property (ICustomBendAllowance)

Gets or sets the value of the bend deduction.

.NET Syntax

Visual Basic (Declaration)

```
Property BendDeduction As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance
Dim value As System.Double
```

```
instance.BendDeduction = value
```

```
value = instance.BendDeduction
```

C#

```
System.double BendDeduction {get; set;}
```

C++/CLI

```
property System.double BendDeduction {
    System.double get();
    void set ( & System.double value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Value of the bend deduction

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::BendDeduction](#).

Example

See [ICustomBendAllowance](#) examples.

Example

[Change Bend Radius of Sketched Bend \(VBA\)](#)

Remarks

If using this property to set a value for the bend deduction, then the [type of custom bend allowance](#) is set to this type. However, the last ICustomBendAllowance property called to set a value also re-sets the type of custom bend allowance to its type.

See the ICustomBendAllowance Remarks.

See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

BendTableFile Property (ICustomBendAllowance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomBendAllowance Interface](#) : BendTableFile Property (ICustomBendAllowance)

Gets or sets the path and file name for the bend table.

.NET Syntax

Visual Basic (Declaration)

```
Property BendTableFile As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance  
Dim value As System.String
```

```
instance.BendTableFile = value
```

```
value = instance.BendTableFile
```

C#

```
System.string BendTableFile {get; set;}
```

C++/CLI

```
property System.String^ BendTableFile {  
    System.String^ get();  
    void set ( & System.String^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Path and file name for the bend table

 Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::BendTableFile](#).

 Example

See [ICustomBendAllowance](#) examples.

 Example

[Change Bend Radius of Sketch Bend \(VBA\)](#)

 Remarks

When using this property to set the path and file name for a bend table, then the [type of custom bend allowance](#) is set to this type. However, the last ICustomBendAllowance property called to set a value also re-sets the type of custom bend allowance to its type.

See the ICustomBendAllowance Remarks.

 See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

 Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

KFactor Property (ICustomBendAllowance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomBendAllowance Interface](#) : KFactor Property (ICustomBendAllowance)

Gets or sets the K-factor.

 .NET Syntax

Visual Basic (Declaration)

Property KFactor As System.Double

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance  
Dim value As System.Double
```

```
instance.KFactor = value
```

```
value = instance.KFactor
```

C#

```
System.double KFactor {get; set;}
```

C++/CLI

```
property System.double KFactor {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

K-factor value

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::KFactor](#).

Example

See [ICustomBendAllowance](#) examples.

Example

[Change Bend Radius of Sketch Bend \(VBA\)](#)

Remarks

When using this property to set a value for K-factor, then the [type of custom bend allowance](#) is set to this type. However, the last ICustomBendAllowance property called to set a value also re-sets the type of custom bend allowance to its type.

See the ICustomBendAllowance Remarks.

See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Type Property (ICustomBendAllowance)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomBendAllowance Interface](#) : Type Property (ICustomBendAllowance)

Gets or sets the bend allowance type.

.NET Syntax

Visual Basic (Declaration)

Property Type As System.Integer

Visual Basic (Usage)



```
Dim instance As ICustomBendAllowance
Dim value As System.Integer

instance.Type = value

value = instance.Type
```

C#

```
System.int Type {get; set;}
```

C++/CLI

```
property System.int Type {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Bend allowance type as defined in [swBendAllowanceTypes_e](#)

Visual Basic for Applications (VBA) Syntax

See [CustomBendAllowance::Type](#).

Example

See the [ICustomBendAllowance](#) examples.

See the [IBaseFlangeFeatureData](#) examples.

Example

[Change Bend Radius of Sketch Bend \(VBA\)](#)
[Set Custom Bend Deduction \(VBA\)](#)
[Set Custom Bend Deduction \(VB.NET\)](#)
[Set Custom Bend Deduction \(C#\)](#)

Remarks

After setting [ICustomBendAllowance::BendAllowance](#), [ICustomBendAllowance::BendDeduction](#), [ICustomBendAllowance::BendTableFile](#), [ICustomBendAllowance::BendCalculationTableFile](#), and [ICustomBendAllowance::KFactor](#) use this property to set the value for the type. If you do not set this property last, the ICustomBendAllowance property set last automatically overrides any previously set custom bend allowance type.

See the ICustomBendAllowance Remarks.

See [Accessing Selections that Define Features](#) for additional details on using this property.

See Also

[ICustomBendAllowance Interface](#)
[ICustomBendAllowance Members](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

ICustomPropertyManager (Type)

ICustomPropertyManager Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomPropertyManager Interface

Allows access to the custom properties.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICustomPropertyManager
```

Visual Basic (Usage)

```
Dim instance As ICustomPropertyManager
```

C#

```
public interface ICustomPropertyManager
```

C++/CLI

```
public interface class ICustomPropertyManager
```

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager](#).

Example

- [Get Custom Property Values on Cut List Folders \(VBA\)](#)
- [Get Custom Properties of Referenced Part \(C#\)](#)
- [Get Custom Properties of Referenced Part \(VB.NET\)](#)
- [Get Custom Properties of Referenced Part \(VBA\)](#)
- [Get Custom Properties for Configuration \(VBA\)](#)
- [Get Custom Properties for Configuration \(VB.NET\)](#)
- [Get Custom Properties for Configuration \(C#\)](#)

Accessors

- [IComponent2::CustomPropertyManager](#)
- [IConfiguration::CustomPropertyManager](#)
- [ICutListItem::CustomPropertyManager](#)
- [IFeature::CustomPropertyManager](#)
- [IModelDocExtension::CustomPropertyManager](#)

Access Diagram

[CustomPropertyManager](#)

See Also

- [ICustomPropertyManager Members](#)
- [SolidWorks.Interop.sldworks Namespace](#)

ICustomPropertyManager Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomPropertyManager Interface

For a list of all members of this type, see [ICustomPropertyManager members](#).

Public Methods

Name	Description
 Add	Obsolete. Superseded by ICustomPropertyManager::Add2 .
 Add2	Obsolete. Superseded by ICustomPropertyManager::Add3 .
 Add3	Adds a custom property to a configuration or model document.
 Delete	Obsolete. Superseded by ICustomPropertyManager::Delete2 .
 Delete2	Deletes the specified custom property.
 Get	Obsolete. Superseded by ICustomPropertyManager::Get2 .
 Get2	Obsolete. Superseded by ICustomPropertyManager::Get3 .
 Get3	Obsolete. Superseded by ICustomPropertyManager::Get4 .
 Get4	Obsolete. Superseded by ICustomPropertyManager::Get5 .
 Get5	Obsolete. Superseded by ICustomPropertyManager::Get6 .
 Get6	Gets the value and the evaluated value of the specified custom property.
 GetAll	Obsolete. Superseded by ICustomPropertyManager::GetAll2 .
 GetAll2	Obsolete. Superseded by ICustomPropertyManager::GetAll3 .
 GetAll3	Gets all of the custom properties for this configuration.
 GetNames	Gets the names of the custom properties.
 GetType	Obsolete. Superseded by ICustomPropertyManager::GetType2 .
 GetType2	Gets the type of the specified custom property for a configuration or model document.
 IGetAll	Gets all of the custom properties for this configuration.
 IGetNames	Gets the names of the custom properties.
 IsCustomPropertyEditable	Gets whether the specified custom property is editable in the specified configuration.
 LinkProperty	Sets whether to link or unlink the specified custom property to or from its parent part.
 Set	Obsolete. Superseded by ICustomPropertyManager::Set2 .
 Set2	Sets the value for the specified custom property.

[Top](#)

See Also

[ICustomPropertyManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICustomPropertyManager Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomPropertyManager Interface

The following tables list the members exposed by [ICustomPropertyManager](#).

Public Properties

Name	Description
 Count	Gets the number of custom properties.
 LinkAll	Gets or sets whether to link or unlink all custom properties to or from their parent parts.
 Owner	Gets the owner of this custom property.

[Top](#)

Public Methods

Name	Description
 Add	Obsolete. Superseded by ICustomPropertyManager::Add2 .
 Add2	Obsolete. Superseded by ICustomPropertyManager::Add3 .
 Add3	Adds a custom property to a configuration or model document.
 Delete	Obsolete. Superseded by ICustomPropertyManager::Delete2 .
 Delete2	Deletes the specified custom property.
 Get	Obsolete. Superseded by ICustomPropertyManager::Get2 .
 Get2	Obsolete. Superseded by ICustomPropertyManager::Get3 .
 Get3	Obsolete. Superseded by ICustomPropertyManager::Get4 .
 Get4	Obsolete. Superseded by ICustomPropertyManager::Get5 .
 Get5	Obsolete. Superseded by ICustomPropertyManager::Get6 .
 Get6	Gets the value and the evaluated value of the specified custom property.
 GetAll	Obsolete. Superseded by ICustomPropertyManager::GetAll2 .
 GetAll2	Obsolete. Superseded by ICustomPropertyManager::GetAll3 .
 GetAll3	Gets all of the custom properties for this configuration.
 GetNames	Gets the names of the custom properties.
 GetType	Obsolete. Superseded by ICustomPropertyManager::GetType2 .
 GetType2	Gets the type of the specified custom property for a configuration or model document.
 IGetAll	Gets all of the custom properties for this configuration.
 IGetNames	Gets the names of the custom properties.
 IsCustomPropertyEditable	Gets whether the specified custom property is editable in the specified configuration.
 LinkProperty	Sets whether to link or unlink the specified custom property to or from its parent part.
 Set	Obsolete. Superseded by ICustomPropertyManager::Set2 .
 Set2	Sets the value for the specified custom property.

[Top](#)

See Also

[ICustomPropertyManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICustomPropertyManager Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomPropertyManager Interface

For a list of all members of this type, see [ICustomPropertyManager members](#).

Public Properties

Name	Description
 Count	Gets the number of custom properties.
 LinkAll	Gets or sets whether to link or unlink all custom properties to or from their parent parts.
 Owner	Gets the owner of this custom property.

[Top](#)

See Also

[ICustomPropertyManager Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Add Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Add Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Add2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Add( _  
    ByVal FieldName As System.String, _  
    ByVal FieldType As System.String, _  
    ByVal FieldValue As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim FieldType As System.String  
Dim FieldValue As System.String  
Dim value As System.Integer  
  
value = instance.Add(FieldName, FieldType, FieldValue)
```

C#

```
System.int Add(  
    System.string FieldName,  
    System.string FieldType,  
    System.string FieldValue  
)
```

C++/CLI

```
System.int Add(  
& System.String^ FieldName,  
& System.String^ FieldType,  
& System.String^ FieldValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

FieldType

FieldValue

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Add](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

Add2 Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Add2 Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Add3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Add2( _  
    ByVal FieldName As System.String, _  
    ByVal FieldType As System.Integer, _  
    ByVal FieldValue As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim FieldType As System.Integer  
Dim FieldValue As System.String  
Dim value As System.Integer  
  
value = instance.Add2(FieldName, FieldType, FieldValue)
```

C#

```
System.int Add2(  
    System.string FieldName,  
    System.int FieldType,  
    System.string FieldValue  
)
```

C++/CLI

```
System.int Add2(  
& System.String^ FieldName,  
& System.int FieldType,  
& System.String^ FieldValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of custom property

FieldType

Type of custom property as defined in [swCustomInfoType_e](#)

FieldValue

Value of custom property

Return Value

- 1 if custom property is added
- 0 if custom property is not added
- -1 if the custom property already exists

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Add2](#).

See Also

[ICustomPropertyManager Interface](#)

[ICustomPropertyManager Members](#)

[ICustomerPropertyManager::Delete Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

Adds a custom property to a configuration or model document.

.NET Syntax

Visual Basic (Declaration)

```
Function Add3( _
    ByVal FieldName As System.String, _
    ByVal FieldType As System.Integer, _
    ByVal FieldValue As System.String, _
    ByVal OverwriteExisting As System.Integer _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager
Dim FieldName As System.String
Dim FieldType As System.Integer
Dim FieldValue As System.String
Dim OverwriteExisting As System.Integer
Dim value As System.Integer

value = instance.Add3(FieldName, FieldType, FieldValue, OverwriteExisting)
```

C#

```
System.int Add3(
    System.string FieldName,
    System.int FieldType,
    System.string FieldValue,
    System.int OverwriteExisting
)
```

C++/CLI

```
System.int Add3(
    & System.String^ FieldName,
    & System.int FieldType,
    & System.String^ FieldValue,
    & System.int OverwriteExisting
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of custom property

FieldType

Type of custom property as defined in [swCustomInfoType_e](#)

FieldValue

Value of custom property

OverwriteExisting

Overwrite option as defined in [swCustomPropertyAddOption_e](#)

Return Value

Result code as defined in [swCustomInfoAddResult_e](#)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Add3](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Configuration \(VB.NET\)](#)
[Get Custom Properties for Configuration \(C#\)](#)

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Delete2 Method \(\)](#)
[ICustomPropertyManager::Set2 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Count Property (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Count Property (ICustomPropertyManager)

Gets the number of custom properties.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property Count As System.Integer

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim value As System.Integer
```

```
value = instance.Count
```

C#

```
System.int Count {get;}
```

C++/CLI

```
property System.int Count {  
    System.int get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

0 or the number of custom properties

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager.Count](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Cut-list Item \(VBA\)](#)

Remarks

Call this method before calling [ICustomPropertyManager::GetNames](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Delete Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Delete Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Delete2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Delete( _  
    ByVal FieldName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim value As System.Integer  
  
value = instance.Delete(FieldName)
```

C#

```
System.int Delete(  
    System.string FieldName  
)
```

C++/CLI

```
System.int Delete(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName
Name of the custom property to delete

Return Value

0 if the custom property is deleted, 1 if not

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Delete](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomerPropertyManager::Add2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Delete2 Method (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Delete2 Method (ICustomPropertyManager)

Deletes the specified custom property.

.NET Syntax

Visual Basic (Declaration)

```
Function Delete2( _  
    ByVal FieldName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim value As System.Integer  
  
value = instance.Delete2(FieldName)
```

C#

```
System.int Delete2(  
    System.string FieldName  
)
```

C++/CLI

```
System.int Delete2(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName
Name of the custom property to delete

Return Value

Result code as defined in [swCustomInfoDeleteResult_e](#)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Delete2](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Configuration \(VB.NET\)](#)
[Get Custom Properties for Configuration \(C#\)](#)

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Add3 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Get Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Get2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get( _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim value As System.String  
  
value = instance.Get(FieldName)
```

C#

```
System.string Get(  
    System.string FieldName  
)
```

C++/CLI

```
System.String^ Get(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Get2 Method (ICustomPropertyManager)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get2 Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Get3](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub Get2( _  
    ByVal FieldName As System.String, _  
    ByRef ValOut As System.String, _  
    ByRef ReesolvedValOut As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim ValOut As System.String  
Dim ReesolvedValOut As System.String  
  
instance.Get2(FieldName, ValOut, ReesolvedValOut)
```

C#

```
void Get2(
    System.string FieldName,
    out System.string ValOut,
    out System.string ReesolvedValOut
)
```

C++/CLI

```
void Get2(
    & System.String^ FieldName,
    & [Out] System.String^ ValOut,
    & [Out] System.String^ ReesolvedValOut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of the custom property

ValOut

Value of the custom property

ReesolvedValOut

Evaluated value of the custom property

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get2](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)

[Get Custom Properties for Cut-list Item \(VBA\)](#)

[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)

[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)

[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

See Also

[ICustomPropertyManager Interface](#)

[ICustomPropertyManager Members](#)

[ICustomPropertyManager::GetAll Method](#)

[ICustomPropertyManager::IGetAll Method](#)

[ICustomPropertyManager::Set Method](#)

Availability

SOLIDWORKS 2004 SP4, Revision Number 12.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

Get3 Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get3 Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Get4](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get3( _
    ByVal FieldName As System.String, _
    ByVal UseCached As System.Boolean, _
    ByRef ValOut As System.String, _
    ByRef ResolvedValOut As System.String _
) As System.Boolean
```

Visual Basic (Usage)

```
Dim instance As ICustomPropertyManager
Dim FieldName As System.String
```



```
Dim UseCached As System.Boolean
Dim ValOut As System.String
Dim ResolvedValOut As System.String
Dim value As System.Boolean

value = instance.Get3(FieldName, UseCached, ValOut, ResolvedValOut)
```

C#

```
System.bool Get3(
    System.string FieldName,
    System.bool UseCached,
    out System.string ValOut,
    out System.string ResolvedValOut
)
```

C++/CLI

```
System.bool Get3(
    & System.String^ FieldName,
    & System.bool UseCached,
    [Out] System.String^ ValOut,
    [Out] System.String^ ResolvedValOut
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of the custom property

UseCached

True if configuration has been activated, false if not (see **Remarks**)

ValOut

Value of the custom property

ResolvedValOut

Evaluated value of the custom property

Return Value

True if up-to-date data is returned, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get3](#).

Remarks

This method can get the cached custom property, even if the configuration is not currently active, without having to change configurations.

If UseCached is set to...	And the configuration has already been activated...	Then...
True	Yes	• Up-to-date data is returned and return value = True
True	No	• Cached data is returned and return value = False
False	Yes	• Up-to-date data is returned and return value = True
False	No	• Up-to-date data is returned and return value = True

This method returns configuration-specific, linked, custom-property, evaluated data more quickly than the now obsolete [ICustomPropertyManager::Get2 method](#), if the configuration was previously activated.

If you always want up-to-date data, then you should set UseCached to false. This may result in a more time-consuming call if the configuration was not previously activated.

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

Availability

SOLIDWORKS 2008 SP4, Revision Number 16.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

Get4 Method (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get4 Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Get5](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get4( _  
    ByVal FieldName As System.String, _  
    ByVal UseCached As System.Boolean, _  
    ByRef ValOut As System.String, _  
    ByRef ResolvedValOut As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim UseCached As System.Boolean  
Dim ValOut As System.String  
Dim ResolvedValOut As System.String  
Dim value As System.Boolean  
  
value = instance.Get4(FieldName, UseCached, ValOut, ResolvedValOut)
```

C#

```
System.bool Get4(  
    System.string FieldName,  
    System.bool UseCached,  
    out System.string ValOut,  
    out System.string ResolvedValOut  
)
```

C++/CLI

```
System.bool Get4(  
& System.String^ FieldName,  
& System.bool UseCached,  
& [Out] System.String^ ValOut,  
& [Out] System.String^ ResolvedValOut  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of the custom property

UseCached

True if the configuration has been activated, false if not (see **Remarks**)

ValOut

Value of the custom property

ResolvedValOut

Evaluated value of the custom property

Return Value

True if up-to-date data is returned, false if not (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get4](#).

Example

[Get Custom Properties of Referenced Part \(C#\)](#)
[Get Custom Properties of Referenced Part \(VB.NET\)](#)
[Get Custom Properties of Referenced Part \(VBA\)](#)

Remarks

This method can get the cached custom property, even if the configuration is not currently active, without having to change configurations.

If UseCached is set to...	And the configuration has already been activated...	Then...
True	Yes	. Up-to-date data is returned and return value = true
True	No	. Cached data is returned and return value = false
False	Yes	. Up-to-date data is returned and return value = true
False	No	. Up-to-date data is returned and return value = true

This method returns configuration-specific, linked, custom-property, evaluated data more quickly than the now obsolete [ICustomPropertyManager::Get2](#), if the configuration was previously activated.

If you always want up-to-date data, then you should set UseCached to false. This might result in a more time-consuming call if the configuration was not previously activated.

This method does not preface the resolved evaluated values of external referenced documents with **fromparent+**, unlike the now obsolete [ICustomPropertyManager::Get3](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

Availability

SOLIDWORKS 2011 SP4, Revision Number 19.4

SOLIDWORKS API Help

[Send comments on this topic.](#)

Get5 Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get5 Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Get6](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Get5( _  
    ByVal FieldName As System.String, _  
    ByVal UseCached As System.Boolean, _  
    ByRef ValOut As System.String, _  
    ByRef ResolvedValOut As System.String, _  
    ByRef WasResolved As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)

```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim UseCached As System.Boolean  
Dim ValOut As System.String  
Dim ResolvedValOut As System.String  
Dim WasResolved As System.Boolean  
Dim value As System.Integer
```



```
value = instance.Get5(Fieldname, UseCached, ValOut, ResolvedValOut, WasResolved)
```

C#

```
System.int Get5(  
    System.string Fieldname,  
    System.bool UseCached,  
    out System.string ValOut,  
    out System.string ResolvedValOut,  
    out System.bool WasResolved  
)
```

C++/CLI

```
System.int Get5(  
& System.String^ Fieldname,  
& System.bool UseCached,  
& [Out] System.String^ ValOut,  
& [Out] System.String^ ResolvedValOut,  
& [Out] System.bool WasResolved  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fieldname
Name of the custom property
UseCached
True if the configuration has been activated, false if not (see **Remarks**)
ValOut
Value of the custom property
ResolvedValOut
Evaluated value of the custom property
WasResolved
True if the value was evaluated, false if not (see **Remarks**)

Return Value

Result code as defined in [swCustomInfoGetResult_e](#)

 Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get5](#).

 Remarks

This method returns configuration-specific, linked, and evaluated custom-property data more quickly than the now obsolete ICustomPropertyManager::Get2, if the configuration is previously activated.

This method gets the cached custom property, even if its configuration is not currently active.

If UseCached is set to...	And the configuration has already been activated...	Then...
True	Yes	Up-to-date data is returned and WasResolved = true
True	No	Cached data is returned and WasResolved = false
False	Yes	Up-to-date data is returned and WasResolved = true
False	No	Up-to-date data is returned and WasResolved = true

If you always want up-to-date data, then you should set UseCached to false.

If the configuration is not previously activated, this method might take longer, as it loops through all of the model's configurations to find the specified custom property. When it finishes, the model might not be in its original configuration. To return the model to its original configuration, call [IModelDoc2::ForceRebuild3](#) after calling this method.

This method does not preface the resolved evaluated values of external referenced documents with fromparent+, unlike the now obsolete ICustomPropertyManager::Get3.

 See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::GetAll2 Method \(\)](#)
[ICustomPropertyManager::GetNames Method \(\)](#)
[ICustomPropertyManager::GetType2 Method \(\)](#)
[ICustomPropertyManager::IGetNames Method \(\)](#)
[ICustomPropertyManager::Set2 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Get6 Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Get6 Method (ICustomPropertyManager)

Gets the value and the evaluated value of the specified custom property.

.NET Syntax

Visual Basic (Declaration)

```
Function Get6( _  
    ByVal FieldName As System.String, _  
    ByVal UseCached As System.Boolean, _  
    ByRef ValOut As System.String, _  
    ByRef ResolvedValOut As System.String, _  
    ByRef WasResolved As System.Boolean, _  
    ByRef LinkToProperty As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim UseCached As System.Boolean  
Dim ValOut As System.String  
Dim ResolvedValOut As System.String  
Dim WasResolved As System.Boolean  
Dim LinkToProperty As System.Boolean  
Dim value As System.Integer
```

```
value = instance.Get6(FieldName, UseCached, ValOut, ResolvedValOut, WasResolved, LinkToProperty)
```

C#

```
System.int Get6(  
    System.string FieldName,  
    System.bool UseCached,  
    out System.string ValOut,  
    out System.string ResolvedValOut,  
    out System.bool WasResolved,  
    out System.bool LinkToProperty  
)
```

C++/CLI

```
System.int Get6(  
& System.String^ FieldName,  
& System.bool UseCached,  
& [Out] System.String^ ValOut,  
& [Out] System.String^ ResolvedValOut,  
& [Out] System.bool WasResolved,  
& [Out] System.bool LinkToProperty  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName
Name of the custom property
UseCached
True if the configuration has been activated, false if not (see **Remarks**)
ValOut
Value of the custom property
ResolvedValOut
Evaluated value of the custom property
WasResolved
True if the value was evaluated, false if not (see **Remarks**)
LinkToProperty
True to link FieldName to its parent part, false to not

Return Value

Result code as defined in [swCustomInfoGetResult_e](#)

 Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Get6](#).

 Example

See the **Get Custom Properties for Configuration** examples in [ICustomPropertyManager](#).

 Remarks

This method returns configuration-specific, linked, and evaluated custom-property data more quickly than the now obsolete ICustomPropertyManager::Get2, if the configuration is previously activated.

This method gets the cached custom property, even if its configuration is not currently active.

If UseCached is set to...	And the configuration has already been activated...	Then...
True	Yes	Up-to-date data is returned and WasResolved = true
True	No	Cached data is returned and WasResolved = false
False	Yes	Up-to-date data is returned and WasResolved = true
False	No	Up-to-date data is returned and WasResolved = true

If you always want up-to-date data, then you should set UseCached to false.

If the configuration is not previously activated, this method might take longer, as it loops through all of the model's configurations to find the specified custom property. When it finishes, the model might not be in its original configuration. To return the model to its original configuration, call [IModelDoc2::ForceRebuild3](#) after calling this method.

This method does not preface the resolved evaluated values of external referenced documents with fromparent+, unlike the now obsolete ICustomPropertyManager::Get3.

 See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::GetAll3 Method \(\)](#)
[ICustomPropertyManager::GetNames Method \(\)](#)
[ICustomPropertyManager::GetType2 Method \(\)](#)
[ICustomPropertyManager::Set2 Method \(\)](#)

 Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

GetAll Method (ICustomPropertyManager)

[See Also](#)



Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetAll( _  
    ByRef PropNames As System.Object, _  
    ByRef PropTypes As System.Object, _  
    ByRef PropValues As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim PropNames As System.Object  
Dim PropTypes As System.Object  
Dim PropValues As System.Object  
Dim value As System.Integer  
  
value = instance.GetAll(PropNames, PropTypes, PropValues)
```

C#

```
System.int GetAll(  
    out System.object PropNames,  
    out System.object PropTypes,  
    out System.object PropValues  
)
```

C++/CLI

```
System.int GetAll(  
& [Out] System.Object^ PropNames,  
& [Out] System.Object^ PropTypes,  
& [Out] System.Object^ PropValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropNames

Array of the names of custom properties

PropTypes

Array of property types as defined in [swCustomInfoType_e](#)

PropValues

Array of values of custom properties

Return Value

Number of custom properties

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetAll](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Get2 Method](#)
[ICustomPropertyManager::IGetAll Method](#)
[ICustomPropertyManager::Set Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0



Obsolete. Superseded by [ICustomPropertyManager::GetAll3](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetAll2( _  
    ByRef PropNames As System.Object, _  
    ByRef PropTypes As System.Object, _  
    ByRef PropValues As System.Object, _  
    ByRef Resolved As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim PropNames As System.Object  
Dim PropTypes As System.Object  
Dim PropValues As System.Object  
Dim Resolved As System.Object  
Dim value As System.Integer  
  
value = instance.GetAll2(PropNames, PropTypes, PropValues, Resolved)
```

C#

```
System.int GetAll2(  
    out System.object PropNames,  
    out System.object PropTypes,  
    out System.object PropValues,  
    out System.object Resolved  
)
```

C++/CLI

```
System.int GetAll2(  
& [Out] System.Object^ PropNames,  
& [Out] System.Object^ PropTypes,  
& [Out] System.Object^ PropValues,  
& [Out] System.Object^ Resolved  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropNames

Array of the names of custom properties retrieved

PropTypes

Array of types of PropNames as defined in [swCustomInfoType_e](#)

PropValues

Array of evaluated values of PropNames

Resolved

Array of evaluation statuses of PropNames as defined in [swCustomInfoGetResult_e](#)

Return Value

Number of custom properties retrieved

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetAll2](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Get5 Method \(\)](#)
[ICustomPropertyManager::Get2 Method \(\)](#)
[ICustomPropertyManager::GetNames Method \(\)](#)
[ICustomPropertyManager::ICutNames Method \(\)](#)
[ICustomPropertyManager::GetType2 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetAll3 Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : GetAll3 Method (ICustomPropertyManager)

Gets all of the custom properties for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAll3( _  
    ByRef PropNames As System.Object, _  
    ByRef PropTypes As System.Object, _  
    ByRef PropValues As System.Object, _  
    ByRef Resolved As System.Object, _  
    ByRef PropLink As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim PropNames As System.Object  
Dim PropTypes As System.Object  
Dim PropValues As System.Object  
Dim Resolved As System.Object  
Dim PropLink As System.Object  
Dim value As System.Integer  
  
value = instance.GetAll3(PropNames, PropTypes, PropValues, Resolved, PropLink)
```

C#

```
System.int GetAll3(  
    out System.object PropNames,  
    out System.object PropTypes,  
    out System.object PropValues,  
    out System.object Resolved,  
    out System.object PropLink  
)
```

C++/CLI

```
System.int GetAll3(  
& [Out] System.Object^ PropNames,  
& [Out] System.Object^ PropTypes,  
& [Out] System.Object^ PropValues,  
& [Out] System.Object^ Resolved,  
& [Out] System.Object^ PropLink  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropNames

Array of the names of custom properties retrieved

PropTypes

Array of types of PropNames as defined in [swCustomInfoType_e](#)

PropValues

Array of evaluated values of PropNames

Resolved

Array of evaluation statuses of PropNames as defined in [swCustomInfoGetResult_e](#)

PropLink

Array of integers indicating whether PropNames are linked to their parent parts:

1 = link

0 = no link

Return Value

Number of custom properties returned

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetAll3](#).

Example

See the **Get Custom Properties for Configuration** examples in [ICustomPropertyManager](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Get6 Method \(\)](#)
[ICustomPropertyManager::Set2 Method \(\)](#)
[ICustomPropertyManager::GetNames Method \(\)](#)
[ICustomPropertyManager::GetType2 Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetNames Method (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : GetNames Method (ICustomPropertyManager)

Gets the names of the custom properties.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNames() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim value As System.Object  
  
value = instance.GetNames()
```

C#

```
System.object GetNames()
```

C++/CLI

```
System.Object^ GetNames();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Names of the custom properties

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetNames](#).

Example

[Add and Get Custom Properties \(VBA\)](#)
[Get Custom Properties for Cut-list Item \(VBA\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(C#\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VB.NET\)](#)
[Get Solid Bodies from Cut-list Folders and Get Custom Properties \(VBA\)](#)

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::GetNames Method](#)
[ICustomPropertyManager::Get5 Method \(\)](#)
[ICustomPropertyManager::GetAll2 Method \(\)](#)
[ICustomPropertyManager::IsCustomPropertyEditable Method \(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : GetType Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::GetType2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetType( _  
    ByVal FieldName As System.String _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim value As System.String  
  
value = instance.GetType(FieldName)
```

C#

```
System.string GetType(  
    System.string FieldName  
)
```

C++/CLI

```
System.String^ GetType(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetType](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetType2 Method (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : GetType2 Method (ICustomPropertyManager)

Gets the type of the specified custom property for a configuration or model document.

■ .NET Syntax

Visual Basic (Declaration)

```
Function GetType2( _  
    ByVal FieldName As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim value As System.Integer  
  
value = instance.GetType2(FieldName)
```

C#

```
System.int GetType2(  
    System.string FieldName  
)
```

C++/CLI

```
System.int GetType2(  
& System.String^ FieldName  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName

Name of the custom property whose type to get

Return Value

Type of custom property as defined in [swCustomInfoType_e](#)

■ Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::GetType2](#).

■ Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Configuration \(VB.NET\)](#)
[Get Custom Properties for Configuration \(C#\)](#)

■ Remarks

This method is not currently implemented for features.

■ See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::GetNames Method \(\)](#)
[ICustomPropertyManager::Get5 Method \(\)](#)

■ Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAll Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : IGetAll Method (ICustomPropertyManager)

Gets all of the custom properties for this configuration.

.NET Syntax

Visual Basic (Declaration)

```
Sub IGetAll( _  
    ByVal Count As System.Integer, _  
    ByRef PropNames As System.String, _  
    ByRef PropTypes As System.Integer, _  
    ByRef PropValues As System.String _  
)
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim Count As System.Integer  
Dim PropNames As System.String  
Dim PropTypes As System.Integer  
Dim PropValues As System.String  
  
instance.IGetAll(Count, PropNames, PropTypes, PropValues)
```

C#

```
void IGetAll(  
    System.int Count,  
    out System.string PropNames,  
    out System.int PropTypes,  
    out System.string PropValues  
)
```

C++/CLI

```
void IGetAll(  
& System.int Count,  
& [Out] System.String^ PropNames,  
& [Out] System.int PropTypes,  
& [Out] System.String^ PropValues  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of custom properties

PropNames

Array of the names of custom properties

PropTypes

Array of property types as defined in [swCustomInfoType_e](#)

PropValues

Array of values of custom properties

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::IGetAll](#).

See Also

[ICustomPropertyManager Interface](#)

[ICustomPropertyManager Members](#)

[ICustomPropertyManager::Get2 Method](#)

[ICustomPropertyManager::GetAll Method](#)

Availability

SOLIDWORKS 2007 FCS, Revision Number 15.0



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : IGetNames Method (ICustomPropertyManager)

Gets the names of the custom properties.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNames( _  
    ByVal Count As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim Count As System.Integer  
Dim value As System.String  
  
value = instance.IGetNames(Count)
```

C#

```
System.string IGetNames(  
    System.int Count  
)
```

C++/CLI

```
System.String^ IGetNames(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of custom properties

Return Value

- in-process, unmanaged C++: Pointer to an array of strings of the names of the custom properties
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ICustomPropertyManager::Count](#) before calling this method.

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::GetNames Method \(\)](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IsCustomPropertyEditable Method (ICustomPropertyManager)

See Also [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : IsCustomPropertyEditable Method (ICustomPropertyManager)

Gets whether the specified custom property is editable in the specified configuration.

.NET Syntax

Visual Basic (Declaration)

```
Function IsCustomPropertyEditable( _
    ByVal PropertyName As System.String, _
    ByVal ConfigurationName As System.String _
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager
Dim PropertyName As System.String
Dim ConfigurationName As System.String
Dim value As System.Boolean

value = instance.IsCustomPropertyEditable(PropertyName, ConfigurationName)
```

C#

```
System.bool IsCustomPropertyEditable(
    System.string PropertyName,
    System.string ConfigurationName
)
```

C++/CLI

```
System.bool IsCustomPropertyEditable(
    & System.String^ PropertyName,
    & System.String^ ConfigurationName
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PropertyName
Custom property name
ConfigurationName
Configuration name

Return Value

True if the custom property is editable, false if not

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::IsCustomPropertyEditable](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Configuration \(VB.NET\)](#)
[Get Custom Properties for Configuration \(C#\)](#)

Remarks

Use [ICustomPropertyManager::GetNames](#) to populate PropertyName.

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

LinkAll Property (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : LinkAll Property (ICustomPropertyManager)

Gets or sets whether to link or unlink all custom properties to or from their parent parts.

.NET Syntax

Visual Basic (Declaration)

```
Property LinkAll As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim value As System.Boolean  
  
instance.LinkAll = value  
value = instance.LinkAll
```

C#

```
System.bool LinkAll {get; set;}
```

C++/CLI

```
property System.bool LinkAll {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to link all custom properties, false to unlink all

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::LinkAll](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::LinkProperty Method \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

LinkProperty Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : LinkProperty Method (ICustomPropertyManager)

Sets whether to link or unlink the specified custom property to or from its parent part.

.NET Syntax

Visual Basic (Declaration)

```
Function LinkProperty( _  
    ByVal FieldName As System.String, _  
    ByVal FieldLink As System.Boolean _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim FieldLink As System.Boolean  
Dim value As System.Integer
```

```
value = instance.LinkProperty(Fieldname, FieldLink)
```

C#

```
System.int LinkProperty(  
    System.string Fieldname,  
    System.bool FieldLink  
)
```

C++/CLI

```
System.int LinkProperty(  
& System.String^ Fieldname,  
& System.bool FieldLink  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Fieldname

Name of the custom property to link or unlink

FieldLink

True to link the custom property, false to unlink it

Return Value

Result code as defined in [swCustomLinkSetResult_e](#)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::LinkProperty](#).

Remarks

This method is valid for cut-list, feature, model, and configuration custom properties.

See Also

[ICustomPropertyManager Interface](#)

[ICustomPropertyManager Members](#)

[ICustomPropertyManager::LinkAll Property \(\)](#)

Availability

SOLIDWORKS 2018 FCS, Revision Number 26.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Owner Property (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Owner Property (ICustomPropertyManager)

Gets the owner of this custom property.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property Owner As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICustomPropertyManager
```

```
Dim value As System.Object
```

```
value = instance.Owner
```

C#



```
System.Object Owner {get;}
```

C++/CLI

```
property System.Object^ Owner {  
    System.Object^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Pointer to owner of the custom property; currently either a [body](#) or a [feature](#)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Owner](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Set Method (ICustomPropertyManager)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Set Method (ICustomPropertyManager)

Obsolete. Superseded by [ICustomPropertyManager::Set2](#).

.NET Syntax

Visual Basic (Declaration)

```
Function Set( _  
    ByVal FieldName As System.String, _  
    ByVal FieldValue As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim FieldValue As System.String  
Dim value As System.Integer  
  
value = instance.Set(FieldName, FieldValue)
```

C#

```
System.int Set(  
    System.string FieldName,  
    System.string FieldValue  
)
```

C++/CLI

```
System.int Set(  
    & System.String^ FieldName,  
    & System.String^ FieldValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName
Name of the existing custom property
FieldValue
Value for the existing custom property

Return Value

- 0 if the value for the existing custom property is set
- 1 if the value for the existing custom property is not set
- -1 if the custom property does not exist

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Set](#).

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Get2 Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

Set2 Method (ICustomPropertyManager)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomPropertyManager Interface](#) : Set2 Method (ICustomPropertyManager)

Sets the value for the specified custom property.

.NET Syntax

Visual Basic (Declaration)

```
Function Set2( _  
    ByVal FieldName As System.String, _  
    ByVal FieldValue As System.String _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomPropertyManager  
Dim FieldName As System.String  
Dim FieldValue As System.String  
Dim value As System.Integer  
  
value = instance.Set2(FieldName, FieldValue)
```

C#

```
System.int Set2(  
    System.string FieldName,  
    System.string FieldValue  
)
```

C++/CLI

```
System.int Set2(  
& System.String^ FieldName,  
& System.String^ FieldValue  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FieldName
Name of the existing custom property
FieldValue
Value for the existing custom property

Return Value

Result code as defined in [swCustomInfoSetResult_e](#)

Visual Basic for Applications (VBA) Syntax

See [CustomPropertyManager::Set2](#).

Example

[Get Custom Properties for Configuration \(VBA\)](#)
[Get Custom Properties for Configuration \(VB.NET\)](#)
[Get Custom Properties for Configuration \(C#\)](#)

See Also

[ICustomPropertyManager Interface](#)
[ICustomPropertyManager Members](#)
[ICustomPropertyManager::Get5 Method \(\)](#)
[ICustomPropertyManager::GetAll2 Method \(\)](#)
[ICustomPropertyManager::Add3 Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0