

SOLIDWORKS API (.NET VBA C#) — Reference (65/337): ICustomSymbol-ICutListSortOptions

SOLIDWORKS API Documentation (converted from CHM)

ICustomSymbol (Type)

ICustomSymbol Interface

[See Also](#) [Members](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomSymbol Interface

Obsolete. Superseded by [ISketchBlockDefinition](#) and [ISketchBlockInstance](#).

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICustomSymbol
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
```

C#

```
public interface ICustomSymbol
```

C++/CLI

```
public interface class ICustomSymbol
```

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol](#).

See Also

[ICustomSymbol Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICustomSymbol Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomSymbol Interface

For a list of all members of this type, see [ICustomSymbol members](#).

Public Methods

Name	Description
GetAnnotation	Obsolete. Not superseded.
GetArcAtIndex	Obsolete. Superseded by INote::GetArcAtIndex .
GetArcCount	Obsolete. Superseded by INote::GetArcCount .
GetArrowHeadAtIndex	Obsolete. Superseded by INote::GetArrowHeadAtIndex .
GetArrowHeadCount	Obsolete. Superseded by INote::GetArrowHeadCount .
GetArrowHeadInfo	Obsolete. Superseded by INote::GetArrowHeadInfo .
GetLeaderAtIndex	Obsolete. Superseded by INote::GetLeaderAtIndex .
GetLeaderCount	Obsolete. Superseded by INote::GetLeaderCount .
GetLineAtIndex	Obsolete. Superseded by INote::GetLineAtIndex .
GetLineCount	Obsolete. Superseded by INote::GetLineCount .
GetNext	Obsolete. Not superseded.
GetNoteCount	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount .

		
	GetNotes	Obsolete. Superseded by ISketchBlockDefinition::GetNotes .
	GetSketch	Obsolete. Superseded by ISketchBlockDefinition::GetSketch .
	GetSketchPosition	Obsolete. Not superseded.
	GetText	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount and ISketchBlockDefinition::GetNotes .
	GetTextAngleAtIndex	Obsolete. Superseded by INote::GetTextAngleAtIndex .
	GetTextAtIndex	Obsolete. Superseded by INote::GetTextAtIndex .
	GetTextCount	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount .
	GetTextHeightAtIndex	Obsolete. Superseded by INote::GetTextHeightAtIndex .
	GetTextInvertAtIndex	Obsolete. Superseded by INote::GetTextInvertAtIndex .
	GetTextJustificationAtIndex	Obsolete. Superseded by INote::GetTextJustificationAtIndex .
	GetTextLineSpacingAtIndex	Obsolete. Superseded by INote::GetTextLineSpacingAtIndex .
	GetTextPositionAtIndex	Obsolete. Superseded by INote::GetTextPositionAtIndex .
	GetTextRefPositionAtIndex	Obsolete. Superseded by INote::GetTextRefPositionAtIndex .
	GetTriangleAtIndex	Obsolete. Superseded by INote::GetTriangleAtIndex .
	GetTriangleCount	Obsolete. Superseded by INote::GetTriangleCount .
	HasExtraLeader	Obsolete. Superseded by INote::HasExtraLeader .
	IGetAnnotation	Obsolete. Not superseded.
	IGetArcAtIndex	Obsolete. Superseded by INote::IGetArcAtIndex .
	IGetArrowHeadAtIndex	Obsolete. Superseded by INote::IGetArrowHeadAtIndex .
	IGetArrowHeadInfo	Obsolete. Superseded by INote::IGetArrowHeadInfo .
	IGetLeaderAtIndex	Obsolete. Superseded by INote::IGetLeaderAtIndex .
	IGetLineAtIndex	Obsolete. Superseded by INote::IGetLineAtIndex .
	IGetNext	Obsolete. Not superseded.
	IGetNotes	Obsolete. Superseded by ISketchBlockDefinition::IGetNotes .
	IGetSketch	Obsolete. Superseded by ISketchBlockDefinition::GetSketch .
	IGetSketchPosition	Obsolete. Not superseded.
	IGetTextPositionAtIndex	Obsolete. Superseded by INote::IGetTextPositionAtIndex .
	IGetTriangleAtIndex	Obsolete. Superseded by INote::IGetTriangleAtIndex .
	IsAttached	Obsolete. Superseded by INote::IsAttached .
	SetText	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount and ISketchBlockDefinition::GetNotes .
	SetTextJustificationAtIndex	Obsolete. Superseded by INote::SetTextJustificationAtIndex .

[Top](#)

See Also

[ICustomSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICustomSymbol Interface Members

[See Also](#) [Properties](#) [Methods](#)

[SolidWorks.Interop.sldworks Namespace](#) : ICustomSymbol Interface

The following tables list the members exposed by [ICustomSymbol](#).

Public Properties

Name	Description
 Angle	Obsolete. Superseded by ISketchBlockInstance.Angle .
 Scale2	Obsolete. Superseded by ISketchBlockInstance.Scale .
 TextVisible	Obsolete. Superseded by ISketchBlockInstance.TextDisplay .

[Top](#)

Public Methods

Name	Description
 GetAnnotation	Obsolete. Not superseded.
 GetArcAtIndex	Obsolete. Superseded by INote.GetArcAtIndex .
 GetArcCount	Obsolete. Superseded by INote.GetArcCount .
 GetArrowHeadAtIndex	Obsolete. Superseded by INote.GetArrowHeadAtIndex .
 GetArrowHeadCount	Obsolete. Superseded by INote.GetArrowHeadCount .
 GetArrowHeadInfo	Obsolete. Superseded by INote.GetArrowHeadInfo .
 GetLeaderAtIndex	Obsolete. Superseded by INote.GetLeaderAtIndex .
 GetLeaderCount	Obsolete. Superseded by INote.GetLeaderCount .
 GetLineAtIndex	Obsolete. Superseded by INote.GetLineAtIndex .
 GetLineCount	Obsolete. Superseded by INote.GetLineCount .
 GetNext	Obsolete. Not superseded.
 GetNoteCount	Obsolete. Superseded by ISketchBlockDefinition.GetNoteCount .
 GetNotes	Obsolete. Superseded by ISketchBlockDefinition.GetNotes .
 GetSketch	Obsolete. Superseded by ISketchBlockDefinition.GetSketch .
 GetSketchPosition	Obsolete. Not superseded.
 GetText	Obsolete. Superseded by ISketchBlockDefinition.GetNoteCount and ISketchBlockDefinition.GetNotes .
 GetTextAngleAtIndex	Obsolete. Superseded by INote.GetTextAngleAtIndex .
 GetTextAtIndex	Obsolete. Superseded by INote.GetTextAtIndex .
 GetTextCount	Obsolete. Superseded by ISketchBlockDefinition.GetNoteCount .
 GetTextHeightAtIndex	Obsolete. Superseded by INote.GetTextHeightAtIndex .
 GetTextInvertAtIndex	Obsolete. Superseded by INote.GetTextInvertAtIndex .
 GetTextJustificationAtIndex	Obsolete. Superseded by INote.GetTextJustificationAtIndex .
 GetTextLineSpacingAtIndex	Obsolete. Superseded by INote.GetTextLineSpacingAtIndex .
 GetTextPositionAtIndex	Obsolete. Superseded by INote.GetTextPositionAtIndex .
 GetTextRefPositionAtIndex	Obsolete. Superseded by INote.GetTextRefPositionAtIndex .
 GetTriangleAtIndex	Obsolete. Superseded by INote.GetTriangleAtIndex .
 GetTriangleCount	Obsolete. Superseded by INote.GetTriangleCount .
 HasExtraLeader	Obsolete. Superseded by INote.HasExtraLeader .
 IGetAnnotation	Obsolete. Not superseded.
 IGetArcAtIndex	Obsolete. Superseded by INote.IGetArcAtIndex .
 IGetArrowHeadAtIndex	Obsolete. Superseded by INote.IGetArrowHeadAtIndex .
 IGetArrowHeadInfo	Obsolete. Superseded by INote.IGetArrowHeadInfo .
 IGetLeaderAtIndex	Obsolete. Superseded by INote.IGetLeaderAtIndex .
 IGetLineAtIndex	Obsolete. Superseded by INote.IGetLineAtIndex .
 IGetNext	Obsolete. Not superseded.

 IGetNotes	Obsolete. Superseded by ISketchBlockDefinition::IGetNotes .
 IGetSketch	Obsolete. Superseded by ISketchBlockDefinition::GetSketch .
 IGetSketchPosition	Obsolete. Not superseded.
 IGetTextPositionAtIndex	Obsolete. Superseded by INote::IGetTextPositionAtIndex .
 IGetTriangleAtIndex	Obsolete. Superseded by INote::IGetTriangleAtIndex .
 IsAttached	Obsolete. Superseded by INote::IsAttached .
 SetText	Obsolete. Superseded by ISketchBlockDefinition::GetNoteCount and ISketchBlockDefinition::GetNotes .
 SetTextJustificationAtIndex	Obsolete. Superseded by INote::SetTextJustificationAtIndex .

[Top](#)

 See Also

[ICustomSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments](#) on this topic.

ICustomSymbol Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICustomSymbol Interface

For a list of all members of this type, see [ICustomSymbol members](#).

 Public Properties

Name	Description
 Angle	Obsolete. Superseded by ISketchBlockInstance::Angle .
 Scale2	Obsolete. Superseded by ISketchBlockInstance::Scale .
 TextVisible	Obsolete. Superseded by ISketchBlockInstance::TextDisplay .

[Top](#)

 See Also

[ICustomSymbol Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help [Send comments](#) on this topic.

Angle Property (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : Angle Property (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockInstance::Angle](#).

 .NET Syntax

Visual Basic (Declaration)

Property Angle As System.Double

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Double
```

```
instance.Angle = value  
value = instance.Angle
```

C#

```
System.double Angle {get; set;}
```

C++/CLI

```
property System.double Angle {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::Angle](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetAnnotation Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetAnnotation Method (ICustomSymbol)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetAnnotation() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetAnnotation()
```

C#

```
System.object GetAnnotation()
```

C++/CLI

```
System.Object^ GetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetAnnotation](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetArcAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetArcAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArcAtIndex(Index)
```

C#

```
System.object GetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArcAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetArcAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArcCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetArcCount Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetArcCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArcCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Integer  
  
value = instance.GetArcCount()
```

C#

```
System.int GetArcCount()
```

C++/CLI

```
System.int GetArcCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetArcCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetArrowHeadAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetArrowHeadAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetArrowHeadAtIndex(Index)
```

C#

```
System.object GetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetArrowHeadAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetArrowHeadAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetArrowHeadCount Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetArrowHeadCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Integer  
  
value = instance.GetArrowHeadCount()
```

C#

```
System.int GetArrowHeadCount()
```

C++/CLI

```
System.int GetArrowHeadCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetArrowHeadCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetArrowHeadInfo Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetArrowHeadInfo Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetArrowHeadInfo](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetArrowHeadInfo() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetArrowHeadInfo()
```

C#

```
System.object GetArrowHeadInfo()
```

C++/CLI

```
System.Object^ GetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetArrowHeadInfo](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLeaderAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetLeaderAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetLeaderAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetLeaderAtIndex(Index)
```

C#

```
System.object GetLeaderAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetLeaderAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetLeaderAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLeaderCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetLeaderCount Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetLeaderCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLeaderCount() As System.Integer
```

```
Dim instance As ICustomSymbol
Dim value As System.Integer

value = instance.GetLeaderCount()
```

C#

```
System.int GetLeaderCount()
```

C++/CLI

```
System.int GetLeaderCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetLeaderCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLineAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetLineAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetLineAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineAtIndex(
    ByVal Index As System.Integer _
) As System.Object
```

Visual Basic (Usage)

```
Dim instance As ICustomSymbol
Dim Index As System.Integer
Dim value As System.Object

value = instance.GetLineAtIndex(Index)
```

C#

```
System.object GetLineAtIndex(
    System.int Index
)
```

C++/CLI

```
System.Object^ GetLineAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetLineAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetLineCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetLineCount Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetLineCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Integer  
  
value = instance.GetLineCount()
```

C#

```
System.int GetLineCount()
```

C++/CLI

```
System.int GetLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetLineCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNext Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetNext Method (ICustomSymbol)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetNext() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetNext()
```

C#

```
System.Object GetNext()
```

C++/CLI

```
System.Object^ GetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetNext](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNoteCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetNoteCount Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetNoteCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNoteCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Integer  
  
value = instance.GetNoteCount()
```

C#

```
System.int GetNoteCount()
```

C++/CLI

```
System.int GetNoteCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetNoteCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetNotes Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetNotes Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetNotes() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetNotes()
```

C#

```
System.object GetNotes()
```

C++/CLI

```
System.Object^ GetNotes();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetNotes](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetSketch Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetSketch Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetSketch](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketch() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetSketch()
```

C#

```
System.object GetSketch()
```

C++/CLI

```
System.Object^ GetSketch();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetSketch](#).

See Also

GetSketchPosition Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetSketchPosition Method (ICustomSymbol)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSketchPosition() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Object  
  
value = instance.GetSketchPosition()
```

C#

```
System.object GetSketchPosition()
```

C++/CLI

```
System.Object^ GetSketchPosition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetSketchPosition](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

GetText Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetText Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetNoteCount](#) and [ISketchBlockDefinition::GetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetText( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetText(Index)
```

C#

```
System.string GetText(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetText(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetText](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAngleAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextAngleAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextAngleAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAngleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextAngleAtIndex(Index)
```

C#

```
System.double GetTextAngleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextAngleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextAngleAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextAtIndex( _  
    ByVal Index As System.Integer _  
) As System.String
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.String  
  
value = instance.GetTextAtIndex(Index)
```

C#

```
System.string GetTextAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.String^ GetTextAtIndex(  
    & System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextCount Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetNoteCount](#).

.NET Syntax

Visual Basic (Declaration)

Function GetTextCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim value As System.Integer

value = instance.GetTextCount()
```

C#

```
System.int GetTextCount()
```

C++/CLI

```
System.int GetTextCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextHeightAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextHeightAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextHeightAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextHeightAtIndex( _
    ByVal Index As System.Integer _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim Index As System.Integer
Dim value As System.Double

value = instance.GetTextHeightAtIndex(Index)
```

C#

```
System.double GetTextHeightAtIndex(
    System.int Index
)
```

C++/CLI

```
System.double GetTextHeightAtIndex(
    & System.int Index
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextHeightAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextInvertAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextInvertAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextInvertAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextInvertAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextInvertAtIndex(Index)
```

C#

```
System.int GetTextInvertAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextInvertAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextInvertAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextJustificationAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextJustificationAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextJustificationAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextJustificationAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextJustificationAtIndex(Index)
```

C#

```
System.int GetTextJustificationAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextJustificationAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextJustificationAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextLineSpacingAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextLineSpacingAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextLineSpacingAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextLineSpacingAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.GetTextLineSpacingAtIndex(Index)
```

C#

```
System.double GetTextLineSpacingAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double GetTextLineSpacingAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextLineSpacingAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextPositionAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextPositionAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextPositionAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Object
```

```
value = instance.GetTextPositionAtIndex(Index)
```

C#

```
System.object GetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextPositionAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTextRefPositionAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTextRefPositionAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTextRefPositionAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTextRefPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Integer  
  
value = instance.GetTextRefPositionAtIndex(Index)
```

C#

```
System.int GetTextRefPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.int GetTextRefPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTextRefPositionAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetTriangleAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTriangleAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTriangleAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetTriangleAtIndex(Index)
```

C#

```
System.object GetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTriangleAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetTriangleCount Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : GetTriangleCount Method (ICustomSymbol)

Obsolete. Superseded by [INote::GetTriangleCount](#).

.NET Syntax

Visual Basic (Declaration)

```
Function GetTriangleCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Integer  
  
value = instance.GetTriangleCount()
```

C#

```
System.int GetTriangleCount()
```

C++/CLI

```
System.int GetTriangleCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::GetTriangleCount](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

HasExtraLeader Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : HasExtraLeader Method (ICustomSymbol)

Obsolete. Superseded by [INote::HasExtraLeader](#).

.NET Syntax

Visual Basic (Declaration)

```
Function HasExtraLeader() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim value As System.Boolean

value = instance.HasExtraLeader()
```

C#

```
System.bool HasExtraLeader()
```

C++/CLI

```
System.bool HasExtraLeader();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::HasExtraLeader](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetAnnotation Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetAnnotation Method (ICustomSymbol)

Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetAnnotation() As Annotation
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim value As Annotation
```

```
value = instance.IGetAnnotation()
```

C#

```
Annotation IGetAnnotation()
```

C++/CLI

```
Annotation^ IGetAnnotation();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetAnnotation](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetArcAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetArcAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetArcAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArcAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArcAtIndex(Index)
```

C#

```
System.double IGetArcAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArcAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetArcAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArrowHeadAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetArrowHeadAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetArrowHeadAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetArrowHeadAtIndex(Index)
```

C#

```
System.double IGetArrowHeadAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetArrowHeadAtIndex(  
&    System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetArrowHeadAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetArrowHeadInfo Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetArrowHeadInfo Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetArrowHeadInfo](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetArrowHeadInfo() As System.Double
```

```
Dim instance As ICustomSymbol
Dim value As System.Double

value = instance.IGetArrowHeadInfo()
```

C#

```
System.double IGetArrowHeadInfo()
```

C++/CLI

```
System.double IGetArrowHeadInfo();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetArrowHeadInfo](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLeaderAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetLeaderAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetLeaderAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLeaderAtIndex( _
    ByVal Index As System.Integer, _
    ByRef PointCount As System.Integer _
) As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ICustomSymbol
Dim Index As System.Integer
Dim PointCount As System.Integer
Dim value As System.Double

value = instance.IGetLeaderAtIndex(Index, PointCount)
```

C#

```
System.double IGetLeaderAtIndex(
    System.int Index,
    out System.int PointCount
)
```

C++/CLI

```
System.double IGetLeaderAtIndex(
    & System.int Index,
    & [Out] System.int PointCount
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index
PointCount

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetLeaderAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLineAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetLineAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetLineAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLineAtIndex(  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetLineAtIndex(Index)
```

C#

```
System.double IGetLineAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetLineAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetLineAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNext Method (ICustomSymbol)

[See Also](#)



Obsolete. Not superseded.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNext() As CustomSymbol
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim value As CustomSymbol
```

```
value = instance.IGetNext()
```

C#

```
CustomSymbol IGetNext()
```

C++/CLI

```
CustomSymbol^ IGetNext();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetNext](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetNotes Method (ICustomSymbol)

[See Also](#)



SolidWorks.Interop.sldworks Namespace > ICustomSymbol Interface : IGetNotes Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::IGetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetNotes( _
    ByVal Count As System.Integer _
) As Note
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim Count As System.Integer
Dim value As Note
```

```
value = instance.IGetNotes(Count)
```

C#

```
Note IGetNotes(
    System.int Count
)
```

C++/CLI

```
Note^ IGetNotes(
    & System.int Count
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

 Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetNotes](#).

 See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSketch Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetSketch Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetSketch](#).

 .NET Syntax

Visual Basic (Declaration)

Function IGetSketch() As Sketch

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As Sketch  
  
value = instance.IGetSketch()
```

C#

Sketch IGetSketch()

C++/CLI

Sketch^ IGetSketch();

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

 Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetSketch](#).

 See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetSketchPosition Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetSketchPosition Method (ICustomSymbol)

Obsolete. Not superseded.

 .NET Syntax

Visual Basic (Declaration)

Function IGetSketchPosition() As System.Double

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim value As System.Double

value = instance.IGetSketchPosition()
```

C#

```
System.double IGetSketchPosition()
```

C++/CLI

```
System.double IGetSketchPosition();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol.IGetSketchPosition](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTextPositionAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetTextPositionAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote.IGetTextPositionAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTextPositionAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol
Dim Index As System.Integer
Dim value As System.Double

value = instance.IGetTextPositionAtIndex(Index)
```

C#

```
System.double IGetTextPositionAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTextPositionAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetTextPositionAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IGetTriangleAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IGetTriangleAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::IGetTriangleAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IGetTriangleAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim value As System.Double  
  
value = instance.IGetTriangleAtIndex(Index)
```

C#

```
System.double IGetTriangleAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.double IGetTriangleAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IGetTriangleAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

IsAttached Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : IsAttached Method (ICustomSymbol)

Obsolete. Superseded by [INote::IsAttached](#).

.NET Syntax

Visual Basic (Declaration)

```
Function IsAttached() As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Boolean
```

```
value = instance.IsAttached()
```

C#

```
System.bool IsAttached()
```

C++/CLI

```
System.bool IsAttached();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::IsAttached](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

Scale2 Property (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : Scale2 Property (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockInstance::Scale](#).

.NET Syntax

Visual Basic (Declaration)

```
Property Scale2 As System.Double
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Double
```

```
instance.Scale2 = value
```

```
value = instance.Scale2
```

C#

```
System.double Scale2 {get; set;}
```

C++/CLI

```
property System.double Scale2 {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::Scale2](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetText Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : SetText Method (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockDefinition::GetNoteCount](#) and [ISketchBlockDefinition::GetNotes](#).

.NET Syntax

Visual Basic (Declaration)

```
Function SetText( _  
    ByVal Index As System.Integer, _  
    ByVal Text As System.String _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim Text As System.String  
Dim value As System.Boolean  
  
value = instance.SetText(Index, Text)
```

C#

```
System.bool SetText(  
    System.int Index,  
    System.string Text  
)
```

C++/CLI

```
System.bool SetText(  
& System.int Index,  
& System.String^ Text  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Text

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::SetText](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetTextJustificationAtIndex Method (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : SetTextJustificationAtIndex Method (ICustomSymbol)

Obsolete. Superseded by [INote::SetTextJustificationAtIndex](#).

.NET Syntax

Visual Basic (Declaration)

```
Sub SetTextJustificationAtIndex( _  
    ByVal Index As System.Integer, _  
    ByVal Justification As System.Integer _  
)
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim Index As System.Integer  
Dim Justification As System.Integer  
  
instance.SetTextJustificationAtIndex(Index, Justification)
```

C#

```
void SetTextJustificationAtIndex(  
    System.int Index,  
    System.int Justification  
)
```

C++/CLI

```
void SetTextJustificationAtIndex(  
& System.int Index,  
& System.int Justification  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Justification

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol::SetTextJustificationAtIndex](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

TextVisible Property (ICustomSymbol)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICustomSymbol Interface](#) : TextVisible Property (ICustomSymbol)

Obsolete. Superseded by [ISketchBlockInstance::TextDisplay](#).

.NET Syntax

Visual Basic (Declaration)

```
Property TextVisible As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICustomSymbol  
Dim value As System.Boolean
```

```
instance.TextVisible = value
```

```
value = instance.TextVisible
```

C#

```
System.bool TextVisible {get; set;}
```

C++/CLI

```
property System.bool TextVisible {  
    System.bool get();  
    void set ( &    System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Visual Basic for Applications (VBA) Syntax

See [CustomSymbol.TextVisible](#).

See Also

[ICustomSymbol Interface](#)
[ICustomSymbol Members](#)

ICutListItem (Type)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICutListItem Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListItem Interface

Allows access to a configuration-specific cut list folder.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICutListItem
```

Visual Basic (Usage)



```
Dim instance As ICutListItem
```

C#

```
public interface ICutListItem
```

C++/CLI

```
public interface class ICutListItem
```

Visual Basic for Applications (VBA) Syntax

See [CutListItem](#).

Example

'VBA

'Preconditions:

' 1. Open a part that has one or more configuration-specific cut lists with custom properties. (Or you can ask SOLIDWORKS API Support to send the models that work with this ICutListItem sample code.)

' 2. Open an Immediate window.

'Postconditions: Inspect all the configurations' cut lists' custom properties in the Immediate window.

'=====

```
Option Explicit
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim vConfigNameArr As Variant
Dim vConfigName As Variant
Dim vcutlistItems As Variant
Dim vcutlistItem As Variant
Dim cutlistItem As SldWorks.CutListItem
Dim cusPropMgr As SldWorks.CustomPropertyManager
Dim config As SldWorks.Configuration
Dim lRetVal As Long
Dim vPropNames As Variant
Dim vPropTypes As Variant
Dim vPropValues As Variant
Dim resolved() As Long
Dim linkProp() As Long
Dim i As Long
Dim j As Long
Dim propName As Variant
```

Sub main()

```
    Set swApp = Application.SldWorks
    Set swModel = swApp.ActiveDoc
```

```
    vConfigNameArr = swModel.GetConfigurationNames()
    For Each vConfigName In vConfigNameArr
```

```
Debug.Print "Configuration: " & vConfigName
Set config = swModel.GetConfigurationByName(vConfigName)
vcutlistItems = config.GetCutListItems()
i = 1
For Each vcutlistItem In vcutlistItems
    Debug.Print "Cut list item #" & i & " custom properties:"
    Set cutlistItem = vcutlistItem
    Set cusPropMgr = cutlistItem.CustomPropertyManager()
    lRetVal = cusPropMgr.GetAll3(vPropNames, vPropTypes, vPropValues, resolved, linkProp)
    j = 0
    For Each propName In vPropNames
        Debug.Print " " & propName & " " & vPropValues(j)
        j = j + 1
    Next
    i = i + 1
Next
Next
End Sub
```

 Example

[Get Configuration-specific Cut List Custom Properties \(VB.NET\)](#)
[Get Configuration-specific Cut List Custom Properties \(C#\)](#)

 Accessors

[IConfiguration::GetCutListItems](#)

 Access Diagram

[CutListItem](#)

 See Also

[ICutListItem Members](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICutListItem Interface Members

[See Also](#) [Properties](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListItem Interface

The following tables list the members exposed by [ICutListItem](#).

 Public Properties

Name	Description
 CustomPropertyManager	Gets the custom property manager for this configuration-specific cut list.

[Top](#)

 See Also

[ICutListItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

ICutListItem Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListItem Interface

For a list of all members of this type, see [ICutListItem members](#).

 Public Properties

Name	Description
 CustomPropertyManager	Gets the custom property manager for this configuration-specific cut list.

[Top](#)

See Also

[ICutListItem Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CustomPropertyManager Property (ICutListItem)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICutListItem Interface](#) : CustomPropertyManager Property (ICutListItem)

Gets the custom property manager for this configuration-specific cut list.

.NET Syntax

Visual Basic (Declaration)

```
ReadOnly Property CustomPropertyManager As CustomPropertyManager
```

Visual Basic (Usage)



```
Dim instance As ICutListItem  
Dim value As CustomPropertyManager  
  
value = instance.CustomPropertyManager
```

C#

```
CustomPropertyManager CustomPropertyManager {get;}
```

C++/CLI

```
property CustomPropertyManager^ CustomPropertyManager {  
    CustomPropertyManager^ get();  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[ICustomPropertyManager](#)

Visual Basic for Applications (VBA) Syntax

See [CutListItem::CustomPropertyManager](#).

See Also

[ICutListItem Interface](#)
[ICutListItem Members](#)

Availability

SOLIDWORKS 2024 FCS, Revision Number 32

ICutListSortOptions (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICutListSortOptions Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListSortOptions Interface

Allows access to cut list sorting options.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ICutListSortOptions
```

Visual Basic (Usage)

```
Dim instance As ICutListSortOptions
```

C#

```
public interface ICutListSortOptions
```

C++/CLI

```
public interface class ICutListSortOptions
```

Visual Basic for Applications (VBA) Syntax

See [CutListSortOptions](#).

Example

[Get Features of Multibody Sheet Metal Part \(VBA\)](#)
[Get Features of Multibody Sheet Metal Part \(VB.NET\)](#)
[Get Features of Multibody Sheet Metal Part \(C#\)](#)

Remarks

The sub-weldment folder structure is retained for all cut list sorting options.

See **Sorting Cut Lists** in the SOLIDWORKS Design user-interface help.

Accessors

[IBodyFolder::GetCutListSortOptions](#)

Access Diagram

[CutListSortOptions](#)

See Also

[ICutListSortOptions Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBodyFolder::SortCutList Method \(\)](#)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ICutListSortOptions Interface Methods

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListSortOptions Interface

For a list of all members of this type, see [ICutListSortOptions members](#).

Public Methods

Name	Description
 GetFacesOrFeaturesToExclude	Gets the faces or features to exclude from cut list sorting.
 SetFacesOrFeaturesToExclude	Sets the faces or features to exclude from cut list sorting.

[Top](#)

See Also

[ICutListSortOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBodyFolder::SortCutList Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICutListSortOptions Interface Members

[See Also](#) [Properties](#) [Methods](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListSortOptions Interface

The following tables list the members exposed by [ICutListSortOptions](#).

Public Properties

Name	Description
 CollectIdenticalBodies	Gets or sets whether to collect identical bodies into a cut list sub-folder.

[Top](#)

Public Methods

Name	Description
 GetFacesOrFeaturesToExclude	Gets the faces or features to exclude from cut list sorting.
 SetFacesOrFeaturesToExclude	Sets the faces or features to exclude from cut list sorting.

[Top](#)

See Also

[ICutListSortOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBodyFolder::SortCutList Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ICutListSortOptions Interface Properties

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) : ICutListSortOptions Interface

For a list of all members of this type, see [ICutListSortOptions members](#).

Public Properties

Name	Description
 CollectIdenticalBodies	Gets or sets whether to collect identical bodies into a cut list sub-folder.

[Top](#)

See Also

[ICutListSortOptions Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IBodyFolder::SortCutList Method \(\)](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

CollectIdenticalBodies Property (ICutListSortOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICutListSortOptions Interface](#) : CollectIdenticalBodies Property (ICutListSortOptions)

Gets or sets whether to collect identical bodies into a cut list sub-folder.

.NET Syntax

Visual Basic (Declaration)

```
Property CollectIdenticalBodies As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ICutListSortOptions  
Dim value As System.Boolean  
  
instance.CollectIdenticalBodies = value  
  
value = instance.CollectIdenticalBodies
```

C#

```
System.bool CollectIdenticalBodies {get; set;}
```

C++/CLI

```
property System.bool CollectIdenticalBodies {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to collect identical bodies, false to not

Visual Basic for Applications (VBA) Syntax

See [CutListSortOptions::CollectIdenticalBodies](#).

Example

See the [ICutListSortOptions](#) examples.

Remarks

If set to true, this property puts all bodies that are geometrically identical, but generated in different features, into a cut list item sub-folder in the FeatureManager design tree.

If this is a weldment, identical bodies do not move between weldment sub-folders during the sort.

See Also

[ICutListSortOptions Interface](#)
[ICutListSortOptions Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFacesOrFeaturesToExclude Method (ICutListSortOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICutListSortOptions Interface](#) : GetFacesOrFeaturesToExclude Method (ICutListSortOptions)

Gets the faces or features to exclude from cut list sorting.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFacesOrFeaturesToExclude() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ICutListSortOptions  
Dim value As System.Object  
  
value = instance.GetFacesOrFeaturesToExclude()
```

C#

```
System.object GetFacesOrFeaturesToExclude()
```

C++/CLI

```
System.Object^ GetFacesOrFeaturesToExclude();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of [IFace2](#) or [IFeature](#) to exclude

Visual Basic for Applications (VBA) Syntax

See [CutListSortOptions::GetFacesOrFeaturesToExclude](#).

See Also

[ICutListSortOptions Interface](#)
[ICutListSortOptions Members](#)
[ICutListSortOptions::SetFacesOrFeaturesToExclude Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

SetFacesOrFeaturesToExclude Method (ICutListSortOptions)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ICutListSortOptions Interface](#) : SetFacesOrFeaturesToExclude Method (ICutListSortOptions)

Sets the faces or features to exclude from cut list sorting.

.NET Syntax

Visual Basic (Declaration)

```
Function SetFacesOrFeaturesToExclude( _  
    ByVal Entities As System.Object _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ICutListSortOptions  
Dim Entities As System.Object  
Dim value As System.Integer  
  
value = instance.SetFacesOrFeaturesToExclude(Entities)
```

C#

```
System.int SetFacesOrFeaturesToExclude(  
    System.object Entities  
)
```

C++/CLI

```
System.int SetFacesOrFeaturesToExclude(  
& System.Object^ Entities  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Entities

Array of [IFace2](#) or [IFeature](#) to exclude

Return Value

Error code as defined in [swCutListExclusionStatus_e](#)

Visual Basic for Applications (VBA) Syntax

See [CutListSortOptions::SetFacesOrFeaturesToExclude](#).

Remarks

In order to avoid cut list sorting issues using [IBodyFolder::SortCutList](#), the Entities array must contain entities of selection type BODYFEATURE or FACE.

Faces and features you cannot exclude:

- Chamfers that remove an entire face.
- Suppressed features.
- Features that create new bodies from sketches, such as boss-extrude, revolve, and sweep.
- Certain sheet metal features.

See Also

[ICutListSortOptions Interface](#)

[ICutListSortOptions Members](#)

[ICutListSortOptions::GetFacesOrFeaturesToExclude Method \(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0